



**ECOSYS M2030dn/PN**

**ECOSYS M2030dn**

**ECOSYS M2530dn**

**ECOSYS M2035dn**

**ECOSYS M2535dn**

# **SERVICE MANUAL**

Published in February 2015  
2PKSM067  
Rev.7

## **CAUTION**

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

It may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for proper disposal.

## **ATTENTION**

IL Y A UN RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN MODÈLE DE TYPE INCORRECT. METTRE AU REBUT LES BATTERIES UTILISÉES SELON LES INSTRUCTIONS DONNÉES.

Il peut être illégal de jeter les batteries dans des eaux d'égout municipales. Vérifiez avec les fonctionnaires municipaux de votre région pour les détails concernant des déchets solides et une mise au rebut appropriée.

### **Notation of products in the manual**

For the purpose of this service manual, products are identified by print speed, and presence of FAX.

ECOSYS M2030dn Type PN	: 3in1 model by 30ppm (without FAX and document processor)
ECOSYS M2030dn	: 3in1 model by 30ppm (without FAX)
ECOSYS M2530dn	: 4in1 model by 30ppm (with FAX)
ECOSYS M2035dn	: 3in1 model by 35ppm (without FAX)
ECOSYS M2535dn	: 4in1 model by 35ppm (with FAX)

## Revision history

Revision	Date	Pages	Revised contents
1	12 November 2013	1-3-23, 1-3-65	Correction: FAX country code
2	9 January 2014	Contents	Correction
		1-3-19 to 24	Correction: U411 and U425
		Address	Correction
3	15 Febraury 2014	1-1-2	Correction: Amperage rating
		1-2-1	Correction: Power supply specification
		1-3-19, 1-3-20 1-3-22 to 24	Changed: Parts number of original
		1-3-25, 1-3-26	Added: Procedure change
		1-3-63	Added: the explanation to (59) Media type attributes
		1-4-29, 1-4-30	Added: Code 3102
		1-6-1, 1-6-2	Added: Safe- Update
		2-4-3	Added: Comment to (2)Repetitive defects gauge
4	4 April 2014	1-6-2	Correction: Fig 1-6-2
5	20 May 2014	Contents	Correction
		1-3-11 1-3-13 to 28 1-3-32 1-3-34 to 37 1-3-71 1-3-75 to 78	Added: Maintenance mode U001/010/019/021/034/065/066/067/068/070 071/072/130/207/265/346/402/403/404 901/905/920/928/995
		1-3-38	Correction: Description of table
		1-6-1, 1-6-2	Correction: Correction of an explanatory note
6	14 November 2014	Contents	Correction
		1-3-2 to 5	Correction: (2) Maintenance modes item list
7	30 January 2015	1-1-6 to 8	Correction: Number of part, missing pages
		1-3-87	Correction: 5 to 100 (%)

This page is intentionally left blank.





---


# Safety precautions


---


This booklet provides safety warnings and precautions for our service personnel to ensure the safety of their customers, their machines as well as themselves during maintenance activities. Service personnel are advised to read this booklet carefully to familiarize themselves with the warnings and precautions described here before engaging in maintenance activities.

## Safety warnings and precautions


Various symbols are used to protect our service personnel and customers from physical danger and to prevent damage to their property. These symbols are described below:

 **DANGER:** High risk of serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **WARNING:** Serious bodily injury or death may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

 **CAUTION:** Bodily injury or damage to property may result from insufficient attention to or incorrect compliance with warning messages using this symbol.

### Symbols

The triangle () symbol indicates a warning including danger and caution. The specific point of attention is shown inside the symbol.



General warning.



Warning of risk of electric shock.



Warning of high temperature.

 indicates a prohibited action. The specific prohibition is shown inside the symbol.



General prohibited action.



Disassembly prohibited.

 indicates that action is required. The specific action required is shown inside the symbol.



General action required.



Remove the power plug from the wall outlet.



Always ground the copier.

## 1. Installation Precautions

### WARNING

- Do not use a power supply with a voltage other than that specified. Avoid multiple connections to one outlet: they may cause fire or electric shock. When using an extension cable, always check that it is adequate for the rated current. ....
- Connect the ground wire to a suitable grounding point. Not grounding the copier may cause fire or electric shock. Connecting the earth wire to an object not approved for the purpose may cause explosion or electric shock. Never connect the ground cable to any of the following: gas pipes, lightning rods, ground cables for telephone lines and water pipes or faucets not approved by the proper authorities. ....













### CAUTION:

- Do not place the copier on an infirm or angled surface: the copier may tip over, causing injury. ....
- Do not install the copier in a humid or dusty place. This may cause fire or electric shock. ....
- Do not install the copier near a radiator, heater, other heat source or near flammable material. This may cause fire. ....
- Allow sufficient space around the copier to allow the ventilation grills to keep the machine as cool as possible. Insufficient ventilation may cause heat buildup and poor copying performance. ....
- Always handle the machine by the correct locations when moving it. ....
- Always use anti-toppling and locking devices on copiers so equipped. Failure to do this may cause the copier to move unexpectedly or topple, leading to injury. ....
- Avoid inhaling toner or developer excessively. Protect the eyes. If toner or developer is accidentally ingested, drink a lot of water to dilute it in the stomach and obtain medical attention immediately. If it gets into the eyes, rinse immediately with copious amounts of water and obtain medical attention. ....
- Advise customers that they must always follow the safety warnings and precautions in the copier's instruction handbook. ....







## 2. Precautions for Maintenance

### WARNING

- Always remove the power plug from the wall outlet before starting machine disassembly. .... 
- Always follow the procedures for maintenance described in the service manual and other related brochures. .... 
- Under no circumstances attempt to bypass or disable safety features including safety mechanisms and protective circuits. .... 
- Always use parts having the correct specifications. .... 
- Always use the thermostat or thermal fuse specified in the service manual or other related brochure when replacing them. Using a piece of wire, for example, could lead to fire or other serious accident. .... 
- When the service manual or other serious brochure specifies a distance or gap for installation of a part, always use the correct scale and measure carefully. .... 
- Always check that the copier is correctly connected to an outlet with a ground connection. .... 
- Check that the power cable covering is free of damage. Check that the power plug is dust-free. If it is dirty, clean it to remove the risk of fire or electric shock. .... 
- Never attempt to disassemble the optical unit in machines using lasers. Leaking laser light may damage eyesight. .... 
- Handle the charger sections with care. They are charged to high potentials and may cause electric shock if handled improperly. .... 

### CAUTION

- Wear safe clothing. If wearing loose clothing or accessories such as ties, make sure they are safely secured so they will not be caught in rotating sections. .... 
- Use utmost caution when working on a powered machine. Keep away from chains and belts. .... 
- Handle the fixing section with care to avoid burns as it can be extremely hot. .... 
- Check that the fixing unit thermistor, heat and press rollers are clean. Dirt on them can cause abnormally high temperatures. .... 

• Do not remove the ozone filter, if any, from the copier except for routine replacement. ....



• Do not pull on the AC power cord or connector wires on high-voltage components when removing them; always hold the plug itself. ....



• Do not route the power cable where it may be stood on or trapped. If necessary, protect it with a cable cover or other appropriate item. ....



• Treat the ends of the wire carefully when installing a new charger wire to avoid electric leaks. ....



• Remove toner completely from electronic components. ....



• Run wire harnesses carefully so that wires will not be trapped or damaged. ....



• After maintenance, always check that all the parts, screws, connectors and wires that were removed, have been refitted correctly. Special attention should be paid to any forgotten connector, trapped wire and missing screws. ....



• Check that all the caution labels that should be present on the machine according to the instruction handbook are clean and not peeling. Replace with new ones if necessary. ....



• Handle greases and solvents with care by following the instructions below: ....



- Use only a small amount of solvent at a time, being careful not to spill. Wipe spills off completely.
- Ventilate the room well while using grease or solvents.
- Allow applied solvents to evaporate completely before refitting the covers or turning the power switch on.
- Always wash hands afterwards.

• Never dispose of toner or toner bottles in fire. Toner may cause sparks when exposed directly to fire in a furnace, etc. ....



• Should smoke be seen coming from the copier, remove the power plug from the wall outlet immediately. ....



### 3. Miscellaneous

#### WARNING

• Never attempt to heat the drum or expose it to any organic solvents such as alcohol, other than the specified refiner; it may generate toxic gas. ....



• Keep the machine away from flammable liquids, gases, and aerosols. A fire or an electric shock might occur. ....



This page is intentionally left blank.

# CONTENTS

## 1-1 Specifications

1-1-1 Specifications .....	1-1-1
1-1-2 Parts names .....	1-1-6
(1) Overall .....	1-1-6
(2) Operation panel .....	1-1-7
(3) Option .....	1-1-8
1-1-3 Machine cross section .....	1-1-9

## 1-2 Installation

1-2-1 Installation environment .....	1-2-1
1-2-2 Unpacking .....	1-2-2
(1) Unpacking .....	1-2-2
(2) Removing the tapes .....	1-2-3
1-2-3 Installing the expansion memory (option) .....	1-2-6

## 1-3 Maintenance Mode

1-3-1 Maintenance mode .....	1-3-1
(1) Executing a maintenance item .....	1-3-1
(2) Maintenance modes item list .....	1-3-2
(3) Contents of the maintenance mode items .....	1-3-6
1-3-2 Service mode .....	1-3-79
(1) Executing a service mode .....	1-3-79
(2) Description of service mode .....	1-3-80

## 1-4 Troubleshooting

1-4-1 Paper misfeed detection .....	1-4-1
(1) Paper misfeed indication .....	1-4-1
(2) Paper misfeed detection condition .....	1-4-2
1-4-2 Self-diagnostic function .....	1-4-6
(1) Self-diagnostic function .....	1-4-6
(2) Self diagnostic codes .....	1-4-7
1-4-3 Image formation problems .....	1-4-16
(1) Completely blank printout .....	1-4-17
(2) All-black printout .....	1-4-18
(3) Dropouts .....	1-4-18
(4) Black dots .....	1-4-19
(5) Black horizontal streaks .....	1-4-19
(6) Black vertical streaks .....	1-4-19
(7) Unsharpness .....	1-4-20
(8) Gray background .....	1-4-20
(9) Dirt on the top edge or back of the paper .....	1-4-20
(10) Undulated printing at the right edge (scanning start position) .....	1-4-21
1-4-4 Electric problems .....	1-4-22
1-4-5 Mechanical problems .....	1-4-25
1-4-6 Send error code .....	1-4-26
(1) Scan to SMB error codes .....	1-4-26
(2) Scan to FTP error codes .....	1-4-27
(3) Scan to E-mail error codes .....	1-4-29

1-4-7 Error codes .....	1-4-31
(1) Error code .....	1-4-31
(2) Table of general classification .....	1-4-32
(2-1) U004XX error code table: Interrupted phase B .....	1-4-35
(2-2) U006XX error code table: Problems with the unit .....	1-4-36
(2-3) U008XX error code table: Page transmission error.....	1-4-36
(2-4) U009XX error code table: Page reception error .....	1-4-36
(2-5) U010XX error code table: G3 transmission.....	1-4-37
(2-6) U011XX error code table: G3 reception .....	1-4-39
(2-7) U017XX error code table: V.34 transmission .....	1-4-40
(2-8) U018XX error code table: V.34 reception.....	1-4-41
(2-9) U023XX error code table: Relay command abnormal reception .....	1-4-41
(2-10) U044XX error code table: Encrypted transmission .....	1-4-41

## 1-5 Assembly and Disassembly

1-5-1 Precautions for assembly and disassembly.....	1-5-1
(1) Precautions.....	1-5-1
(2) Drum unit .....	1-5-1
(3) Toner .....	1-5-1
(4) How to tell a genuine Kyocera toner container.....	1-5-2
1-5-2 Outer covers .....	1-5-3
(1) Detaching and refitting the left cover and right cover .....	1-5-3
1-5-3 Paper feed section.....	1-5-6
(1) Detaching and refitting the paper feed assembly (paper feed roller and pickup roller) ....	1-5-6
(2) Detaching and refitting the retard roller assembly .....	1-5-8
(3) Detaching and refitting the MP paper feed roller .....	1-5-10
(4) Note on removing and Installing the upper registration roller and lower registration roller .....	1-5-12
1-5-4 Optical section .....	1-5-13
(1) Detaching and refitting the DP.....	1-5-13
(2) Detaching and refitting the scanner unit .....	1-5-14
(3) Detaching and refitting the laser scanner unit (LSU) .....	1-5-17
(4) Replacing the image scanner unit (ISU) .....	1-5-21
1-5-5 Developer section .....	1-5-27
(1) Detaching and refitting the developer unit.....	1-5-27
1-5-6 Drum section .....	1-5-28
(1) Detaching and refitting the drum unit.....	1-5-28
(2) Detaching and refitting the main charger unit.....	1-5-29
1-5-7 Transfer/separation section .....	1-5-30
(1) Detaching and refitting the transfer roller .....	1-5-30
1-5-8 Fuser section .....	1-5-32
(1) Detaching and refitting the fuser unit.....	1-5-32
(2) Switching the fuser pressure .....	1-5-36
1-5-9 PWBs.....	1-5-37
(1) Detaching and refitting the control PWB.....	1-5-37
(2) Detaching and refitting the power source PWB.....	1-5-40
(3) Detaching and refitting the high voltage PWB .....	1-5-43
(4) Detaching and refitting the scanner PWB.....	1-5-47
(5) Detaching and refitting the FAX control PWB.....	1-5-48
1-5-10 Others .....	1-5-49
(1) Detaching and refitting the main motor.....	1-5-49
(2) Direction of installing the left cooling fan motor, right cooling fan motor .....	1-5-50



1-5-11 Document processor .....	1-5-51
(1) Detaching and refitting the DP rear cover and DP front cover .....	1-5-51
(2) Detaching and refitting the DP drive PWB.....	1-5-52
(3) Detaching and refitting the feed pulley and forwarding pulley .....	1-5-53
(4) Detaching and refitting the separation pad assembly.....	1-5-56
 1-6 Requirements on PWB Replacement	
1-6-1 Upgrading the firmware .....	1-6-1
1-6-2 Remarks on control PWB replacement.....	1-6-3
 2-1 Mechanical Construction	
2-1-1 Paper feed/conveying section .....	2-1-1
(1) Cassette paper feed section.....	2-1-1
(2) MP tray paper feed section.....	2-1-2
(3) Paper conveying section .....	2-1-3
2-1-2 Drum section .....	2-1-4
(1) Drum section .....	2-1-4
(2) Main charger unit.....	2-1-5
2-1-3 Optical section .....	2-1-6
(1) Scanner unit .....	2-1-6
(2) Image scanner unit (ISU).....	2-1-7
(3) Laser scanner unit .....	2-1-9
2-1-4 Developing section .....	2-1-11
2-1-5 Transfer/separation section .....	2-1-13
2-1-6 Cleaning section .....	2-1-14
2-1-7 Fuser section .....	2-1-16
2-1-8 Paper exit section .....	2-1-18
2-1-9 Duplex/conveying section.....	2-1-20
2-1-10 Document processor .....	2-1-21
(1) Original feed section.....	2-1-21
(2) Original conveying section.....	2-1-22
(3) Original switchback/eject sections.....	2-1-23
 2-2 Electrical Parts Layout	
2-2-1 Electrical parts layout .....	2-2-1
(1) PWBs.....	2-2-1
(2) Switches and sensors.....	2-2-3
(3) Other electrical components.....	2-2-4
(4) Document processor .....	2-2-5
 2-3 Operation of the PWBs	
2-3-1 Power source PWB .....	2-3-1
2-3-2 Control PWB .....	2-3-4
2-3-3 Scanner PWB .....	2-3-11
2-3-4 DP drive PWB.....	2-3-14

2-4 Appendixes

2-4-1 Appendixes ..... 2-4-1

    (1) Wiring diagram ..... 2-4-1

    (2) Repetitive defects gauge ..... 2-4-3

    (3) Maintenance parts list..... 2-4-4

    (4) Firmware Environment Commands ..... 2-4-5

    (5) Maintenance Commands..... 2-4-13

INSTALLATION GUIDE

PAPER FEEDER

## 1-1-1 Specifications

### Machine

Item		Specifications			
		3 in 1 model (without FAX)		4 in 1 model (with FAX)	
		30ppm	35ppm	30ppm	35ppm
Type		Desktop			
Printing method		Electrophotography by semiconductor laser, single drum system			
Originals		Sheet, Book, 3-dimensional objects (maximum original size: Folio/Legal)			
Original feed system		Fixed			
Paper weight	Cassette	60 to 120 g/m <sup>2</sup> (Duplex: 60 to 105 g/m <sup>2</sup> )			
	MP tray	60 to 220 g/m <sup>2</sup>			
Paper type	Cassette	Plain, Preprinted, Bond, Recycled, Rough, Letterhead, Color, Prepunched, High quality, Custom 1-8			
	MP tray	Plain, Transparency, Preprinted, Labels, Bond, Recycled, Vellum, Rough, Letterhead, Color, Prepunched, Envelope, Cardstock, Thick, High quality, Custom 1-8			
Paper size	Cassette	A4, A5, B5, Letter, Legal, Statement,Oficio II, Folio, 16K, 216×340, Custom			
	MP tray	A4, A5, A6, B5, ISO B5, Letter, Legal, Statement, Executive, Oficio II, Folio, 16K, 216×340, Custom			
Zoom level		Manual mode : 25 to 400%, 1% increments Auto mode : 400%, 200%, 141%, 129%, 115%, 90%, 86%, 78%, 70%, 64%, 50%, 25%			
Copying speed					
When using the DP (Cassette)	A4R	20 sheets/min			
	LetterR	21 sheets/min			
	Leagal	17 sheets/min			
	B5R	22 sheets/min			
	A5R	17 sheets/min			
When the DP is not used (Cassette)	A4R	30 sheets/min	35 sheets/min	30 sheets/min	35 sheets/min
	LetterR	32 sheets/min	37 sheets/min	32 sheets/min	37 sheets/min
	Leagal	26 sheets/min	30 sheets/min	26 sheets/min	30 sheets/min
	B5R	24 sheets/min	24 sheets/min	24 sheets/min	24 sheets/min
	A5R	17 sheets/min	17 sheets/min	17 sheets/min	17 sheets/min
	A6R	17 sheets/min	17 sheets/min	17 sheets/min	17 sheets/min
First copy time (A4, feed from cassette)		When using the DP : 7.9 s or less When the DP is not used: 6.9 s or less			
Warm-up time (22 °C/71.6 °F, 60% RH)		Power on : 20 s or less			
Paper capacity	Cassette	250 sheets (80g/m <sup>2</sup> )			
	MP tray	50 sheets (80 g/m <sup>2</sup> , plain paper, A4/Letter or less)			

Item		Specifications			
		3 in 1 model (without FAX)		4 in 1 model (with FAX)	
		30ppm	35ppm	30ppm	35ppm
Output tray capacity		150 sheets (80g/m <sup>2</sup> )			
Continuous copying		1 to 999 sheets			
Light source		Exposure lamp (LED)			
Scanning system		Flat bed scanning by CCD image sensor			
Photoconductor		OPC drum (diameter 30 mm)			
Image write system		Semiconductor laser			
Charging system		Scorotron (positive charging)			
Developing system		Mono component dry developing method Toner replenishing: Automatic from the toner container			
Transfer system		Transfer roller (negative chargeing)			
Separation system		Small diameter separation, discharger electrode			
Cleaning system		Drum: Counter blade			
Charge erasing system		Exposure by cleaning lamp (LED)			
Fusing system		Heat and pressure fusing with the heat roller and the press roller Heat source: halogen heater Abnormally high temperature protection devices: thermostat			
CPU		PowerPC465S (667MHz)			
Main memory	Standard	512 MB			
	Maximum	1536 MB			
Interface	Standard	USB interface connector: 1 (USB 2.0) USB host: 1 Network interface: 1 (10BASE-T/100BASE-TX/1000BASE-T)			
	Option	eKUIO slot: 1 (It uses it by fax in 4in1 model.)			
Resolution	Reading	600 × 600 dpi			
	Writing	600 × 600 dpi			
Operating environment	Temperature	10 to 32.5 °C/50 to 90.5 °F			
	Humidity	15 to 80% RH			
	Altitude	2,500 m/8,202 ft or less			
	Brightness	1,500 lux or less			
Dimensions (W × D × H)		494 × 410 × 366 mm 19 7/16 × 16 1/8 × 14 7/16" (When using the original cover)		494 × 430 × 448 mm 19 7/16 × 16 15/16 × 17 1/4" (When using the DP)	
Weight (with toner container)		15 kg / 33.1 lb (with original cover) 18 kg / 39.7 lb (with DP)			
Space required (W × D) (using MP tray)		494 × 613 mm 19 7/16 × 24 1/8"		494 × 633 mm 19 7/16 × 24 15/16"	

Item	Specifications			
	3 in 1 model (without FAX)		4 in 1 model (with FAX)	
	30ppm	35ppm	30ppm	35ppm
<b>Rated input</b>	120 V AC, 60 Hz, more than 8.0 A 220 - 240 V AC, 50 Hz, more than 4.2 A			
<b>Options</b>	Paper feeder × 2, Expanded memory, SD card (for printer), Network interface kit			

## Printer

Item		Specifications	
		30ppm	35ppm
Printing speed			
Simplex (Cassette)	A4R	30 sheets/min	35 sheets/min
	LetterR	32 sheets/min	37 sheets/min
	Leagal	26 sheets/min	30 sheets/min
	B5R	24 sheets/min	24 sheets/min
	A5R	17 sheets/min	17 sheets/min
	A6R	17 sheets/min	17 sheets/min
Duplex (Cassette)	A4R	17 sheets/min	19 sheets/min
	LetterR	18 sheets/min	20 sheets/min
	Leagal	16 sheets/min	18 sheets/min
First print time (A4, feed from cassette)		7.0 s or less (Excluding time for system stabilization immediately after turning on the main power.)	
Resolution		Fast 1200 600 dpi 300 dpi	Fine 1200 Fast 1200 600 dpi 300 dpi
Operating system		Windows 2000, Windows XP, Windows XP Professional, Windows Server 2003, Windows Server 2003 x64 Edition, Windows Vista x86 Edition, Windows Vista x64 Edition, Windows 7 x86 Edition, Windows 7 x64 Edition, Windows 8 x86 Edition, Windows 8 x64 Edition, Windows Server 2008, Windows Server 2008 x64 Edition, Windows Server 2012 x64 Edition Apple Macintosh OS 9.x, Apple Macintosh OS X	
Interface		USB interface connector: 1 (USB 2.0) USB host: 1 Network interface: 1 (10BASE-T/100BASE-TX/1000BASE-T)	
Page description language		PRESCRIBE	

**Scanner**

<b>Item</b>		<b>Specifications</b>
<b>Operating system</b>		Windows Vista, Windows 7, Windows 8, Windows Server 2008, Windows Server 2012
<b>Resolution</b>		600 dpi, 400 dpi, 300 dpi, 200 dpi, 200 × 400 dpi, 200 × 100 dpi
<b>File format</b>		JPEG, TIFF, PDF, XPS
<b>Scanning speed</b>	<b>Simplex</b>	B/W : 35 images/min Color: 14 images/min (A4 landscape, 300 dpi, Image quality: Text/Photo original)
	<b>Duplex</b>	B/W : 18 images/min Color: 8 images/min (A4 landscape, 300 dpi, Image quality: Text/Photo original)
<b>Interface</b>		Ethernet (10 BASE-T/100 BASE-TX/1000BASE-T), USB2.0
<b>Network protocol</b>		TCP/IP
<b>Transmission system</b>		PC transmission SMB: Scan to PC E-mail SMTP: Scan to E-mail FTP transmission FTP, FTP over SSL: Scan to FTP USB transmission USB: Scan to USB TWAIN scan *1 WIA scan *2

\*1 Available operating system: Windows XP, Windows Server 2003, Windows Vista, Windows Server 2008, Windows 7

\*2 Available operating system: Windows Vista, Windows Server 2008, Windows 7

**Document processor (Standard model only)**

Item	Specifications
<b>Original feed method</b>	Automatic feed
<b>Supported original types</b>	Sheet originals
<b>Original sizes</b>	Maximum: A4/Legal Minimum : A5/Statement
<b>Original weights</b>	Simplex: 50 to 120 g/m <sup>2</sup> Duplex : 50 to 110 g/m <sup>2</sup>
<b>Loading capacity</b>	50 sheets (50 to 80 g/m <sup>2</sup> ) or less
<b>Dimensions (W × D × H)</b>	490 × 339 × 104 mm 19 5/16 × 13 3/8 × 4 1/8"
<b>Weight</b>	3 kg/ 6.6 lb or less


**FAX (4 in 1 model (with FAX) only)**

Item	Specifications
<b>Compatibility</b>	Super G3
<b>Communication line</b>	Subscriber telephone line
<b>Transmission time</b>	3 s or less (33600 bps, JBIG, ITU-T A4 #1 chart)
<b>Transmission speed</b>	33600/31200/28800/26400/24000/21600/19200/16800/14400/12000/9600/ 7200/4800/2400 bps
<b>Coding scheme</b>	JBIG/MMR/MR/MH
<b>Error correction</b>	ECM
<b>Original size</b>	A4, B5(JIS), A5, Legal, Letter, Statement, Oficio II, 216x340
<b>Automatic document feed</b>	Max. 50 sheets
<b>Scanner resolution</b>	Horizontal × Vertical 200 × 100 dpi Normal (8 dot/mm × 3.85 line/mm) 200 × 200 dpi Fine (8 dot/mm × 7.7 line/mm) 200 × 400 dpi Super fine (8 dot/mm × 15.4 line/mm) 400 × 400 dpi Ultra fine (16 dot/mm × 15.4 line/mm)
<b>Printing resolution</b>	600 × 600 dpi
<b>Gradations</b>	256 shades
<b>One-Touch key</b>	22 keys
<b>Multi-Station transmission</b>	Max. 100 destinations
<b>Substitute memory reception</b>	256 sheets or more (when using ITU-T A4 #1 chart)
<b>Image memory capacity</b>	3.5 MB (standard) (for incoming faxed originals)
<b>Report output</b>	Sent result report, FAX RX result report, Activity report, Status page

NOTE: These specifications are subject to change without notice.

## 1-1-2 Parts names

### (1) Overall



**Figure 1-1-1**

- |                                  |                                  |                              |
|----------------------------------|----------------------------------|------------------------------|
| 1. Platen (contact glass)        | 12. Paper stopper                | 23. Power switch             |
| 2. Original size Indicator plate | 13. Paper width guides           | 24. Power cord connector     |
| 3. Operation panel               | 14. Cassette                     | 25. Top cover                |
| 4. Top cover                     | 15. Paper width guides (MP tray) | 26. Original width guides *2 |
| 5. Front cover                   | 16. MP (Multi-Purpose) tray      | 27. Original table *2        |
| 6. Main charger cleaner          | 17. MP tray extension            | 28. Original eject table *2  |
| 7. Drum unit                     | 18. USB Interface connector      | 29. Opening handle *2        |
| 8. Lock lever                    | 19. Network Interface connector  | 30. USB host connector       |
| 9. Toner container               | 20. Tel connector (T1) *1        | 31. Original cover *3        |
| 10. Top tray                     | 21. Line connector (L1) *1       |                              |
| 11. Paper length guide           | 22. Rear cover                   |                              |

\*1: 4in1 model (with FAX) only

\*2: Only model with Document Processor as standard / \*3: Only model with original cover as standard



## (2) Operation panel




Figure 1-1-2

- |                                  |                             |                         |
|----------------------------------|-----------------------------|-------------------------|
| 1. System menu/Counter key (LED) | 11. Document Box key (LED)  | 22. Reset key           |
| 2. Status/Job Cancel key (LED)   | 12. FAX key (LED) *         | 23. Attention indicator |
| 3. Copy key (LED)                | 13. Send key (LED)          | 24. Back key            |
| 4. Address Book key              | 14. Shift Lock key (LED)    | 25. OK key              |
| 5. Address Recall/Pause key *    | 15. Left Select key         | 26. Cursor keys         |
| 6. Confirm Destination key       | 16. Processing indicator    | 27. Start key (LED)     |
| 7. Add Destination key           | 17. Memory indicator        | 28. Stop key            |
| 8. On Hook key *                 | 18. Right Select key        | 29. Program keys        |
| 9. One-touch keys                | 19. Function Menu key (LED) | 30. Logout key (LED)    |
| 10. Message display              | 20. Numeric keys            |                         |
|                                  | 21. Clear key               |                         |

\*: 4in1 model (with FAX) only

(3) Option




Figure 1-1-3

- 1. Machine
- 2. Paper feeder

## 1-1-3 Machine cross section





Figure 1-1-4

- |                                 |                                |
|---------------------------------|--------------------------------|
| 1. Cassette                     | 8. Laser scanner unit (LSU)    |
| 2. MP tray                      | 9. Transfer/separation section |
| 3. Paper feed/conveying section | 10. Fuser section              |
| 4. Toner container              | 11. Exit section               |
| 5. Developer unit               | 12. Duplex/conveying section   |
| 6. Main charger unit            | 13. Scanner section            |
| 7. Drum unit                    |                                |

**Figure 1-1-5**

- 14. Image scanner unit (ISU)
- 15. Document processor (DP) \*

\* : Only model with Document Processor as standard

## 1-2-1 Installation environment

1. Temperature: 10 to 32.5°C/50 to 90.5°F
2. Humidity: 15 to 80%RH
3. Power supply: 120 V AC, 10.0 A or more  
220 - 240 V AC, 6.0 A or more
4. Power source frequency: 50 Hz  $\pm 0.3\%$ /60 Hz  $\pm 0.3\%$
5. Installation location

Avoid direct sunlight or bright lighting. Ensure that the photoconductor will not be exposed to direct sunlight or other strong light when removing paper jams.

Avoid locations subject to high temperature and high humidity or low temperature and low humidity; an abrupt change in the environmental temperature; and cool or hot, direct air.

Avoid places subject to dust and vibrations.

Choose a surface capable of supporting the weight of the machine.


Place the machine on a level surface (maximum allowance inclination: 1°).

Avoid air-borne substances that may adversely affect the machine or degrade the photoconductor, such as mercury, acidic or alkaline vapors, inorganic gasses, NOx, SOx gases and chlorine-based organic solvents.

Select a well-ventilated location.

6. Allow sufficient access for proper operation and maintenance of the machine.

(Model with document processor as standard)



(Model with original cover as standard)





Figure 1-2-1

## 1-2-2 Unpacking

### (1) Unpacking



**Figure 1-2-2**

- |                     |                              |
|---------------------|------------------------------|
| 1. Machine          | 11. Plastic bag              |
| 2. Outer case       | 12. Power cord               |
| 3. Inner frame      | 13. Plastic bag (250 ´ 600)  |
| 4. Bottom pad L     | 14. Operation labels         |
| 5. Bottom pad R     | 15. Operation label pad      |
| 6. Machine cover    | 16. Plastic bag (240 ´ 350)  |
| 7. Top pad L        | 17. Plastic bag              |
| 8. Top pad R        | 18. Modular cable *          |
| 9. Accessory spacer | 19. Quick installation guide |
| 10. Toner container | 20. Safety guide 1           |

- |                                |
|--------------------------------|
| 21. Safety guide 2             |
| 22. Toner OSHA leaflet *       |
| 23. EEA information leaflet ** |
| 24. DVD-ROM                    |

\* 120 V AC model only.

\*\* 220-240 V AC model only.

## (2) Removing the tapes

### <Procedure>

1. Remove two tapes.
2. Open the sheet.




Figure 1-2-3

3. Remove two tapes A.
4. Open the top cover.
5. Remove the tape B and then remove the spacer.
6. Close the top cover.






Figure 1-2-4

7. Remove two tapes.



**Figure 1-2-5**



- 8. Open the DP.
- 9. Remove the sheet.
- 10. Remove the paper.



**Figure 1-2-6**



11. Remove the tape A.
12. Move the lock lever to the position of release.
  - \* : When turning on power if the lock lever is not released, the error message is displayed.
13. Close the DP.
14. Remove eight tapes B.

**Figure 1-2-7**

## 1-2-3 Installing the expansion memory (option)

### <Procedure>

1. Turn off the power switch and pull out the power cable.  
Caution: Do not insert or remove expansion memory while machine power is on.  
Doing so may cause damage to the machine and the expansion memory.
2. Remove the right side cover.
3. Remove the screw.




Figure 1-2-8

4. Open the memory slot cover.
5. Insert the expansion memory into the memory socket so that the notches on the memory align with the corresponding protrusions in the slot.
6. Close the memory slot cover.
7. Secure the screw.
8. Refit the right side cover.
9. Print a status page to check the memory expansion.  
If memory expansion has been properly performed, information on the installed memory is printed with the total memory capacity has been increased. Standard memory capacity 256 MB.





Figure 1-2-9

## 1-3-1 Maintenance mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

### (1) Executing a maintenance item



**(2) Maintenance modes item list**

Section	Item No.	Content of maintenance item	Initial setting
General	U000	Outputting an maintenance report	-
	U001	Exit Maintenance Mode	-
	U002	Setting the factory default data	-
	U004	Setting the machine number	-
	U010	Set Mainte ID	-
	U019	Firmware Version	-
Initialization	U021	Memory initializing	-
Drive, paper feed and paper conveying system	U034	Adjust Paper Timing Data LSU Out Top LSU Out Left	600/0/0/0 600/0/0/0/0/0
Optical	U065	Adjust Scanner Motor Speed	0/0
	U066	Adjust Table Leading Edge Timing	0/0
	U067	Adjust Table Center	0/0
	U068	Adjust DP Scan Position	0/0
	U070	Adjust DP Motor Speed	0
	U071	Adjust DP Leading Edge Timing	0/0/0/0/0
	U072	Adjust DP Original Center	-/-/0
Developer	U130	Set Toner Install	-
Operation panel and support equipment	U203	Checking DP operation	-
	U207	Checking the operation panel keys	-
	U222	Setting the IC card type	Other
Mode setting	U250	Setting the maintenance cycle	100000
	U251	Checking/clearing the maintenance count	0
	U252	Setting the destination	-
	U253	Switching between double and single counts	Double count
	U260	Selecting the timing for copy counting	EJECT
	U265	Setting OEM purchaser code	-
	U285	Setting service status page	ON
	U332	Setting the size conversion factor	1.0
	U345	Setting the value for maintenance due indication	0
	U346	Selecting Sleep Mode	ON/ON

Section	Item No.	Content of maintenance item	Initial setting
Image processing	U402	Adjust Print Margin	4.0/3.0/3.0/3.9
	U403	Adjust Scanning Margin(Table)	2.0/2.0/2.0/2.0
	U404	Adjust Scanning Margin(DP)	3.0/2.5/3.0/4.0
	U411	Auto Adj Scn	-
	U425	Set Target	-
Fax	U600	Initializing all data	-
	U601	Initializing permanent data	-
	U603	Setting user data 1	DTMF
	U604	Setting user data 2	2 (120 V) 1 (220-240 V)
	U605	Clearing data	-
	U610	Setting system 1 Setting the number of lines to be ignored when receiving a fax at 100% magnification Setting the number of lines to be ignored when receiving a fax in the auto reduction mode Setting the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode	3 0 0
	U611	Setting system 2 Setting the number of adjustment lines for automatic reduction Setting the number of adjustment lines for automatic reduction when A4 paper is set Setting the number of adjustment lines for automatic reduction when letter size paper is set	7 22 26
	U612	Setting system 3 Selecting if auto reduction in the auxiliary direction is to be performed Setting the automatic printing of the protocol list	ON OFF
	U620	Setting the remote switching mode	ONE
	U625	Setting the transmission system 1 Setting the auto redialing interval Setting the number of times of auto redialing	3 (120 V) 2 (220-240 V) 2 (120 V) 3 (220-240 V)
	U630	Setting communication control 1 Setting the communication starting speed Setting the reception speed Setting the waiting period to prevent echo problems at the sender Setting the waiting period to prevent echo problems at the receiver	14400bps/V17 14400bps 300 75

Section	Item No.	Content of maintenance item	Initial setting
Fax	U631	Setting communication control 2 Setting ECM transmission Setting ECM reception Setting the frequency of the CED signal	ON ON 2100
	U632	Setting communication control 3 Setting the DIS signal to 4 bytes Setting the short protocol transmission Setting the reception of a short protocol transmission Setting the CNG detection times in the fax/telephone auto select mode	OFF ON ON 2TIME
	U633	Setting communication control 4 Enabling/disabling V.34 communication Setting the V.34 symbol speed (3429 Hz) Setting the number of times of DIS signal reception Setting the reference for RTN signal output	ON ON ONCE 15%
	U634	Setting communication control 5	0
	U640	Setting communication time 1 Setting the one-shot detection time for remote switching Setting the continuous detection time for remote switching	7 80
	U641	Setting communication time 2 Setting the T0 time-out time Setting the T1 time-out time Setting the T2 time-out time Setting the Ta time-out time Setting the Tb1 time-out time Setting the Tb2 time-out time Setting the Tc time-out time Setting the Td time-out time	56 36 69 30 20 80 60 9 (120 V) 6 (220-240 V)
	U650	Setting modem 1 Setting the G3 transmission cable equalizer Setting the G3 reception cable equalizer Setting the modem detection level	0dB 0dB 43dBm
	U651	Setting modem 2 Modem output level  DTMF output level (main value)  DTMF output level (level difference)	9 (120 V) 10 (220-240 V) 5 (120 V) 10.5 (220-240 V) 2 (120 V) 2.5 (220-240 V)
	U660	Setting the NCU Setting the connection to PBX/PSTN Setting PSTN dial tone detection Setting busy tone detection Setting for a PBX Setting the loop current detection before dialing	PSTN ON ON LOOP ON
	U670	Outputting lists	-

Section	Item No.	Content of maintenance item	Initial setting
Fax	U695	FAX function customize	ON/OFF
	U699	Setting the software switches	-
Others	U901	Clr Paper FD Cnt	-
	U905	Option Cnt	-
	U910	Clearing the black ratio data	-
	U917	Setting backup data reading/writing	-
	U920	Chg Cnt	-
	U927	Clearing the all copy counts and machine life counts (one time only)	-
	U928	Life Cnt	-
	U977	Data capture mode	-
	U995	Mem Data Indi	-

**(3) Contents of the maintenance mode items**

Item No.	Description																
U000	<p><b>Outputting an maintenance report</b></p> <p><b>Description</b> Outputs lists of the current settings of the maintenance items and paper jam and service call occurrences. Outputs the event log. Also sends output data to the USB memory. Printing a report is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.</p> <p><b>Purpose</b> To check the current setting of the maintenance items, or paper jam or service call occurrences. Before initializing or replacing the backup RAM, output a list of the current settings of the maintenance items to reenter the settings after initialization or replacement.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be output using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Output list</th></tr> </thead> <tbody> <tr> <td>MAINTENANCE</td><td>List of the current settings of the maintenance modes</td></tr> <tr> <td>EVENT</td><td>Outputs the event log</td></tr> <tr> <td>ALL</td><td>Outputs the all reports</td></tr> </tbody> </table> <ol style="list-style-type: none"> <li>3. Press the start key. A list is output.</li> </ol> <p><b>Method: Send to the USB memory</b></p> <ol style="list-style-type: none"> <li>1. Turn the power switch off.</li> <li>2. Insert USB memory in USB memory slot.</li> <li>3. Turn the power switch on.</li> <li>4. Enter the maintenance item.</li> <li>5. Press the start key.</li> <li>6. Select the item to be send.</li> <li>7. Select [TEXT] or [HTML].</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Output list</th></tr> </thead> <tbody> <tr> <td>Print</td><td>Outputs the report</td></tr> <tr> <td>USB (TEXT)</td><td>Sends output data to the USB memory (text type)</td></tr> <tr> <td>USB (HTML)</td><td>Sends output data to the USB memory (HTML type)</td></tr> </tbody> </table> <ol style="list-style-type: none"> <li>8. Press the start key. Output will be sent to the USB memory.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Output list	MAINTENANCE	List of the current settings of the maintenance modes	EVENT	Outputs the event log	ALL	Outputs the all reports	Display	Output list	Print	Outputs the report	USB (TEXT)	Sends output data to the USB memory (text type)	USB (HTML)	Sends output data to the USB memory (HTML type)
Display	Output list																
MAINTENANCE	List of the current settings of the maintenance modes																
EVENT	Outputs the event log																
ALL	Outputs the all reports																
Display	Output list																
Print	Outputs the report																
USB (TEXT)	Sends output data to the USB memory (text type)																
USB (HTML)	Sends output data to the USB memory (HTML type)																





Item No.	Description				
U000	Detail of event log				
	No.	Items	Description		
	(1)	System version			
	(2)	System date			
	(3)	Engine soft version			
	(4)	Engine boot version			
	(5)	Operation panel mask version			
	(6)	Machine serial number			
	(7)	Paper Jam Log	#	Count.	Event
			Remembers 1 to 16 of occurrence. If the occurrence of the previous paper jam is less than 16, all of the paper jams are logged. When the occurrence exceeds 16, the oldest occurrence is removed.	The total page count at the time of the paper jam.	Log code (2 digit, hexadecimal, 5 categories)  (a) Cause of a paper jam (b) Paper source (c) Paper size (d) Paper type (e) Paper eject
			(a) Cause of paper jam (Hexadecimal)		
			Refer to page 1-4-2 for paper jam location 0100: Secondary paper feed request time out 0101: Waiting for process package to be ready 0105: Warm up request time out 0107: Waiting for fuser package to be ready 0110: Top cover open 0501: No paper feed from cassette 1 0502: No paper feed from cassette 2 0503: No paper feed from cassette 3 0508: No paper feed from duplex section 0509: No paper feed from MP tray 0511: Multiple sheets in cassette 1 0512: Multiple sheets in cassette 2 0513: Multiple sheets in cassette 3 0518: Multiple sheets in duplex section 0519: Multiple sheets in MP tray 1403: PF feed sensor 1 non arrival jam (cassette 3) 1413: PF feed sensor 1 stay jam (cassette 3) 1420: PF feed sensor 1 initial jam (Warm up) 1620: PF feed sensor 2 initial jam (Warm up) 4002: Registration sensor non arrival jam (cassette 2) 4003: Registration sensor non arrival jam (cassette 3) 4012: Registration sensor stay jam (cassette 2) 4013: Registration sensor stay jam (cassette 3) 4020: Registration sensor initial jam (Warm up) 4201: Eject sensor non arrival jam (cassette 1) 4202: Eject sensor non arrival jam (cassette 2) 4203: Eject sensor non arrival jam (cassette 3)		

Item No.	Description		
U000			
	<b>No.</b>	<b>Items</b>	<b>Description</b>
	(7) cont.	Paper Jam Log	4208: Eject sensor non arrival jam (duplex) 4209: Eject sensor non arrival jam (Mp tray) 4211: Eject sensor stay jam (cassette 1) 4212: Eject sensor stay jam (cassette 2) 4213: Eject sensor stay jam (cassette 3) 4218: Eject sensor stay jam (duplex) 4219: Eject sensor stay jam (MP tray) 4220: Eject sensor initial jam (Warm up) 4301: Duplex sensor non arrival jam (cassette 1) 4302: Duplex sensor non arrival jam (cassette 2) 4303: Duplex sensor non arrival jam (cassette 3) 4309: Duplex sensor non arrival jam (MP tray) 4311: Duplex sensor stay jam (cassette 1) 4312: Duplex sensor stay jam (cassette 2) 4313: Duplex sensor stay jam (cassette 3) 4319: Duplex sensor stay jam (MP tray) 9000: No original feed 9001: DP original conveying jam 9003: DP original swichback non arrival jam 9004: DP original swichback stay jam 9011: DP top cover open 9401: DP timing sensor stay jam
			(b) Detail of paper source (Hexadecimal)
			00: MP tray 01: Cassette 1 02: Cassette 2 (paper feeder 1) 03: Cassette 3 (paper feeder 2) 05 to 09: Reserved

Item No.	Description			
U000	(7) cont.	Paper Jam Log	Description	
			(c) Detail of paper size (Hexadecimal)	
			00: (Not specified)	0B: B4
			01: Monarch	0C: Ledger
			02: Business	0D: A5R
			03: International DL	0E: A6
			04: International C5	0F: B6
			05: Executive	10: Commercial #9
			06: Letter-R	11: Commercial #6
			07: Legal	12: ISO B5
			08: A4R	13: Custom size
			08: A4E	1E: C4
			09: B5R	1F: Postcard
			09: B5E	20: Reply-paid post-card
			0A: A3	21: Oficio II
			(d) Detail of paper type (Hexadecimal)	
			01: Plain	0A: Color
			02: Transparency	0B: Prepunched
			03: Preprinted	0C: Envelope
			04: Labels	0D: Cardstock
			05: Bond	0E: Coated
			06: Recycled	0F: 2nd side
			07: Vellum	10: Media 16
			08: Rough	11: High quality
			09: Letterhead	
			(e) Detail of paper eject location (Hexadecimal)	
			01: Face down (FD)	
	(8)	Service Call Log	#	Count.
			Remembers 1 to 8 of occurrence of self diagnostics error. If the occurrence of the previous diagnostics error is less than 8, all of the diagnostics errors are logged.	The total page count at the time of the self diagnostics error.
				Service Code
				Self diagnostic error code (See page 1-4-7)
				Example: 01.6000
				01: Self diagnostic error 6000: Self diagnostic error code number

Item No.	Description				
U000					
	No.	Items	Description		
	(9)	Maintenance Log	#	Count.	Item
			Remembers 1 to 8 of occurrence of replacement. If the occurrence of the previous replacement of toner container is less than 8, all of the occurrences of replacement are logged.	The total page count at the time of the replacement of the toner container.	Code of maintenance replacing item (1 byte, 2 categories)  First byte (Replacing item) 01: Toner container 02: Maintenance kit  Second byte (Type of replacing item) 00: Black 01: MK-1130/1140 MK-1132/1142
	(10)	Unknown Toner Log	#	Count.	Item
			Remembers 1 to 5 of occurrence of unknown toner detection. If the occurrence of the previous unknown toner detection is less than 5, all of the unknown toner detection are logged.	The total page count at the time of the [Toner Empty] error with using an unknown toner container.  * :The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted.	Unknown toner log code (1 byte, 2 categories)  First byte 01: Fixed (Toner container)  Second byte 00: Fixed (Black)

Item No.	Description				
U000					
	No.	Items	Description		
	(11)	Counter Log	(f) Paper jam	(g) Self diagnostic error	(h) Maintenance item replacing
		Comprised of three log counters including paper jams, self diagnostics errors, and replacement of the toner container.	Indicates the log counter of paper jams depending on location.  Refer to Paper Jam Log.  All instances including those are not occurred are displayed.	Indicates the log counter of self diagnostics errors depending on cause. (See page 1-4-7)  Example: C6000: 4  Self diagnostics error 6000 has happened four times.	Indicates the log counter depending on the maintenance item for maintenance.  T: Toner container 00: Black M: Maintenance kit 01: MK-1130/1140 MK-1132/1142  Example: T00: 1 The toner container has been replaced once.  * :The toner replacement log is triggered by toner empty. This record may contain such a reference as the toner container is inserted twice or a used toner container is inserted.
U001	<b>Exit Maintenance Mode</b>  <b>Description</b> Exits the maintenance mode and returns to the normal copy mode. <b>Purpose</b> To exit the maintenance mode.  <b>Method</b> 1. Press the start key. The normal copy mode is entered.				

Item No.	Description										
U002	<p><b>Setting the factory default data</b></p> <p><b>Description</b> Restores the machine conditions to the factory default settings.</p> <p><b>Purpose</b> To move the image scanner unit to the home position. (position in which the frame can be fixed).</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select [MODE1(ALL)] using the cursor up/down keys.</li> <li>3. Press the start key. The image scanner returns to the home position.</li> <li>4. Turn the power switch off and on. * : An error code is displayed in case of an initialization error. When errors occurred, turn power switch off then on, and execute initialization using maintenance item U002.</li> </ol> <p><b>Error codes</b></p> <table> <tr> <th>Codes</th><th>Description</th></tr> <tr> <td>0001</td><td>Controller error</td></tr> <tr> <td>0020</td><td>Engine error</td></tr> <tr> <td>0040</td><td>Scanner error</td></tr> </table>	Codes	Description	0001	Controller error	0020	Engine error	0040	Scanner error		
Codes	Description										
0001	Controller error										
0020	Engine error										
0040	Scanner error										
U004	<p><b>Setting the machine number</b></p> <p><b>Description</b> Sets or displays the machine number.</p> <p><b>Purpose</b> To check or set the machine number.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key. If the machine serial number of engine PWB matches with that of main PWB</li> </ol> <table> <tr> <th>Display</th><th>Operation</th></tr> <tr> <td>MACHINE No.</td><td>Displays the machine serial number</td></tr> </table> <p>If the machine serial number of engine PWB does not match with that of main PWB</p> <table> <tr> <th>Display</th><th>Operation</th></tr> <tr> <td>MACHINE No. (MAIN)</td><td>Displays the machine serial number of main</td></tr> <tr> <td>MACHINE No. (ENG)</td><td>Displays the machine serial number of engine</td></tr> </table> <p><b>Setting</b> Carry out if the machine serial number does not match.</p> <ol style="list-style-type: none"> <li>1. Press [EXECUTE].</li> <li>2. Press the start key. Writing of serial No. starts.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Operation	MACHINE No.	Displays the machine serial number	Display	Operation	MACHINE No. (MAIN)	Displays the machine serial number of main	MACHINE No. (ENG)	Displays the machine serial number of engine
Display	Operation										
MACHINE No.	Displays the machine serial number										
Display	Operation										
MACHINE No. (MAIN)	Displays the machine serial number of main										
MACHINE No. (ENG)	Displays the machine serial number of engine										

Item No.	Description						
U010	<p><b>Set Mainte ID</b></p> <p><b>Description</b> Maintenance mode ID for markets is changed.</p> <p><b>Purpose</b> The brittleness of a security function is improved by changing maintenance mode ID for markets.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be set.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Change</td><td>Maintenance mode ID for markets is changed.</td></tr> <tr> <td>Initialize</td><td>Maintenance mode ID for markets is initialized.</td></tr> </tbody> </table> <p><b>[Setting: Change]</b></p> <ol style="list-style-type: none"> <li>1. Select the [New ID(Reconfirm)].</li> <li>2. New ID is inputted using a ten key. * : New ID of 8 figures is taken as the arbitrary combination of 0 to 9, *, and #. (* or # is certainly included)</li> <li>3. Select the [Excute].</li> <li>4. Press the start key. ID is set.</li> <li>5. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.</li> </ol> <p><b>[Setting: Initialaize]</b></p> <ol style="list-style-type: none"> <li>1. Select the [Excute].</li> <li>2. Press the start key. ID is intialized.</li> <li>3. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Change	Maintenance mode ID for markets is changed.	Initialize	Maintenance mode ID for markets is initialized.
Display	Description						
Change	Maintenance mode ID for markets is changed.						
Initialize	Maintenance mode ID for markets is initialized.						




Item No.	Description																						
U019	<p><b>Firmware Version</b></p> <p><b>Description</b> Displays the part number of the ROM fitted to each PWB.</p> <p><b>Purpose</b> To check the part number or to decide, if the newest version of ROM is installed.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key. The ROM version are displayed.</li> <li>2. Change the screen using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Main</td><td>Main ROM</td></tr> <tr> <td>MMI</td><td>Operation ROM</td></tr> <tr> <td>Engine</td><td>Engine ROM</td></tr> <tr> <td>Engine Boot</td><td>Engine booting</td></tr> <tr> <td>Scanner</td><td>Scanner ROM</td></tr> <tr> <td>Scanner Boot</td><td>Scanner booting</td></tr> <tr> <td>Option Language</td><td>Optional language ROM</td></tr> <tr> <td>Fax APL</td><td>Fax APL</td></tr> <tr> <td>Fax IPL</td><td>Fax IPL</td></tr> <tr> <td>Fax Boot</td><td>Fax Boot</td></tr> </tbody> </table> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Main	Main ROM	MMI	Operation ROM	Engine	Engine ROM	Engine Boot	Engine booting	Scanner	Scanner ROM	Scanner Boot	Scanner booting	Option Language	Optional language ROM	Fax APL	Fax APL	Fax IPL	Fax IPL	Fax Boot	Fax Boot
Display	Description																						
Main	Main ROM																						
MMI	Operation ROM																						
Engine	Engine ROM																						
Engine Boot	Engine booting																						
Scanner	Scanner ROM																						
Scanner Boot	Scanner booting																						
Option Language	Optional language ROM																						
Fax APL	Fax APL																						
Fax IPL	Fax IPL																						
Fax Boot	Fax Boot																						

Item No.	Description										
U021	<p><b>Memory initializing</b></p> <p><b>Description</b> Initializes all settings, except those pertinent to the type of machine, namely each counter, service call history and mode setting. Also initializes backup RAM according to region specification selected in maintenance item U252 Setting the destination.</p> <p><b>Purpose</b> To return the machine settings to their factory default.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select [Execute].</li> <li>3. Press the start key. All data other than that for adjustments due to variations between machines is initialized based on the destination setting.</li> <li>4. Turn the main power switch off and on.</li> </ol> <p>* : An error code is displayed in case of an initialization error. When errors occurred, turn main power switch off then on, and execute initialization using maintenance item U021.</p> <p><b>Error codes</b></p> <table> <tr> <th>Codes</th><th>Description</th></tr> <tr> <td>0001</td><td>Entity error</td></tr> <tr> <td>0002</td><td>Controller error</td></tr> <tr> <td>0020</td><td>Engine error</td></tr> <tr> <td>0040</td><td>Scanner error</td></tr> </table>	Codes	Description	0001	Entity error	0002	Controller error	0020	Engine error	0040	Scanner error
Codes	Description										
0001	Entity error										
0002	Controller error										
0020	Engine error										
0040	Scanner error										

Item No.	Description																															
U034	<div><div>Adjust Paper Timing Data</div><div><div>Description</div><div>Adjusts the leading edge registration or center line.</div><div>Purpose</div><div>Make the adjustment if there is a regular error between the leading edges of the copy image and original.</div><div>Make the adjustment if there is a regular error between the center lines of the copy image and original.</div><div>Method</div><div><div>1. Press the start key.</div><div>2. Select the item to be adjusted.</div></div><div><table><tr><th>Display</th><th>Description</th></tr><tr><td>LSU Out Top</td><td>Leading edge registration adjustment</td></tr><tr><td>LSU Out Left</td><td>Center line adjustment</td></tr></table></div><div><div>Adjustment: [LSU Out Top]</div><div><div>1. Press the system menu key.</div><div>2. Press the start key to output a test pattern.</div><div>3. Press the system menu key.</div><div>4. Select the item to be adjusted.</div></div><div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Top</td><td>Standard value</td><td>0 to 1180</td><td>600</td><td>1dot</td></tr><tr><td>MPT</td><td>Paper feed from MP tray</td><td>-70 to 70</td><td>0</td><td>1dot</td></tr><tr><td>Cassette</td><td>Paper feed from cassette</td><td>-70 to 70</td><td>0</td><td>1dot</td></tr><tr><td>Duplex</td><td>Duplex mode (second)</td><td>-70 to 70</td><td>0</td><td>1dot</td></tr></table></div><div><div>5. Change the setting value using the cursor left/right keys or numeric keys.</div><div>For output example 1, increase the value. For output example 2, decrease the value.</div><div><div><div>Leading edge registration (20 ± 1.0 mm)</div><div></div></div><div><div>Correct image</div><div></div></div><div><div>Output example 1</div><div></div></div><div><div>Output example 2</div><div></div></div></div></div></div></div></div>	Display	Description	LSU Out Top	Leading edge registration adjustment	LSU Out Left	Center line adjustment	Display	Description	Setting range	Initial setting	Change in value per step	Top	Standard value	0 to 1180	600	1dot	MPT	Paper feed from MP tray	-70 to 70	0	1dot	Cassette	Paper feed from cassette	-70 to 70	0	1dot	Duplex	Duplex mode (second)	-70 to 70	0	1dot
Display	Description																															
LSU Out Top	Leading edge registration adjustment																															
LSU Out Left	Center line adjustment																															
Display	Description	Setting range	Initial setting	Change in value per step																												
Top	Standard value	0 to 1180	600	1dot																												
MPT	Paper feed from MP tray	-70 to 70	0	1dot																												
Cassette	Paper feed from cassette	-70 to 70	0	1dot																												
Duplex	Duplex mode (second)	-70 to 70	0	1dot																												

Item No.	Description																																			
U034	<div><div><div><b>Caution</b></div><div>Check the copy image after the adjustment. If the image is still incorrect, perform the following adjustments in maintenance mode.</div><div><div><div>U034</div><div>→</div><div><div>U066 (P.1-3-21)</div><div>→</div><div><div>U071 (P.1-3-25)</div></div></div></div></div><div><div><b>Adjustment: [LSU Out Left]</b></div><div><div>1. Press the system menu key.</div><div>2. Press the start key to output a test pattern.</div><div>3. Press the system menu key.</div><div>4. Select the item to be adjusted.</div></div><table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>Left</td><td>Standard value</td><td>0 to 1180</td><td>600</td><td>1 dot</td></tr><tr><td>MPT</td><td>Paper feed from MP tray</td><td>-70 to 70</td><td>0</td><td>1 dot</td></tr><tr><td>Cassette1</td><td>Paper feed from optional cassette1</td><td>-70 to 70</td><td>0</td><td>1 dot</td></tr><tr><td>Cassette2</td><td>Paper feed from optional cassette2</td><td>-70 to 70</td><td>0</td><td>1 dot</td></tr><tr><td>Cassette3</td><td>Paper feed from optional cassette3</td><td>-70 to 70</td><td>0</td><td>1 dot</td></tr><tr><td>Duplex</td><td>Duplex mode (second)</td><td>-70 to 70</td><td>0</td><td>1 dot</td></tr></tbody></table><div><div>5. Change the setting value using the cursor left/right keys or numeric keys.</div><div>For output example 1, increase the value. For output example 2, decrease the value.</div><div><div><div>Center line of printing (within ± 2.0 mm)</div><div><div><div><div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div><div></div></div></div></div></div></div></div></div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	Left	Standard value	0 to 1180	600	1 dot	MPT	Paper feed from MP tray	-70 to 70	0	1 dot	Cassette1	Paper feed from optional cassette1	-70 to 70	0	1 dot	Cassette2	Paper feed from optional cassette2	-70 to 70	0	1 dot	Cassette3	Paper feed from optional cassette3	-70 to 70	0	1 dot	Duplex	Duplex mode (second)	-70 to 70	0	1 dot
Display	Description	Setting range	Initial setting	Change in value per step																																
Left	Standard value	0 to 1180	600	1 dot																																
MPT	Paper feed from MP tray	-70 to 70	0	1 dot																																
Cassette1	Paper feed from optional cassette1	-70 to 70	0	1 dot																																
Cassette2	Paper feed from optional cassette2	-70 to 70	0	1 dot																																
Cassette3	Paper feed from optional cassette3	-70 to 70	0	1 dot																																
Duplex	Duplex mode (second)	-70 to 70	0	1 dot																																

Item No.	Description															
U065	<div><div>Adjust Scanner Motor Speed</div><div><div>Description</div><div>Adjusts the magnification of the original scanning.</div><div>Purpose</div><div>Make the adjustment if the magnification in the main scanning direction is incorrect. Make the adjustment if the magnification in the auxiliary scanning direction is incorrect.</div><div>Method</div><div><div>1. Press the start key.</div><div>2. Press the system menu key.</div><div>3. Place an original and press the start key to make a test copy.</div><div>4. Press the system menu key.</div><div>5. Select the item to be adjusted.</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Main Scan</td><td>Scanner magnification in the main scanning direction</td><td>-32 to 127</td><td>0</td><td>0.1 %</td></tr><tr><td>Sub Scan</td><td>Scanner magnification in the auxiliary scanning direction</td><td>-25 to 25</td><td>0</td><td>0.1 %</td></tr></table><div><div>Adjustment: [Main Scan]</div><div><div>1. Change the setting value using the cursor left/right keys or numeric keys.</div><div>For copy example 1, increase the value. For copy example 2, decrease the value.</div><div>Increasing the setting enlarges the image and decreasing it narrows the image.</div><div><div><div><div></div></div><div>Original</div></div><div><div><div></div></div><div>Copy example 1</div></div><div><div><div></div></div><div>Copy example 2</div></div></div></div><div><div>Figure 1-3-4</div><div><div>2. Press the start key. The value is set.</div></div></div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	Main Scan	Scanner magnification in the main scanning direction	-32 to 127	0	0.1 %	Sub Scan	Scanner magnification in the auxiliary scanning direction	-25 to 25	0	0.1 %
Display	Description	Setting range	Initial setting	Change in value per step												
Main Scan	Scanner magnification in the main scanning direction	-32 to 127	0	0.1 %												
Sub Scan	Scanner magnification in the auxiliary scanning direction	-25 to 25	0	0.1 %												

Item No.	Description
U065	<p><b>Adjustment: [Sub Scan]</b></p> <p>1. Change the setting value using the left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. Increasing the value makes the image longer, while decreasing the value makes the image shorter.</p> <div data-bbox="667 436 1054 660"><p>Original      Copy example 1      Copy example 2</p></div> <p><b>Figure 1-3-5</b></p> <p>2. Press the start key. The value is set.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description															
U066	<div><div>Adjust Table Leading Edge Timing</div><div><div>Description</div><div>Adjusts the scanner leading edge registration of the original scanning.</div><div>Purpose</div><div>Make the adjustment if there is a regular error between the leading edges of the copy image and original.</div><div>Adjustment</div><div><div><div>1. Press the start key.</div><div>2. Press the system menu key.</div><div>3. Place an original and press the start key to make a test copy.</div><div>4. Press the system menu key.</div><div>5. Select the item to be adjusted.</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Front</td><td>Scanner leading edge registration</td><td>-45 to 45</td><td>0</td><td>0.086 mm</td></tr><tr><td>Rotate</td><td>Scanner leading edge registration (rotate copying)</td><td>-45 to 45</td><td>0</td><td>0.086 mm</td></tr></table><div><div>6. Change the setting value using the cursor left/right keys or numeric keys.</div><div>For copy example 1, increase the value. For copy example 2, decrease the value.</div><div>Increasing the value moves the image forward and decreasing the value moves the image backward.</div><div><div><div>Leading edge registration of the copy image (+1.0/-1.5 mm or less)</div><div><div><div><div></div><div></div><div></div></div><div><div>Original</div><div>Copy example 1</div><div>Copy example 2</div></div></div></div><div>Figure 1-3-6</div></div><div><div>7. Press the start key. The value is set.</div><div><div>Caution</div><div>If the above adjustment does not optimize the leading edge registration, proceed with the following maintenance modes.</div><div><div><div>U034 (P.1-3-17)</div><div>U065 (P.1-3-19)</div><div>U066</div></div></div><div><div>Completion</div><div>Press the stop key. The screen for selecting a maintenance item No. is displayed.</div></div></div></div></div></div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	Front	Scanner leading edge registration	-45 to 45	0	0.086 mm	Rotate	Scanner leading edge registration (rotate copying)	-45 to 45	0	0.086 mm
Display	Description	Setting range	Initial setting	Change in value per step												
Front	Scanner leading edge registration	-45 to 45	0	0.086 mm												
Rotate	Scanner leading edge registration (rotate copying)	-45 to 45	0	0.086 mm												







Item No.	Description															
U067	<div>Adjust Table Center</div> <div><div>Description</div><div>Adjusts the scanner center line of the original scanning.</div><div>Purpose</div><div>Make the adjustment if there is a regular error between the center lines of the copy image and original.</div><div>Adjustment</div><div><div><div>1. Press the start key.</div><div>2. Press the system menu key.</div><div>3. Place an original and press the start key to make a test copy.</div><div>4. Press the system menu key.</div><div>5. Select the item to be adjusted.</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Front</td><td>Scanner center line</td><td>-70 to 70</td><td>0</td><td>0.085 mm</td></tr><tr><td>Rotate</td><td>Scanner center line (rotate copying)</td><td>-40 to 40</td><td>0</td><td>0.085 mm</td></tr></table><div><div>6. Change the setting value using the cursor left/right keys or numeric keys.</div><div>For copy example 1, decrease the value. For copy example 2, increase the value.</div><div>Increasing the value moves the image leftward and decreasing it moves the image rightward.</div><div><div>Center line of the copy image (within ± 2.0 mm)</div><div><div><div><div></div></div></div><div>Original</div><div><div><div></div></div></div><div>Copy example 1</div><div><div><div></div></div></div><div>Copy example 2</div></div></div><div>Figure 1-3-7</div><div><div>7. Press the start key. The value is set.</div><div><div>Caution</div><div>If the above adjustment does not optimize the center line, proceed with the following maintenance modes.</div><div><div><div>U034 (P.1-3-17)</div><div>U065 (P.1-3-19)</div><div>U067</div></div></div><div><div>Completion</div><div>Press the stop key. The screen for selecting a maintenance item No. is displayed.</div></div></div></div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	Front	Scanner center line	-70 to 70	0	0.085 mm	Rotate	Scanner center line (rotate copying)	-40 to 40	0	0.085 mm
Display	Description	Setting range	Initial setting	Change in value per step												
Front	Scanner center line	-70 to 70	0	0.085 mm												
Rotate	Scanner center line (rotate copying)	-40 to 40	0	0.085 mm												



Item No.	Description															
U068	<p><b>Adjust DP Scan Position</b></p> <p><b>Description</b> Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.</p> <p><b>Purpose</b> Used when the image fogging occurs because the scanning position is not proper when the DP is used. Run U071 to adjust the timing of DP leading edge when the scanning position is changed.</p> <p><b>Setting</b> 1. Press the start key.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>DP Read</td><td>Starting position adjustment for scanning originals</td><td>-33 to 33</td><td>0</td><td>0.086 mm</td></tr><tr><td>Black Line</td><td>Scanning position for the test copy originals</td><td>0 to 3</td><td>0</td><td>0.22 mm</td></tr></table> <p>2. Select [DP Read]. 3. Change the setting using the cursor left/right keys or numeric keys. When the setting value is increased, the scanning position moves to the right and it moves to the left when the setting value is decreased. 4. Press the start key. The value is set. 5. Select [Black Line]. 6. Change the setting using the left/right keys or numeric keys. 7. Press the start key. The value is set. 8. Set the original (the one which density is known) in the DP and press the system menu key. 9. Press the start key. Test copy is executed. 10. Perform the test copy at each scanning position with the setting value from 0 to 3 and check that no black line appears and the image is normally scanned.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	Change in value per step	DP Read	Starting position adjustment for scanning originals	-33 to 33	0	0.086 mm	Black Line	Scanning position for the test copy originals	0 to 3	0	0.22 mm
Display	Description	Setting range	Initial setting	Change in value per step												
DP Read	Starting position adjustment for scanning originals	-33 to 33	0	0.086 mm												
Black Line	Scanning position for the test copy originals	0 to 3	0	0.22 mm												

Item No.	Description										
U070	<div><div>Adjust DP Motor Speed</div><div><div>Description</div><div>Adjusts the DP original scanning speed.</div><div>Purpose</div><div>Make the adjustment if the magnification is incorrect in the auxiliary scanning direction when the DP is used.</div><div>Adjustment</div><div><div><div>1. Press the start key.</div><div>2. Press the system menu key.</div><div>3. Place an original on the DP and press the start key to make a test copy.</div><div>4. Press the system menu key.</div><div>5. Select [Convey Speed].</div></div><table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Convey Speed</td><td>Magnification in the auxiliary scanning direction of CCD (first side)</td><td>-25 to 25</td><td>0</td><td>0.1 %</td></tr></table><div><div><div>6. Change the setting value using the cursor left/right keys or numeric keys.</div><div>For copy example 1, increase the value. For copy example 2, decrease the value.</div><div>Increasing the value makes the image longer, while decreasing the value makes the image shorter.</div></div><div><div><div><div><div></div></div></div><div>Original</div></div><div><div><div><div></div></div></div><div>Copy example 1</div></div><div><div><div><div></div></div></div><div>Copy example 2</div></div></div><div>Figure 1-3-8</div><div><div><div>7. Press the start key. The value is set.</div></div><div><div>Completion</div><div>Press the stop key. The screen for selecting a maintenance item No. is displayed.</div></div></div></div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	Convey Speed	Magnification in the auxiliary scanning direction of CCD (first side)	-25 to 25	0	0.1 %
Display	Description	Setting range	Initial setting	Change in value per step							
Convey Speed	Magnification in the auxiliary scanning direction of CCD (first side)	-25 to 25	0	0.1 %							

Item No.	Description																														
U071	<p><b>Adjust DP Leading Edge Timing</b></p> <p><b>Description</b> Adjusts the DP original scanning timing.</p> <p><b>Purpose</b> Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Press the system menu key.</li><li>3. Place an original on the DP and press the start key to make a test copy.</li><li>4. Press the system menu key.</li><li>5. Select the item to be adjusted.</li></ol> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Front Head</td><td>Leading edge registration of CCD (first side)</td><td>-32 to 32</td><td>0</td><td>0.196 mm</td></tr><tr><td>Front Tail</td><td>Trailing edge registration of CCD (first side)</td><td>-32 to 32</td><td>0</td><td>0.196 mm</td></tr><tr><td>Back Head</td><td>Leading edge registration of CCD (second side)</td><td>-45 to 45</td><td>0</td><td>0.196 mm</td></tr><tr><td>Back Tail</td><td>Trailing edge registration of CCD (second side)</td><td>-45 to 45</td><td>0</td><td>0.196 mm</td></tr><tr><td>Rotate</td><td>Leading edge registration (rotate copying)</td><td>-128 to 127</td><td>0</td><td>0.196 mm</td></tr></table>	Display	Description	Setting range	Initial setting	Change in value per step	Front Head	Leading edge registration of CCD (first side)	-32 to 32	0	0.196 mm	Front Tail	Trailing edge registration of CCD (first side)	-32 to 32	0	0.196 mm	Back Head	Leading edge registration of CCD (second side)	-45 to 45	0	0.196 mm	Back Tail	Trailing edge registration of CCD (second side)	-45 to 45	0	0.196 mm	Rotate	Leading edge registration (rotate copying)	-128 to 127	0	0.196 mm
Display	Description	Setting range	Initial setting	Change in value per step																											
Front Head	Leading edge registration of CCD (first side)	-32 to 32	0	0.196 mm																											
Front Tail	Trailing edge registration of CCD (first side)	-32 to 32	0	0.196 mm																											
Back Head	Leading edge registration of CCD (second side)	-45 to 45	0	0.196 mm																											
Back Tail	Trailing edge registration of CCD (second side)	-45 to 45	0	0.196 mm																											
Rotate	Leading edge registration (rotate copying)	-128 to 127	0	0.196 mm																											

Item No.	Description
U071	<p><b>Adjustment: Leading edge registration</b></p> <p>1. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value. Increasing the value moves the image forward and decreasing the value moves the image backward.</p> <div><div><p>Original</p></div><div><p>Copy example 1</p></div><div><p>Copy example 2</p></div></div> <p><b>Figure 1-3-9</b></p> <p>2. Press the start key. The value is set.</p> <p><b>Caution</b> If the first side is adjusted, check the second side and if adjustment is required, carry out the adjustment. If the above adjustment does not optimize the leading edge registration, proceed with the following maintenance modes.</p> <div><div>U034 (P.1-3-17)</div><div>→</div><div>U071</div></div> <p><b>Adjustment: Trailing edge registration</b></p> <p>1. Change the setting value using the cursor left/right keys or numeric keys. For copy example 1, increase the value. For copy example 2, decrease the value.</p> <div><div><p>Original</p></div><div><p>Copy example 1</p></div><div><p>Copy example 2</p></div></div> <p><b>Figure 1-3-10</b></p> <p>2. Press the start key. The value is set.</p> <p><b>Caution</b> If the first side is adjusted, check the second side and if adjustment is required, carry out the adjustment.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																				
U072	<div><div>Adjust DP Original Center</div><div><div>Description</div><div>Adjusts the scanning start position for the DP original.</div><div>Purpose</div><div>Make the adjustment if there is a regular error between the centers of the original and the copy image when the DP is used.</div><div>Adjustment</div><div><div><div>1. Press the start key.</div><div>2. Press the system menu key.</div><div>3. Place an original on the DP and press the start key to make a test copy.</div><div>4. Press the system menu key.</div><div>5. Select the item to be adjusted.</div></div><table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>Front</td><td>DP center line (first side)</td><td>-39 to 39</td><td>-</td><td>0.085 mm</td></tr><tr><td>Back</td><td>DP center line (second side)</td><td>-39 to 39</td><td>-</td><td>0.085 mm</td></tr><tr><td>Rotate</td><td>DP center line (rotate copying)</td><td>-39 to 39</td><td>0</td><td>0.085 mm</td></tr></tbody></table><div><div><div>6. Change the setting value using the cursor left/right keys or numeric keys.</div><div>For copy example 1, increase the value. For copy example 2, decrease the value.</div><div>Increasing the value moves the image rightward and decreasing it moves the image leftward.</div></div><div><div><div><div><div></div></div><div>Original</div></div><div><div><div></div></div><div>Copy example 1</div></div><div><div><div></div></div><div>Copy example 2</div></div></div></div><div>Figure 1-3-11</div><div><div>7. Press the start key. The value is set.</div><div><div>Caution</div><div>If the first side is adjusted, check the second side and if adjustment is required, carry out the adjustment.</div><div>If the above adjustment does not optimize the center line, proceed with the following maintenance modes.</div><div><div><div><div>U034 (P.1-3-17)</div><div>U065 (P.1-3-19)</div><div>U067 (P.1-3-22)</div><div>U072</div></div></div></div><div><div>Completion</div><div>Press the stop key. The screen for selecting a maintenance item No. is displayed.</div></div></div></div></div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	Front	DP center line (first side)	-39 to 39	-	0.085 mm	Back	DP center line (second side)	-39 to 39	-	0.085 mm	Rotate	DP center line (rotate copying)	-39 to 39	0	0.085 mm
Display	Description	Setting range	Initial setting	Change in value per step																	
Front	DP center line (first side)	-39 to 39	-	0.085 mm																	
Back	DP center line (second side)	-39 to 39	-	0.085 mm																	
Rotate	DP center line (rotate copying)	-39 to 39	0	0.085 mm																	

Item No.	Description				
U130	<p><b>Set Toner Install</b></p> <p><b>Description</b> To set ON/OFF of the toner installation mode.</p> <p><b>Purpose</b> Toner installation is performed at the time of a machine setup.</p> <p><b>Setting</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select [Mode].</li> <li>3. Set at On or Off.</li> <li>4. Press the start key.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Mode</td><td>Setting a toner installation mode.</td></tr> </tbody> </table> <p>* : 0:Off / 1:On * : The toner installation is performed when power is turned on and off.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Mode	Setting a toner installation mode.
Display	Description				
Mode	Setting a toner installation mode.				

Item No.	Description																
U203	<p><b>Checking DP operation</b></p> <p><b>Description</b> Simulates the original conveying operation separately in the DP.</p> <p><b>Purpose</b> To check the DP operation.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Place an original in the DP if running this simulation with paper.</li> <li>3. Select the speed to be operated using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>NORMAL SPEED</td><td>Normal reading (600 dpi)</td></tr> <tr> <td>HIGH SPEED</td><td>High-speed reading</td></tr> </tbody> </table> <ol style="list-style-type: none"> <li>4. Press the start key.</li> <li>5. Select the item to be operated using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>CCD ADP (NON P)</td><td>Without paper, single-sided original of CCD (continuous operation)</td></tr> <tr> <td>CCD ADP</td><td>With paper, single-sided original of CCD</td></tr> <tr> <td>CCD RADP (NON P)</td><td>Without paper, double-sided original of CCD (continuous operation)</td></tr> <tr> <td>CCD RADP</td><td>With paper, double-sided original of CCD</td></tr> </tbody> </table> <ol style="list-style-type: none"> <li>6. Press the start key. The operation starts.</li> <li>7. To stop continuous operation, press the stop key.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	NORMAL SPEED	Normal reading (600 dpi)	HIGH SPEED	High-speed reading	Display	Description	CCD ADP (NON P)	Without paper, single-sided original of CCD (continuous operation)	CCD ADP	With paper, single-sided original of CCD	CCD RADP (NON P)	Without paper, double-sided original of CCD (continuous operation)	CCD RADP	With paper, double-sided original of CCD
Display	Description																
NORMAL SPEED	Normal reading (600 dpi)																
HIGH SPEED	High-speed reading																
Display	Description																
CCD ADP (NON P)	Without paper, single-sided original of CCD (continuous operation)																
CCD ADP	With paper, single-sided original of CCD																
CCD RADP (NON P)	Without paper, double-sided original of CCD (continuous operation)																
CCD RADP	With paper, double-sided original of CCD																
U207	<p><b>Checking the operation panel keys</b></p> <p><b>Description</b> Checks operation of the operation panel keys.</p> <p><b>Purpose</b> To check operation of all the keys and LEDs on the operation panel.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key. The screen for executing is displayed.</li> <li>2. [Count0] is displayed and the left most LED on the operation panel lights.</li> <li>3. As the keys lined up in the same line as the lit indicator are pressed in the order from the top to the bottom, the figure shown on the touch panel increases in increments of 1. When all the keys in that line are pressed and if there are any LEDs corresponding to the keys in the line on the immediate right, the top LED in that line will light.</li> <li>4. When all the keys on the operation panel have been pressed, all the LEDs light for up to 10 seconds.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>																

Item No.	Description						
U222	<p><b>Setting the IC card type</b></p> <p><b>Description</b> Sets the type of IC card.</p> <p><b>Purpose</b> To change the type of IC card.</p> <p><b>Setting</b></p> <p>1. Press the start key.</p> <p>2. Select the item using the cursor up/down keys.</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>OTHER</td><td>The type of IC card is SSFC.</td></tr><tr><td>SSFC</td><td>The type of IC card is not SSFC.</td></tr></table> <p>* : Initial setting: OTHER</p> <p>3. Press the start key. The setting is set.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	OTHER	The type of IC card is SSFC.	SSFC	The type of IC card is not SSFC.
Display	Description						
OTHER	The type of IC card is SSFC.						
SSFC	The type of IC card is not SSFC.						
U250	<p><b>Setting the maintenance cycle</b></p> <p><b>Description</b> Displays, clears and changes the maintenance cycle.</p> <p><b>Purpose</b> To check and change the maintenance cycle.</p> <p><b>Method</b></p> <p>1. Press the start key. The currently set maintenance cycle is displayed.</p> <p><b>Setting</b></p> <p>1. Select [M.CNT A] using the cursor up/down keys.</p> <p>2. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Maintenance cycle</td><td>0 to 9999999</td><td>100000</td></tr></table> <p>3. Press the start key. The value is set.</p> <p><b>Clearing</b></p> <p>1. Select [CLEAR] using the cursor up/down keys.</p> <p>2. Press the start key. The count is cleared.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Maintenance cycle	0 to 9999999	100000
Description	Setting range	Initial setting					
Maintenance cycle	0 to 9999999	100000					



Item No.	Description						
U251	<p><b>Checking/clearing the maintenance count</b></p> <p><b>Description</b> Displays, clears and changes the maintenance count.</p> <p><b>Purpose</b> To check the maintenance count. Also to clear the count during maintenance service (replacing the maintenance kit).</p> <p><b>Method</b> 1. Press the start key. The maintenance count is displayed.</p> <p><b>Setting</b> 1. Select [M.CNT A] using the cursor up/down keys. 2. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Maintenance count</td><td>0 to 9999999</td><td>0</td></tr></table> <p>3. Press the start key. The count is set.</p> <p><b>Clearing</b> 1. Select [CLEAR] using the cursor up/down keys. 2. Press the start key. The count is cleared.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Maintenance count	0 to 9999999	0
Description	Setting range	Initial setting					
Maintenance count	0 to 9999999	0					

Item No.	Description														
U252	<p><b>Setting the destination</b></p> <p><b>Description</b> Switches the operations and screens of the machine according to the destination.</p> <p><b>Purpose</b> To be executed after initializing the backup RAM, in order to return the setting to the value before replacement or initialization.</p> <p><b>Setting</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the destination using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>INCH</td><td>Inch (North America) specifications</td></tr> <tr> <td>EUROPE METRIC</td><td>Metric (Europe) specifications</td></tr> <tr> <td>ASIA PACIFIC</td><td>Metric (Asia Pacific) specifications</td></tr> <tr> <td>AUSTRALIA</td><td>Australia specifications</td></tr> <tr> <td>CHINA</td><td>China specifications</td></tr> <tr> <td>KOREA</td><td>Korea specifications</td></tr> </tbody> </table> <ol style="list-style-type: none"> <li>3. Press the start key.</li> <li>4. Turn the power switch off and on.</li> </ol>	Display	Description	INCH	Inch (North America) specifications	EUROPE METRIC	Metric (Europe) specifications	ASIA PACIFIC	Metric (Asia Pacific) specifications	AUSTRALIA	Australia specifications	CHINA	China specifications	KOREA	Korea specifications
Display	Description														
INCH	Inch (North America) specifications														
EUROPE METRIC	Metric (Europe) specifications														
ASIA PACIFIC	Metric (Asia Pacific) specifications														
AUSTRALIA	Australia specifications														
CHINA	China specifications														
KOREA	Korea specifications														
U253	<p><b>Switching between double and single counts</b></p> <p><b>Description</b> Switches the count system for the total counter and other counters.</p> <p><b>Purpose</b> Used to select, according to the preference of the user (copy service provider), if folio size paper is to be counted as one sheet (single count) or two sheets (double count).</p> <p><b>Setting</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the count system using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>SGL COUNT(ALL)</td><td>Single count for all size paper</td></tr> <tr> <td>DBL COUNT(FOLIO)</td><td>Double count for Folio size or larger</td></tr> </tbody> </table> <p>* : Initial setting: DBL COUNT(FOLIO)</p> <ol style="list-style-type: none"> <li>3. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	SGL COUNT(ALL)	Single count for all size paper	DBL COUNT(FOLIO)	Double count for Folio size or larger								
Display	Description														
SGL COUNT(ALL)	Single count for all size paper														
DBL COUNT(FOLIO)	Double count for Folio size or larger														

Item No.	Description						
U260	<p><b>Selecting the timing for copy counting</b></p> <p><b>Description</b> Changes the copy count timing for the total counter and other counters.</p> <p><b>Purpose</b> To be set according to user request.</p> <p><b>Setting</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the copy count timing using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>FEED</td><td>When secondary paper feed starts</td></tr> <tr> <td>EJECT</td><td>When the paper is ejected</td></tr> </tbody> </table> <p>* : Initial setting: EJECT</p> <ol style="list-style-type: none"> <li>3. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FEED	When secondary paper feed starts	EJECT	When the paper is ejected
Display	Description						
FEED	When secondary paper feed starts						
EJECT	When the paper is ejected						
U265	<p><b>Setting OEM purchaser code</b></p> <p><b>Description</b> Sets the OEM purchaser code.</p> <p><b>Purpose</b> Sets the code when replacing the main PWB and the like.</p> <p><b>Setting</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Change the setting value using the numeric keys.</li> <li>3. Press the start key. The setting is set.</li> <li>4. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.</li> </ol>						
U285	<p><b>Setting service status page</b></p> <p><b>Description</b> Determines displaying the digital dot coverage report on reporting.</p> <p><b>Purpose</b> According to user request, changes the setting.</p> <p><b>Setting</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select ON or OFF using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Displays the digital dot coverage</td></tr> <tr> <td>OFF</td><td>Not to display the digital dot coverage</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> <li>3. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Displays the digital dot coverage	OFF	Not to display the digital dot coverage
Display	Description						
ON	Displays the digital dot coverage						
OFF	Not to display the digital dot coverage						

Item No.	Description								
U332	<p><b>Setting the size conversion factor</b></p> <p><b>Description</b> Sets the coefficient of nonstandard sizes in relation to the A4/Letter size. The coefficient set here is used to convert the black ratio in relation to the A4/Letter size and to display the result in user simulation.</p> <p><b>Purpose</b> To set the coefficient for converting the black ratio for nonstandard sizes in relation to the A4/Letter size.</p> <p><b>Setting</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Change the setting using the cursor left/right keys or numeric keys.</li></ol> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>CALC.RATE</td><td>Size parameter</td><td>0.1 to 3.0</td><td>1.0</td></tr></table> <ol style="list-style-type: none"><li>3. Press the start key. The value is set.</li></ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	CALC.RATE	Size parameter	0.1 to 3.0	1.0
Display	Description	Setting range	Initial setting						
CALC.RATE	Size parameter	0.1 to 3.0	1.0						
U345	<p><b>Setting the value for maintenance due indication</b></p> <p><b>Description</b> Sets when to display a message notifying that the time for maintenance is about to be reached, by setting the number of copies that can be made before the current maintenance cycle ends. When the difference between the number of copies of the maintenance cycle and that of the maintenance count reaches the set value, the message is displayed.</p> <p><b>Purpose</b> To change the time for maintenance due indication.</p> <p><b>Setting</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Select [COUNT] using the cursor up/down keys.</li><li>3. Change the setting using the cursor left/right keys.</li></ol> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)</td><td>0 to 9999</td><td>0</td></tr></table> <ol style="list-style-type: none"><li>4. Press the start key. The value is set.</li></ol> <p><b>Clearing</b></p> <ol style="list-style-type: none"><li>1. Select [CLEAR] using the cursor up/down keys.</li><li>2. Press the start key. The value is cleared.</li></ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0		
Description	Setting range	Initial setting							
Time for maintenance due indication (Remaining number of copies that can be made before the current maintenance cycle ends)	0 to 9999	0							







Item No.	Description												
U346	<p><b>Selecting Sleep Mode</b></p> <p><b>Description</b> Switches configurations for sleep modes.</p> <p><b>Purpose</b> Use this to switch configurations for sleep modes.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to set.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Timer/Sleep Level</td><td>Undisplayed setting of BAM conformity Timer change and Sleep Level</td></tr> <tr> <td>Auto Sleep</td><td>On/Off setting of an Auto Sleep function</td></tr> </tbody> </table> <p><b>Setting</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select On or Off.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>On</td><td>On setting</td></tr> <tr> <td>Off</td><td>Off setting</td></tr> </tbody> </table> <p>Initial setting: On</p> <ol style="list-style-type: none"> <li>3. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b> Press the stop key.</p> <p>* : The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Timer/Sleep Level	Undisplayed setting of BAM conformity Timer change and Sleep Level	Auto Sleep	On/Off setting of an Auto Sleep function	Display	Description	On	On setting	Off	Off setting
Display	Description												
Timer/Sleep Level	Undisplayed setting of BAM conformity Timer change and Sleep Level												
Auto Sleep	On/Off setting of an Auto Sleep function												
Display	Description												
On	On setting												
Off	Off setting												

Item No.	Description																									
U402	<div><div>Adjust Print Margin</div><div><div>Description</div><div>Adjusts margins for image printing.</div><div>Purpose</div><div>Make the adjustment if margins are incorrect.</div><div>Adjustment</div><div><div><div>1. Press the start key.</div><div>2. Press the system menu key.</div><div>3. Press the start key to output a test pattern.</div><div>4. Press the system menu key.</div><div>5. Select the item to be adjusted.</div></div><table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>Lead</td><td>Printer leading edge margin</td><td>0.0 to 10.0</td><td>4.0</td><td>0.1mm</td></tr><tr><td>A Margin</td><td>Printer left margin</td><td>0.0 to 10.0</td><td>3.0</td><td>0.1mm</td></tr><tr><td>C Margin</td><td>Printer right margin</td><td>0.0 to 10.0</td><td>3.0</td><td>0.1mm</td></tr><tr><td>Trail</td><td>Printer trailing edge margin</td><td>0.0 to 10.0</td><td>3.9</td><td>0.1mm</td></tr></tbody></table><div><div>6. Change the setting value using the cursor left/right keys or numeric keys.</div><div>Increasing the value makes the margin wider, and decreasing it makes the margin narrower.</div></div><div><div><div><div>Printer leading edge margin (4.0 +1.5/-1.0 mm)</div><div>Printer left margin (2.5 +1.5/-2.0 mm)</div><div>Printer right margin (2.5 +1.5/-2.0 mm)</div><div>Printer trailing edge margin (4.0 mm or less)</div></div><div><div><div><div></div><div></div><div></div><div></div></div><div></div></div></div></div><div>Figure 1-3-12</div><div><div>7. Press the start key. The value is set.</div><div><div>Caution</div><div>If the above adjustment does not optimize the margins, perform the following maintenance modes.</div><div><div><div>U034 (P.1-3-17)</div><div></div><div>U402</div></div><div>Completion</div><div>Press the stop key. The screen for selecting a maintenance item No. is displayed.</div></div></div></div></div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	Lead	Printer leading edge margin	0.0 to 10.0	4.0	0.1mm	A Margin	Printer left margin	0.0 to 10.0	3.0	0.1mm	C Margin	Printer right margin	0.0 to 10.0	3.0	0.1mm	Trail	Printer trailing edge margin	0.0 to 10.0	3.9	0.1mm
Display	Description	Setting range	Initial setting	Change in value per step																						
Lead	Printer leading edge margin	0.0 to 10.0	4.0	0.1mm																						
A Margin	Printer left margin	0.0 to 10.0	3.0	0.1mm																						
C Margin	Printer right margin	0.0 to 10.0	3.0	0.1mm																						
Trail	Printer trailing edge margin	0.0 to 10.0	3.9	0.1mm																						

Item No.	Description																									
U403	<div><div>Adjust Scanning Margin(Table)</div><div><div>Description</div><div>Adjusts margins for scanning the original on the contact glass.</div><div>Purpose</div><div>Make the adjustment if margins are incorrect.</div><div>Adjustment</div><div><div><div>1. Press the start key.</div><div>2. Press the system menu key.</div><div>3. Place an original and press the start key to make a test copy.</div><div>4. Press the system menu key.</div><div>5. Select the item to be adjusted.</div></div><table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>A Margin</td><td>Scanner left margin</td><td>0.0 to 10.0</td><td>2.0</td><td>0.5 mm</td></tr><tr><td>B Margin</td><td>Scanner leading edge margin</td><td>0.0 to 10.0</td><td>2.0</td><td>0.5 mm</td></tr><tr><td>C Margin</td><td>Scanner right margin</td><td>0.0 to 10.0</td><td>2.0</td><td>0.5 mm</td></tr><tr><td>D Margin</td><td>Scanner trailing edge margin</td><td>0.0 to 10.0</td><td>2.0</td><td>0.5 mm</td></tr></tbody></table><div><div>6. Change the setting value using the cursor left/right keys or numeric keys.</div><div>Increasing the value makes the margin wider, and decreasing it makes the margin narrower.</div><div><div><div><div>Leading edge margin of the copy image (4.0 +1.5/-1.0 mm)</div><div>Left margin of the copy image (2.5 +1.5/-2.0 mm)</div><div>Right margin of the copy image (2.5 +1.5/-2.0 mm)</div><div>Trailing edge margin of the copy image (4.0 mm or less)</div></div></div><div>Figure 1-3-13</div><div><div>7. Press the start key. The value is set.</div><div><div>Caution</div><div>If the above adjustment does not optimize the margins, perform the following maintenance modes.</div><div><div><div>U034 (P.1-3-17)</div><div>U402 (P.1-3-36)</div><div>U403</div></div></div><div><div>Completion</div><div>Press the stop key. The indication for selecting a maintenance item No. appears.</div></div></div></div></div></div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	A Margin	Scanner left margin	0.0 to 10.0	2.0	0.5 mm	B Margin	Scanner leading edge margin	0.0 to 10.0	2.0	0.5 mm	C Margin	Scanner right margin	0.0 to 10.0	2.0	0.5 mm	D Margin	Scanner trailing edge margin	0.0 to 10.0	2.0	0.5 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
A Margin	Scanner left margin	0.0 to 10.0	2.0	0.5 mm																						
B Margin	Scanner leading edge margin	0.0 to 10.0	2.0	0.5 mm																						
C Margin	Scanner right margin	0.0 to 10.0	2.0	0.5 mm																						
D Margin	Scanner trailing edge margin	0.0 to 10.0	2.0	0.5 mm																						

Item No.	Description																									
U404	<div><div>Adjust Scanning Margin(DP)</div><div><div>Description</div><div>Adjusts margins for scanning the original from the DP.</div><div>Purpose</div><div>Make the adjustment if margins are incorrect.</div><div>Adjustment</div><div><div><div>1. Press the start key.</div><div>2. Press the system menu key.</div><div>3. Place an original on the DP and press the start key to make a test copy.</div><div>4. Press the system menu key.</div><div>5. Select the item to be adjusted.</div></div><table><thead><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr></thead><tbody><tr><td>A Margin</td><td>DP left margin</td><td>0.0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>B Margin</td><td>DP leading edge margin</td><td>0.0 to 10.0</td><td>2.5</td><td>0.5 mm</td></tr><tr><td>C Margin</td><td>DP right margin</td><td>0.0 to 10.0</td><td>3.0</td><td>0.5 mm</td></tr><tr><td>D Margin</td><td>DP trailing edge margin</td><td>0.0 to 10.0</td><td>4.0</td><td>0.5 mm</td></tr></tbody></table><div><div>6. Change the setting value using the cursor left/right keys or numeric keys.</div><div>Increasing the value makes the margin wider, and decreasing it makes the margin narrower.</div></div><div><div><div><div><div>DP leading edge margin (4.0 +1.5/-1.0 mm)</div><div>DP left margin (2.5 +1.5/-2.0 mm)</div><div>DP right margin (2.5 +1.5/-2.0 mm)</div><div>DP trailing edge margin (4.0 mm or less)</div></div></div><div><div><div><div><div></div><div></div><div></div><div></div></div></div></div></div><div><div>Figure 1-3-14</div></div><div><div>7. Press the start key. The value is set.</div></div><div><div>Caution</div><div>If the above adjustment does not optimize the margins, perform the following maintenance modes.</div><div><div><div><div>U034 (P.1-3-17)</div><div>U402 (P.1-3-36)</div><div>U403 (P.1-3-37)</div><div>U404</div></div></div></div><div><div>Completion</div><div>Press the stop key. The screen for selecting a maintenance item No. is displayed.</div></div></div></div></div></div></div></div>	Display	Description	Setting range	Initial setting	Change in value per step	A Margin	DP left margin	0.0 to 10.0	3.0	0.5 mm	B Margin	DP leading edge margin	0.0 to 10.0	2.5	0.5 mm	C Margin	DP right margin	0.0 to 10.0	3.0	0.5 mm	D Margin	DP trailing edge margin	0.0 to 10.0	4.0	0.5 mm
Display	Description	Setting range	Initial setting	Change in value per step																						
A Margin	DP left margin	0.0 to 10.0	3.0	0.5 mm																						
B Margin	DP leading edge margin	0.0 to 10.0	2.5	0.5 mm																						
C Margin	DP right margin	0.0 to 10.0	3.0	0.5 mm																						
D Margin	DP trailing edge margin	0.0 to 10.0	4.0	0.5 mm																						



Item No.	Description																	
U411	Auto Adj Scn																	
	<b>Description</b>																	
	Uses a specified original and automatically adjusts the following items in the scanner and the DP scanning sections.																	
	Scanner section: Original size magnification, leading edge timing, center line, input gamma, input gamma in monochrome mode and matrix.																	
	DP scanning section: Original size magnification, leading edge timing, center line.																	
	<b>Purpose</b>																	
	To perform automatic adjustment of various items in the scanner and the DP scanning sections.																	
	<b>Method</b>																	
	1. Press the start key.																	
	2. Select the item. The screen for executing is displayed.																	
	<table><thead><tr><th>Display</th><th>Description</th><th>Original to be used for adjustment (P/N)</th></tr></thead><tbody><tr><td>Table</td><td>Automatic adjustment in the scanner section.  Equal magnification (sub scanning direction), leading edge timing, center line, input gamma, input gamma in monochrome mode and matrix, chromatic aberration.</td><td>302NM94340 </td></tr><tr><td>DP</td><td>Automatic adjustment in the DP scanning section.  Original size magnification, leading edge timing, center line.</td><td>302NM94330 </td></tr><tr><td>All</td><td>Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section.</td><td>302NM94340 302NM94330</td></tr><tr><td>Target</td><td>Set-up for obtaining the target value</td><td>302NM94340 302NM94330</td></tr></tbody></table>	Display	Description	Original to be used for adjustment (P/N)	Table	Automatic adjustment in the scanner section.  Equal magnification (sub scanning direction), leading edge timing, center line, input gamma, input gamma in monochrome mode and matrix, chromatic aberration.	302NM94340 	DP	Automatic adjustment in the DP scanning section.  Original size magnification, leading edge timing, center line.	302NM94330 	All	Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section.	302NM94340 302NM94330	Target	Set-up for obtaining the target value	302NM94340 302NM94330		
Display	Description	Original to be used for adjustment (P/N)																
Table	Automatic adjustment in the scanner section.  Equal magnification (sub scanning direction), leading edge timing, center line, input gamma, input gamma in monochrome mode and matrix, chromatic aberration.	302NM94340 																
DP	Automatic adjustment in the DP scanning section.  Original size magnification, leading edge timing, center line.	302NM94330 																
All	Performs automatic adjustment in the DP scanning section following automatic adjustment in the scanner section.	302NM94340 302NM94330																
Target	Set-up for obtaining the target value	302NM94340 302NM94330																

Item No.	Description																
U411	<p><b>Method: Table</b></p> <p><b>To Automaticary enter the target value</b> : Usually, it adjusts here.</p> <ol style="list-style-type: none"> <li>1. Set a specified original (P/N: 302NM94340) on the platen.</li> <li>2. Enter maintenance item U411.</li> <li>3. Select [Target].</li> <li>4. Select [Auto] and press the start key.</li> <li>5. Select [Table].</li> <li>6. Press the start key. Auto adjustment starts.</li> </ol> <p><b>To manually enter the target value</b> : When adjustment is automatically impossible.</p> <ol style="list-style-type: none"> <li>1. Enter the target values which are shown on the specified original (P/N: 302NM94340) executing maintenance item U425.</li> <li>2. Set a specified original (P/N: 302NM94340) on the platen.</li> <li>3. Enter maintenance item U411.</li> <li>4. Select [Target].</li> <li>5. Select [U425] and press the start key.</li> <li>6. Select [Table].</li> <li>7. Press the start key. Auto adjustment starts.</li> </ol> <p><b>Method: DP</b></p> <ol style="list-style-type: none"> <li>1. Set a specified original (P/N: 302NM94330) on the DP face up.</li> <li>2. Enter maintenance item U411.</li> <li>3. Select [DP].</li> <li>4. Press the start key. Auto adjustment starts.</li> </ol> <p>* : When automatic adjustment has normally completed, [OK] is displayed. If a problem occurs during auto adjustment, error code is displayed and operation stops. Should this happen, determine the details of the problem and repeat the procedure from the beginning.</p> <p><b>Error Codes</b></p> <table border="1"> <thead> <tr> <th>Codes</th><th>Description</th></tr> </thead> <tbody> <tr> <td>00</td><td>Automatic adjustment success</td></tr> <tr> <td>01</td><td>Black band detection error (scanner auxiliary scanning direction leading edge skew )</td></tr> <tr> <td>02</td><td>Black band detection error (scanner main scanning direction far end skew)</td></tr> <tr> <td>03</td><td>Black band detection error (scanner main scanning direction near end skew)</td></tr> <tr> <td>03</td><td>Black band detection error (scanner auxiliary scanning direction trailing edge skew)</td></tr> <tr> <td>04</td><td>Black band is not detected (scanner auxiliary scanning direction leading edge)</td></tr> <tr> <td>05</td><td>Black band is not detected (scanner main scanning direction far end)</td></tr> </tbody> </table>	Codes	Description	00	Automatic adjustment success	01	Black band detection error (scanner auxiliary scanning direction leading edge skew )	02	Black band detection error (scanner main scanning direction far end skew)	03	Black band detection error (scanner main scanning direction near end skew)	03	Black band detection error (scanner auxiliary scanning direction trailing edge skew)	04	Black band is not detected (scanner auxiliary scanning direction leading edge)	05	Black band is not detected (scanner main scanning direction far end)
Codes	Description																
00	Automatic adjustment success																
01	Black band detection error (scanner auxiliary scanning direction leading edge skew )																
02	Black band detection error (scanner main scanning direction far end skew)																
03	Black band detection error (scanner main scanning direction near end skew)																
03	Black band detection error (scanner auxiliary scanning direction trailing edge skew)																
04	Black band is not detected (scanner auxiliary scanning direction leading edge)																
05	Black band is not detected (scanner main scanning direction far end)																

Item No.	Description	
U411	Error Codes	
	Codes	Description
	06	Black band is not detected (scanner main scanning direction near end)
	07	Black band is not detected (scanner auxiliary scanning direction trailing edge)
	08	Black band is not detected (DP main scanning direction far end)
	09	Black band is not detected (DP main scanning direction near end)
	0a	Black band is not detected (DP auxiliary scanning direction leading edge)
	0b	Black band is not detected (DP auxiliary scanning direction leading edge original check)
	0c	Black band is not detected (DP auxiliary scanning direction trailing edge)
	0d	White band is not detected (DP auxiliary scanning direction trailing edge)
	0e	DMA time out
	0f	Auxiliary scanning direction magnification error
	10	Auxiliary scanning direction leading edge error
	11	Auxiliary scanning direction trailing edge error
	12	DP uxiliary scanning direction skew error
	13	Maintenance request error
	14	Main scanning direction center line error
	15	DP main scanning direction skew error
	16	Main scanning direction magnification error
	17	Service call error
	18	DP paper misfeed error
	19	PWB replacement error
	1a	Original error
	1b	Input gamma adjustment original error
	1c	Matrix adjustment original error
	1d	Original for the white reference compensation coefficient error
	1e	Lab value searching error
	1f	Lab value comparing error
	20	Input gamma correction coefficient error
	21	Color correction matrix coefficient error
	30	Chromatic aberration adjustment original error
	63	Completed to obtain a test RAW
	<b>Completion</b>	
Press the stop key. The screen for selecting a maintenance item is displayed.		

Item No.	Description																																																
U425	<p><b>Set Target</b></p> <p><b>Description</b> Enters the lab values that is indicated on the back of the chart (P/N: 302NM94340) used for adjustment.</p> <p><b>Purpose</b> Performs data input in order to correct for differences in originals during automatic adjustment.</p> <p><b>Method</b> 1. Press the start key. 2. Select the item to be set</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>Table</td><td>Setting the value of the table adjustment.</td></tr><tr><td>DP</td><td>Setting the value of DP adjustment.</td></tr></table> <p><b>Method: Table</b> 1. Press the start key. 2. Select the item to be set..</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>White</td><td>Setting the white patch for the original for adjustment</td></tr><tr><td>Black</td><td>Setting the black patch for the original for adjustment</td></tr><tr><td>Gray1</td><td>Setting the Gray1 patch for the original for adjustment</td></tr><tr><td>Gray2</td><td>Setting the Gray2 patch for the original for adjustment</td></tr><tr><td>Gray3</td><td>Setting the Gray3 patch for the original for adjustment</td></tr><tr><td>C</td><td>Setting the cyan patch for the original for adjustment</td></tr><tr><td>M</td><td>Setting the magenta patch for the original for adjustment</td></tr><tr><td>Y</td><td>Setting the yellow patch for the original for adjustment</td></tr><tr><td>R</td><td>Setting the red patch for the original for adjustment</td></tr><tr><td>G</td><td>Setting the green patch for the original for adjustment</td></tr><tr><td>B</td><td>Setting the blue patch for the original for adjustment</td></tr><tr><td>Adjust Original</td><td>Setting the main and auxiliary scanning directions</td></tr></table> <p>3. Select the item to be set.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>L</td><td>Setting the L value</td><td>0.0 to 100.0</td><td>93.6/10.6/76.2/25.2/51.3 72.6/48.1/86.2/46.7/67.8/38.8</td></tr><tr><td>a</td><td>Setting the a value</td><td>-200.0 to 200.0</td><td>0.9/-0.2/-0.2/-0.2/-0.3 -32.8/69.9/-18.6/54.2/-51.3/25.3</td></tr><tr><td>b</td><td>Setting the b value</td><td>-200.0 to 200.0</td><td>-0.4/-0.7/1.2/-0.2/0.3 -11.5/-6.1/81.7/38.6/48.9/-22.8</td></tr></table> <p>4. Enters the value that is indicated on the back of the chart using the cursor right/left keys or numeric keys. 5. Press the start key. The value is set.</p>	Display	Description	Table	Setting the value of the table adjustment.	DP	Setting the value of DP adjustment.	Display	Description	White	Setting the white patch for the original for adjustment	Black	Setting the black patch for the original for adjustment	Gray1	Setting the Gray1 patch for the original for adjustment	Gray2	Setting the Gray2 patch for the original for adjustment	Gray3	Setting the Gray3 patch for the original for adjustment	C	Setting the cyan patch for the original for adjustment	M	Setting the magenta patch for the original for adjustment	Y	Setting the yellow patch for the original for adjustment	R	Setting the red patch for the original for adjustment	G	Setting the green patch for the original for adjustment	B	Setting the blue patch for the original for adjustment	Adjust Original	Setting the main and auxiliary scanning directions	Display	Description	Setting range	Initial setting	L	Setting the L value	0.0 to 100.0	93.6/10.6/76.2/25.2/51.3 72.6/48.1/86.2/46.7/67.8/38.8	a	Setting the a value	-200.0 to 200.0	0.9/-0.2/-0.2/-0.2/-0.3 -32.8/69.9/-18.6/54.2/-51.3/25.3	b	Setting the b value	-200.0 to 200.0	-0.4/-0.7/1.2/-0.2/0.3 -11.5/-6.1/81.7/38.6/48.9/-22.8
Display	Description																																																
Table	Setting the value of the table adjustment.																																																
DP	Setting the value of DP adjustment.																																																
Display	Description																																																
White	Setting the white patch for the original for adjustment																																																
Black	Setting the black patch for the original for adjustment																																																
Gray1	Setting the Gray1 patch for the original for adjustment																																																
Gray2	Setting the Gray2 patch for the original for adjustment																																																
Gray3	Setting the Gray3 patch for the original for adjustment																																																
C	Setting the cyan patch for the original for adjustment																																																
M	Setting the magenta patch for the original for adjustment																																																
Y	Setting the yellow patch for the original for adjustment																																																
R	Setting the red patch for the original for adjustment																																																
G	Setting the green patch for the original for adjustment																																																
B	Setting the blue patch for the original for adjustment																																																
Adjust Original	Setting the main and auxiliary scanning directions																																																
Display	Description	Setting range	Initial setting																																														
L	Setting the L value	0.0 to 100.0	93.6/10.6/76.2/25.2/51.3 72.6/48.1/86.2/46.7/67.8/38.8																																														
a	Setting the a value	-200.0 to 200.0	0.9/-0.2/-0.2/-0.2/-0.3 -32.8/69.9/-18.6/54.2/-51.3/25.3																																														
b	Setting the b value	-200.0 to 200.0	-0.4/-0.7/1.2/-0.2/0.3 -11.5/-6.1/81.7/38.6/48.9/-22.8																																														


Item No.	Description																
U425	<p><b>Setting: [Adjust Original] *</b>: This setting is usually unnecessary.</p> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Dist1</td><td>Sets the adjustment value of a leading edge.</td><td>4.0 to 6.0</td><td>5.0</td></tr><tr><td>Dist2</td><td>Sets the adjustment value of a left edge.</td><td>9.0 to 11.0</td><td>10.0</td></tr><tr><td>Dist3</td><td>Sets the adjustment value of a trailing edge.</td><td>265.0 to 267.0</td><td>266.0</td></tr></table> <p>1. Measure the distance from the leading edge to the top of black belt 1 of the original at A, B and C.</p> <p>Measurement procedure</p> <p>1) Measure the distance from the leading edge to the top of black belt 1 of the original at A (30 mm from the left edge), B (105 mm from the left edge) and C (180 mm from the left edge), respectively.</p> <p>2) Apply the following formula for the values obtained: ((A + B + C) / 3)</p> <p>2. Enter the values solved using the cursor right/left keys or numeric keys in [Dist1].</p> <p>3. Press the start key. The value is set.</p> <p>4. Measure the distance from the left edge to the right edge black belt 2 of the original at F.</p> <p>Measurement procedure</p> <p>1) Measure the distance from the left edge to the right edge black belt 2 of the original at F (21 mm from the top edge of black belt 1).</p> <p>5. Enter the values using the cursor right/left keys or numeric keys in [Dist2].</p> <p>6. Press the start key. The value is set.</p> <p>7. Measure the distance from the top edge of black belt 1 to the bottom of black belt 3 of the original at D and E.</p> <p>1) Measure the distance from the top edge of black belt 1 to the bottom of black belt 3 of the original at D (30 mm from the left edge) and E (180 mm from the left edge), respectively.</p> <p>2) Apply the following formula for the values obtained: (D/2 + E/2)</p> <p>8. Enter the measured value using the cursor right/left keys or numeric keys in [Dist3].</p> <p>Press the start key. The value is set.</p> <div><p>Original for adjustment (P/N: 302NM94340)</p><div><p>[Dist1] = (A+B+C)/3</p><p>[Dist2] = F</p><p>[Dist3] = D/2+E/2</p></div></div>	Display	Description	Setting range	Initial setting	Dist1	Sets the adjustment value of a leading edge.	4.0 to 6.0	5.0	Dist2	Sets the adjustment value of a left edge.	9.0 to 11.0	10.0	Dist3	Sets the adjustment value of a trailing edge.	265.0 to 267.0	266.0
Display	Description	Setting range	Initial setting														
Dist1	Sets the adjustment value of a leading edge.	4.0 to 6.0	5.0														
Dist2	Sets the adjustment value of a left edge.	9.0 to 11.0	10.0														
Dist3	Sets the adjustment value of a trailing edge.	265.0 to 267.0	266.0														

Figure 1-3-15

Figure 1-3-15


Item No.	Description																
U425	Setting: [DP] *: This setting is usually unnecessary.																
	<table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Lead</td><td>A value of length of detecting the leading edge.</td><td>14.0 to 16.0</td><td>15.0</td></tr><tr><td>Main Scan</td><td>A value of width of main scan.</td><td>14.0 to 16.0</td><td>15.0</td></tr><tr><td>Sub Scan</td><td>A value of length of sub scan.</td><td>265.0 to 269.0</td><td>267.0</td></tr></table>	Display	Description	Setting range	Initial setting	Lead	A value of length of detecting the leading edge.	14.0 to 16.0	15.0	Main Scan	A value of width of main scan.	14.0 to 16.0	15.0	Sub Scan	A value of length of sub scan.	265.0 to 269.0	267.0
	Display	Description	Setting range	Initial setting													
	Lead	A value of length of detecting the leading edge.	14.0 to 16.0	15.0													
	Main Scan	A value of width of main scan.	14.0 to 16.0	15.0													
Sub Scan	A value of length of sub scan.	265.0 to 269.0	267.0														
<div>1. Measure the distance from the leading edge to the black belt (inside) of the original at A.</div> <div>2. Enter the measured value using the cursor right/left keys or numeric keys in [Lead].</div> <div>3. Measure the distance from the left edge to the black belt (inside) of the original at B.</div> <div>4. Enter the measured value using the cursor right/left keys or numeric keys in [Main Scan].</div> <div>5. Measure the distance from the black belt of leading edge (inside) to the black belt of trailing edge (inside) of the original at C.</div> <div>6. Enter the measured value using the cursor right/left keys or numeric keys in [Sub Scan].</div> <div>7. Press the start key. The value is set.</div>																	
<div></div> <div>Original for adjustment (P/N: 302NM94330)</div>																	

Figure 1-3-16

Completion

Press the stop key. The screen for selecting a maintenance item No. is displayed.

Figure 1-3-16

**Completion**

Press the stop key. The screen for selecting a maintenance item No. is displayed.

Item No.	Description																																																																																
U600	<p><b>Initializing all data</b></p> <p><b>Description</b> Initializes software switches and all data in the backup data on the FAX control PWB, according to the destination and OEM. Executes the check of the file system, when abnormality of the file system is detected, initializes the file system, communication past record and register setting contents.</p> <p><b>Purpose</b> To initialize the FAX control PWB.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Press the start key. The screen for entering the destination code and OEM code is displayed.</li><li>2. Select [Country Code] and enter a destination code using the numeric keys (refer to the destination code list on following for the destination code). OEM code is no operation necessary.</li><li>3. Select [Execute] and press the start key. Data initialization starts. To cancel data initialization, press the stop key.</li><li>4. After data initialization, the entered destination, OEM codes and ROM version are displayed. A ROM version displays three kinds, application, boot, and IPL.</li></ol> <p><b>Destination code list</b></p> <table><tr><th>Code</th><th>Destination</th><th>Code</th><th>Destination</th></tr><tr><td>000</td><td>Japan</td><td>250</td><td>Russia</td></tr><tr><td>007</td><td>Argentina</td><td>253</td><td>CTR21 (European nations)</td></tr><tr><td>009</td><td>Australia</td><td></td><td>Italy</td></tr><tr><td>022</td><td>Brazil</td><td></td><td>Germany</td></tr><tr><td>038</td><td>China</td><td></td><td>Spain</td></tr><tr><td>080</td><td>Hong Kong</td><td></td><td>U.K.</td></tr><tr><td>084</td><td>Indonesia</td><td></td><td>Netherlands</td></tr><tr><td>088</td><td>Israel</td><td></td><td>Sweden</td></tr><tr><td>097</td><td>Korea</td><td></td><td>France</td></tr><tr><td>108</td><td>Malaysia</td><td></td><td>Austria</td></tr><tr><td>115</td><td>Mexico</td><td></td><td>Switzerland</td></tr><tr><td>126</td><td>New Zealand</td><td></td><td>Belgium</td></tr><tr><td>136</td><td>Peru</td><td></td><td>Denmark</td></tr><tr><td>137</td><td>Philippines</td><td></td><td>Finland</td></tr><tr><td>152</td><td>Saudi Arabiat</td><td></td><td>Portugal</td></tr><tr><td>156</td><td>Singapore</td><td></td><td>Ireland</td></tr><tr><td>159</td><td>South Africa</td><td></td><td>Norway</td></tr><tr><td>169</td><td>Thailand</td><td>254</td><td>Taiwan</td></tr><tr><td>181</td><td>U.S.A.</td><td></td><td></td></tr></table>	Code	Destination	Code	Destination	000	Japan	250	Russia	007	Argentina	253	CTR21 (European nations)	009	Australia		Italy	022	Brazil		Germany	038	China		Spain	080	Hong Kong		U.K.	084	Indonesia		Netherlands	088	Israel		Sweden	097	Korea		France	108	Malaysia		Austria	115	Mexico		Switzerland	126	New Zealand		Belgium	136	Peru		Denmark	137	Philippines		Finland	152	Saudi Arabiat		Portugal	156	Singapore		Ireland	159	South Africa		Norway	169	Thailand	254	Taiwan	181	U.S.A.		
Code	Destination	Code	Destination																																																																														
000	Japan	250	Russia																																																																														
007	Argentina	253	CTR21 (European nations)																																																																														
009	Australia		Italy																																																																														
022	Brazil		Germany																																																																														
038	China		Spain																																																																														
080	Hong Kong		U.K.																																																																														
084	Indonesia		Netherlands																																																																														
088	Israel		Sweden																																																																														
097	Korea		France																																																																														
108	Malaysia		Austria																																																																														
115	Mexico		Switzerland																																																																														
126	New Zealand		Belgium																																																																														
136	Peru		Denmark																																																																														
137	Philippines		Finland																																																																														
152	Saudi Arabiat		Portugal																																																																														
156	Singapore		Ireland																																																																														
159	South Africa		Norway																																																																														
169	Thailand	254	Taiwan																																																																														
181	U.S.A.																																																																																

Item No.	Description								
U601	<p><b>Initializing permanent data</b></p> <p><b>Description</b> Initializes software switches on the FAX control PWB according to the destination and OEM.</p> <p><b>Purpose</b> To initialize the FAX control PWB without changing user registration data.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key. The screen for entering the destination code and OEM code is displayed.</li> <li>2. Select [Country Code] and enter a destination code using the numeric keys (refer to the destination code list on following for the destination code). OEM code is no operation necessary.</li> <li>3. Select [Execute] and press the start key. Data initialization starts. To cancel data initialization, press the stop key.</li> <li>4. After data initialization, the entered destination, OEM codes and ROM version are displayed. A ROM version displays three kinds, application, boot, and IPL.</li> </ol>								
U603	<p><b>Setting user data 1</b></p> <p><b>Description</b> Makes user settings to enable the use of the machine as a fax.</p> <p><b>Purpose</b> To be run after installation of the facsimile kit if necessary.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select [LINE TYPE] and press the start key.</li> <li>3. Select the setting using the cursor up/down keys.</li> </ol> <table border="1" data-bbox="338 1267 1401 1460"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>DTMF</td><td>DTMF</td></tr> <tr> <td>10PPS</td><td>10 PPS</td></tr> <tr> <td>20PPS</td><td>20 PPS</td></tr> </tbody> </table> <p>* : Initial setting: DTMF</p> <ol style="list-style-type: none"> <li>4. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DTMF	DTMF	10PPS	10 PPS	20PPS	20 PPS
Display	Description								
DTMF	DTMF								
10PPS	10 PPS								
20PPS	20 PPS								



Item No.	Description						
U604	<p><b>Setting user data 2</b></p> <p><b>Description</b> Makes user settings to enable the use of the machine as a fax.</p> <p><b>Purpose</b> Use this if the user wishes to adjust the number of rings that occur before the unit switches into fax receiving mode when fax/telephone auto-select is enabled.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Select [RINGS(F/P)#].</li><li>3. Change the setting using the cursor left/right keys or numeric keys.</li></ol> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of fax/telephone rings</td><td>0 to 15</td><td>2 (120 V)/1 (220-240 V)</td></tr></table> <p>* : If you set this to 0, the unit will start fax reception without any ringing.</p> <ol style="list-style-type: none"><li>4. Press the start key. The value is set.</li></ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Number of fax/telephone rings	0 to 15	2 (120 V)/1 (220-240 V)
Description	Setting range	Initial setting					
Number of fax/telephone rings	0 to 15	2 (120 V)/1 (220-240 V)					
U605	<p><b>Clearing data</b></p> <p><b>Description</b> Initializes data related to the fax transmission such as transmission history.</p> <p><b>Purpose</b> To clear the transmission history.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Select [CLEAR COM.REC.].</li><li>3. Press the start key. Initialization processing starts. When processing is finished, [Completed] is displayed.</li></ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>						

Item No.	Description																								
U610	<p><b>Setting system 1</b></p> <p><b>Description</b> Makes settings for fax reception regarding the sizes of the fax paper and received images and automatic printing of the protocol list.</p> <p><b>Method</b> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys.</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>CUT LINE:100%</td><td>Sets the number of lines to be ignored when receiving a fax at 100% magnification.</td></tr><tr><td>CUT LINE:AUTO</td><td>Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.</td></tr><tr><td>CUT LINE:A4</td><td>Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.</td></tr></table> <p><b>Setting the number of lines to be ignored when receiving a fax at 100% magnification</b> Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when recording the data at 100% magnification. If the number of excess lines is below the setting, those lines are ignored. If over the setting, they are recorded on the next page.</p> <p>1. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Number of lines to be ignored when receiving at 100%</td><td>0 to 22</td><td>3</td><td>16 lines</td></tr></table> <p>* : Increase the setting if a blank second page is output, and decrease it if the received image does not include the entire transmitted data.</p> <p>2. Press the start key. The value is set.</p> <p><b>Setting the number of lines to be ignored when receiving a fax in the auto reduction mode</b> Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode. If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.</p> <p>1. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Number of lines to be ignored when receiving in the auto reduction mode</td><td>0 to 22</td><td>0</td><td>16 lines</td></tr></table> <p>* : Increase the setting if a page received in the reduction mode is over-reduced and too much trailing edge margin is left. Decrease it if the received image does not include all transmitted data.</p> <p>2. Press the start key. The value is set.</p>	Display	Description	CUT LINE:100%	Sets the number of lines to be ignored when receiving a fax at 100% magnification.	CUT LINE:AUTO	Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.	CUT LINE:A4	Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving at 100%	0 to 22	3	16 lines	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving in the auto reduction mode	0 to 22	0	16 lines
Display	Description																								
CUT LINE:100%	Sets the number of lines to be ignored when receiving a fax at 100% magnification.																								
CUT LINE:AUTO	Sets the number of lines to be ignored when receiving a fax in the auto reduction mode.																								
CUT LINE:A4	Sets the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode.																								
Description	Setting range	Initial setting	Change in value per step																						
Number of lines to be ignored when receiving at 100%	0 to 22	3	16 lines																						
Description	Setting range	Initial setting	Change in value per step																						
Number of lines to be ignored when receiving in the auto reduction mode	0 to 22	0	16 lines																						

Item No.	Description								
U610	<p><b>Setting the number of lines to be ignored when receiving a fax (A4R/LetterR) in the auto reduction mode</b></p> <p>Sets the maximum number of lines to be ignored if the received data volume exceeds the recording capacity when the data is recorded in the auto reduction mode onto A4R or LetterR paper under the conditions below.</p> <p>If the number of excess lines is below the setting, those lines are ignored. If over the setting, the entire data on a page is further reduced so that it can be recorded on the same page.</p> <p>1. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode</td><td>0 to 22</td><td>0</td><td>16 lines</td></tr></table> <p>* : Increase the setting if a page received in the reduction mode is over-reduced and too much trailing edge margin is left. Decrease it if the received image does not include all transmitted data.</p> <p>2. Press the start key. The value is set.</p> <p><b>Completion</b></p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode	0 to 22	0	16 lines
Description	Setting range	Initial setting	Change in value per step						
Number of lines to be ignored when receiving a fax (A4R, letter) in the auto reduction mode	0 to 22	0	16 lines						

Item No.	Description																										
U611	<p><b>Setting system 2</b></p> <p><b>Description</b> Sets the number of adjustment lines for automatic reduction.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Select the item to be set using the cursor up/down keys.</li></ol> <table><tr><th>Display</th><th>Description</th></tr><tr><td>ADJ LINES</td><td>Sets the number of adjustment lines for automatic reduction.</td></tr><tr><td>ADJ LINES(A4)</td><td>Sets the number of adjustment lines for automatic reduction when A4 paper is set.</td></tr><tr><td>ADJ LINES(LT)</td><td>Sets the number of adjustment lines for automatic reduction when letter size paper is set.</td></tr></table> <p><b>Setting the number of adjustment lines for automatic reduction</b> Sets the number of adjustment lines for automatic reduction.</p> <ol style="list-style-type: none"><li>1. Change the setting using the cursor left/right keys or numeric keys.</li></ol> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of adjustment lines for automatic reduction</td><td>0 to 22</td><td>7</td></tr></table> <ol style="list-style-type: none"><li>2. Press the start key. The value is set.</li></ol> <p><b>Setting the number of adjustment lines for automatic reduction when A4 paper is set</b> Sets the number of adjustment lines for automatic reduction when A4 paper is set.</p> <ol style="list-style-type: none"><li>1. Change the setting using the cursor left/right keys or numeric keys.</li></ol> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of adjustment lines for automatic reduction when A4 paper is set</td><td>0 to 22</td><td>22</td></tr></table> <ol style="list-style-type: none"><li>2. Press the start key. The value is set.</li></ol> <p><b>Setting the number of adjustment lines for automatic reduction when letter size paper is set</b> Sets the number of adjustment lines for automatic reduction when letter size paper is set.</p> <ol style="list-style-type: none"><li>1. Change the setting using the cursor left/right keys or numeric keys.</li></ol> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of adjustment lines for automatic reduction when letter size paper is set</td><td>0 to 26</td><td>26</td></tr></table> <ol style="list-style-type: none"><li>2. Press the start key. The value is set.</li></ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ADJ LINES	Sets the number of adjustment lines for automatic reduction.	ADJ LINES(A4)	Sets the number of adjustment lines for automatic reduction when A4 paper is set.	ADJ LINES(LT)	Sets the number of adjustment lines for automatic reduction when letter size paper is set.	Description	Setting range	Initial setting	Number of adjustment lines for automatic reduction	0 to 22	7	Description	Setting range	Initial setting	Number of adjustment lines for automatic reduction when A4 paper is set	0 to 22	22	Description	Setting range	Initial setting	Number of adjustment lines for automatic reduction when letter size paper is set	0 to 26	26
Display	Description																										
ADJ LINES	Sets the number of adjustment lines for automatic reduction.																										
ADJ LINES(A4)	Sets the number of adjustment lines for automatic reduction when A4 paper is set.																										
ADJ LINES(LT)	Sets the number of adjustment lines for automatic reduction when letter size paper is set.																										
Description	Setting range	Initial setting																									
Number of adjustment lines for automatic reduction	0 to 22	7																									
Description	Setting range	Initial setting																									
Number of adjustment lines for automatic reduction when A4 paper is set	0 to 22	22																									
Description	Setting range	Initial setting																									
Number of adjustment lines for automatic reduction when letter size paper is set	0 to 26	26																									

Item No.	Description																						
U612	<p><b>Setting system 3</b></p> <p><b>Description</b> Makes settings for fax transmission regarding operation and automatic printing of the protocol list.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be set using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>AUTO REDUCTION</td><td>Selects if auto reduction in the auxiliary direction is to be performed.</td></tr> <tr> <td>PROTOCOL LIST</td><td>Sets the automatic printing of the protocol list.</td></tr> <tr> <td>DETECT TRAIL</td><td>Sets the detection of trailing edge margin.</td></tr> </tbody> </table> <p><b>Selecting if auto reduction in the auxiliary direction is to be performed</b> Sets whether to receive a long document by automatically reducing it in the auxiliary direction or at 100% magnification.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor left/right keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Auto reduction is performed if the received document is longer than the fax paper.</td></tr> <tr> <td>OFF</td><td>Auto reduction is not performed.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Setting the automatic printing of the protocol list</b> Sets if the protocol list is automatically printed out.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor left/right keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>The protocol list is automatically printed out after communication.</td></tr> <tr> <td>OFF</td><td>The protocol list is not printed out automatically.</td></tr> <tr> <td>ERR</td><td>The protocol list is automatically printed out after communication only if a communication error occurs.</td></tr> </tbody> </table> <p>* : Initial setting: OFF</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol>	Display	Description	AUTO REDUCTION	Selects if auto reduction in the auxiliary direction is to be performed.	PROTOCOL LIST	Sets the automatic printing of the protocol list.	DETECT TRAIL	Sets the detection of trailing edge margin.	Display	Description	ON	Auto reduction is performed if the received document is longer than the fax paper.	OFF	Auto reduction is not performed.	Display	Description	ON	The protocol list is automatically printed out after communication.	OFF	The protocol list is not printed out automatically.	ERR	The protocol list is automatically printed out after communication only if a communication error occurs.
Display	Description																						
AUTO REDUCTION	Selects if auto reduction in the auxiliary direction is to be performed.																						
PROTOCOL LIST	Sets the automatic printing of the protocol list.																						
DETECT TRAIL	Sets the detection of trailing edge margin.																						
Display	Description																						
ON	Auto reduction is performed if the received document is longer than the fax paper.																						
OFF	Auto reduction is not performed.																						
Display	Description																						
ON	The protocol list is automatically printed out after communication.																						
OFF	The protocol list is not printed out automatically.																						
ERR	The protocol list is automatically printed out after communication only if a communication error occurs.																						

Item No.	Description						
<b>U612</b>	<p><b>Selecting if detection of trail edge margin is to be performed</b></p> <p>This determines whether trailing edge margin is detected (to prevent image from being mutilated) while printing a received Fax.</p> <p>1. Select the setting using the cursor left/right keys.</p> <table border="1" data-bbox="338 423 1401 568"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>The trail edge margin is detected.</td></tr> <tr> <td>OFF</td><td>The trail edge margin is not detected.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <p>2. Press the start key. The setting is set.</p> <p><b>Completion</b></p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	The trail edge margin is detected.	OFF	The trail edge margin is not detected.
Display	Description						
ON	The trail edge margin is detected.						
OFF	The trail edge margin is not detected.						
<b>U620</b>	<p><b>Setting the remote switching mode</b></p> <p><b>Description</b></p> <p>Sets the signal detection method for remote switching. Be sure to change the setting according to the type of telephone connected to the machine.</p> <p><b>Setting</b></p> <p>1. Press the start key.</p> <p>2. Select [REMORT MODE] and press the start key.</p> <p>3. Select the mode using the cursor up/down keys.</p> <table border="1" data-bbox="338 1189 1401 1335"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ONE</td><td>One-shot detection</td></tr> <tr> <td>CONT</td><td>Continuous detection</td></tr> </tbody> </table> <p>* : Initial setting: ONE</p> <p>4. Press the start key. The setting is set.</p> <p><b>Completion</b></p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ONE	One-shot detection	CONT	Continuous detection
Display	Description						
ONE	One-shot detection						
CONT	Continuous detection						

Item No.	Description																		
U625	<p><b>Setting the transmission system 1</b></p> <p><b>Description</b> Makes settings for the auto redialing interval and the number of times of auto redialing.</p> <p><b>Purpose</b> Change the setting to prevent the following problems: fax transmission is not possible due to too short redial interval, or fax transmission takes too much time to complete due to too long redial interval.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Select the item to be set using the cursor up/down keys.</li></ol> <table><tr><th>Display</th><th>Description</th></tr><tr><td>INTERVAL</td><td>Setting the auto redialing interval</td></tr><tr><td>TIMES</td><td>Setting the number of times of auto redialing</td></tr></table> <p><b>Setting the auto redialing interval</b></p> <ol style="list-style-type: none"><li>1. Change the setting using the cursor left/right keys.</li></ol> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Redialing interval</td><td>1 to 9 (min.)</td><td>3 (120 V)/2 (220-240 V)</td></tr></table> <ol style="list-style-type: none"><li>2. Press the start key. The value is set.</li></ol> <p><b>Setting the number of times of auto redialing</b></p> <ol style="list-style-type: none"><li>1. Change the setting using the cursor left/right keys or numeric keys.</li></ol> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of redialing</td><td>0 to 15</td><td>2 (120 V)/3 (220-240 V)</td></tr></table> <ol style="list-style-type: none"><li>2. Press the start key. The value is set.</li></ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	INTERVAL	Setting the auto redialing interval	TIMES	Setting the number of times of auto redialing	Description	Setting range	Initial setting	Redialing interval	1 to 9 (min.)	3 (120 V)/2 (220-240 V)	Description	Setting range	Initial setting	Number of redialing	0 to 15	2 (120 V)/3 (220-240 V)
Display	Description																		
INTERVAL	Setting the auto redialing interval																		
TIMES	Setting the number of times of auto redialing																		
Description	Setting range	Initial setting																	
Redialing interval	1 to 9 (min.)	3 (120 V)/2 (220-240 V)																	
Description	Setting range	Initial setting																	
Number of redialing	0 to 15	2 (120 V)/3 (220-240 V)																	

Item No.	Description																				
U630	<p><b>Setting communication control 1</b></p> <p><b>Description</b> Makes settings for fax transmission regarding the communication.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be set using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>TX SPEED</td><td>Sets the communication starting speed.</td></tr> <tr> <td>RX SPEED</td><td>Sets the reception speed.</td></tr> <tr> <td>TX ECHO</td><td>Sets the waiting period to prevent echo problems at the sender.</td></tr> <tr> <td>RX ECHO</td><td>Sets the waiting period to prevent echo problems at the receiver.</td></tr> </tbody> </table> <p><b>Setting the communication starting speed</b> Sets the initial communication speed when starting transmission. When the destination unit has V.34 capability, V.34 is selected for transmission, regardless of this setting.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>14400bps/V17</td><td>V.17, 14400 bps</td></tr> <tr> <td>9600bps/V29</td><td>V.17, 9600 bps</td></tr> <tr> <td>4800bps/V27ter</td><td>V.27ter, 4800 bps</td></tr> <tr> <td>2400bps/V27ter</td><td>V.27ter, 2400 bps</td></tr> </tbody> </table> <p>* : Initial setting: 14400bps/V17</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol>	Display	Description	TX SPEED	Sets the communication starting speed.	RX SPEED	Sets the reception speed.	TX ECHO	Sets the waiting period to prevent echo problems at the sender.	RX ECHO	Sets the waiting period to prevent echo problems at the receiver.	Display	Description	14400bps/V17	V.17, 14400 bps	9600bps/V29	V.17, 9600 bps	4800bps/V27ter	V.27ter, 4800 bps	2400bps/V27ter	V.27ter, 2400 bps
Display	Description																				
TX SPEED	Sets the communication starting speed.																				
RX SPEED	Sets the reception speed.																				
TX ECHO	Sets the waiting period to prevent echo problems at the sender.																				
RX ECHO	Sets the waiting period to prevent echo problems at the receiver.																				
Display	Description																				
14400bps/V17	V.17, 14400 bps																				
9600bps/V29	V.17, 9600 bps																				
4800bps/V27ter	V.27ter, 4800 bps																				
2400bps/V27ter	V.27ter, 2400 bps																				



Item No.	Description																						
U630	<p><b>Setting the reception speed</b></p> <p>Sets the reception speed that the sender is informed of using the DIS or NSF signal. When the destination unit has V.34 capability, V.34 is selected, regardless of the setting.</p> <p>1. Select the setting using the cursor up/down keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>14400bps</td><td>V.17, V.33, V.29, V.27ter</td></tr> <tr> <td>9600bps</td><td>V.29, V.27ter</td></tr> <tr> <td>4800bps</td><td>V.27ter</td></tr> <tr> <td>2400bps</td><td>V.27ter (fallback only)</td></tr> </tbody> </table> <p>* : Initial setting: 14400bps</p> <p>2. Press the start key. The setting is set.</p> <p><b>Setting the waiting period to prevent echo problems at the sender</b></p> <p>Sets the period before a DCS signal is sent after a DIS signal is received. Used when problems occur due to echoes at the sender.</p> <p>1. Select the setting using the cursor up/down keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>500</td><td>Sends a DCS 500 ms after receiving a DIS.</td></tr> <tr> <td>300</td><td>Sends a DCS 300 ms after receiving a DIS.</td></tr> </tbody> </table> <p>* : Initial setting: 300</p> <p>2. Press the start key. The setting is set.</p> <p><b>Setting the waiting period to prevent echo problems at the receiver</b></p> <p>Sets the period before an NSF, CSI or DIS signal is sent after a CED signal is received. Used when problems occur due to echoes at the receiver.</p> <p>1. Select the setting using the cursor up/down keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>500</td><td>Sends an NSF, CSI or DIS 500 ms after receiving a CED.</td></tr> <tr> <td>75</td><td>Sends an NSF, CSI or DIS 75 ms after receiving a CED.</td></tr> </tbody> </table> <p>* : Initial setting: 75</p> <p>2. Press the start key. The setting is set.</p> <p><b>Completion</b></p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	14400bps	V.17, V.33, V.29, V.27ter	9600bps	V.29, V.27ter	4800bps	V.27ter	2400bps	V.27ter (fallback only)	Display	Description	500	Sends a DCS 500 ms after receiving a DIS.	300	Sends a DCS 300 ms after receiving a DIS.	Display	Description	500	Sends an NSF, CSI or DIS 500 ms after receiving a CED.	75	Sends an NSF, CSI or DIS 75 ms after receiving a CED.
Display	Description																						
14400bps	V.17, V.33, V.29, V.27ter																						
9600bps	V.29, V.27ter																						
4800bps	V.27ter																						
2400bps	V.27ter (fallback only)																						
Display	Description																						
500	Sends a DCS 500 ms after receiving a DIS.																						
300	Sends a DCS 300 ms after receiving a DIS.																						
Display	Description																						
500	Sends an NSF, CSI or DIS 500 ms after receiving a CED.																						
75	Sends an NSF, CSI or DIS 75 ms after receiving a CED.																						

Item No.	Description																										
U631	<p><b>Setting communication control 2</b></p> <p><b>Description</b> Makes settings regarding fax transmission.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be set using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ECM TX</td><td>Sets ECM transmission.</td></tr> <tr> <td>ECM RX</td><td>Sets ECM reception.</td></tr> <tr> <td>CED FREQ.</td><td>Sets the frequency of the CED signal.</td></tr> </tbody> </table> <p><b>Setting ECM transmission</b> To be set to OFF when reduction of transmission costs is of higher priority than image quality. This should not be set to OFF when connecting to the IP (Internet Protocol) telephone line.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>ECM transmission is enabled.</td></tr> <tr> <td>OFF</td><td>ECM transmission is disabled.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Setting ECM reception</b> To be set to OFF when reduction of transmission costs is of higher priority than image quality. This should not be set to OFF when connecting to the IP (Internet Protocol) telephone line.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>ECM reception is enabled.</td></tr> <tr> <td>OFF</td><td>ECM reception is disabled.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Setting the frequency of the CED signal</b> Sets the frequency of the CED signal. Used as one of the measures to improve transmission performance for international communications.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>2100</td><td>2100 Hz</td></tr> <tr> <td>1100</td><td>1100 Hz</td></tr> </tbody> </table> <p>* : Initial setting: 2100</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ECM TX	Sets ECM transmission.	ECM RX	Sets ECM reception.	CED FREQ.	Sets the frequency of the CED signal.	Display	Description	ON	ECM transmission is enabled.	OFF	ECM transmission is disabled.	Display	Description	ON	ECM reception is enabled.	OFF	ECM reception is disabled.	Display	Description	2100	2100 Hz	1100	1100 Hz
Display	Description																										
ECM TX	Sets ECM transmission.																										
ECM RX	Sets ECM reception.																										
CED FREQ.	Sets the frequency of the CED signal.																										
Display	Description																										
ON	ECM transmission is enabled.																										
OFF	ECM transmission is disabled.																										
Display	Description																										
ON	ECM reception is enabled.																										
OFF	ECM reception is disabled.																										
Display	Description																										
2100	2100 Hz																										
1100	1100 Hz																										


Item No.	Description																												
U632	<p><b>Setting communication control 3</b></p> <p><b>Description</b> Makes settings for fax transmission regarding the communication.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be set using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>DIS 4BYTE</td><td>Sets the DIS signal to 4 bytes.</td></tr> <tr> <td>SHORT PRTCL TX</td><td>Sets the short protocol transmission.</td></tr> <tr> <td>SHORT PRTCL RX</td><td>Sets the reception of short protocol transmission.</td></tr> <tr> <td>NUM OF CNG(F/T)</td><td>Sets the CNG detection times in the fax/telephone auto select mode.</td></tr> </tbody> </table> <p><b>Setting the DIS signal to 4 bytes</b> Sets if bit 33 and later bits of the DIS/DTC signal are sent.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Bit 33 and later bits of the DIS/DTC signal are not sent.</td></tr> <tr> <td>OFF</td><td>Bit 33 and later bits of the DIS/DTC signal are sent.</td></tr> </tbody> </table> <p>* : Initial setting: OFF</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Setting the short protocol transmission</b> Sets if short protocol transmission is performed.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Short protocol transmission is performed.</td></tr> <tr> <td>OFF</td><td>Short protocol transmission is not performed.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Setting the reception of a short protocol transmission</b> Selects whether to receive or ignore transmission using short protocol. If a short protocol transmission is received when an auto switching device is attached to the machine, communication problems, including auto switching inability, sometimes occur. Change the setting to ignore short protocol transmission to prevent such problems.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Receives short protocol transmission.</td></tr> <tr> <td>OFF</td><td>Ignores short protocol transmission.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol>	Display	Description	DIS 4BYTE	Sets the DIS signal to 4 bytes.	SHORT PRTCL TX	Sets the short protocol transmission.	SHORT PRTCL RX	Sets the reception of short protocol transmission.	NUM OF CNG(F/T)	Sets the CNG detection times in the fax/telephone auto select mode.	Display	Description	ON	Bit 33 and later bits of the DIS/DTC signal are not sent.	OFF	Bit 33 and later bits of the DIS/DTC signal are sent.	Display	Description	ON	Short protocol transmission is performed.	OFF	Short protocol transmission is not performed.	Display	Description	ON	Receives short protocol transmission.	OFF	Ignores short protocol transmission.
Display	Description																												
DIS 4BYTE	Sets the DIS signal to 4 bytes.																												
SHORT PRTCL TX	Sets the short protocol transmission.																												
SHORT PRTCL RX	Sets the reception of short protocol transmission.																												
NUM OF CNG(F/T)	Sets the CNG detection times in the fax/telephone auto select mode.																												
Display	Description																												
ON	Bit 33 and later bits of the DIS/DTC signal are not sent.																												
OFF	Bit 33 and later bits of the DIS/DTC signal are sent.																												
Display	Description																												
ON	Short protocol transmission is performed.																												
OFF	Short protocol transmission is not performed.																												
Display	Description																												
ON	Receives short protocol transmission.																												
OFF	Ignores short protocol transmission.																												

Item No.	Description																				
U632	<p><b>Setting the CNG detection times in the fax/telephone auto select mode</b></p> <p>Sets the CNG detection times in the fax/telephone auto select mode.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>1TIME</td><td>Detects CNG once.</td></tr> <tr> <td>2TIMES</td><td>Detects CNG twice.</td></tr> </tbody> </table> <p>* : Initial setting: 2TIMES</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b></p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	1TIME	Detects CNG once.	2TIMES	Detects CNG twice.														
Display	Description																				
1TIME	Detects CNG once.																				
2TIMES	Detects CNG twice.																				
U633	<p><b>Setting communication control 4</b></p> <p><b>Description</b></p> <p>Makes settings for fax transmission regarding the communication.</p> <p><b>Purpose</b></p> <p>To reduce transmission errors when a low quality line is used.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be set using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>V.34</td><td>Enables or disables V.34 communication.</td></tr> <tr> <td>V.34-3429Hz</td><td>Sets the V.34 symbol speed (3429 Hz).</td></tr> <tr> <td>DIS 2RES</td><td>Sets the number of times of DIS signal reception.</td></tr> <tr> <td>RTN CHECK</td><td>Sets the reference for RTN signal output.</td></tr> </tbody> </table> <p><b>Enabling/disabling V.34 communication</b></p> <p>Sets whether V.34 communication is enabled/disabled for transmission and reception.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>V.34 communication is enabled for both transmission and reception.</td></tr> <tr> <td>TX</td><td>V.34 communication is enabled for transmission only.</td></tr> <tr> <td>RX</td><td>V.34 communication is enabled for reception only.</td></tr> <tr> <td>OFF</td><td>V.34 communication is disabled for both transmission and reception.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol>	Display	Description	V.34	Enables or disables V.34 communication.	V.34-3429Hz	Sets the V.34 symbol speed (3429 Hz).	DIS 2RES	Sets the number of times of DIS signal reception.	RTN CHECK	Sets the reference for RTN signal output.	Display	Description	ON	V.34 communication is enabled for both transmission and reception.	TX	V.34 communication is enabled for transmission only.	RX	V.34 communication is enabled for reception only.	OFF	V.34 communication is disabled for both transmission and reception.
Display	Description																				
V.34	Enables or disables V.34 communication.																				
V.34-3429Hz	Sets the V.34 symbol speed (3429 Hz).																				
DIS 2RES	Sets the number of times of DIS signal reception.																				
RTN CHECK	Sets the reference for RTN signal output.																				
Display	Description																				
ON	V.34 communication is enabled for both transmission and reception.																				
TX	V.34 communication is enabled for transmission only.																				
RX	V.34 communication is enabled for reception only.																				
OFF	V.34 communication is disabled for both transmission and reception.																				

Item No.	Description																						
U633	<p><b>Setting the V.34 symbol speed (3429 Hz)</b> Sets if the V.34 symbol speed 3429 Hz is used.</p> <ol style="list-style-type: none"> <li>Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>V.34 symbol speed 3429 Hz is used.</td></tr> <tr> <td>OFF</td><td>V.34 symbol speed 3429 Hz is not used.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> <li>Press the start key. The setting is set.</li> </ol> <p><b>Setting the number of times of DIS signal reception</b> Sets the number of times to receive the DIS signal to once or twice. Used as one of the correction measures for transmission errors and other problems.</p> <ol style="list-style-type: none"> <li>Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ONCE</td><td>Responds to the first signal.</td></tr> <tr> <td>TWICE</td><td>Responds to the second signal.</td></tr> </tbody> </table> <p>* : Initial setting: ONCE</p> <ol style="list-style-type: none"> <li>Press the start key. The setting is set.</li> </ol> <p><b>Setting the reference for RTN signal output</b> Sets the error line rate as the reference for RTN signal output. If transmission errors occur frequently due to the quality of the line, they can be reduced by lowering this setting.</p> <ol style="list-style-type: none"> <li>Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>5%</td><td>Error line rate of 5%</td></tr> <tr> <td>10%</td><td>Error line rate of 10%</td></tr> <tr> <td>15%</td><td>Error line rate of 15%</td></tr> <tr> <td>20%</td><td>Error line rate of 20%</td></tr> </tbody> </table> <p>* : Initial setting: 15%</p> <ol style="list-style-type: none"> <li>Press the start key. The setting is set.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	V.34 symbol speed 3429 Hz is used.	OFF	V.34 symbol speed 3429 Hz is not used.	Display	Description	ONCE	Responds to the first signal.	TWICE	Responds to the second signal.	Display	Description	5%	Error line rate of 5%	10%	Error line rate of 10%	15%	Error line rate of 15%	20%	Error line rate of 20%
Display	Description																						
ON	V.34 symbol speed 3429 Hz is used.																						
OFF	V.34 symbol speed 3429 Hz is not used.																						
Display	Description																						
ONCE	Responds to the first signal.																						
TWICE	Responds to the second signal.																						
Display	Description																						
5%	Error line rate of 5%																						
10%	Error line rate of 10%																						
15%	Error line rate of 15%																						
20%	Error line rate of 20%																						

Item No.	Description																		
U634	<p><b>Setting communication control 5</b></p> <p><b>Description</b> Sets the maximum number of error bytes judged acceptable when receiving a TCF signal. Used as a measure to ease transmission conditions if transmission errors occur.</p> <p><b>Setting</b> 1. Press the start key. 2. Change the setting using the cursor left/right keys or numeric keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Number of allowed error bytes when detecting TCF</td><td>0 to 255</td><td>0</td></tr></table> <p>3. Press the start key. The value is set.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Number of allowed error bytes when detecting TCF	0 to 255	0												
Description	Setting range	Initial setting																	
Number of allowed error bytes when detecting TCF	0 to 255	0																	
U640	<p><b>Setting communication time 1</b></p> <p><b>Description</b> Sets the detection time when one-shot detection is selected for remote switching. (This setting item will be displayed, but the setting made is ineffective.) Sets the detection time when continuous detection is selected for remote switching. (This setting item will be displayed, but the setting made is ineffective.)</p> <p><b>Method</b> 1. Press the start key. 2. Select the item to be set using the cursor up/down keys.</p> <table><tr><th>Display</th><th>Description</th></tr><tr><td>TIME (ONE)</td><td>Sets the one-shot detection time for remote switching.</td></tr><tr><td>TIME (CONT)</td><td>Sets the continuous detection time for remote switching.</td></tr></table> <p><b>Setting the one-shot detection time for remote switching</b> 1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>One-shot detection time for remote switching</td><td>0 to 255</td><td>7</td></tr></table> <p>2. Press the start key. The value is set.</p> <p><b>Setting the continuous detection time for remote switching</b> 1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Continuous detection time for remote switching</td><td>0 to 255</td><td>80</td></tr></table> <p>2. Press the start key. The value is set.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	TIME (ONE)	Sets the one-shot detection time for remote switching.	TIME (CONT)	Sets the continuous detection time for remote switching.	Description	Setting range	Initial setting	One-shot detection time for remote switching	0 to 255	7	Description	Setting range	Initial setting	Continuous detection time for remote switching	0 to 255	80
Display	Description																		
TIME (ONE)	Sets the one-shot detection time for remote switching.																		
TIME (CONT)	Sets the continuous detection time for remote switching.																		
Description	Setting range	Initial setting																	
One-shot detection time for remote switching	0 to 255	7																	
Description	Setting range	Initial setting																	
Continuous detection time for remote switching	0 to 255	80																	

Item No.	Description																														
U641	<p><b>Setting communication time 2</b></p> <p><b>Description</b> Sets the time-out time for fax transmission.</p> <p><b>Purpose</b> To improve transmission performance for international communications mainly.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Select the item to be set using the cursor up/down keys.</li></ol> <table><tr><th>Display</th><th>Description</th></tr><tr><td>T0 TIME OUT</td><td>Sets the T0 time-out time.</td></tr><tr><td>T1 TIME OUT</td><td>Sets the T1 time-out time.</td></tr><tr><td>T2 TIME OUT</td><td>Sets the T2 time-out time.</td></tr><tr><td>Ta TIME OUT</td><td>Sets the Ta time-out time.</td></tr><tr><td>Tb1 TIME OUT</td><td>Sets the Tb1 time-out time.</td></tr><tr><td>Tb2 TIME OUT</td><td>Sets the Tb2 time-out time.</td></tr><tr><td>Tc TIME OUT</td><td>Sets the Tc time-out time.</td></tr><tr><td>Td TIME OUT</td><td>Sets the Td time-out time.</td></tr></table> <p><b>Setting the T0 time-out time</b> Sets the time before detecting a CED or DIS signal after a dialing signal is sent. Depending on the quality of the exchange, or when the auto select function is selected at the destination unit, a line can be disconnected. Change the setting to prevent this problem.</p> <ol style="list-style-type: none"><li>1. Change the setting using the cursor left/right keys.</li></ol> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>T0 time-out time</td><td>30 to 90 s</td><td>56</td></tr></table> <ol style="list-style-type: none"><li>2. Press the start key. The value is set.</li></ol> <p><b>Setting the T1 time-out time</b> Sets the time before receiving the correct signal after call reception. No change is necessary for this maintenance item.</p> <ol style="list-style-type: none"><li>1. Change the setting using the cursor left/right keys.</li></ol> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>T1 time-out time</td><td>30 to 90 s</td><td>36</td></tr></table> <ol style="list-style-type: none"><li>2. Press the start key. The value is set.</li></ol>	Display	Description	T0 TIME OUT	Sets the T0 time-out time.	T1 TIME OUT	Sets the T1 time-out time.	T2 TIME OUT	Sets the T2 time-out time.	Ta TIME OUT	Sets the Ta time-out time.	Tb1 TIME OUT	Sets the Tb1 time-out time.	Tb2 TIME OUT	Sets the Tb2 time-out time.	Tc TIME OUT	Sets the Tc time-out time.	Td TIME OUT	Sets the Td time-out time.	Description	Setting range	Initial setting	T0 time-out time	30 to 90 s	56	Description	Setting range	Initial setting	T1 time-out time	30 to 90 s	36
Display	Description																														
T0 TIME OUT	Sets the T0 time-out time.																														
T1 TIME OUT	Sets the T1 time-out time.																														
T2 TIME OUT	Sets the T2 time-out time.																														
Ta TIME OUT	Sets the Ta time-out time.																														
Tb1 TIME OUT	Sets the Tb1 time-out time.																														
Tb2 TIME OUT	Sets the Tb2 time-out time.																														
Tc TIME OUT	Sets the Tc time-out time.																														
Td TIME OUT	Sets the Td time-out time.																														
Description	Setting range	Initial setting																													
T0 time-out time	30 to 90 s	56																													
Description	Setting range	Initial setting																													
T1 time-out time	30 to 90 s	36																													

Item No.	Description							
U641	<b>Setting the T2 time-out time</b> The T2 time-out time decides the following. From CFR signal output to image data reception From image data reception to the next signal reception In ECM, from RNR signal detection to the next signal reception 1. Change the setting using the cursor left/right keys.							
	Description	Setting range	Initial setting	Change in value per step	T2 time-out time	1 to 255	69	100 ms
	Description	Setting range	Initial setting	Change in value per step				
	T2 time-out time	1 to 255	69	100 ms				
	2. Press the start key. The value is set.							
	<b>Setting the Ta time-out time</b> In the fax/telephone auto select mode, sets the time to continue ringing an operator through the connected telephone after receiving a call as a fax machine (see figure 1-3-17). A fax signal is received within the Ta set time, or the fax mode is selected automatically when the time elapses. In fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.							
	1. Change the setting using the cursor left/right keys.							
	Description	Setting range	Initial setting	Ta time-out time	1 to 255	30		
	Description	Setting range	Initial setting					
	Ta time-out time	1 to 255	30					
2. Press the start key. The value is set.								
								
<b>Figure 1-3-17 Ta/Tb1/Tb2 time-out time</b>								
<b>Setting the Tb1 time-out time</b> In the fax/telephone auto select mode, sets the time to start sending the ring back tone after receiving a call as a fax machine (see figure 1-3-17). In fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.								
1. Change the setting using the cursor left/right keys.								
Description	Setting range	Initial setting	Change in value per step	Tb1 time-out time	1 to 255	20	100 ms	
Description	Setting range	Initial setting	Change in value per step					
Tb1 time-out time	1 to 255	20	100 ms					
2. Press the start key. The value is set.								



Item No.	Description																				
U641	<p><b>Setting the Tb2 time-out time</b></p> <p>In the fax/telephone auto select mode, sets the time to start ringing an operator through the connected telephone after receiving a call as a fax machine (see figure 1-3-17). In the fax/telephone auto select mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p>1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th><th>Change in value per step</th></tr><tr><td>Tb2 time-out time</td><td>1 to 255</td><td>80</td><td>100 ms</td></tr></table> <p>2. Press the start key. The value is set.</p> <p><b>Setting the Tc time-out time</b></p> <p>In the TAD mode, set the time to check if there are any triggers for shifting to fax reception after a connected telephone receives a call. Only the telephone function is available if shifting is not made within the set Tc time.</p> <p>In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call.</p> <p>1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Tc time-out time</td><td>1 to 255</td><td>60</td></tr></table> <p>2. Press the start key. The value is set.</p> <p><b>Setting the Td time-out time</b></p> <p>Sets the length of the time required to determine silent status (fax), one of the triggers for Tc time check. In the TAD mode, change the setting when fax reception is unsuccessful or a telephone fails to receive a call. Be sure not to set it too short; otherwise, the mode may be shifted to fax while the unit is being used as a telephone.</p> <p>1. Change the setting using the cursor left/right keys.</p> <table><tr><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>Td time-out time</td><td>1 to 255</td><td>9 (120 V)/6 (220-240 V)</td></tr></table> <p>2. Press the start key. The value is set.</p> <p><b>Completion</b></p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Description	Setting range	Initial setting	Change in value per step	Tb2 time-out time	1 to 255	80	100 ms	Description	Setting range	Initial setting	Tc time-out time	1 to 255	60	Description	Setting range	Initial setting	Td time-out time	1 to 255	9 (120 V)/6 (220-240 V)
Description	Setting range	Initial setting	Change in value per step																		
Tb2 time-out time	1 to 255	80	100 ms																		
Description	Setting range	Initial setting																			
Tc time-out time	1 to 255	60																			
Description	Setting range	Initial setting																			
Td time-out time	1 to 255	9 (120 V)/6 (220-240 V)																			

Item No.	Description								
U650	<p><b>Setting modem 1</b></p> <p><b>Description</b> Sets the G3 cable equalizer. Sets the modem detection level.</p> <p><b>Purpose</b> Perform the following adjustment to make the equalizer compatible with the line characteristics. To improve the transmission performance when a low quality line is used.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be set using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>REG. G3 TX EQR</td><td>Sets the G3 transmission cable equalizer.</td></tr> <tr> <td>REG. G3 RX EQR</td><td>Sets the G3 reception cable equalizer.</td></tr> <tr> <td>RX MODEM LEVEL</td><td>Sets the modem detection level.</td></tr> </tbody> </table> <p><b>Setting the G3 transmission cable equalizer</b></p> <ol style="list-style-type: none"> <li>1. Select [0dB], [4dB], [8dB] or [12dB] using the cursor up/down keys. * : Initial setting: 0dB</li> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Setting the G3 reception cable equalizer</b></p> <ol style="list-style-type: none"> <li>1. Select [0dB], [4dB], [8dB] or [12dB] using the cursor up/down keys. * : Initial setting: 0dB</li> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Setting the modem detection level</b></p> <ol style="list-style-type: none"> <li>1. Select [33dBm], [38dBm], [43dBm] or [48dBm] using the cursor up/down keys. * : Initial setting: 43dBm</li> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	REG. G3 TX EQR	Sets the G3 transmission cable equalizer.	REG. G3 RX EQR	Sets the G3 reception cable equalizer.	RX MODEM LEVEL	Sets the modem detection level.
Display	Description								
REG. G3 TX EQR	Sets the G3 transmission cable equalizer.								
REG. G3 RX EQR	Sets the G3 reception cable equalizer.								
RX MODEM LEVEL	Sets the modem detection level.								

Item No.	Description																
U651	<p><b>Setting modem 2</b></p> <p><b>Description</b> Sets the modem output level. Sets the DTMF output level of a push-button dial telephone.</p> <p><b>Purpose</b> Used if problems occur when sending a signal with a push-button dial telephone.</p> <p><b>Setting</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Select the item to be set using the cursor up/down keys.</li><li>3. Change the setting using the cursor left/right keys or numeric keys.</li></ol> <table><tr><th>Display</th><th>Description</th><th>Setting range</th><th>Initial setting</th></tr><tr><td>SGL LV MDM</td><td>Modem output level</td><td>1 to 15</td><td>9 (120 V) 10 (220-240 V)</td></tr><tr><td>DTMF LV(C)</td><td>DTMF output level (main value)</td><td>0 to 15.0</td><td>5 (120 V) 10.5 (220-240 V)</td></tr><tr><td>DTMF LV(D)</td><td>DTMF output level (level difference)</td><td>0 to 5.5</td><td>2 (120 V) 2.5 (220-240 V)</td></tr></table> <ol style="list-style-type: none"><li>4. Press the start key. The setting is set.</li></ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Setting range	Initial setting	SGL LV MDM	Modem output level	1 to 15	9 (120 V) 10 (220-240 V)	DTMF LV(C)	DTMF output level (main value)	0 to 15.0	5 (120 V) 10.5 (220-240 V)	DTMF LV(D)	DTMF output level (level difference)	0 to 5.5	2 (120 V) 2.5 (220-240 V)
Display	Description	Setting range	Initial setting														
SGL LV MDM	Modem output level	1 to 15	9 (120 V) 10 (220-240 V)														
DTMF LV(C)	DTMF output level (main value)	0 to 15.0	5 (120 V) 10.5 (220-240 V)														
DTMF LV(D)	DTMF output level (level difference)	0 to 5.5	2 (120 V) 2.5 (220-240 V)														

Item No.	Description																								
U660	<p><b>Setting the NCU</b></p> <p><b>Description</b> Makes setting regarding the network control unit (NCU).</p> <p><b>Purpose</b> To be set when installing the facsimile kit.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be set using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>EXCHANGE</td><td>Sets the connection to PBX/PSTN.</td></tr> <tr> <td>DIAL TONE</td><td>Sets PSTN dial tone detection.</td></tr> <tr> <td>BUSY TONE</td><td>Sets busy tone detection.</td></tr> <tr> <td>PBX SETTING</td><td>Setting for a PBX.</td></tr> <tr> <td>DC LOOP</td><td>Sets the loop current detection before dialing.</td></tr> </tbody> </table> <p><b>Setting the connection to PBX/PSTN</b> Selects if a fax is to be connected to either a PBX or public switched telephone network.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>PSTN</td><td>Connected to the public switched telephone network.</td></tr> <tr> <td>PBX</td><td>Connected to a PBX.</td></tr> </tbody> </table> <p>* : Initial setting: PSTN</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol> <p><b>Setting PSTN dial tone detection</b> Selects if the dial tone is detected to check the telephone is off the hook when a fax is connected to a public switched telephone network.</p> <ol style="list-style-type: none"> <li>1. Select the setting using the cursor up/down keys.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Detects the dial tone.</td></tr> <tr> <td>OFF</td><td>Does not detect the dial tone.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <ol style="list-style-type: none"> <li>2. Press the start key. The setting is set.</li> </ol>	Display	Description	EXCHANGE	Sets the connection to PBX/PSTN.	DIAL TONE	Sets PSTN dial tone detection.	BUSY TONE	Sets busy tone detection.	PBX SETTING	Setting for a PBX.	DC LOOP	Sets the loop current detection before dialing.	Display	Description	PSTN	Connected to the public switched telephone network.	PBX	Connected to a PBX.	Display	Description	ON	Detects the dial tone.	OFF	Does not detect the dial tone.
Display	Description																								
EXCHANGE	Sets the connection to PBX/PSTN.																								
DIAL TONE	Sets PSTN dial tone detection.																								
BUSY TONE	Sets busy tone detection.																								
PBX SETTING	Setting for a PBX.																								
DC LOOP	Sets the loop current detection before dialing.																								
Display	Description																								
PSTN	Connected to the public switched telephone network.																								
PBX	Connected to a PBX.																								
Display	Description																								
ON	Detects the dial tone.																								
OFF	Does not detect the dial tone.																								

Item No.	Description																				
U660	<p><b>Setting busy tone detection</b></p> <p>When a fax signal is sent, sets whether the line is disconnected immediately after a busy tone is detected, or the busy tone is not detected and the line remains connected until T0 time-out time. Fax transmission may fail due to incorrect busy tone detection. When set to 2, this problem may be prevented. However, the line is not disconnected within the T0 time-out time even if the destination line is busy.</p> <p>1. Select the setting using the cursor up/down keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Detects busy tone.</td></tr> <tr> <td>OFF</td><td>Does not detect busy tone.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <p>2. Press the start key. The setting is set.</p> <p><b>Setting for a PBX</b></p> <p>Selects the mode to connect an outside call when connected to a PBX. According to the type of the PBX connected, select the mode to connect an outside call.</p> <p>1. Select the setting using the cursor up/down keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>EARTH</td><td>Earth mode</td></tr> <tr> <td>FLASH</td><td>Flashing mode</td></tr> <tr> <td>LOOP</td><td>Code number mode</td></tr> </tbody> </table> <p>* : Initial setting: LOOP</p> <p>2. Press the start key. The setting is set.</p> <p><b>Setting the loop current detection before dialing</b></p> <p>Sets if the loop current detection is performed before dialing.</p> <p>1. Select the setting using the cursor up/down keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Performs loop current detection before dialing.</td></tr> <tr> <td>OFF</td><td>Does not perform loop current detection before dialing.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <p>2. Press the start key. The setting is set.</p> <p><b>Completion</b></p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	ON	Detects busy tone.	OFF	Does not detect busy tone.	Display	Description	EARTH	Earth mode	FLASH	Flashing mode	LOOP	Code number mode	Display	Description	ON	Performs loop current detection before dialing.	OFF	Does not perform loop current detection before dialing.
Display	Description																				
ON	Detects busy tone.																				
OFF	Does not detect busy tone.																				
Display	Description																				
EARTH	Earth mode																				
FLASH	Flashing mode																				
LOOP	Code number mode																				
Display	Description																				
ON	Performs loop current detection before dialing.																				
OFF	Does not perform loop current detection before dialing.																				

Item No.	Description																				
U670	<p><b>Outputting lists</b></p> <p><b>Description</b> Outputs a list of data regarding fax transmissions. Printing a list is disabled either when a job is remaining in the buffer or when [Pause All Print Jobs] is pressed to halt printing.</p> <p><b>Purpose</b> To check conditions of use, settings and transmission procedures of the fax.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be output using the cursor up/down keys.</li> <li>3. Press the start key. The selected list is output.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>SETTING LIST</td><td>Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.</td></tr> <tr> <td>ACTION LIST</td><td>Outputs a list of error history, transmission line details and other information.</td></tr> <tr> <td>SELF ST REPORT</td><td>Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.</td></tr> <tr> <td>PROTOCOL LIST</td><td>Outputs a list of transmission procedures.</td></tr> <tr> <td>ERROR LIST</td><td>Outputs a list of error.</td></tr> <tr> <td>ADDR BOOK (No.)</td><td>Outputs address book in order IDs were added</td></tr> <tr> <td>ADDR BOOK (Name)</td><td>Outputs address book in order of names</td></tr> <tr> <td>ONE-TOUCH LIST</td><td>Outputs a list of one-touch.</td></tr> <tr> <td>GROUP LIST</td><td>Outputs a list of group.</td></tr> </tbody> </table> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	SETTING LIST	Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.	ACTION LIST	Outputs a list of error history, transmission line details and other information.	SELF ST REPORT	Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.	PROTOCOL LIST	Outputs a list of transmission procedures.	ERROR LIST	Outputs a list of error.	ADDR BOOK (No.)	Outputs address book in order IDs were added	ADDR BOOK (Name)	Outputs address book in order of names	ONE-TOUCH LIST	Outputs a list of one-touch.	GROUP LIST	Outputs a list of group.
Display	Description																				
SETTING LIST	Outputs a list of software switches, self telephone number, confidential boxes, ROM versions and other information.																				
ACTION LIST	Outputs a list of error history, transmission line details and other information.																				
SELF ST REPORT	Outputs a list of settings in maintenance mode (own-status report) regarding fax transmission only.																				
PROTOCOL LIST	Outputs a list of transmission procedures.																				
ERROR LIST	Outputs a list of error.																				
ADDR BOOK (No.)	Outputs address book in order IDs were added																				
ADDR BOOK (Name)	Outputs address book in order of names																				
ONE-TOUCH LIST	Outputs a list of one-touch.																				
GROUP LIST	Outputs a list of group.																				

Item No.	Description																		
U695	<p><b>FAX function customize</b></p> <p><b>Description</b> Sets fax batch transmission ON/OFF. Also changes the print size priority at the time of small size reception.</p> <p><b>Purpose</b> To be executed as required.</p> <p><b>Setting</b> 1. Select the setting using the cursor up/down keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>FAX BULK TX</td><td>fax batch transmission ON/OFF</td></tr> <tr> <td>A5 PT PRI CHG</td><td>Change of print size priority at the time of small size reception</td></tr> </tbody> </table> <p><b>Setting: [FAX BULK TX]</b> 1. Select ON or OFF using the cursor left/right keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>Fax batch transmission is enabled.</td></tr> <tr> <td>OFF</td><td>Fax batch transmission is disabled.</td></tr> </tbody> </table> <p>* : Initial setting: ON</p> <p>2. Press the start key. The setting is set.</p> <p><b>Setting: [A5 PT PRI CHG]</b> 1. Select ON or OFF using the cursor left/right keys.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ON</td><td>At the time of A5 size reception: A5→B5→A4</td></tr> <tr> <td>OFF</td><td>At the time of A5 size reception: A5→A4→B5</td></tr> </tbody> </table> <p>* : Initial setting: OFF</p> <p>2. Press the start key. The setting is set.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	FAX BULK TX	fax batch transmission ON/OFF	A5 PT PRI CHG	Change of print size priority at the time of small size reception	Display	Description	ON	Fax batch transmission is enabled.	OFF	Fax batch transmission is disabled.	Display	Description	ON	At the time of A5 size reception: A5→B5→A4	OFF	At the time of A5 size reception: A5→A4→B5
Display	Description																		
FAX BULK TX	fax batch transmission ON/OFF																		
A5 PT PRI CHG	Change of print size priority at the time of small size reception																		
Display	Description																		
ON	Fax batch transmission is enabled.																		
OFF	Fax batch transmission is disabled.																		
Display	Description																		
ON	At the time of A5 size reception: A5→B5→A4																		
OFF	At the time of A5 size reception: A5→A4→B5																		

Item No.	Description																																														
U699	<p><b>Setting the software switches</b></p> <p><b>Description</b> Sets the software switches on the FAX control PWB individually.</p> <p><b>Purpose</b> To change the setting when a problem such as split output of received originals occurs. Since the communication performance is largely affected, normally this setting need not be changed.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Press the start key.</li><li>2. Press [SW No.].</li><li>3. Enter the desired software switch number (3 digits) using the numeric keys and press the enter key.</li><li>4. Use numeric keys 7 to 0 to switch each bit between 0 and 1.</li><li>5. Press the start key to set the value.</li></ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p> <p><b>List of Software Switches of Which the Setting Can Be Changed</b></p> <p><b>&lt;Communication control procedure&gt;</b></p> <table><tr><th>No.</th><th>Bit</th><th>Item</th></tr><tr><td rowspan="2">36</td><td>7654</td><td>Coding format in transmission</td></tr><tr><td>3210</td><td>Coding format in reception</td></tr><tr><td rowspan="6">37</td><td>5</td><td>33600 bps/V34</td></tr><tr><td>4</td><td>31200 bps/V34</td></tr><tr><td>3</td><td>28800 bps/V34</td></tr><tr><td>2</td><td>26400 bps/V34</td></tr><tr><td>1</td><td>24000 bps/V34</td></tr><tr><td>0</td><td>21600 bps/V34</td></tr><tr><td rowspan="8">38</td><td>7</td><td>19200 bps/V34</td></tr><tr><td>6</td><td>16800 bps/V34</td></tr><tr><td>5</td><td>14400 bps/V34</td></tr><tr><td>4</td><td>12000 bps/V34</td></tr><tr><td>3</td><td>9600 bps/V34</td></tr><tr><td>2</td><td>7200 bps/V34</td></tr><tr><td>1</td><td>4800 bps/V34</td></tr><tr><td>0</td><td>2400 bps/V34</td></tr><tr><td>41</td><td>3</td><td>FSK detection in V.8</td></tr><tr><td rowspan="2">42</td><td>4</td><td>4800 bps when low-speed setting is active</td></tr><tr><td>2</td><td>FIF length in transmission of more than 4 times of DIS/DTC signal</td></tr></table>	No.	Bit	Item	36	7654	Coding format in transmission	3210	Coding format in reception	37	5	33600 bps/V34	4	31200 bps/V34	3	28800 bps/V34	2	26400 bps/V34	1	24000 bps/V34	0	21600 bps/V34	38	7	19200 bps/V34	6	16800 bps/V34	5	14400 bps/V34	4	12000 bps/V34	3	9600 bps/V34	2	7200 bps/V34	1	4800 bps/V34	0	2400 bps/V34	41	3	FSK detection in V.8	42	4	4800 bps when low-speed setting is active	2	FIF length in transmission of more than 4 times of DIS/DTC signal
No.	Bit	Item																																													
36	7654	Coding format in transmission																																													
	3210	Coding format in reception																																													
37	5	33600 bps/V34																																													
	4	31200 bps/V34																																													
	3	28800 bps/V34																																													
	2	26400 bps/V34																																													
	1	24000 bps/V34																																													
	0	21600 bps/V34																																													
38	7	19200 bps/V34																																													
	6	16800 bps/V34																																													
	5	14400 bps/V34																																													
	4	12000 bps/V34																																													
	3	9600 bps/V34																																													
	2	7200 bps/V34																																													
	1	4800 bps/V34																																													
	0	2400 bps/V34																																													
41	3	FSK detection in V.8																																													
42	4	4800 bps when low-speed setting is active																																													
	2	FIF length in transmission of more than 4 times of DIS/DTC signal																																													



Item No.	Description		
U699	<Communication time setting>		
	No.	Bit	Item
	53	76543210	T3 timeout setting
	54	76543210	T4 timeout setting (automatic equipment)
	55	76543210	T5 timeout setting
	60	76543210	Time before transmission of CNG (1100 Hz) signal
	63	76543210	T0 timeout setting (manual equipment)
	64	7	Phase C timeout in ECM reception
	66	76543210	Timeout 1 in countermeasures against echo
	68	76543210	Timeout for FSK detection start in V.8
	<Modem setting>		
	No.	Bit	Item
	89	76543	RX gain adjust
	<NCU setting>		
	No.	Bit	Item
	121	7654	Dial tone/busy tone detection pattern
	122	7654	Busy tone detection pattern
		1	Busy tone detection in automatic FAX/TEL switching
	125	76543210	Access code registration for connection to PSTN
	126	7654	FAX/TEL automatic switching ringback tone ON/OFF cycle
	<Calling time setting>		
	No.	Bit	Item
	133	76543210	DTMF signal transmission time
	134	76543210	DTMF signal pause time
	141	76543210	Ringer detection cycle (minimum)
	142	76543210	Ringer detection cycle (maximum)
	143	76543210	Ringer ON time detection
	144	76543210	Ringer OFF time detection
	145	76543210	Ringer OFF non-detection time
	147	76543210	Dial tone detection time (continuous tone)
	148	76543210	Allowable dial tone interruption time
	149	76543210	Time for transmitting selection signal after closing the DC circuit
	151	76543210	Ringer frequency detection invalid time

Item No.	Description												
U901	<p><b>Clr Paper FD Cnt</b></p> <p><b>Description</b> Displays copy counts by paper feed locations.</p> <p><b>Purpose</b> To check the time to replace consumable parts.</p> <p><b>Method</b> 1. Press the start key. The counts by paper feed locations are displayed.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>MPT</td><td>MP tray</td></tr> <tr> <td>Cass1</td><td>Cassette 1</td></tr> <tr> <td>Cass2</td><td>Cassette 2 (paper feeder)</td></tr> <tr> <td>Cass3</td><td>Cassette 3 (paper feeder)</td></tr> <tr> <td>Dup</td><td>Duplex unit</td></tr> </tbody> </table> <p>* : When an optional paper feed unit is not installed, the corresponding count is not displayed.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	MPT	MP tray	Cass1	Cassette 1	Cass2	Cassette 2 (paper feeder)	Cass3	Cassette 3 (paper feeder)	Dup	Duplex unit
Display	Description												
MPT	MP tray												
Cass1	Cassette 1												
Cass2	Cassette 2 (paper feeder)												
Cass3	Cassette 3 (paper feeder)												
Dup	Duplex unit												
U905	<p><b>Option Cnt</b></p> <p><b>Description</b> Displays the counts of DP.</p> <p><b>Purpose</b> To check the use of DP.</p> <p><b>Method</b> 1. Press the start key. 2. Select [DP]. The count is displayed.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>DP</td><td>Counts of DP</td></tr> </tbody> </table> <p><b>Method: [DP]</b></p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>ADP</td><td>Counts of single-sided originals that has passed through the DP.</td></tr> <tr> <td>RADP</td><td>Counts of double-sided originals that has passed through the DP.</td></tr> </tbody> </table> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	DP	Counts of DP	Display	Description	ADP	Counts of single-sided originals that has passed through the DP.	RADP	Counts of double-sided originals that has passed through the DP.		
Display	Description												
DP	Counts of DP												
Display	Description												
ADP	Counts of single-sided originals that has passed through the DP.												
RADP	Counts of double-sided originals that has passed through the DP.												

Item No.	Description
U910	<p data-bbox="290 241 651 275"><b>Clearing the black ratio data</b></p> <p data-bbox="290 311 440 340"><b>Description</b></p> <p data-bbox="290 344 922 374">Clears the accumulated black ratio data for A4 sheet.</p> <p data-bbox="290 380 400 409"><b>Purpose</b></p> <p data-bbox="290 414 1129 443">To clear data as required at times such as during maintenance service.</p> <p data-bbox="290 486 387 515"><b>Method</b></p> <ol data-bbox="308 519 1094 618" style="list-style-type: none"><li>1. Press the start key.</li><li>2. Select [ALL CLEAR] using the cursor up/down keys.</li><li>3. Press the start key. The accumulated black ratio data is cleared.</li></ol> <p data-bbox="290 658 440 687"><b>Completion</b></p> <p data-bbox="290 692 1254 721">Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>

Item No.	Description																								
U917	<p><b>Setting backup data reading/writing</b></p> <p><b>Description</b> Retrieves the backup data to a USB memory from the machine; or writes the data from the USB memory to the machine.</p> <p><b>Purpose</b> To store and write data when replacing the control PWB.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Press the power key on the operation panel, and after verifying the power indicator has gone off, switch off the power switch.</li><li>2. Insert USB memory in USB memory slot.</li><li>3. Turn the power switch on. Wait for 10 seconds to allow the machine to recognize the USB memory.</li><li>4. Enter the maintenance item.</li><li>5. Press the start key.</li><li>6. Select [Export] or [Import] using the cursor up/down keys and press the start key.</li></ol> <table><tr><th>Display</th><th>Description</th></tr><tr><td>IMPORT</td><td>Writing data from the USB memory to the machine</td></tr><tr><td>EXPORT</td><td>Retrieving from the machine to a USB memory</td></tr></table> <ol style="list-style-type: none"><li>7. Select the item using the cursor up/down keys.</li></ol> <table><tr><th>Display</th><th>Description</th><th>Depending data</th></tr><tr><td>ADDRESS BOOK</td><td>Address book</td><td>-</td></tr><tr><td>JOB ACCNT.</td><td>Job accounting</td><td>-</td></tr><tr><td>ONE TOUCH USER PROGRAM</td><td>Information on one-touch key User managements Program information</td><td>Address book Job accounting Job accountings and user managements</td></tr><tr><td>DOCUMENT BOX</td><td>Document box information</td><td>Job accountings and user managements</td></tr><tr><td>FAX FORWARD</td><td>FAX transfer information</td><td>Job accountings, user managements and document box information</td></tr></table> <p>* : Since data are dependent with each other, data other than those assigned are also retrieved or written in.</p> <ol style="list-style-type: none"><li>8. Select [ON] using the cursor left/right keys.</li><li>9. Press the start key. Starts reading or writing. The progress of selected item is displayed in %. When an error occurs, the operation is canceled and an error code is displayed.</li><li>10. When normally completed, [FIN] is displayed.</li><li>11. Turn the power switch off and on after completing writing when selecting [IMPORT].</li></ol>	Display	Description	IMPORT	Writing data from the USB memory to the machine	EXPORT	Retrieving from the machine to a USB memory	Display	Description	Depending data	ADDRESS BOOK	Address book	-	JOB ACCNT.	Job accounting	-	ONE TOUCH USER PROGRAM	Information on one-touch key User managements Program information	Address book Job accounting Job accountings and user managements	DOCUMENT BOX	Document box information	Job accountings and user managements	FAX FORWARD	FAX transfer information	Job accountings, user managements and document box information
Display	Description																								
IMPORT	Writing data from the USB memory to the machine																								
EXPORT	Retrieving from the machine to a USB memory																								
Display	Description	Depending data																							
ADDRESS BOOK	Address book	-																							
JOB ACCNT.	Job accounting	-																							
ONE TOUCH USER PROGRAM	Information on one-touch key User managements Program information	Address book Job accounting Job accountings and user managements																							
DOCUMENT BOX	Document box information	Job accountings and user managements																							
FAX FORWARD	FAX transfer information	Job accountings, user managements and document box information																							

Item No.	Description			
U917	<b>Error Codes</b>			
	<b>Codes</b>	<b>Description</b>	<b>Codes</b>	<b>Description</b>
	e002	Parameter error	e31e	User managements error
	e003	File write error	e31f	User managements open error
	e004	File initialization error	e320	User managements error
	e005	File error	e410	Box file open error
	e006	Processing error	e411	Box error in writing
	e010	Address book clear error (contact)	e412	Box error in reading
	e011	Address book open error (contact)	e413	Box list error
	e012	Address book list error (contact)	e414	Box list error
	e013	Address book list error (contact)	e415	Box error
	e014	Address book clear error (group)	e416	Box error
	e015	Address book open error (group)	e417	Box open error
	e016	Address book list error (group)	e418	Box close error
	e017	Address book list error (group)	e419	Box creation error
	e110	Job accounting clear error	e41a	Box creation error
	e111	Job accounting open error	e41b	Box deletion error
	e112	Job accounting open error	e41c	Box movement error
	e113	Job accounting error in writing	e510	Program error in writing
	e114	Job accounting list error	e511	Program error in reading
	e115	Job accounting list error	e710	Fax memory open error
	e210	One-touch open error	e711	Fax memory initialization error
	e211	One-touch list error	e712	Fax memory list error
	e212	One-touch list error	e713	Fax memory error
	e310	User managements backup error	e714	Fax memory error
	e311	User managements clear error	e715	Fax memory mode error
	e312	User managements open error	e716	Fax memory error
	e313	User managements open error	e717	Fax memory error
	e314	User managements open error	e718	Fax memory mode error
	e315	User managements error in writing	e910	File reading error
	e316	User managements list error	e911	File writing error
	e317	User managements list error	e912	Data mismatch
	e318	User managements list error	e913	Log file open error
	e319	User managements list error	e914	Log file error in writing
	e31a	User managements open error	e915	Directory open error
	e31b	User managements error	e916	Directory error in reading
	e31c	User managements error	e917	Synchronization error
	e31d	User managements open error	e918	Synchronization error

Item No.	Description			
U917	<b>Error Codes</b>			
	<b>Codes</b>	<b>Description</b>	<b>Codes</b>	<b>Description</b>
	d000	Unspecified error	d00b	File reading error
	d001	HDD unavailable	d00c	File writing error
	d002	USB memory is not inserted	d00d	File copy error
	d003	File for writing is not found in the USB	d00e	File compressed error
	d004	File for reading is not found in the HDD	d00f	File decompressed error
	d005	USB error in writing	d010	Directory open error
	d006	USB error in reading	d011	Directory creation error
	d007	USB unmount error	d012	File writing error
	d008	File rename error	d013	File reading error
	d009	File open error	d014	File deletion error
	d00a	File close error	d015	File copy error to the USB
<p><b>Supplement</b></p> <p>The following restrictions apply to the data which were imported from 4 in 1 model (with FAX) to 3 in 1 model (without FAX).</p> <p>Personal address book: FAX-related data are not imported.</p> <p>Group address book: Group addresses including FAX addresses are not imported.</p> <p>Job accounting data: Initial values are added for FAX-related data.</p> <p>One-touch data: Groups assigned with FAX addresses or those including FAX are not imported.</p> <p>User management data: Initial values are added for out-going FAXes of authentication.</p> <p>Program data: Not imported. (The same applies when data are imported from 3 in 1 to 4 in 1 model.)</p> <p><b>Completion</b></p> <p>Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>				

Item No.	Description								
U920	<p><b>Chg Cnt</b></p> <p><b>Description</b> Checks the copy counts.</p> <p><b>Purpose</b> To check the copy counts.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select the item to be check.</li> </ol> <p>* : The current counts are displayed.</p> <table border="1" data-bbox="338 631 1401 824"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>B/W Copy</td><td>Count value of black/white copy</td></tr> <tr> <td>B/W Prn</td><td>Count value of black/white print</td></tr> <tr> <td>B/W Fax</td><td>Count value of black/white FAX</td></tr> </tbody> </table> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	B/W Copy	Count value of black/white copy	B/W Prn	Count value of black/white print	B/W Fax	Count value of black/white FAX
Display	Description								
B/W Copy	Count value of black/white copy								
B/W Prn	Count value of black/white print								
B/W Fax	Count value of black/white FAX								
U927	<p><b>Clearing the all copy counts and machine life counts (one time only)</b></p> <p><b>Description</b> Resets all of the counts back to zero.</p> <p><b>Supplement</b> The total account counter and the machine life counter can be cleared only once if all count values are 1000 or less.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Press [EXECUTE].</li> <li>3. Press the start key. All copy counts and machine life counts are cleared. [CAN NOT EXECUTE] is displayed if the count cannot be cleared.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>								

Item No.	Description				
U928	<p><b>Life Cnt</b></p> <p><b>Description</b> Displays the machine life counts.</p> <p><b>Purpose</b> To check the machine life counts.</p> <p><b>Method</b> 1. Press the start key. The current machine life counts is displayed.</p> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Cnt</td><td>Machine life counts</td></tr> </tbody> </table> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Cnt	Machine life counts
Display	Description				
Cnt	Machine life counts				
U977	<p><b>Data capture mode</b></p> <p><b>Description</b> Store the print data sent to the machine into USB memory.</p> <p><b>Purpose</b> In case to occur the error at printing, check the print data sent to the machine.</p> <p><b>Method</b> 1. Insert USB memory in USB memory slot. 2. Turn the power switch on. 3. Enter the maintenance item. 4. Press the start key. 5. Select [EXECUTE]. 6. Press the start key. 7. Send the print data to the machine. Once the print data is stored into USB memory, OK will be displayed.</p> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>				




Item No.	Description										
U995	<p><b>Mem Data Indi</b></p> <p><b>Description</b> Displays the memory data.</p> <p><b>Purpose</b> To check the memory data.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Press the start key.</li> <li>2. Select [Print Engine].</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Print Engine</td><td>A display and setup of the Engine section memory</td></tr> </tbody> </table> <ol style="list-style-type: none"> <li>3. Press the start key.</li> </ol> <table border="1"> <thead> <tr> <th>Display</th><th>Description</th></tr> </thead> <tbody> <tr> <td>Offset</td><td>Reference offset</td></tr> <tr> <td>Data</td><td>Reference data</td></tr> </tbody> </table> <ol style="list-style-type: none"> <li>4. Press the start key. The setting is set.</li> <li>5. Turn the main power switch off and on. Allow more than 5 seconds between Off and On.</li> </ol> <p><b>Completion</b> Press the stop key. The screen for selecting a maintenance item No. is displayed.</p>	Display	Description	Print Engine	A display and setup of the Engine section memory	Display	Description	Offset	Reference offset	Data	Reference data
Display	Description										
Print Engine	A display and setup of the Engine section memory										
Display	Description										
Offset	Reference offset										
Data	Reference data										

## 1-3-2 Service mode

The machine is equipped with a maintenance function which can be used to maintain and service the machine.

### (1) Executing a service mode



**(2) Description of service mode**

Service items	Description
Service Status	<p data-bbox="391 295 925 324"><b>Printing a status page for service purpose</b></p> <p data-bbox="391 360 539 389"><b>Description</b></p> <p data-bbox="391 396 1420 459">Prints a status page for service purpose. The status page includes various settings and service cumulative.</p> <p data-bbox="391 465 497 495"><b>Purpose</b></p> <p data-bbox="391 501 1396 530">To acquire the current printing environmental parameters and cumulative information.</p> <p data-bbox="391 566 486 595"><b>Method</b></p> <ol data-bbox="406 602 1136 739" style="list-style-type: none"><li>1. Enter the Service Setting menu.</li><li>2. Select [Service Status] using the cursor up/down keys.</li><li>3. Press the start key.</li><li>4. Press [Yes] (the Left Select key). Two pages will be printed.</li></ol> <p data-bbox="391 775 539 804"><b>Completion</b></p> <p data-bbox="391 810 614 840">Press the stop key.</p>

Service items	Description
	<div><div>Service status page (1)</div><div><div>Service Status Page</div><div>MFP</div><div>(2) 2013/06/07 15:15</div><div>(1) Firmware version 2PN_2000.000.000 2013.06.07</div><div>(3) [XXXXXXXX] (4) [XXXXXXXX] (5) [XXXXXXXX]</div><div><div>Controller Information</div><div><div>Memory status</div><div>(7) Standard Size 2.0 GB</div><div>(8) Option Slot 128.0 KB</div><div>(9) Total Size 2.0 GB</div><div>Time</div><div>(10) Local Time Zone +01:00 Tokio</div><div>(11) Date and Time 06/04/2010 12:00</div><div>(12) Time Server 10.183.53.13</div><div>Installed Options</div><div>(13) Document Processor Installed</div><div>(14) Paper Feeder2: Installed</div><div>(15) Paper Feeder3: Installed</div><div>(16) Memory Card Not Installed</div><div>(17) IC card Authentication Kit (B) Installed</div><div>Print Setting</div><div>(18) MP Tray Priority Auto Feed</div><div>Print Coverage</div><div>(19) Average(%) / Usage Page(A4/Letter Conversion)</div><div>(20) Total</div><div>K: 1.10 / 1111111.11</div><div>(21) Copy</div><div>K: 1.10 / 1111111.11</div><div>(22) Printer</div><div>K: 1.10 / 1111111.11</div><div>(23) FAX</div><div>K: 1.10 / 1111111.11</div><div>(24) Period (27/10/2009 - 03/11/2009 08:40)</div><div>(25) Last Page (%) 1.00</div><div><div>FAX Information</div><div>(26) Rings (Normal) 3</div><div>(27) Rings (FAX/TEL) 3</div><div>(28) Rings (TAD) 3</div><div>(29) Option DIMM Size 16MB</div><div>(30) FRPO Status</div><div>User Top Margin A1+A2/100 0.00</div><div>User Left Margin A3+A4/100 0.00</div><div>PDF mode Y5 00</div><div>RP Code</div><div>(31) 1234 5678 9012</div><div>(32) 5678 9012 3456</div><div>(33) 9012 3456 7890</div><div>(34) 3456 7890 1234</div></div></div></div></div><div>1</div><div>(6) [XXXXXXXXXXXXXXXXXXXX]</div></div>

Figure 1-3-18

Figure 1-3-18

Service items	Description
Service status page (2)	
<div> <div> <h2>Service Status Page</h2> <p>MFP</p> <p>Firmware version 2PN_2000.000.000 2013.06.07</p> </div> <div> <p>2013/06/07 15:15</p> <p>[XXXXXXXX] [XXXXXXXX] [XXXXXXXX]</p> </div> </div>	
<div> <div> <h3>Engine Information</h3> <p>(35) NVRAM Version                   1F31255_1F31255</p> <p>(36) Scanner Version                2PN_1200.001.089</p> <p>(37) FAX Slot1</p> <p>        FAX BOOT Version           2PN_5000.001.001</p> <p>        FAX APL Version            2PN_5100.001.001</p> <p>        FAX IPL Version            2PN_5200.001.001</p> <p>(38) MAC Address                    00:C0:EE:D0:01:0D</p> <p>(39) DP Counters</p> <p>        Total                        1234</p> </div> <div> <h3>Send Information</h3> <p>(40) Date and Time                  10/06/30</p> <p>(41) Address</p> </div> </div>	
<div> <p>1/2 (42) (43)</p> <p>(44) 100/100</p> <p>(45) 0/0/0/0/</p> </div>	
<div> <p>(46) 0000000/0000000/0000000/0000000/0000000/0000000/</p> <p>0000000/</p> <p>F00/U00/0/0/0/0/30/70/abcde/1/0/1/ (47)(48)(49)(50)(51)(52)(53)(54)(55)(56)(57)(58)</p> <p>(59) 0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/0000/</p> <p>0000/0000/0000/0000/0000/0000/0000/0000/0000/</p> <p>(60) 12345678/11223344/00001234abcd567800001234abcd5678/01234567890123456789012345678901/0008/00/07</p> <p>XXXXXXXX (61)</p> <p>(62) [ABCDEFGHJIJ] [ABCDEFGHJIJ]</p> <p>(63) [2PN_81BR.001.010]</p> <p>(64) 00070107FE/0700FE00FE/00FE000100/0000000000/000000A010A/0A0A0A3200/0000000000/0000000000/</p> <p>0008000000/080000001D/0096009B00/9B009BFFFB/0082000000/000000</p> </div>	
<div> <p>1/5/ (65) (66)</p> <p>1/ (67)</p> <p>0/15:47 (68) (69)</p> </div>	
<div> <div></div> <div>2</div> <div>[XXXXXXXXXXXXXXXXXXXX]</div> </div>	

Service items	Description	
	<b>Detail of service status page</b>	
	<b>No.</b>	<b>Description</b>
		<b>Supplement</b>
	(1)	Firmware version -
	(2)	System date -
	(3)	Engine soft version -
	(4)	Engine boot version -
	(5)	Operation panel mask version -
	(6)	Machine serial number -
	(7)	Standard memory size -
	(8)	Optional memory size -
	(9)	Total memory size -
	(10)	Local time zone -
	(11)	Report output date Day/Month/Year hour:minute
	(12)	NTP server name -
	(13)	Presence or absence of the document processor Installed/Not Installed
	(14)	Presence or absence of the optional paper feeder2 Installed/Not Installed
	(15)	Presence or absence of the optional paper feeder3 Installed/Not Installed
	(16)	Presence or absence of the optional memory card Installed/Not Installed
	(17)	Presence or absence of the card authentication kit (B) Installed/Not Installed
	(18)	Print setting Off/Auto Feed/Always
	(19)	Page of relation to the A4/Letter * :Print Coverage provides a close-matching reference of toner consumption and will not match with the actual toner consumption.
	(20)	Average coverage for total -
	(21)	Average coverage for copy -
	(22)	Average coverage for printer -
	(23)	Average coverage for fax -
	(24)	Cleared date and output date -
	(25)	Coverage on the final output page -
	(26)	Number of rings 0 to 15
	(27)	Number of rings before automatic switching 0 to 15
	(28)	Number of rings before connecting to answering machine 0 to 15


Service items	Description	
	<b>No.</b>	<b>Description</b>
	(29)	Option DIMM Size
	(30)	FRPO Setting
	(31)	RP code
	(32)	RP code
	(33)	RP code
	(34)	RP code
	(35)	NV RAM version
	(36)	Scanner firmware version
	(37)	Fax firmware version
	(38)	Mac address
	(39)	Number of original feed from DP
	(40)	The last sent date and time
	(41)	Transmission address

Service items	Description	
	<b>No.</b>	<b>Description</b>
		<b>Supplement</b>
	(42)	Destination information -
	(43)	Area information -
	(44)	Margin settings Top margin/Left margin
	(44)	Margin/Page length/Page width settings Top margin integer part/Top margin decimal part/ Left margin integer part/Left margin decimal part/
	(46)	Life counter (The first line) Machine life/MP tray/Cassette 1/Cassette 2/ Cassette 3 /Duplex
		Life counter (The second line) Maintenance kit
	(47)	Panel lock information 0: OFF 1: Partial lock 2: Full lock
	(48)	USB information 0: Not installed 1: Full speed 2: Hi speed
	(49)	Paper handling information 0: Paper source unit select 1: Paper source unit
	(50)	Auto cassette change 0:Auto cassette change prohibition 1:Auto cassette change permission
	(51)	Black and white printing double count mode 0: All single counts 1: A3, Single count, Less than 420 mm (length) 2: Legal, Single count, 356 mm or less (length) 3: Folio, Single count, Less than 330 mm (length)
	(52)	Billing counting timing -
	(53)	Temperature (machine outside) -
	(54)	Absolute temperature (machineoutside) -
	(55)	Fixed assets number -
	(56)	Job end judgment time-out time -
	(57)	Job end detection mode -
	(58)	Prescribe environmental reset 0: OFF 1: ON
	(59)	Media type attributes 1 to 28 (Not used: 18, 19, 20)  *: For details on settings, refer to MDAT command in "Prescribe Commands Reference Manual.  Weight settings 0: Light/1: Normal 1 / 2: Normal 2 / 3: Normal 3/ 4: Heavy 1 / 5: Heavy 2 / 6: Heavy 3 / 7: Extra Heavy Fuser settings 0: High / 1: Middle / 2: Low / 3: Vellum Duplex settings 0: Disable / 1: Enable



Service items	Description		
	<b>No.</b>	<b>Description</b>	<b>Supplement</b>
	(60)	RFID information	-
	(61)	RFID reader/writer version information	-
	(62)	Soft version of the optional paper feeder	-
	(63)	Version of the optional message	-
	(64)	Maintenance information	-
	(65)	Toner low setting	0: Enabled 1: Disabled
	(66)	Toner low detection level	5 to 100 (%)
	(67)	Full-page print mode	0: Normal mode (Factory setting) 1: Full-page mode
	(68)	Wake UP mode	0: OFF (Don't wake up) 1: ON (Do wake up)
	(69)	Wake Up Timer	Displays the wake-up time

Service items	Description
<b>Network Status</b>	<p data-bbox="389 241 823 275"><b>Printing a status page for network</b></p> <p data-bbox="389 311 539 340"><b>Description</b></p> <p data-bbox="389 344 772 374">Prints a status page for network.</p> <p data-bbox="389 380 497 409"><b>Purpose</b></p> <p data-bbox="389 414 994 443">To acquire the detailed network setting information.</p> <p data-bbox="389 486 485 515"><b>Method</b></p> <ol data-bbox="405 519 1321 651" style="list-style-type: none"><li>1. Enter the Service Setting menu.</li><li>2. Select [Network Status] using the cursor up/down keys.</li><li>3. Press the start key.</li><li>4. Press [Yes] in the confirmation display. Network status page will be printed.</li></ol> <p data-bbox="389 694 539 723"><b>Completion</b></p> <p data-bbox="389 728 616 757">Press the stop key.</p>

Service items	Description
<b>Test Page</b>	<p><b>Printing a test page</b></p> <p><b>Description</b> The halftones of sixteen different levels are printed for test.</p> <p><b>Purpose</b> The developmental time of image error, the test print is performed for judgement of the engine-side or the scanner-side.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Enter the Service Setting menu.</li> <li>2. Select [Test Page].</li> <li>3. Press the start key.</li> <li>4. Press [Yes] (the Left Select key). Test page will be printed.</li> </ol> <div data-bbox="552 741 691 808"> <p>Gray scale (16 levels)</p> </div>  <p style="text-align: center;"><b>Figure 1-3-20</b></p> <p><b>Completion</b> Press the stop key.</p>
<b>New Developer</b>	<p><b>Perform the toner installation of the developer unit.</b></p> <p><b>Description</b> Perform the toner installation when the developer unit has been replaced.</p> <p><b>Purpose</b> Perform when the developer unit is replaced.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Enter the Service Setting menu.</li> <li>2. Select [New Developer] using the cursor up/down keys.</li> <li>3. Press [Yes] in the confirmation display.</li> </ol> <p><b>Completion</b> Press the stop key.</p>

Service items	Description																																																																																
FAX country code	<p><b>FAX Country Code</b></p> <p><b>Description</b> Initializes software switches and all data in the backup data on the FAX control PWB, according to the destination.</p> <p><b>Purpose</b> To initialize the FAX control PWB.</p> <p><b>Method</b></p> <ol style="list-style-type: none"><li>1. Enter the Service Setting menu.</li><li>2. Select [FAX Country Code] using the cursor up/down keys.</li><li>3. Press the start key.</li><li>4. Enter a destination code using the numeric keys.</li><li>5. Press the start key. The setting is set.</li><li>6. Press the start key. Data initialization starts.</li></ol> <p><b>Destination code list</b></p> <table><tr><th>Code</th><th>Destination</th><th>Code</th><th>Destination</th></tr><tr><td>000</td><td>Japan</td><td>250</td><td>Russia</td></tr><tr><td>007</td><td>Argentina</td><td>253</td><td>CTR21 (European nations)</td></tr><tr><td>009</td><td>Australia</td><td></td><td>Italy</td></tr><tr><td>022</td><td>Brazil</td><td></td><td>Germany</td></tr><tr><td>038</td><td>China</td><td></td><td>Spain</td></tr><tr><td>080</td><td>Hong Kong</td><td></td><td>U.K.</td></tr><tr><td>084</td><td>Indonesia</td><td></td><td>Netherlands</td></tr><tr><td>088</td><td>Israel</td><td></td><td>Sweden</td></tr><tr><td>097</td><td>Korea</td><td></td><td>France</td></tr><tr><td>108</td><td>Malaysia</td><td></td><td>Austria</td></tr><tr><td>115</td><td>Mexico</td><td></td><td>Switzerland</td></tr><tr><td>126</td><td>New Zealand</td><td></td><td>Belgium</td></tr><tr><td>136</td><td>Peru</td><td></td><td>Denmark</td></tr><tr><td>137</td><td>Philippines</td><td></td><td>Finland</td></tr><tr><td>152</td><td>Saudi Arabiat</td><td></td><td>Portugal</td></tr><tr><td>156</td><td>Singapore</td><td></td><td>Ireland</td></tr><tr><td>159</td><td>South Africa</td><td></td><td>Norway</td></tr><tr><td>169</td><td>Thailand</td><td>254</td><td>Taiwan</td></tr><tr><td>181</td><td>U.S.A.</td><td></td><td></td></tr></table> <p><b>Completion</b> Press the stop key.</p>	Code	Destination	Code	Destination	000	Japan	250	Russia	007	Argentina	253	CTR21 (European nations)	009	Australia		Italy	022	Brazil		Germany	038	China		Spain	080	Hong Kong		U.K.	084	Indonesia		Netherlands	088	Israel		Sweden	097	Korea		France	108	Malaysia		Austria	115	Mexico		Switzerland	126	New Zealand		Belgium	136	Peru		Denmark	137	Philippines		Finland	152	Saudi Arabiat		Portugal	156	Singapore		Ireland	159	South Africa		Norway	169	Thailand	254	Taiwan	181	U.S.A.		
Code	Destination	Code	Destination																																																																														
000	Japan	250	Russia																																																																														
007	Argentina	253	CTR21 (European nations)																																																																														
009	Australia		Italy																																																																														
022	Brazil		Germany																																																																														
038	China		Spain																																																																														
080	Hong Kong		U.K.																																																																														
084	Indonesia		Netherlands																																																																														
088	Israel		Sweden																																																																														
097	Korea		France																																																																														
108	Malaysia		Austria																																																																														
115	Mexico		Switzerland																																																																														
126	New Zealand		Belgium																																																																														
136	Peru		Denmark																																																																														
137	Philippines		Finland																																																																														
152	Saudi Arabiat		Portugal																																																																														
156	Singapore		Ireland																																																																														
159	South Africa		Norway																																																																														
169	Thailand	254	Taiwan																																																																														
181	U.S.A.																																																																																

Service items	Description								
FAX call Setting	<p><b>FAX call setting</b></p> <p><b>Description</b>  Selects if a fax is to be connected to either a PBX or public switched telephone network.  Selects the mode to connect an outside call when connected to a PBX.  Access code registration for connection to PSTN.</p> <p><b>Purpose</b>  To be executed as required.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Enter the Service Setting menu.</li> <li>2. Select [FAX Call Set.] using the cursor up/down keys.</li> <li>3. Press the start key.</li> </ol> <table border="1" data-bbox="437 701 1385 893"> <thead> <tr> <th data-bbox="437 701 703 745">Display</th><th data-bbox="703 701 1385 745">Description</th></tr> </thead> <tbody> <tr> <td data-bbox="437 745 703 790">Exchange Select.</td><td data-bbox="703 745 1385 790">Setting the connection to PBX/PSTN</td></tr> <tr> <td data-bbox="437 790 703 835">PBX Setting</td><td data-bbox="703 790 1385 835">Setting for a PBX</td></tr> <tr> <td data-bbox="437 835 703 880">Dial No. to PSTN</td><td data-bbox="703 835 1385 880">Setting access code to PSTN</td></tr> </tbody> </table> <p><b>Setting the connection to PBX/PSTN</b></p> <ol style="list-style-type: none"> <li>1. Select [Exchange Select.] using the cursor up/down keys.</li> <li>2. Press the start key.</li> <li>3. Select [PBX] or [PSTN] using the cursor up/down keys.</li> <li>4. Press the start key. The setting is set.</li> </ol> <p><b>Setting for PBX</b></p> <ol style="list-style-type: none"> <li>1. Select [PBX Setting] using the cursor up/down keys.</li> <li>2. Press the start key.</li> <li>3. Select [Loop], [Flash] or [Earth] using the cursor up/down keys.</li> <li>4. Press the start key. The setting is set.</li> </ol> <p><b>Setting access code to PSTN</b></p> <ol style="list-style-type: none"> <li>1. Select [Dial No. to PSTN] using the cursor up/down keys.</li> <li>2. Press the start key.</li> <li>3. Enter access code using the numeric keys. (0 to 9, 00 to 99)</li> <li>4. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b>  Press the stop key.</p>	Display	Description	Exchange Select.	Setting the connection to PBX/PSTN	PBX Setting	Setting for a PBX	Dial No. to PSTN	Setting access code to PSTN
Display	Description								
Exchange Select.	Setting the connection to PBX/PSTN								
PBX Setting	Setting for a PBX								
Dial No. to PSTN	Setting access code to PSTN								

Service items	Description
Remote diagnostics	<p><b>Setting remote diagnostics</b></p> <p><b>Description</b> Sets the remote diagnostics.</p> <p><b>Purpose</b> Used to establish communication between the machine and the service facility when a problem is encountered.</p> <p><b>Method</b></p> <ol style="list-style-type: none"> <li>1. Enter the Service Setting menu.</li> <li>2. Select [Remote Diag.Set.] using the cursor up/down keys.</li> <li>3. Press the start key.</li> <li>4. Select [On] using the cursor up/down keys.</li> <li>5. Press the start key. The setting is set.</li> <li>6. Select [Remote Diag. ID] using the cursor up/down keys.</li> <li>7. Press the start key.</li> <li>8. Enter the prespecified remote diagnostics ID number (0000 to 9999) using the numeric keys.</li> <li>9. Press the start key. The setting is set.</li> </ol> <p><b>Completion</b> Press the stop key.</p>



## 1-4-1 Paper misfeed detection

### (1) Paper misfeed indication

When a paper misfeed occurs, the machine immediately stops printing and displays the paper misfeed message on the operation panel. To remove paper misfed in the machine, pull out the paper cassette, open the front cover, rear cover or duplexer's cover, or remove the drum unit.



Figure 1-4-1 Paper misfeed indication

**(2) Paper misfeed detection condition****Figure 1-4-2**



Code	Contents	Conditions	Jam location*
0100	Secondary paper feed request time out	Secondary paper feed request given by the controller is unreachable.	E
0101	Waiting for process package to be ready	Process package won't be ready.	E
0105	Registration sensor not detected	Activation of the registration sensor (on/off) is undetected for 90 s during printing.	
0107	Waiting for fuser package to be ready	Fuser package won't be ready.	E
0110	Upper cover open	The upper cover is opened during printing.	-
0501	No paper feed from cassette 1	The registration sensor (RS) does not turn on during paper feed from cassette 1.	A
0502	No paper feed from cassette 2	PF paper feed sensor 1 (PFPS1) does not turn on during paper feed from cassette 2 (Retry 1 times).	B
0503	No paper feed from cassette 3	PF paper feed sensor 2 (PFPS2) does not turn on during paper feed from cassette 3 (Retry 1 times).	C
0508	No paper feed from duplex section	The registration sensor (RS) does not turn on during paper feed from the duplex section.	F
0509	No paper feed from MP tray	The registration sensor (RS) does not turn on during paper feed from the MP tray.	D
0511	Multiple sheets in cassette 1	The registration sensor (RS) does not turn off during paper feed from cassette 1.	E
0512	Multiple sheets in cassette 2	PF paper feed sensor 1 (PFPS1) does not turn off during paper feed from cassette 2.	B
0513	Multiple sheets in cassette 3	PF paper feed sensor 2 (PFPS2) does not turn off during paper feed from cassette 3.	C
0518	Multiple sheets in duplex section	The registration sensor (RS) does not turn off during paper feed from the duplex section.	E
0519	Multiple sheets in MP tray	The registration sensor (RS) does not turn off during paper feed from the MP tray.	E
1403	PF paper feed sensor 1 non arrival jam	PF paper feed sensor 1 (PFPS1) does not turn on during paper feed from cassette 3.	G
1413	PF paper feed sensor 1 stay jam	PF paper feed sensor 1 (PFPS1) does not turn off during paper feed from cassette 3.	F
1420		Paper remains at the PF paper feed sensor 1 (PFPS1) when power is turned on.	B
1620	PF paper feed sensor 2 stay jam	Paper remains at the PF paper feed sensor 2 (PFPS2) when power is turned on.	C
4002	Registration sensor non arrival jam	The registration sensor (RS) does not turn on during paper feed from cassette 2.	A
4003		The registration sensor (RS) does not turn on during paper feed from cassette 3.	A

\*: Refer to figure 1-4-2 for paper jam location (see page 1-4-2).

Code	Contents	Conditions	Jam location*
4012	Registration sensor stay jam	The registration sensor (RS) does not turn off during paper feed from cassette 2.	E
4013		The registration sensor (RS) does not turn off during paper feed from cassette 3.	E
4020		When a power supply is turned on, the registration sensor (RS) does not turn off.	E
4201	Eject sensor non arrival jam	The eject sensor (ES) does not turn on during paper feed from cassette 1.	E
4202		The eject sensor (ES) does not turn on during paper feed from cassette 2.	E
4203		The eject sensor (ES) does not turn on during paper feed from cassette 3.	E
4208		The eject sensor (ES) does not turn on during paper feed from duplex section.	E
4209		The eject sensor (ES) does not turn on during paper feed from MP tray.	E
4211	Eject sensor stay jam	The eject sensor (ES) does not turn off during paper feed from cassette 1.	G
4212		The eject sensor (ES) does not turn off during paper feed from cassette 2.	G
4213		The eject sensor (ES) does not turn off during paper feed from cassette 3.	G
4218		The eject sensor (ES) does not turn off during paper feed from the duplex section.	G
4219		The eject sensor (ES) does not turn off during paper feed from the MP tray.	G
4220		Paper remains at the eject sensor (ES) when power is turned on.	G

\*: Refer to figure 1-4-2 for paper jam location (see page 1-4-2).

Code	Contents	Conditions	Jam location*
4301	Duplex sensor non arrival jam	The eject sensor (ES) does not turn on after a switchback start, during paper feed from cassette 1.	G
4302		The eject sensor (ES) does not turn on after a switchback start, during paper feed from cassette 2.	G
4303		The eject sensor (ES) does not turn on after a switchback start, during paper feed from cassette 3.	G
4309		The eject sensor (ES) does not turn on after a switchback start, during paper feed from the MP tray.	G
4311	Duplex sensor stay jam	The eject sensor (ES) does not turn off after a switchback start, during paper feed from cassette 1.	F
4312		The eject sensor (ES) does not turn off after a switchback start, during paper feed from cassette 2.	F
4313		The eject sensor (ES) does not turn off after a switchback start, during paper feed from cassette 3.	F
4319		The duplex sensor (DUS) does not turn off after a switchback start, during paper feed from the MP tray.	F
9000	No paper feed from DP	DP timing sensor (DPTS) does not turn on during original feed from DP (Retry 5 times).	H
9001	DP original conveying jam	DP timing sensor (DPTS) turns off within the specified time since the sensor turns on.	H
9003	DP original switchback jam	During duplex switchback scanning, the DP timing sensor (DPTS) does not turn off within specified time.	H
9004		During duplex switchback scanning, the DP timing sensor (DPTS) does not turn on within specified time since original switchback operation starts.	H
9011	DP top cover open	The DP top cover is opened during original feeding.	H
9410	DP timing sensor stay jam	The DP timing sensor (DPTS) does not turned off within the specified time its turning on.	H

\*: Refer to figure 1-4-2 for paper jam location (see page 1-4-2).

## 1-4-2 Self-diagnostic function

### (1) Self-diagnostic function

This machine is equipped with self-diagnostic function. When a problem is detected, the machine stops printing and display an error message on the operation panel. An error message consists of a message prompting a contact to service personnel, total print count, and a four-digit error code indicating the type of the error. (The display varies depending on the type of the error.)




Figure 1-4-3

**(2) Self diagnostic codes**

Code	Contents	Remarks	
		Causes	Check procedures /corrective measures
0030	<b>FAX control PWB system error</b> Processing with the fax software was disabled due to a hardware problem.	Defective FAX control PWB.	Replace the FAX control PWB (See page 1-5-48).
0070	<b>FAX control PWB incompatible detection Error</b> Abnormal detection of FAX control PWB incompatibility In the initial communication with the FAX control PWB, any normal communication command is not transmitted.	Defective fax software.	Install the fax software.
		Defective FAX control PWB.	Replace the FAX control PWB (See page 1-5-48).
0100	<b>Backup memory device error</b>	Defective flash memory.	Replace the control PWB (See page 1-5-37).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
0120	<b>MAC address data error</b>	Defective flash memory.	Replace the control PWB (See page 1-5-37).
0130	<b>Backup memory read/write error</b>	Defective flash memory.	Replace the control PWB (See page 1-5-37).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
0140	<b>Backup memory data error</b>	Defective flash memory.	Replace the control PWB (See page 1-5-37).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
0150	<b>Control PWB EEPROM error</b> Detecting control PWB EEPROM (U17) communication error.	Improper installation control PWB EEPROM (U17).	Check the installation of the EEPROM (U17) and remedy if necessary (See page 1-5-37).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
		Data damage of control PWB EEPROM (U17).	Contact the Service Administrative Division.
0170	<b>Billing counting error</b>	Defective control PWB.	Replace the control PWB (See page 1-5-37).
		Data damage of control PWB EEPROM (U17).	Contact the Service Administrative Division.


Code	Contents	Remarks	
		Causes	Check procedures /corrective measures
0180	<b>Machine number mismatch</b> Machine number of main and engine does not match.	The main PWB or the engine PWB were exchanged.	U004 Setting the machine number (See page 1-3-12).
		Data damage of control PWB EEPROM (U17).	Contact the Service Administrative Division.
0420	<b>Paper feeder communication error</b> Communication error between control PWB and optional paper feeder.	Improper installation paper feeder.	Follow installation instruction carefully again.
		Defective harness between control PWB (YC30) and paper feeder interface connector, or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
		Defective harness between PF main PWB (YC5) and paper feeder interface connector, or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness (Refer to the service manual for the paper feeder).
		Defective PF main PWB.	Replace the PF main PWB (Refer to the service manual for the paper feeder).
0830	<b>FAX control PWB flash program area checksum error</b> A checksum error occurred with the program of the FAX control PWB.	Defective fax software.	Install the fax software.
		Defective FAX control PWB.	Replace the FAX control PWB (See page 1-5-48).
0840	<b>Faults of RTC</b> The time is judged to go back based on the comparison of the RTC time and the current time or five years or more have passed.	Defective control PWB.	Replace the control PWB (See page 1-5-37).
		The battery is disconnected from the control PWB.	Check visually and remedy if necessary.

Code	Contents	Remarks	
		Causes	Check procedures /corrective measures
<b>0870</b>	<b>FAX control PWB to control PWB high capacity data transfer problem</b> High-capacity data transfer between the FAX control PWB and the control PWB of the machine was not normally performed even if the data transfer was retried the specified times.	Improper installation FAX control PWB.	Reinstall the FAX control PWB (See page 1-5-48).
		Defective FAX control PWB or control PWB.	Replace the FAX control PWB or control PWB and check for correct operation. (See page 1-5-48 or 1-5-37).
<b>0920</b>	<b>Fax file system error</b> The backup data is not retained for file system abnormality of flash memory of the FAX control PWB.	Defective FAX control PWB.	Replace the FAX control PWB (See page 1-5-48).
<b>2000</b>	<b>Main motor error</b> The main motor ready input is not given for 2 s during the main motor is ON.	Defective harness between main motor (CN1) and control PWB (YC17), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness (See page 1-5-37).
		Defective drive transmission system of the main motor.	Check if the rollers and gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective main motor.	Replace the main motor (See page 1-5-49).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
<b>2610</b>	<b>PF paper feed motor error (paper feeder)</b> The PF paper feed motor of cassette 2 ready input is not given for 2 s during the PF paper feed motor is ON.	Defective harness between PF paper feed motor and PF main PWB (YC4), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness (Refer to the service manual for the paper feeder).
		Defective PF paper feed motor drive transmission system.	Check if the gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective PF main motor.	Replace the PF main motor.
		Defective control PWB.	Replace the control PWB (See page 1-5-37).

Code	Contents	Remarks	
		Causes	Check procedures /corrective measures
<b>2620</b>	<b>PF paper feed motor error (Paper feeder)</b> The PF paper feed motor of cassette 3 ready input is not given for 2 s during the PF paper feed motor is ON.	Defective harness between PF paper feed motor and PF main PWB (YC4), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness (Refer to the service manual for the paper feeder).
		Defective PF paper feed motor drive transmission system.	Check if the gears rotate smoothly. If not, grease the bushings and gears. Check for broken gears and replace if any.
		Defective PF main motor.	Replace the PF main motor (Refer to the service manual for the paper feeder).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
<b>3100</b>	<b>ISU home position error</b>	Defective FFC between CCD PWB (YC1) and control PWB (YC8).	Replace the image scanner unit (ISU) (See page 1-5-21).
		Defective FFC between control PWB (YC6) and scanner PWB (YC103), or improper FFC insertion.	Reinsert the FFC. Also check for continuity within the FFC. If none, remedy or replace the FFC.
		Defective home position sensor.	Replace the home position sensor.
		Defective harness between ISU motor and scanner PWB (YC104), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
		Defective ISU motor.	Replace the ISU motor.



Code	Contents	Remarks	
		Causes	Check procedures /corrective measures
<b>3200</b>	<b>Exposure lamp error</b> The exposure lamp is not turned on.	Defective FFC between scanner PWB (YC103) and control PWB (YC6), or improper FFC insertion.	Reinsert the FFC. Also check for continuity within the FFC. If none, remedy or replace the FFC.
		Defective FFC between CCD PWB (YC1) and control PWB (YC8).	Replace the image scanner unit (ISU) (See page 1-5-21).
		Defective harness between CCD PWB (YC3) and LED drive PWB (YC1), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
		Defective harness between LED drive PWB (YC2) and exposure lamp, or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
		Defective exposure lamp.	Replace the exposure lamp (See page 1-5-27).
		Defective LED drive PWB.	Replace the LED drive PWB (See page 1-5-27).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
<b>3300</b>	<b>AGC error</b> After AGC, correct input is not obtained at CCD.	Defective FFC between CCD PWB (YC1) and control PWB (YC8).	Replace the image scanner unit (ISU) (See page 1-5-21).
		Defective exposure lamp.	Replace the exposure lamp (See page 1-5-27).
		Defective CCD PWB.	Replace the CCD PWB.
		Defective control PWB.	Replace the control PWB (See page 1-5-37).

Code	Contents	Remarks	
		Causes	Check procedures /corrective measures
3500	<b>CPU - ASIC (CCD PWB) communication error</b> An error code is detected.	Defective FFC between CCD PWB (YC1) and control PWB (YC8).	Replace the image scanner unit (ISU) (See page 1-5-21).
		Defective CCD PWB.	Replace the CCD PWB.
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
4000	 <b>Polygon motor (laser scanner unit) error</b> The polygon motor ready input is not given for 6 s during the polygon motor is ON.	Defective harness between polygon motor and control PWB (YC10), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
		Defective laser scanner unit.	Replace the laser scanner unit (See page 1-5-17).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
4200	<b>BD error (laser scanner unit) error</b>	BD sensor does not detect laser beam due to condensation on the polygon mirror.	Turn machine power off for at least 30 minutes, then turn machine on again. If not cured, replace the laser scanner unit (See page 1-5-17).
		Defective laser scanner unit.	Replace the laser scanner unit (See page 1-5-17).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
4700	<b>VIDEO ASIC device error</b> Mismatch of reading data from two locations occurs eight times successively. Mismatch between writing data and reading data occurs eight times successively.	Defective connector cable or poor contact in the connector.	Reinsert the connector. Also check for continuity within the connector cable. If none, replace the cable.
		Defective control PWB.	Replace the control PWB (See page 1-5-37).

Code	Contents	Remarks	
		Causes	Check procedures /corrective measures
<b>6000</b>	<b>Broken Fuser heater wire</b> The fuser temperature does not rise after the Fuser heater has been turned on.	Poor contact in the fuser thermistor connector terminals.	Reinsert the connector (See page 1-5-32).
		Poor contact in the Fuser heater connector terminals.	Reinsert the connector (See page 1-5-32).
		Fuser thermistor installed incorrectly.	Replace the fuser unit (See page 1-5-32).
		Fuser thermal cutout triggered.	Replace the fuser unit (See page 1-5-32).
		Fuser heater installed incorrectly.	Replace the fuser unit (See page 1-5-32).
		Broken Fuser heater wire.	Replace the fuser unit (See page 1-5-32).
<b>6020</b>	<b>Abnormally high fuser thermistor temperature</b> Fuser thermistor detects abnormally temperature. When the temperature of a fuser thermistor detects 195 °C or more at the time of heater OFF and 155 °C or more.	Shorted fuser thermistor.	Replace the fuser unit (See page 1-5-32).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
<b>6030</b>	<b>Broken fuser thermistor wire</b> Input from fuser thermistor is 0 (A/D value).	Poor contact in the fuser thermistor connector terminals.	Reinsert the connector (See page 1-5-32).
		Broken fuser thermistor wire.	Replace the fuser unit (See page 1-5-32).
		Fuser thermistor installed incorrectly.	Replace the fuser unit (See page 1-5-32).
		Fuser thermal cutout triggered.	Replace the fuser unit (See page 1-5-32).
		Fuser heater installed incorrectly.	Replace the fuser unit (See page 1-5-32).
		Broken Fuser heater wire.	Replace the fuser unit (See page 1-5-32).

Code	Contents	Remarks	
		Causes	Check procedures /corrective measures
<b>6400</b>	<b>Zero cross signal error</b> The zero cross signal does not reach the control PWB for specified time.	Defective harness between high voltage PWB (CN202) and control PWB (YC23), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness (See page 1-5-37).
		Defective connection between power source PWB (YC103) and high voltage PWB (CN201).	Reinsert the connector.
		Defective power source PWB.	Replace the power source PWB (See page 1-5-40).
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
<b>7990</b>	<b>Waste toner full</b> The waste toner sensor has detected that the waste toner reservoir (drum unit) is full.	Waste toner reservoir (drum unit) is full.	Turn the power switch off/on to restart the machine. If the error is not resolved, replace the drum unit (See page 1-5-28).
		Defective waste toner sensor.	Replace the waste toner sensor.
		Defective control PWB.	Replace the control PWB (See page 1-5-37).

Code	Contents	Remarks	
		Causes	Check procedures /corrective measures
<b>F000</b>	<b>Control PWB - Operation panel PWB communication error</b>	Defective harness between operation panel PWB (YC1) and control PWB (YC7), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
		Defective operation panel PWB.	Replace the operation panel PWB.
		Defective control PWB.	Replace the control PWB (See page 1-5-37).
<b>F020</b>	<b>Control PWB RAM checksum error</b>	Defective main memory (RAM) on the control PWB.	Turn the power switch off/on to restart the machine. If the error is not resolved, replace control PWB (See page 1-5-37).
		Defective expanded memory (DIMM).	Replace the expanded memory (DIMM).
<b>F040</b>	<b>Control PWB engine communication error</b> A communication error is detected.	Defective control PWB.	Turn the power switch off/on to restart the machine. If the error is not resolved, replace control PWB (See page 1-5-37).
<b>F041</b>	<b>Control PWB - scanner PWB communication error</b> A communication error is detected.	Defective control PWB or scanner PWB.	Turn the power switch off/on to restart the machine. If the error is not resolved, replace control PWB or scanner PWB (See page 1-5-37 or 1-5-47).
<b>F050</b>	<b>Control PWB engine checksum error</b>	Some error may have occurred when downloading the firmware of the control PWB.	Download the firmware of the control PWB again (See page 1-6-1).
		Defective control PWB.	Turn the power switch off/on to restart the machine. If the error is not resolved, replace control PWB (See page 1-5-37).
<b>F186</b>	<b>Control PWB video data control error</b>	Defective control PWB.	Turn the power switch off/on to restart the machine. If the error is not resolved, replace control PWB (See page 1-5-37).

## 1-4-3 Image formation problems

(1) Completely blank printout.




See page 1-4-17

(2) All-black print-out.




See page 1-4-18

(3) Dropouts.




See page 1-4-18

(4) Black dots.




See page 1-4-19

(5) Black horizontal streaks.




See page 1-4-19

(6) Black vertical streaks.




See page 1-4-19

(7) Unsharpness.




See page 1-4-20

(8) Gray background.




See page 1-4-20

(9) Dirt on the top edge or back of the paper.





See page 1-4-20

(10) Undulated printing at the right edge (scanning start position).




See page 1-4-21


**(1) Completely blank printout.**

Print example	Causes	Check procedures/corrective measures
	Connection failure with DP connector.	<p>If a blank copy is made because the original loaded in the DP is not fed after the Start key is pressed: Turn the power switch off, investigate the DP connector connection, and firmly connect the DP connector.</p> 
	Defective drum unit or developer unit.	<p>Open the front cover and check that the drum unit and developer unit are correctly seated (See page 1-5-28 and 1-5-27). Investigate that the terminals between the main charger unit and the drum unit are not in loose contact (See page 1-5-28)</p>
	Defective transfer bias output or developer bias output.	Replace the high voltage PWB (See page 1-5-43).
	<p>Poor contact of developer bias terminal (spring) and high voltage output terminal B (J401, J402, J403) on the high voltage PWB.</p> <p>Poor contact of transfer bias terminal (spring) and transfer bias terminal T (J201, J202, J203) on the high voltage PWB.</p>	Check the high voltage PWB visually and correct or replace if necessary (See page 1-5-43).
	Defective laser scanner unit.	Replace the laser scanner unit (See page 1-5-17).
	Defective control PWB.	Replace the control PWB (See page 1-5-37).

**(2) All-black printout.**


Print example	Causes	Check procedures/corrective measures
	Defective main charger unit.	Open the front cover and check that the drum unit and developer unit are correctly seated (See page 1-5-28 and 1-5-27). Investigate that the terminals between the main charger unit and the drum unit are not in loose contact (See page 1-5-28)
	Poor contact of main charger terminal (spring) and main charger output terminal M on the high voltage PWB.	Check the high voltage PWB visually and correct or replace if necessary (See page 1-5-43).
	Defective main charging output.	Replace the high voltage PWB (See page 1-5-43).
	Broken main charger wire.	Replace the main charger unit (See page 1-5-29).
	Defective control PWB.	Replace the control PWB (See page 1-5-37).

**(3) Dropouts.**


Print example	Causes	Check procedures/corrective measures
	Defective developer roller (developer unit).	If the defects occur at regular intervals of 62.8 mm/2 1/2" (See page 2-4-3), the problem may be the damaged developer roller (in the developer unit). Replace the developer unit (See page 1-5-27).
	Defective drum unit.	If the defects occur at regular intervals of 94 mm/3 11/16" (See page 2-4-3), the problem may be the damaged drum (in the drum unit). Replace the drum unit (See page 1-5-28).
	Defective fuser unit (heat roller or press roller).	If the defects occur at regular intervals of 73.162 mm/ 2 7/8", or 78.5 mm/3 1/16" (See page 2-4-3), the problem may be the damaged heat roller or press roller (in the fuser unit). Replace fuser unit (See page 1-5-32).
	Defective paper specifications.	Paper with rugged surface or dump tends to cause dropouts. Replace paper with the one that satisfies the paper specifications.
	Defective transfer roller installation.	The transfer roller must be supported by the bushes at the both ends. Clean the bush to remove oil and debris. Replace the transfer roller if necessary (See page 1-5-30).
	Defective transfer bias output.	Replace the high voltage PWB or control PWB (See page 1-5-43 or 1-5-37).




**(4) Black dots.**

Print example	Causes	Check procedures/corrective measures
	Defective drum unit or developer unit.	<p>If the defects occur at regular intervals of 94 mm/3 11/16" (See page 2-4-3), the problem may be the damaged drum (in the drum unit). Replace drum unit (See page 1-5-28).</p> <p>If the defects occur at random intervals, the toner may be leaking from the developer unit or drum unit. Replace the developer unit or drum unit (See page 1-5-27 or 1-5-28).</p>


**(5) Black horizontal streaks.**

Print example	Causes	Check procedures/corrective measures
	Defective drum unit's ground.	Check that the drum shaft and the grounding tab (machine) are in good contact. Apply the grounding tab a small amount of electroconductive grease as required.
	Defective drum unit.	Replace the drum unit (See page 1-5-28).


**(6) Black vertical streaks.**

Print example	Causes	Check procedures/corrective measures
	Adhesion of oxide to main charger wire.	Remove the drum unit (See page 1-5-28). Slide the charger cleaner (green) left and right 2 or 3 times to clean the charger wire, then return it to its original position (CLEANER HOME POSITION). Refer to the operation guide.
	Defective drum unit.	A streak of toner remaining on drum after printing means that the cleaning blade (in the drum unit) is not working properly. Replace the drum unit (See page 1-5-28).
	Defective developer roller (developer unit).	Replace the developer unit (See page 1-5-27).


**(7) Unsharpness.**

Print example	Causes	Check procedures/corrective measures
	Defective paper specifications.	Replace paper with the one that satisfies the paper specification.
	Defective transfer roller installation.	The transfer roller must be supported by the bushes at the both ends. Clean the bush to remove oil and debris. Replace the transfer roller if necessary (See page 1-5-30).
	Defective transfer bias output.	Replace the high voltage PWB or control PWB (See page 1-5-43 or 1-5-37).
	EcoPrint mode setting.	The EcoPrint mode can provides faint, unsharp printing because it acts to conserve toner for draft printing purpose. For normal printing, turn the EcoPrint mode off by using the operator panel. For details, refer to the operation guide.


**(8) Gray background.**

Print example	Causes	Check procedures/corrective measures
	Print density setting.	The print density may be set too high. Try adjusting the print density. For details, refer to the operation guide.
	Defective potential on the drum surface.	Replace the drum unit (See page 1-5-28).
	Defective main charger grid.	Clean the main charger grid (See page 1-5-29).
	Defective developer roller (developer unit).	If a developer unit which is known to work normally is available for check, replace the current developer unit in the machine with the normal one. If the symptom disappears, replace the developer unit with a new one (See page 1-5-27).

**(9) Dirt on the top edge or back of the paper.**

Print example	Causes	Check procedures/corrective measures
	Toner contamination in various parts.	Dirty edges and back of the paper can be caused by toner accumulated on such parts as the paper chute guide, paper conveying paths, the bottom of the drum and developer unit, and the fuser unit inlet. Clean these areas and parts to remove toner.
	Defective transfer roller.	If the transfer roller is contaminated with toner, clean the transfer roller using a vacuum cleaner or by continuously printing a low density page until the symptom has faded away.

**(10) Undulated printing at the right edge (scanning start position).**

Print example	Causes	Check procedures/corrective measures
 <p>This vertical line should be straight.</p>	Defective polygon motor (laser scanner unit).	Replace the laser scanner unit (See page 1-5-17).
	Defective control PWB.	Replace the control PWB (See page 1-5-37).

## 1-4-4 Electric problems

Problem	Causes	Check procedures/corrective measures
(1)The machine does not operate when the power switch is turned on.	1. No electricity at the power outlet.	Measure the input voltage.
	2. The power cord is not plugged in properly.	Check the contact between the power plug and the outlet.
	3. The top cover is not closed completely.	Check the top cover.
	4. Broken power cord.	Check for continuity. If none, replace the cord.
	5. Defective power switch.	Check for continuity across the contacts. If none, replace the power source PWB (See page 1-5-40).
	6. Blown fuse in the power source PWB.	Check for continuity. If none, remove the cause of blowing and replace the power source PWB (See page 1-5-40).
	7. Defective interlock switch.	Check for continuity across the contacts of interlock switch. If none, replace the power source PWB (See page 1-5-40).
	8. Defective power source PWB.	Replace the power source PWB (See page 1-5-40).
	9. Defective control PWB.	Replace the control PWB (See page 1-5-37).
(2)Right cooling fan motor does not operate.	1. Broken right cooling fan motor coil.	Check for continuity across the coil. If none, replace the right cooling fan motor.
	2. Defective harness between right cooling fan motor and control PWB (YC27), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
	3. Defective control PWB.	Replace the control PWB (See page 1-5-37).
(3)Left cooling fan motor does not operate.	1. Broken left cooling fan motor coil.	Check for continuity across the coil. If none, replace the left cooling fan motor.
	2. Defective harness between left cooling fan motor and control PWB (YC104), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
	3. Defective control PWB.	Replace the control PWB (See page 1-5-37).

<b>Problem</b>	<b>Causes</b>	<b>Check procedures/corrective measures</b>
(4)Registration clutch does not operate.	1. Broken registration clutch coil.	Check for continuity across the coil. If none, replace the registration clutch.
	2. Defective harness between registration clutch and control PWB (YC20), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
	3. Defective control PWB.	Replace the control PWB (See page 1-5-37).
(5)Paper feed clutch does not operate.	1. Broken paper feed clutch coil.	Check for continuity across the coil. If none, replace the paper feed clutch.
	2. Defective harness between paper feed clutch and control PWB (YC20), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
	3. Defective control PWB.	Replace the control PWB (See page 1-5-37).
(6)Developer clutch does not operate.	1. Broken developer clutch coil.	Check for continuity across the coil. If none, replace the developer clutch.
	2. Defective harness between developer clutch and control PWB (YC20), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
	3. Defective control PWB.	Replace the control PWB (See page 1-5-37).
(7)MP paper feed solenoid does not operate.	1. Broken MP paper feed solenoid coil.	Check for continuity across the coil. If none, replace the MP paper feed solenoid.
	2. Defective harness between MP paper feed solenoid and control PWB (YC21), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
	3. Defective control PWB.	Replace the control PWB (See page 1-5-37).

Problem	Causes	Check procedures/corrective measures
(8) Duplex solenoid does not operate.	1. Broken duplex solenoid coil.	Check for continuity across the coil. If none, replace the duplex solenoid.
	2. Defective harness between duplex solenoid and control PWB (YC29), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
	3. Defective control PWB.	Replace the control PWB (See page 1-5-37).
(9) Cleaning lamp does not turn on.	1. Defective harness between cleaning lamp (YC701) and control PWB (YC28), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
	2. Defective cleaning lamp (PWB).	Replace the cleaning lamp (PWB).
	3. Defective control PWB.	Replace the control PWB (See page 1-5-37).
(10) Paper indicator is flashing when paper is present in the cassette.	1. Defective paper sensor.	Replace the paper sensor.
	2. Defective harness between paper sensor and control PWB (YC18), or improper connector insertion.	Reinsert the connector. Also check for continuity within the connector harness. If none, remedy or replace the harness.
(11) A paper jam in the paper feed/ conveying section or fuser section is indicated when the main power switch is turned on.	1. A piece of paper torn from paper is caught around registration sensor or exit sensor.	Check and remove if any.
	2. Defective registration sensor on the high voltage PWB.	Replace the high voltage PWB (See page 1-5-43).
	3. Defective exit sensor.	Replace the exit sensor.
(12) Attention indicator is lit when the front cover is closed.	1. Defective interlock switch on the power source PWB.	Check for continuity across the interlock switch. If there is no continuity when the interlock switch is on, replace the power source PWB (See page 1-5-40).
(13) When the trouble occurs in the DP.	-	Refer to the DP's service manual.

## 1-4-5 Mechanical problems

Problem	Causes/check procedures	Corrective measures
(1)No primary paper feed.	Check if the surfaces of the paper feed roller is dirty with paper powder.	Clean with isopropyl alcohol.
	Check if the paper feed roller is deformed.	Check visually and replace any deformed paper feed roller (assembly) (See page 1-5-6).
	Defective paper feed clutch installation.	Check visually and remedy if necessary.
(2)No secondary paper feed.	Check if the surfaces of the upper and lower registration rollers are dirty with paper powder.	Clean with isopropyl alcohol.
	Defective registration clutch installation.	Check visually and remedy if necessary.
(3)Skewed paper feed.	Paper width guide in a cassette installed incorrectly.	Check the paper width guide visually and correct or replace if necessary.
(4)Multiple sheets of paper are fed at one time.	Check if the separator pad or MPF separation pad is worn.	Replace the separator pad if it is worn.
	Check if the paper is curled.	Replace the paper.
(5)Paper jams.	Check if the paper is excessively curled.	Replace the paper.
	Check if the contact between the upper and lower registration rollers is correct.	Check visually and remedy if necessary.
	Check if the heat roller or press roller is extremely dirty or deformed.	Replace the fuser unit (See page 1-5-32).
	Check if the contact between the ejection roller and fuser ejection pulley is correct.	Check visually and remedy if necessary.
(6)Toner drops on the paper conveying path.	Check if the drum unit or developer unit is extremely dirty.	Clean the drum unit or developer unit (See page 1-5-28 or 1-5-27).
(7)Abnormal noise is heard.	Check if the pulleys, rollers and gears operate smoothly.	Grease the bearings and gears.
	Check if the following electromagnetic clutches are installed correctly: Paper feed clutch, registration clutch and developer clutch.	Check visually and remedy if necessary.
(8)When the trouble occurs in the DP.		Refer to the DP's service manual.

## 1-4-6 Send error code

This section describes the scanning errors and descriptions, preventive actions, as well as corrective actions. Error codes not described here could fall within software errors.

If such an error is encountered, turn power off then on, and advise the service representative.

### (1) Scan to SMB error codes

Code	Contents	Check procedures/corrective measures
1101	Host destined does not exist on the network.	<ol style="list-style-type: none"> <li>1. Confirm the destined host.</li> <li>2. Confirm the device's network parameters.</li> <li>3. Confirm the parameters of the network to which the device is connected are correct.</li> </ol>
1102	Login to the host has failed.	<ol style="list-style-type: none"> <li>1. Confirm user name and password.</li> <li>2. Confirm the parameters of the network to which the device is connected are correct.</li> <li>3. Check the host if the folder is properly shared.</li> </ol>
1103	Destined host, folder, and/or file names are invalid.	<ol style="list-style-type: none"> <li>1. Check illegal characters are not contained within these names.</li> <li>2. Check the name of the folder and files conform with the naming syntax.</li> <li>3. Confirm destined host and folder.</li> </ol>
1105	SMB protocol is not enabled.	<ol style="list-style-type: none"> <li>1. Confirm device's SMB protocols.</li> </ol>
2101	Login to the host has failed.	<ol style="list-style-type: none"> <li>1. Confirm the destined host.</li> <li>2. Confirm that the LAN cable is properly connected to the device.</li> <li>3. Check the SMB port number.</li> <li>4. Confirm the device's network parameters.</li> <li>5. Confirm the parameters of the network to which the device is connected are correct.</li> </ol>
2201	Writing scanned data has failed.	<ol style="list-style-type: none"> <li>1. Check the file name to save the scanned data.</li> <li>2. Confirm the device's network parameters.</li> <li>3. Confirm the parameters of the network to which the device is connected are correct.</li> </ol>
2203	No response from the host during a certain period of time.	<ol style="list-style-type: none"> <li>1. Confirm the network parameters the device is connected.</li> <li>2. Confirm that the LAN cable is properly connected to the device.</li> </ol>



**(2) Scan to FTP error codes**

Code	Contents	Check procedures/corrective measures
1101	FTP server does not exist on the network.	<ol style="list-style-type: none"> <li>1. Check the FTP server name.</li> <li>2. Confirm device's network parameters.</li> <li>3. Confirm the parameters of the network to which the device is connected are correct.</li> </ol>
1102	Login to the FTP server has failed.	<ol style="list-style-type: none"> <li>1. Confirm user name and password.</li> <li>2. Check the FTP server name.</li> </ol>
1103	Destined folder is invalid.	<ol style="list-style-type: none"> <li>1. Check that the illegal characters are not contained within these names.</li> <li>2. Check the FTP server name.</li> </ol>
1105	FTP protocol is not enabled.	<ol style="list-style-type: none"> <li>1. Confirm device's FTP protocols.</li> </ol>
1131	Initializing TLS has failed.	<ol style="list-style-type: none"> <li>1. Confirm device's security parameters.</li> </ol>
1132	TLS negotiation has failed.	<ol style="list-style-type: none"> <li>1. Confirm device's security parameters.</li> <li>2. Check the FTP server name.</li> </ol>
2101	Access to the FTP server has failed.	<ol style="list-style-type: none"> <li>1. Check the FTP server name.</li> <li>2. Confirm that the LAN cable is properly connected to the device.</li> <li>3. Check the FTP port number.</li> <li>4. Confirm device's network parameters.</li> <li>5. Confirm the network parameters the device is connected.</li> <li>6. Check the FTP server name.</li> </ol>
2102	Access to the FTP server has failed. (Connection timeout)	<ol style="list-style-type: none"> <li>1. Check the FTP server name.</li> <li>2. Check the FTP port number.</li> <li>3. Confirm device's network parameters.</li> <li>4. Confirm the network parameters the device is connected.</li> <li>5. Check the FTP server name.</li> </ol>
2103	The server cannot establish communication.	<ol style="list-style-type: none"> <li>1. Check the FTP server name.</li> <li>2. Check the FTP port number.</li> <li>3. Confirm device's network parameters.</li> <li>4. Confirm the network parameters the device is connected.</li> <li>5. Check the FTP server name.</li> </ol>
2201	Connection with the FTP server has failed.	<ol style="list-style-type: none"> <li>1. Confirm device's network parameters.</li> <li>2. Confirm the network parameters the device is connected.</li> <li>3. Confirm destined folder.</li> <li>4. Check the FTP server name.</li> </ol>
2202	Connection with the FTP server has failed. (Timeout)	<ol style="list-style-type: none"> <li>1. Confirm device's network parameters.</li> <li>2. Confirm the network parameters the device is connected.</li> </ol>
2203	No response from the server during a certain period of time.	<ol style="list-style-type: none"> <li>1. Confirm device's network parameters.</li> <li>2. Confirm the network parameters the device is connected.</li> </ol>

Code	Contents	Check procedures/corrective measures
2231	Connection with the FTP server has failed. (FTPS communication)	1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected.
3101	FTP server responded with an error.	1. Confirm device's network parameters. 2. Confirm the network parameters the device is connected. 3. Check the FTP server.

**(3) Scan to E-mail error codes**

Code	Contents	Check procedures/corrective measures
1101	SMTP/POP3 server does not exist on the network.	<ol style="list-style-type: none"> <li>1. Check the SMTP/POP3 server name.</li> <li>2. Confirm device's network parameters.</li> <li>3. Confirm the parameters of the network to which the device is connected are correct.</li> </ol>
1102	Login to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> <li>1. Confirm user name and password.</li> <li>2. Check the SMTP/POP3 server.</li> </ol>
1104	The domain the destined address belongs is prohibited by scanning restriction.	<ol style="list-style-type: none"> <li>1. Confirm device's SMTP parameters.</li> </ol>
1105	SMTP protocol is not enabled.	<ol style="list-style-type: none"> <li>1. Confirm device's SMTP protocols.</li> </ol>
1106	Sender's address is not specified.	<ol style="list-style-type: none"> <li>1. Confirm device's SMTP protocols.</li> </ol>
2101	Connection to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> <li>1. Check the SMTP/POP3 server name.</li> <li>2. Confirm that the LAN cable is properly connected to the device.</li> <li>3. Check the SMTP/POP3 port number.</li> <li>4. Confirm device's network parameters.</li> <li>5. Confirm the network parameters the device is connected.</li> <li>6. Check the SMTP/POP3 server.</li> </ol>
2102	Connection to the SMTP/POP3 server has failed. (Connection timeout)	<ol style="list-style-type: none"> <li>1. Check the SMTP/POP3 server name.</li> <li>2. Check the SMTP/POP3 port number.</li> <li>3. Confirm device's network parameters.</li> <li>4. Confirm the network parameters the device is connected.</li> <li>5. Check the SMTP/POP3 server.</li> </ol>
2103	The server cannot establish communication.	<ol style="list-style-type: none"> <li>1. Check the SMTP/POP3 server name.</li> <li>2. Check the SMTP/POP3 port number.</li> <li>3. Confirm device's network parameters.</li> <li>4. Confirm the network parameters the device is connected.</li> <li>5. Check the SMTP/POP3 server.</li> </ol>
2201	Connection to the SMTP/POP3 server has failed.	<ol style="list-style-type: none"> <li>1. Confirm device's network parameters.</li> <li>2. Confirm the network parameters the device is connected.</li> </ol>
2202	Connection to the SMTP/POP3 server has failed. (Timeout)	<ol style="list-style-type: none"> <li>1. Confirm device's network parameters.</li> <li>2. Confirm the network parameters the device is connected.</li> </ol>
2204	The size of scanning exceeded its limit.	<ol style="list-style-type: none"> <li>1. Confirm device's network parameters.</li> </ol>
3101	SMTP/POP3 server responded with an error.	<ol style="list-style-type: none"> <li>1. Confirm device's network parameters.</li> <li>2. Confirm the network parameters the device is connected.</li> <li>3. Check the SMTP/POP3 server.</li> </ol>
3102	Error: Server Response.	<ol style="list-style-type: none"> <li>1. Check the SMTP/POP3 server.</li> <li>2. Wait a minute and trye again.</li> </ol>

Code	Contents	Check procedures/corrective measures
3201	No SMTP authentication is found.	<ol style="list-style-type: none"> <li>1. Check the SMTP server.</li> <li>2. The device supports SMTP authentication services including CRAM-MD5, DIGEST-MD5, PLAIN and LOGIN.</li> </ol>
4803	Failed to establish the SSL session.	<ol style="list-style-type: none"> <li>1. Verify the self certificate of the device.</li> <li>2. Check the server certificate of the SMTP/POP3 server.</li> <li>3. Check the SMTP/POP3 configuration of the device and the SMTP/POP3 server.</li> </ol>

## 1-4-7 Error codes

### (1) Error code

Error codes are listed on the communication reports, activity report, etc. The codes consist of an error code indication U followed by a 5-digit number. (Error codes for V34 communication errors start with an E indication, followed by five digits.)

The upper three of the five digits indicate general classification of the error and its cause, while the lower two indicate the detailed classification. Items for which detailed classification is not necessary have 00 as the last two digits.




Figure 1-4-4

**(2) Table of general classification**

<b>Error code</b>	<b>Description</b>
<b>U00000</b>	No response or busy after the set number of redials.
<b>U00100</b>	Transmission was interrupted by a press of the stop/clear key.
<b>U00200</b>	Reception was interrupted by a press of the stop/clear key.
<b>U00300</b>	Recording paper on the destination unit has run out during transmission.
<b>U004XX</b>	A connection was made but interrupted during handshake with the receiver unit (See page 1-4-35 ).
<b>U00500</b>	Multiple communication was interrupted and call was not made on destination units after interruption.
<b>U006XX</b>	Communication was interrupted because of a machine problem (See page 1-4-36 ).
<b>U00700</b>	Communication was interrupted because of a problem in the destination unit.
<b>U008XX</b>	A page transmission error occurred in G3 mode (See page 1-4-36 ).
<b>U009XX</b>	A page reception error occurred in G3 mode (See page 1-4-36 ).
<b>U010XX</b>	Transmission in G3 mode was interrupted by a signal error (See page 1-4-37 ).
<b>U011XX</b>	Reception in G3 mode was interrupted by a signal error (See page 1-4-39 ).
<b>U01400</b>	An invalid one-touch key was specified during communication.
<b>U01500</b>	A communication error occurred when calling in V.8 mode.
<b>U01600</b>	A communication error occurred when called in V.8 mode.
<b>U017XX</b>	A communication error occurred before starting T.30 protocol during transmission in V.34 mode (See page 1-4-40 ).
<b>U018XX</b>	A communication error occurred before starting T.30 protocol during reception in V.34 mode (See page 1-4-41 ).
<b>U02000</b>	Relay broadcast was refused by a relay station because of a mismatch in permit ID number and permit telephone number when a relay command was issued.
<b>U02100</b>	A relay command failed because the destination unit (relay station) had no relay broadcast capability.
<b>U02200</b>	A relay command from a command station failed because a telephone number that was not registered in the relay station was specified. Or, relay broadcast was requested to a relay station but failed because a telephone number that was not registered in the relay station was specified. Or, Subaddress-based relay broadcast transmission failed because the data registered in the Subaddress relay box was deleted.
<b>U023XX</b>	Receiving station information was not normally received in reception of a relay command (See page 1-4-41 ).
<b>U02400</b>	An interoffice subaddress-based relay transmission was interrupted because of a mismatch in the specified relay box number.
<b>U03000</b>	No document was present in the destination unit when polling reception started.
<b>U03100</b>	In reverse polling, although no original was set in the destination unit, transmission was complete.
<b>U03200</b>	In confidential polling reception, data was not accumulated in the specified box in the destination unit. Or, in interoffice subaddress-based bulletin board reception, data was not stored in the box specified by the destination unit.

Error code	Description
<b>U03300</b>	In polling reception from a unit of our make, operation was interrupted due to a mismatch in permit ID or telephone number. Or, in interoffice subaddress-based bulletin board reception, operation was interrupted due to a mismatch in permit ID or telephone number.
<b>U03400</b>	Polling reception was interrupted because of a mismatch in individual numbers (destination unit is either of our make or by another manufacturer).
<b>U03500</b>	In confidential polling reception, the specified confidential box No. was not registered in the destination. Or, in interoffice subaddress-based bulletin board reception, the specified Subaddress confidential box number was not registered in the destination unit. Or, the destination was being accessed.
<b>U03600</b>	Confidential polling reception was interrupted because of a mismatch in specified confidential box No. Or, an interoffice subaddress-based bulletin board reception was interrupted because of a mismatch in the specified subaddress confidential box number.
<b>U03700</b>	Confidential polling reception failed because the destination unit had no confidential polling transmission capability or data was not accumulated in any box in the destination unit. Or, interoffice subaddress-based bulletin board reception failed because the destination unit had no subaddress-based bulletin board transmission capability, or data was not stored in any subaddress confidential box in the destination unit.
<b>U04000</b>	The confidential box specified for confidential transmission was not registered in the destination unit. Or, in interoffice subaddress-based transmission mode, the specified subaddress box number was not registered in the destination unit. Or, the destination was being accessed.
<b>U04100</b>	Confidential transmission failed because the destination unit had no confidential capability. Or, subaddress-based transmission failed because the destination unit had no subaddress-based reception capability.
<b>U04200</b>	In encrypted transmission, the specified encryption box was not registered in the destination unit.
<b>U04300</b>	Encrypted transmission failed because the destination unit had no encrypted communication capability.
<b>U044XX</b>	Communication was interrupted because of an encryption key error during encrypted transmission (See page 1-4-41 ).
<b>U04500</b>	Encrypted reception was interrupted because of a mismatch in encryption keys.
<b>U05000</b>	In transmission with a specified number, the set number of originals was different from the number of transmitted originals.
<b>U05100</b>	Password check transmission or restricted transmission was interrupted because the permit ID's did not agree with.
<b>U05200</b>	Password check reception or restricted reception was interrupted because the permit ID's did not match, the rejected FAX number's did match, or the destination receiver did not return its phone number.
<b>U05300</b>	The password check reception or the restricted reception was interrupted because the permitted numbers did not match, the rejected numbers did match, or the machine in question did not acknowledge its phone number.
<b>U09000</b>	G3 communication was attempted but failed because the destination unit was a G2 machine.

Error code	Description
<b>U12000</b>	Relay broadcast was requested from a command station but memory overflowed during reception. Or, in subaddress-based relay reception, memory overflowed.
<b>U12100</b>	Relay was commanded but memory overflowed in the destination unit (relay station).
<b>U14000</b>	Memory overflowed during confidential reception. Or, in subaddress-based confidential reception, memory overflowed.
<b>U14100</b>	Memory overflowed in the destination unit during confidential transmission. Or, in interoffice subaddress-based transmission, memory overflowed in the destination unit.
<b>U19000</b>	Memory overflowed during memory reception.
<b>U19100</b>	Memory overflowed in the destination unit during transmission.
<b>U19200</b>	Memory transmission failed because a decoding error occurred.
<b>U19300</b>	Transmission failed because an error occurred during JBIG encoding.
<b>U19400</b>	Reception failed because an error occurred during JBIG decoding.



**(2-1) U004XX error code table: Interrupted phase B**

<b>Error code</b>	<b>Description</b>
<b>U00420</b>	A relay request was received from the host center but interrupted because of a mismatch in permit ID or telephone number.
<b>U00421</b>	Subaddress-based relay reception was interrupted because of a mismatch in the specified subaddress relay box number.
<b>U00430</b>	Polling request (confidential or reverse) was received but interrupted because of a mismatch in permit number. Or, subaddress-based bulletin board transmission request was received but interrupted because of a mismatch in permit ID in the transmitting unit.
<b>U00431</b>	Confidential polling transmission was interrupted because the specified confidential box No. was not registered. Or, an subaddress-based bulletin board transmission was interrupted because the specified subaddress confidential box was not registered.
<b>U00432</b>	Confidential polling transmission was interrupted because of a mismatch in confidential box ID number. Or, an subaddress-based bulletin board transmission was interrupted because of a mismatch in Subaddress confidential box numbers.
<b>U00433</b>	Confidential polling request was received but data was not present in the confidential box. Or, subaddress-based bulletin board transmission request was received but data was not present in the subaddress confidential box.
<b>U00434</b>	Confidential polling request was received but interrupted because the specified confidential box No. was intended for encryption.
<b>U00435</b>	Confidential polling request was received but interrupted because the specified confidential box was being accessed. Or, subaddress-based bulletin board transmission request was received but interrupted because the specified subaddress confidential box was being accessed.
<b>U00440</b>	Confidential reception was interrupted because the specified confidential box No. was not registered. Or, subaddress-based confidential reception or subaddress-based relay reception was interrupted because the specified subaddress box was not registered. Or, subaddress based confidential reception or subaddress relay command reception was interrupted because the specified subaddress box No. was being accessed.
<b>U00441</b>	Confidential reception was interrupted because the specified confidential box No. was intended for encryption.
<b>U00450</b>	The destination transmitter disconnected because the permit ID's did not agree with while the destination transmitter is in password-check transmission or restricted transmission.
<b>U00460</b>	Encrypted reception was interrupted because the specified encryption box number was not registered. Or, encrypted reception request was received but interrupted because the specified encryption box was being accessed.
<b>U00462</b>	Encrypted reception was interrupted because the encryption key for the specified encryption box was not registered.

**(2-2) U006XX error code table: Problems with the unit**

Error code	Description
<b>U00600</b>	The document processor cover is open.
<b>U00601</b>	Document jam or the document length exceeds the maximum.
<b>U00602</b>	Image scanning section problem.
<b>U00603</b>	No document feed.
<b>U00604</b>	Document length exceeded the limit of the bitmap memory capacity.
<b>U00610</b>	Recording section cover is open.
<b>U00611</b>	Recording paper JAM
<b>U00613</b>	Image writing section problem
<b>U00614</b>	Nearly empty of recording paper
<b>U00615</b>	Empty of recording paper
<b>U00620</b>	Copier fixing unit problem
<b>U00622</b>	Copier drive motor problem
<b>U00655</b>	CTS was not activated after RTS due to a modem error.
<b>U00656</b>	Data was not transmitted after CTS was activated due to a modem error.
<b>U00670</b>	Power was cut off during communication.
<b>U00677</b>	There was no file to transmit in the memory transmission mode.
<b>U00690</b>	System error.

**(2-3) U008XX error code table: Page transmission error**

Error code	Description
<b>U00800</b>	A page transmission error occurred because of reception of a RTN or PIN signal.
<b>U00810</b>	A page transmission error reoccurred after retry of transmission in the ECM mode.

**(2-4) U009XX error code table: Page reception error**

Error code	Description
<b>U00900</b>	An RTN or PIN signal was transmitted because of a page reception error.
<b>U00910</b>	A page reception error remained after retry of transmission in the ECM mode.

**(2-5) U010XX error code table: G3 transmission**

<b>Error code</b>	<b>Description</b>
<b>U01000</b>	An FTT signal was received for a set number of times after TCF signal transmission at 2400 bps. Or, an RTN signal was received in response to a Q signal (excluding EOP) after transmission at 2400 bps.
<b>U01001</b>	Function of the unit differs from that indicated by a DIS signal.
<b>U01010</b>	No relevant signal was received after transmission of a DNL (MPS or EOM) signal, and the preset number of command retransfers was exceeded (between units of our make).
<b>U01011</b>	No relevant signal was received after transmission of a DCS, TCF signal, and the preset number of command retransfers was exceeded.
<b>U01012</b>	No relevant signal was received after transmission of an NSS1, NSS2 (TCF) signal, and the preset number of command retransfers was exceeded (between units of our make).
<b>U01013</b>	No relevant signal was received after transmission of an NSS3, TCF signal, and the preset number of command retransfers was exceeded (between units of our make).
<b>U01014</b>	No relevant signal was received after transmission of an MPS signal, and the preset number of command retransfers was exceeded.
<b>U01015</b>	No relevant signal was received after transmission of an EOM signal, and the preset number of command retransfers was exceeded.
<b>U01016</b>	An MCF signal was received but no DIS signal was received after transmission of an EOM signal, and T1 timeout was detected.
<b>U01017</b>	No relevant signal was received after transmission of an EOP signal, and the preset number of command retransfers was exceeded.
<b>U01018</b>	No relevant signal was received after transmission of a PRI-EOP signal, and the preset number of command retransfers was exceeded.
<b>U01019</b>	No relevant signal was received after transmission of a CNC signal, and the preset number of command retransfers was exceeded (between units of our make).
<b>U01020</b>	No relevant signal was received after transmission of a CTC signal, and the preset number of command retransfers was exceeded (ECM).
<b>U01021</b>	No relevant signal was received after transmission of an EOR.Q signal, and the preset number of command retransfers was exceeded (ECM).
<b>U01022</b>	No relevant signal was received after transmission of an RR signal, and the preset number of command retransfers was exceeded (ECM).
<b>U01023</b>	No relevant signal was received after transmission of a PSS.NULL signal, and the preset number of command retransfers was exceeded (ECM).
<b>U01024</b>	No relevant signal was received after transmission of a PSS.MPS signal, and the preset number of command retransfers was exceeded (ECM).
<b>U01025</b>	No relevant signal was received after transmission of a PPS.EOM signal, and the preset number of command retransfers was exceeded (ECM).
<b>U01026</b>	No relevant signal was received after transmission of a PPS.EOP signal, and the preset number of command retransfers was exceeded (ECM).
<b>U01027</b>	No relevant signal was received after transmission of a PPS.PRI-EOP signal, and the preset number of command retransfers was exceeded (ECM).
<b>U01028</b>	T5 time-out was detected during ECM transmission (ECM).

Error code	Description
<b>U01040</b>	A DCN or other inappropriate signal was received during standby for DIS signal reception.
<b>U01041</b>	A DCN signal was received after transmission of a DNL (MPS or EOM) signal (between units of our make).
<b>U01042</b>	A DCN signal was received after transmission of a DCS, TCF signal.
<b>U01043</b>	A DCN signal was received after transmission of an NSS1, NSS2 (TCF) signal (between units of our make).
<b>U01044</b>	A DCN signal was received after transmission of an NSS3, TCF signal (between units of our make).
<b>U01045</b>	A DCN or other inappropriate signal was received after transmission of an MPS signal.
<b>U01046</b>	A DCN or other inappropriate signal was received after transmission of an EOM signal.
<b>U01047</b>	A DCN or other inappropriate signal was received after transmission of an EOP signal.
<b>U01048</b>	A DCN signal was received after transmission of a PRI-EOP signal.
<b>U01049</b>	A DCN signal was received after transmission of a CNC signal (between units of our make).
<b>U01050</b>	A DCN signal was received after transmission of a CTC signal (ECM).
<b>U01051</b>	A DCN signal was received after transmission of an EOR.Q signal (ECM).
<b>U01052</b>	A DCN signal was received after transmission of an RR signal (ECM).
<b>U01053</b>	A DCN signal was received after transmission of a PPS.NULL signal (ECM).
<b>U01054</b>	A DCN signal was received after transmission of a PPS.MPS signal (ECM).
<b>U01055</b>	A DCN signal was received after transmission of a PPS.EOM signal (ECM).
<b>U01056</b>	A DCN signal was received after transmission of a PPS.EOP signal (ECM).
<b>U01057</b>	A DCN signal was received after transmission of a PPS.PRI-EOP signal (ECM).
<b>U01070</b>	Polarity reversal was detected during handshake.
<b>U01071</b>	Polarity reversal was detected during message transmission.
<b>U01072</b>	A break in loop current was detected during transmission.
<b>U01073</b>	During reverse polling in V.34 mode at the receiver unit, a CM signal was not detected when transmitting after reception.
<b>U01080</b>	A PIP signal was received after transmission of a PPS.NULL signal.
<b>U01091</b>	During transmission in V.34 mode, communication was interrupted because a PPR signal was received over 10 times even after reducing the communication speed to the minimum with the symbol speed maintained at the level of connection.
<b>U01092</b>	During transmission in V.34 mode, communication was interrupted because of an impossible combination of the symbol speed and communication speed.

**(2-6) U011XX error code table: G3 reception**

<b>Error code</b>	<b>Description</b>
<b>U01100</b>	Function of the unit differs from that indicated by a DCS signal.
<b>U01101</b>	Function of the unit (excl. communication mode select) differs from that indicated by an NSS signal.
<b>U01102</b>	A DTC (NSC) signal was received when no transmission data was in the unit.
<b>U01110</b>	No response after transmission of a DIS signal.
<b>U01111</b>	No response after transmission of a DTC (NSC) signal.
<b>U01112</b>	No training reception after reception of a DCS or NSS signal.
<b>U01113</b>	No response after transmission of an FTT signal.
<b>U01114</b>	No message reception after transmission of a CFR signal.
<b>U01115</b>	No message reception after transmission of an MCF signal.
<b>U01116</b>	No message reception after transmission of a PPR signal.
<b>U01117</b>	No message reception after transmission of a CTR signal.
<b>U01118</b>	No message reception after transmission of an ERR signal.
<b>U01119</b>	No further signals were received after reception of a message.
<b>U01120</b>	No response after transmission of an MCF signal.
<b>U01121</b>	No response after transmission of an RTP signal.
<b>U01122</b>	No response after transmission of an RTN signal.
<b>U01123</b>	No response after transmission of a PIP signal.
<b>U01124</b>	No response after transmission of a PIN signal.
<b>U01125</b>	No response after transmission of a CNS signal (between units of our make).
<b>U01126</b>	No response after transmission of a PPR signal (ECM).
<b>U01127</b>	No response after transmission of an ERR signal (ECM).
<b>U01128</b>	No response after transmission of an RNR signal (ECM).
<b>U01129</b>	No response after transmission of an SPA signal (short protocol).
<b>U01140</b>	A DCN signal was received after transmission of a DIS signal.
<b>U01141</b>	A DCN signal was received after transmission of a DTC signal.
<b>U01142</b>	A DCN signal was received after transmission of a DCS or NSS signal.
<b>U01143</b>	A DCN signal was received after transmission of an FTT signal.
<b>U01144</b>	A DCN signal was received after transmission of a CFR signal.
<b>U01145</b>	A DCN signal was received after reception of a message.
<b>U01146</b>	A DCN signal was received after transmission of an MCF signal (interoffice communication after reception of an MPS, EOM signal or confidential interoffice communication).
<b>U01147</b>	A DCN signal was received after transmission of an RTP signal.
<b>U01148</b>	A DCN signal was received after transmission of an RTN signal.
<b>U01149</b>	A DCN signal was received after transmission of a PIP signal.
<b>U01150</b>	A DCN signal was received after transmission of a PIN signal.
<b>U01151</b>	A DCN signal was received after transmission of a PPR signal (ECM).

Error code	Description
<b>U01152</b>	A DCN signal was received after transmission of a CTR signal (ECM).
<b>U01153</b>	A DCN signal was received after transmission of an ERR signal (ECM).
<b>U01154</b>	A DCN signal was received after transmission of an RNR signal (ECM).
<b>U01155</b>	A DCN signal was received after transmission of an SPA signal (short protocol).
<b>U01160</b>	During message reception, transmission time exceeded the maximum transmission time per line.
<b>U01161</b>	Number of error lines exceeded limits during message reception.
<b>U01162</b>	A break in loop current was detected during message reception.
<b>U01163</b>	Polarity reversal was detected during message reception.
<b>U01164</b>	One page length exceeded the specified length during message reception.
<b>U01170</b>	A decoding error occurred during MMR message reception.
<b>U01172</b>	During reverse polling in V.34 mode at the transmitting unit, a JM signal was not detected after transmission of a CM signal when receiving after transmission.
<b>U01191</b>	Communication was interrupted because an error occurred during an image data reception sequence in the V.34 mode.
<b>U01199</b>	A DIS signal with different FIF was received after transmission of a DIS signal.

## (2-7) U017XX error code table: V.34 transmission

Error code	Description
<b>U01700</b>	A communication error occurred in phase 2 (line probing).
<b>U01720</b>	A communication error occurred in phase 4 (modem parameter exchange).
<b>U01721</b>	Operation was interrupted due to the absence of a common communication speed between units.

U01700: A communication error that occurs at the transmitting unit in the period after transmission of INFO0 before entering phase 3 (primary channel equivalent device training). For example, INFO0/A/Abar (B/Bbar, for polling transmission)/INFOh was not detected.

U01720: A communication error that occurs at the transmitting unit in the period after initiating the control channel before entering the T.30 process. For example, PPh/ALT/MPh/E was not detected.

U01721: In the absence of a common communication speed between units (including when an impossible combination of communication speed and symbol speed occurs) after MPh exchange; 1) a DCN signal was received from the destination unit, and the line was cut; or 2) a DIS (NSF, CSI) signal was received from the destination unit and, in response to the signal, the unit transmitted a DCN signal, and the line was cut.

**(2-8) U018XX error code table: V.34 reception**

Error code	Description
<b>U01800</b>	A communication error occurred in phase 2 (line probing).
<b>U01810</b>	A communication error occurred in phase 3 (primary channel equivalent device training).
<b>U01820</b>	A communication error occurred in phase 4 (modem parameter exchange).
<b>U01821</b>	Operation was interrupted due to the absence of a common communication speed between units.

U01800: A communication error that occurs at the receiver unit in the period after transmission of INFO0 before entering phase 3 (primary channel equivalent device training). For example, INFO0/B/Bbar (A/Abar, for polling reception)/probing tone was not detected.

U01810: A communication error that occurs at the receiver unit in phase 3 (primary channel equivalent device training).

For example, S/Sbar/PP/TRN was not detected.

U01820: A communication error that occurs at the receiver unit in the period after initiating the control channel before entering the T.30 process. For example, PPh/ALT/MPh/E was not detected.

U01821: In the absence of a common communication speed between units (including when an impossible combination of communication speed and symbol speed occurs) after MPh exchange, a DCN signal was transmitted to the destination unit and the line was cut.

**(2-9) U023XX error code table: Relay command abnormal reception**

Error code	Description
<b>U02303</b>	Timeout was detected before a correct DNL signal was received.
<b>U02304</b>	A signal other than MPS or EOM signal was received after a DNL signal was received.

**(2-10) U044XX error code table: Encrypted transmission**

Error code	Description
<b>U04400</b>	Encrypted transmission was interrupted because encryption keys did not agree.
<b>U04401</b>	Calling failed during encrypted transmission because the encryption key was not registered.

This page is intentionally left blank.



## **1-5-1 Precautions for assembly and disassembly**

### **(1) Precautions**

Before starting disassembly, press the Power key on the operation panel to off. Make sure that the Power lamp is off before turning off the power switch. Unplug the power cable from the wall outlet.

When the fax kit is installed, be sure to disconnect the modular code before starting disassembly.

When handling PWBs (printed wiring boards), do not touch parts with bare hands.

The PWBs are susceptible to static charge.

Do not touch any PWB containing ICs with bare hands or any object prone to static charge.

When removing the hook of the connector, be sure to release the hook.

Take care not to get the cables caught.

To reassemble the parts, use the original screws. If the types and the sizes of screws are not known, refer to the PARTS LIST.

### **(2) Drum unit**

Note the following when handling or storing the drum unit.

When removing the drum unit, never expose the drum surface to strong direct light.

Do not leave it for a long time even if it is weak light such as fluorescent lamps.

Keep the drum unit at an ambient temperature between -20°C/-4°F and 40°C/104°F and at a relative humidity not higher than 85% RH. Avoid abrupt changes in temperature and humidity.

Avoid exposure to any substance which is harmful to or may affect the quality of the drum unit.

Do not touch the drum surface with any object. Should it be touched by hands or stained with oil, clean it.

### **(3) Toner**

Store the toner container in a cool, dark place.

Avoid direct light and high humidity.

#### (4) How to tell a genuine Kyocera toner container

As a means of brand protection, the Kyocera toner container utilizes an optical security technology to enable visual validation. A validation viewer is required to accomplish this.

Hold the validation viewer over the left side part of the brand protection seal on the toner container. Through each window of the validation viewer, the left side part of the seal should be seen as follows:

A black-colored band when seen through the left side window ( ● )

A shiny or gold-colored band when seen through the right side window ( ☼ )

The above will reveal that the toner container is a genuine Kyocera branded toner container, otherwise, it is a counterfeit.




Figure 1-5-1

The brand protection seal has an incision as shown below to prohibit reuse.




Figure 1-5-2

## 1-5-2 Outer covers

### (1) Detaching and refitting the left cover and right cover

#### Procedure

1. Remove the screw.
2. Unhook four hooks and then remove the rear upper cover.




Figure 1-5-3

3. Remove the cassette (See page 1-5-6).
4. Open the front cover.
5. Unhook the hook and then remove the controller box cover.





Figure 1-5-4

6. Unhook seven hooks and then remove the right cover.



**Figure 1-5-5**

7. Unhook six hooks and then remove the left cover.




Figure 1-5-6

## 1-5-3 Paper feed section

### (1) Detaching and refitting the paper feed assembly (paper feed roller and pickup roller)

#### Procedure

1. Remove the cassette.




Figure 1-5-7

2. Slide the feed shaft.
3. While pressing the lever and then remove the paper feed roller assembly.





Figure 1-5-8

4. Check or replace the paper feed roller assembly and refit all the removed parts.

When refitting the paper feed roller assembly, be sure to align the paper feed roller pivot with the slotted hole on the feed shaft.



**Figure 1-5-9**

## (2) Detaching and refitting the retard roller assembly

### Procedure

1. Remove the cassette (See page 1-5-6).
2. Push the bottom plate down until it locks.
3. Unhook two hooks and then remove the retard guide.




Figure 1-5-10

4. Remove the retard roller assembly.




Figure 1-5-11



5. Check or replace the retard roller assembly and refit all the removed parts.

Caution: Before refitting the retard roller assembly, firmly install the spring onto the projection of the retard roller assembly.




Figure 1-5-12

### (3) Detaching and refitting the MP paper feed roller

#### Procedure

1. Open the front cover.
2. Pull the MP feed holder (lever) down. :1
3. Slide the MP feed holder. :2
4. Remove the MP paper feed roller. :3





Figure 1-5-13

5. Check or replace the MP paper feed roller and refit all the removed parts.

When refitting the MP paper feed roller, be sure to align the paper feed roller pivot with the slotted hole on the MPF feed shaft.

When refitting the MP paper feed roller, be sure to align the MPF feed shaft pivot with the slotted hole on the MP paper feed roller.



**Figure 1-5-14**

#### (4) Note on removing and Installing the upper registration roller and lower registration roller

When reinstalling the upper registration roller or lower registration roller, be sure to use a new registration L spring and registration R spring. Otherwise, paper feeding may be deteriorated due to the spring hooks possibly being distorted during the spring is unhooked.




Figure 1-5-15

## 1-5-4 Optical section

### (1) Detaching and refitting the DP

#### Procedure

1. Pull the DP out.




Figure 1-5-16

## (2) Detaching and refitting the scanner unit

### Procedure

1. Remove the DP (See page 1-5-13).
2. Remove the left cover and right cover (See page 1-5-3).
3. Remove the FFC and connector from the control PWB.
4. Remove three connectors from the scanner PWB.






Figure 1-5-17


5. Release three clamps and then remove the wires.

**Figure 1-5-18**

6. Remove two screws.

**Figure 1-5-19**

7. Unhook four hooks and then remove the scanner unit.



**Figure 1-5-20**



### (3) Detaching and refitting the laser scanner unit (LSU)

#### Procedure

1. Remove the scanner unit (See page 1-5-14).
2. Remove the screw and then remove the grounding terminal.
3. Remove three connectors from the control PWB.




Figure 1-5-21

4. Remove the wires from three clamps.
5. Remove the connector from the power source PWB.




Figure 1-5-22

6. Unhook four hooks and then remove the frame left duct.
7. Remove the wires from the clamp.






Figure 1-5-23

8. Release the hook and then remove the top cover rack-L from the top cover.




**Figure 1-5-24**

9. Remove four screws from the top cover.




**Figure 1-5-25**

10. Unhook two hooks and then remove the top cover.



**Figure 1-5-26**

11. Release the clamp and then pull out the wires.  
 12. Remove four screws and then remove the laser scanner unit (LSU).  
 13. Check or replace the laser scanner unit (LSU) and refit all the removed parts.



**Figure 1-5-27**

## (4) Replacing the image scanner unit (ISU)

### Procedure

#### Removing the image scanner unit (ISU)

1. Remove the DP (See page 1-5-13).
2. Unhook two hooks by using a flat screwdriver from the pits.
3. Remove the connector and then remove the operation panel.




Figure 1-5-28

4. Remove two screws.
5. Unhook three hooks and then remove the ISU upper frame.




Figure 1-5-29

6. Move the image scanner unit (ISU) in the middle of the ISU shaft.
7. Detach the ISU shaft from the holder by lifting it.
8. Pull the ISU shaft out from the ISU.




Figure 1-5-30

9. Remove the ISU belt from the tension pulley and ISU gear 63/32.
10. Remove the ISU belt from the hooks of the ISU.




Figure 1-5-31

11. Remove the FFC center stopper.




Figure 1-5-32

- 12. Remove the FFC from the FFC tape D.
- 13. Remove the ferrite core from the pit.
- 14. Remove the FFC from the FFC tape A.




Figure 1-5-33

15. Fold the end of the FFC and then pull the FFC out from the ISU lower frame.
16. Remove the FFC tape D and A from the ISU lower frame.
17. Clean the adhesive residue of the FFC tape D and A.




Figure 1-5-34

18. Remove the ferrite core from the FFC.





Figure 1-5-35




**Installing the image scanner unit (ISU)**

1. Peel off the protective seal on one side from the FFC tape D.
2. Stick the FFC tape D on the ISU lower frame, aligned with the marking of the frame.  
(Sticking standards: See right figure)
3. Peel off the protective seal on the other side of the FFC tape A.
4. Stick the FFC tape A on the ISU lower frame.  
(At the right for how to correctly stick the tape in position, see the figure.)

**Figure 1-5-36**

5. Fix the ferrite core onto the FFC.

**Figure 1-5-37**

6. Peel off the protective seal from the FFC tape D.
7. Align the line marking on the FFC with the rib on the ISU lower frame, then fix the FFC to the FFC tape D.
8. Install the ferrite core in the pit.
9. Peel off the released paper from the FFC tape A.
10. Stick the FFC on the FFC tape A.




Figure 1-5-38

11. Thread an end of the FFC through the ISU lower frame.
12. Refer to the step 11 to 1 and refit all the removed parts.

**NOTE:**

When the replacing the image scanner unit (ISU), perform following maintenance modes.

1. U425 Setting the target (see page 1-3-41)
2. U411 Adjusting the scanner automatically (see page 1-3-38)




Figure 1-5-39

## 1-5-5 Developer section

### (1) Detaching and refitting the developer unit

#### Procedure

1. Open the front cover.
2. Remove the developer unit.
3. Check or replace the developer unit and refit all the removed parts.

#### NOTE:

When the periodic maintenance (replacing the maintenance kit, see page 2-4-4), perform following maintenance modes.

1. U251 Clearing the maintenance count (see page 1-3-30)




Figure 1-5-40

## 1-5-6 Drum section

### (1) Detaching and refitting the drum unit

#### Procedure

1. Remove the developer unit (See page 1-5-27).
2. Remove the drum unit.
3. Check or replace the drum unit and refit all the removed parts.

#### NOTE:

When the periodic maintenance (replacing the maintenance kit, see page 2-4-4), perform following maintenance modes.

1. U251 Clearing the maintenance count (see page 1-3-30)




Figure 1-5-41

## (2) Detaching and refitting the main charger unit

### Procedure

1. Remove the developer unit (See page 1-5-27).
2. Remove the drum unit (See page 1-5-28).
3. Remove the tape.
4. While pushing on the main plate 1, slide the main charger unit 2.




Figure 1-5-42

5. Remove the main charger unit by lifting it.
6. Check or replace the main charger unit and refit all the removed parts.




Figure 1-5-43

## 1-5-7 Transfer/separation section

### (1) Detaching and refitting the transfer roller

#### Procedure

1. Remove the developer unit (See page 1-5-27).
2. Remove the drum unit (See page 1-5-28).
3. Slide the paper chute guide and unhook the hooks.
4. Remove the paper chute guide.





Figure 1-5-44

5. Remove the transfer roller's shaft from the both transfer bushes.
6. Remove the gear Z16 from the transfer roller.




Figure 1-5-45

7. Check or replace the transfer roller and refit all the removed parts.

Caution: When refitting the transfer roller, be careful about following point. Push the release lever to raise the lever end, then insert the front of gear Z16 under the release lever end.




Figure 1-5-46

## 1-5-8 Fuser section

### (1) Detaching and refitting the fuser unit

#### Procedure

1. Remove the left cover and right cover  
(See page 1-5-3).
2. Remove the wires from three clamps.
3. Remove the connector from the power source PWB.




Figure 1-5-47

4. Unhook four hooks and then remove the frame left duct.
5. Remove the wires from the clamp.





Figure 1-5-48




6. Remove the connector from the power source PWB.



**Figure 1-5-49**

7. Remove the connector from the control PWB.



**Figure 1-5-50**

8. Remove the rear cover.




Figure 1-5-51

9. Remove two screws and then remove the fuser unit.




Figure 1-5-52

10. Check or replace the fuser unit and refit all the removed parts.

Caution: When reinstalling the fuser unit, tighten up a screw while pressing the fuser unit in order of 1 to 2.




Figure 1-5-53

## (2) Switching the fuser pressure

The fuser pressure may be decreased to suppress the print quality problems such as paper creases and curls.

It must be cautioned that decreasing the fuser pressure could cause loose toner fusing.

### Procedure

1. Remove the cassette (See page 1-5-6).
2. Open the duplex cover.
3. Slide the fuser lever R and L.

Normal: Flush with the front of the machine.

Fuser pressure decreased: Flush with the rear of the machine.






Figure 1-5-34

## 1-5-9 PWBs

### (1) Detaching and refitting the control PWB

## Procedure

1. Remove the FAX control PWB.  
(See page 1-5-48)
2. Remove the right cover.  
(See page 1-5-3)
3. Remove the five connectors from the scanner PWB.
4. Remove twenty connectors and two FFCs from the control PWB.
5. Remove the wires from the clamp.



**Figure 1-5-55**

6. Remove five screws and the grounding terminal and then remove the control box.




Figure 1-5-56

7. Remove seven screws and the grounding terminal and then remove the control PWB.





Figure 1-5-57

8. Check or replace the control PWB and refit all the removed parts.

To replace the control PWB, remove the EEPROM (U17) from the old control PWB and mount it to the new control PWB.



**Figure 1-5-58**

## (2) Detaching and refitting the power source PWB

### Procedure

1. Remove the left cover (See page 1-5-3).
2. Remove the wires from three clamps.
3. Remove five connectors from the power source PWB.




Figure 1-5-59

4. Unhook four hooks and then remove the frame left duct.
5. Remove the wire from the clamp.




Figure 1-5-60



6. Remove the screw and then detach the inlet mount.




Figure 1-5-61

7. Remove five screws.
8. Remove two connectors and then remove the power source PWB assembly.




Figure 1-5-62

9. Remove four screws and then remove the power source PWB from the power source PWB plate.
10. Check or replace the power source PWB and refit all the removed parts.

Caution: The power source PWB sheet must be installed in the specified position.




Figure 1-5-63

### (3) Detaching and refitting the high voltage PWB

#### Procedure

1. Remove the developer unit (See page 1-5-27).
2. Remove the drum unit (See page 1-5-28).
3. Remove the cassette (See page 1-5-6).
4. Remove the left cover and right cover (See page 1-5-3).
5. Remove the power source PWB (See page 1-5-40).
6. Turn the machine with the front side up.
7. Remove the stopper.
8. Remove the DU holder.




Figure 1-5-64

9. Pull the DU bush out.
10. Remove the DU cover assembly.





Figure 1-5-65

11. Remove four screws.
12. Unhook three hooks and then remove the lower base cover.

**Figure 1-5-66**

13. Remove the spring.
14. Remove the cassette pin.




Figure 1-5-67

15. Remove two connectors and then remove the high voltage PWB.
16. Remove the cassette pin holder from the high voltage PWB.




Figure 1-5-68

17. Check or replace the high voltage PWB and refit all the removed parts.

When refitting the high voltage PWB, be careful about following points.

- Position the ground plate so that it is atop the high voltage PWB.
- Each interface is firmly in contact with each spring.
- The bias contact pin must be installed in the specified position.
- The cassette pin must be inserted in the cassette pin holder.




Figure 1-5-69

#### (4) Detaching and refitting the scanner PWB

##### Procedure

1. Remove the right cover (See page 1-5-3).
2. Remove six connectors and the FFC from the scanner PWB.




Figure 1-5-70

3. Remove four screws and then remove the scanner PWB.
4. Check or replace the scanner PWB and refit all the removed parts.

##### NOTE:

When replacing the scanner PWB, perform the following maintenance modes.

1. U425 Setting the target (see page 1-3-41)
2. U411 Adjusting the scanner automatically (see page 1-3-38)




Figure 1-5-71

## (5) Detaching and refitting the FAX control PWB

### Procedure

1. Open the rear cover.
2. Unhook the hook and then remove the controller box cover.




Figure 1-5-72

3. Remove two screws and then remove the FAX control PWB.
4. Check or replace the FAX control PWB and refit all the removed parts.




Figure 1-5-73



## 1-5-10 Others

### (1) Detaching and refitting the main motor

#### Procedure

1. Remove the right cover (See page 1-5-3).
2. Remove the connector.
3. Remove the M3 screw and two M4 screws.
4. Remove the main motor.
5. Check or replace the main motor and refit all the removed parts.






Figure 1-5-74

**(2) Direction of installing the left cooling fan motor, right cooling fan motor**

When detaching or refitting a fan motor, be careful of the airflow direction (intake or exhaust).



**Figure 1-5-75**

## 1-5-11 Document processor

### (1) Detaching and refitting the DP rear cover and DP front cover

#### Procedure

1. Open the DP top cover.
2. Remove two screws.
3. Unhook the hook and then remove the DP rear cover.




Figure 1-5-76

4. Unhook two hooks and then remove the DP front cover.




Figure 1-5-77

## (2) Detaching and refitting the DP drive PWB

Follow the procedure below to check or replace the DP drive PWB.

### Procedure

1. Remove the DP rear cover.  
(See page 1-5-51).
2. Remove eight connectors from the DP drive PWB.
3. Remove the screw and then remove the DP drive PWB.
4. Check or replace the DP drive PWB.  
Refit all the removed parts.




Figure 1-5-78

### (3) Detaching and refitting the feed pulley and forwarding pulley

Follow the procedure below to clean or replace the feed pulley or forwarding pulley.

#### Procedure

1. Remove the DP rear cover and DP front cover (See page P.1-5-51).
2. Remove the stopper.
3. Remove the bush.




Figure 1-5-79

4. Remove the stopper A and then remove the DP paper feed clutch.
5. Remove the stopper B and then remove the PF collar, spring, spring collar S, pin and bush from the PF shaft.




Figure 1-5-80

6. Remove the forwarding pulley assembly.




Figure 1-5-81

#### Detaching the feed pulley

7. Remove the stopper A.
8. Remove the feed pulley assembly from the LF holder.
9. Remove the stopper B.
10. Remove the PF collar, spring, spring collar S and pin from the PF shaft.
11. Remove the feed pulley, one-way clutch, PF pulley gear and pin from the PF shaft.





Figure 1-5-82

**Detaching the forwarding pulley**

12. Remove the PF stopper from the LF holder.
13. Remove the stopper.
14. Pull out the LF shaft and then remove the LF gear 18, forwarding feed joint gear and forwarding pulley.
15. Clean or replace the feed pulley and forwarding pulley.  
Refit all the removed parts.

**Figure 1-5-83**

#### (4) Detaching and refitting the separation pad assembly

Follow the procedure below to clean or replace the separation pad assembly.

##### Procedure

1. Remove the forwarding pulley assembly (See page P.1-5-53).
  2. Remove the separation pad assembly.
  3. Clean or replace the separation pad assembly.
- Refit all the removed parts.




Figure 1-5-84



## 1-6-1 Upgrading the firmware

Follow the procedure below to upgrade the firmware of control PWB (main controller and engine) and scanner PWB.

### Preparation

Extract the file that has the download firmware and put them in the USB Memory.

### Procedure

1. Turn ON the power switch and confirm if the screen shows "Ready to print" then, turn OFF the power switch.
2. Insert USB memory that has the firmware in the USB memory slot.
3. Turn ON the power switch.
4. About 40 seconds later, "FW-Update" will be displayed and blinking the memory LED (this shows to start the download).
5. Display the software that now upgrading (5 minutes).

"FW- Update [CTRL]"

"[ENGJ]"

"[SCAN]"

6. Display the completion of the upgrade (Memory LED is ON condition).
7. Cut the power supply by pulling out the power cable and remove the USB memory.

\* : After the print engine farm is downloaded, it is not possible to turn it off with the power switch.




Figure 1-6-1

### Check the result of the version up

1. Output the service status by the U000 and confirm the firmware version.

### Safe-UPDATE

If the device is accidentally switched off or the USB memory is disconnected and upgrading is incomplete, perform the following.

If the power is accidentally switched off, turn the power on without removing the USB memory and perform the above steps 3 through 7.

If the USB memory is disconnected, reinsert it, then turn the power on and perform the above steps 3 through 7.

In any case, complete the steps to the end.

## Emergency-UPDATE

If Safe Update is processed to the end, the firmware update is complete. In case the message below is indicated, update the firmware after recovery with the steps below.

Note that this is unoperable when the device is operating normally.

FW-Update
Error FFFF

## Preparation

The USB memory must be formatted in FAT or FAT32 in advance.

Extract the main firmware to download from the file.

Rename the file which was extracted from the archive.

[DL\_CTRL.2PK] to [KM\_EMRG.2PK] : 3 in 1 model

[DL\_CTRL.2PL] to [KM\_EMRG.2PL] : 4 in 1 model

Copy the all extracted files to the root of the USB memory.

## Procedure

1. Turn the main power switch off.
2. Insert the USB memory which contains the firmware into the USB memory slot.
3. Turn the main power switch on.
4. Rewriting of the PWB software will start for restoration.  
"Emergency Update" is displayed on the LCD of the operation panel.
5. "Completed" will be displayed when rewriting is successful.  
\* : "Failed" will be displayed when rewriting is failed.
6. Turn the main power switch off.
7. Wait for several seconds and then remove the USB memory from the USB memory slot.
8. Extract the firmware to download from the archive and copy to the root of the formatted USB memory.

**NOTE:** Deletes the "ES\_SKIP.on" file  
When it is contained directly under the USB memory.





Figure 1-6-2

9. Insert the USB memory in which the firmware was copied in the USB memory slot.
10. Perform steps 3 to 7 on the previous page.
11. Turn the main power switch on.
12. Perform maintenance item U000 (Print a maintenance report) to check that the version of ROM U019 has been upgraded.

## 1-6-2 Remarks on control PWB replacement


When replacing the control PWB, remove the EEPROM (U17) from the control PWB that has been removed and then reattach it to the new control PWB.



**Figure 1-6-3**

### Detaching of EEPROM

1. The flat screwdriver is inserted between EEPROM and socket.
2. Detach it little by little right and left and alternately while noting the transformation and the damage of the pin.




**Figure 1-6-4**



## 2-1-1 Paper feed/conveying section


Paper feed/conveying section consists of the paper feed unit that feeds paper from the cassette and the MP tray paper feed unit that feeds paper from the MP tray, and the paper conveying section that conveys the fed paper to the transfer/separation section.

### (1) Cassette paper feed section



**Figure 2-1-1 Cassette paper feed section**

- |                      |                             |
|----------------------|-----------------------------|
| 1. Pickup roller     | 7. Bottom plate             |
| 2. Paper feed roller | 8. Bottom pad               |
| 3. Feed holder       | 9. Cassette base            |
| 4. Retard roller     | 10. Paper sensor            |
| 5. Retard holder     | 11. Actuator (paper sensor) |
| 6. Retard guide      |                             |



**Figure 2-1-2 Cassette paper feed section block diagram**

## (2) MP tray paper feed section




Figure 2-1-3 MP tray paper feed section

- |                               |                     |
|-------------------------------|---------------------|
| 1. MP paper feed roller       | 8. MPF frame        |
| 2. MPF separation pad         | 9. MPF guide R/L    |
| 3. MPF separator              | 10. MPF base        |
| 4. MPF bottom plate           | 11. MPF middle tray |
| 5. MPF friction pad           | 12. MPF upper tray  |
| 6. MP paper sensor            | 13. MPF turn guide  |
| 7. Actuator (MP paper sensor) |                     |






Figure 2-1-4 MP tray paper feed section block diagram

**(3) Paper conveying section****Figure 2-1-5 Paper conveying section**

1. Lower registration roller
2. Upper registration roller
3. Registration sensor
4. Actuator (registration sensor)
5. Feed pulley

**Figure 2-1-6 Paper conveying section block diagram**


## 2-1-2 Drum section

### (1) Drum section

The durable layer of organic photoconductor (OPC) is coated over the aluminum cylinder base. The OPC tends to reduce its own electrical conductance when exposed to light. After a cyclic process of charging, exposure, and development, the electrostatic image is constituted over the OPC layer.

Since the OPC is materialized by resin, it is susceptible to damage caused by sharp edges such as a screwdriver, etc., resulting in a print quality problem. Also, finger prints can cause deterioration of the OPC layer, therefore, the drum (in the drum unit) must be handled with care. Substances like water, alcohol, organic solvent, etc., should be strictly avoided.

As with all other OPC drums, the exposure to a strong light source for a prolonged period can cause a print quality problem. The limit is approximately 500 lux for less than five minutes. If the drum (drum unit) remains removed from the machine, it should be stored in a cool, dark place.



**Figure 2-1-7 Drum unit**

1. Drum
2. Drum shaft
3. Drum cover A
4. Drum cover B



## (2) Main charger unit

As the drum rotates in a “clean (neutral)” state, its photoconductive layer is given a uniform, positive (+) corona charge dispersed by the main charger wire. Due to high-voltage scorotron charging, the charging wire can get contaminated by oxidization after a long run. Therefore, the charger wire must be cleaned at a specific interval. Cleaning the charging wire prevents print quality problems such as black streaks.




Figure 2-1-8 Main charger unit

1. Main charger shield
2. Main charger wire
3. Main charger grid
4. Main charger wire cleaner




Figure 2-1-9 Drum unit and main charger unit block diagram

## 2-1-3 Optical section

### (1) Scanner unit




Figure 2-1-10 Scanner unit

- |                         |                              |
|-------------------------|------------------------------|
| 1. ISU top frame        | 6. ISU belt                  |
| 2. ISU bottom frame     | 7. ISU shaft                 |
| 3. Contact glass        | 8. ISU gear 63/32            |
| 4. DP contact glass     | 9. ISU motor                 |
| 5. Size indicator plate | 10. Image scanner unit (ISU) |

## (2) Image scanner unit (ISU)

The original image is illuminated by the LED and scanned by the CCD image sensor in the CCD PWB (CCD-PWB) via the four mirrors and ISU lens, the reflected light being converted to an electrical signal.

If a document processor (DP) is used, the image scanner unit stops at the position of the DP contact glass and scans sequentially one row of the image on the original in synchronization with the moving timing of the original in the sub scan direction by driving the DP.




Figure 2-1-11 Image scanner unit (ISU)

- |                         |                                |
|-------------------------|--------------------------------|
| 1. Lamp mount           | 8. Mirror D                    |
| 2. ISU housing          | 9. ISU lens                    |
| 3. ISU reflector        | 10. CCD PWB (CCDPWB)           |
| 4. Transparent material | 11. LED drive PWB (LEDDRPWB)   |
| 5. Mirror A             | 12. Home position sensor (HPS) |
| 6. Mirror B             | 13. ISU shaft                  |
| 7. Mirror C             |                                |



### (3) Laser scanner unit

The charged surface of the drum is then scanned by the laser beam from the laser scanner unit. The laser beam (780 nm wavelength) beam is dispersed as the polygon motor revolves to reflect the laser beam over the drum. Various lenses and mirror are housed in the laser scanner unit, adjust the diameter of the laser beam, and focalize it at the drum surface.





Figure 2-1-13 Laser scanner unit

1. Polygon motor (mirror)
2. F- $\theta$  lens
3. F- $\theta$  lens
4. LSU mirror
5. LSU shutter
6. LSU frame
7. LSU cover



**Figure 2-1-14 Laser scanner unit**


- |                           |                                    |
|---------------------------|------------------------------------|
| 1. Polygon motor (mirror) | 6. F-θ lens                        |
| 2. Laser diode (APC PWB)  | 7. PD mirror                       |
| 3. Collimator lens        | 8. SOS lens                        |
| 4. Cylindrical lens       | 9. Pin photo diode sensor (PD PWB) |
| 5. F-θ lens               | 10. LSU mirror                     |

## 2-1-4 Developing section

The latent image constituted on the drum is developed into a visible image. The developing roller contains a 3-pole (S-NS) magnet roller and an aluminum cylinder rotating around the magnet roller. Toner attracts to the magnet sleeve since it is powdery ink made of black resin bound to iron particles. Developing blade, magnetized by magnet, is positioned approximately 0.3 mm above the magnet sleeve to constitute a smooth layer of toner in accordance with the magnet sleeve revolution.


The developing roller is applied with the AC-weighted, positive DC power source. Toner on the magnet sleeve is given a positive charge. The positively charged toner is then attracted to the areas of the drum which was exposed to the laser light. (The gap between the drum and the magnet sleeve is approximately 0.32 mm.) The non-exposed areas of the drum repel the positively charged toner as these areas maintain the positive charge.

The developing roller is also AC-biased to ensure contrast in yielding by compensating the toner's attraction and repelling action during development.



**Figure 2-1-15 Developing unit and toner container**

- |                     |                    |
|---------------------|--------------------|
| 1. Magnet sleeve    | 5. DLP screw A     |
| 2. Magnet roller    | 6. DLP screw B     |
| 3. Developing blade | 7. DLP case        |
| 4. Blade magnet     | 8. Toner container |




**Figure 2-1-16 Developing section block diagram**




## 2-1-5 Transfer/separation section

The transfer/separation section consists of the transfer roller, discharge electrode and paper chute guide. A high voltage generated by the high voltage PWB is applied to the transfer roller for transfer charging. Paper after transfer is separated from the drum.



**Figure 2-1-17 Transfer/separation section**

1. Transfer roller
2. Transfer bushes
3. Discharge electrode
4. DC brush holder
5. Paper chute guide




**Figure 2-1-18 Transfer/separation section block diagram**

## 2-1-6 Cleaning section

After the transferring process, the drum needs to be physically cleaned of toner which is residual after the development process. The cleaning blade is constantly pressed against the drum and scrapes the residual toner off to the sweep roller.


The waste toner is collected at the output end of the sweep roller and sent back to the toner container, into the waste toner reservoir.

After the drum is physically cleaned, it then must be cleaned to the electrically neutral state. This is necessary to erase any residual positive charge, ready to accept the uniform charge for the next print process. The residual charge is canceled by exposing the drum to the light emitted from the cleaning lamp (PWB). This lowers the electrical conductivity of the drum surface making the residual charge on the drum surface escape to the ground.



**Figure 2-1-19 Cleaning section**

1. Cleaning lamp (PWB)
2. Sweep roller
3. Cleaning blade



**Figure 2-1-20 Cleaning section block diagram**

## 2-1-7 Fuser section

The toner on the paper is molten and pressed into the paper as it passes between the heat roller and the press roller in the fuser unit. The heat roller has a heater inside which continuously turns on and off by the fuser thermistor to maintain the constant temperature onto the heat roller surface. The heat roller is resin coated by fluorin to prevent toner from accumulating on the roller after a long run. Care must be taken while handling the heat roller not to scratch the roller surface as doing so may result in print problems. Fuser temperature is optimized to the paper type. The heat roller has four separators (claws) which are continuously in contact with its surface. These separators (claws) prevent the paper on which toner has been fused from being wound around the heat roller causing paper jam. The press roller is made of the heat-resistant silicon rubber. This roller is used to strongly press the paper towards the heat roller by means of press springs. The temperature of the heat roller is constantly monitored by the control PWB using the fuser thermistor. Should the temperature of the heat roller exceed the predetermined value, the fuser thermal cutout is activated to effectively disconnect the heater from power.





Figure 2-1-21 Fuser unit


- |                      |                            |
|----------------------|----------------------------|
| 1. Upper fuser frame | 9. Fuser bushes            |
| 2. Lower fuser frame | 10. Press springs          |
| 3. Heat roller       | 11. Press spring holders   |
| 4. Press roller      | 12. Fuser lever L (R)      |
| 5. Fuser heater      | 13. Exit sensor            |
| 6. Fuser thermostat  | 14. Actuator (exit sensor) |
| 7. Fuser thermistor  | 15. Fuser guide pulley     |
| 8. Separators        |                            |



**Figure 2-1-22 Fuser unit block diagram**


## 2-1-8 Paper exit section

The paper exit section transports the paper which passed the fuser unit towards the top tray. The paper which passed through the fuser unit turns on the actuator (exit sensor) in the fuser unit, and is led by the guide comprised of the rear cover, frame and the FD cover guide, finally reaching the upper FD roller. The paper is delivered to the top tray by the rotation of the upper FD roller.



**Figure 2-1-23 Paper exit section**


1. Exit roller
2. Fuser exit pulley
3. Middle pulley
4. Rear cover
5. Upper FD roller
6. Exit pulley
7. FD cover
8. Top tray
9. Exit sensor
10. Actuator (exit sensor)



**Figure 2-1-24 Paper exit section block diagram**


## 2-1-9 Duplex/conveying section

The duplex/conveying section consists of conveying path which sends the paper sent from the exit section to the paper feed/conveying section when duplex printing.



**Figure 2-1-25 Duplex/conveying section**

- |                    |                            |
|--------------------|----------------------------|
| 1. DU cover B      | 6. Lower base cover        |
| 2. DU holder       | 7. Feed roller             |
| 3. Middle pulley B | 8. Feed pulley             |
| 4. DU roller       | 9. Exit sensor             |
| 5. DU cover A      | 10. Actuator (exit sensor) |



**Figure 2-1-26 Duplex/paper conveying section block diagram**



## 2-1-10 Document processor

### (1) Original feed section

The original feed section consists of the parts shown in figure. An original placed on the original table is conveyed to the original conveying section. Original is fed by the rotation of the DP forwarding pulley and DP feed pulley.




Figure 2-1-27 Original feed section

- |                         |                                   |
|-------------------------|-----------------------------------|
| 1. DP forwarding pulley | 8. Separation mount               |
| 2. DP feed pulley       | 9. Upper guide                    |
| 3. LF holder            | 10. Switchback guide              |
| 4. PF stopper           | 11. DP original sensor (DPOS)     |
| 5. Front separation pad | 12. Actuator (DP original sensor) |
| 6. LF friction plate    | 13. Original table                |
| 7. DP separation pad    |                                   |

]




Figure 2-1-28 Original feed section block diagram

## (2) Original conveying section

The original conveying section consists of the parts shown in figure. A conveyed original is scanned by the optical section (CCD) of main machine when it passes through the DP contact glass of main machine.




Figure 2-1-29 Original conveying section

- |                       |                                |
|-----------------------|--------------------------------|
| 1. Conveying roller A | 5. DP timing sensor (DPTS)     |
| 2. Conveying pulley   | 6. Actuator (DP timing sensor) |
| 3. Conveying bottom   | 7. DP contact glass            |
| 4. Reading guide      |                                |





Figure 2-1-30 Original conveying section block diagram


### (3) Original switchback/eject sections

The original switchback/eject sections consists of the parts shown in figure. An original of which scanning is complete is ejected to the original eject table by the eject roller. In the case of duplex switchback scanning, an original is conveyed temporarily to the switchback tray and conveyed again to the original conveying section by the switchback roller.



**Figure 2-1-31 Original switchback/eject sections**

- |                       |                             |
|-----------------------|-----------------------------|
| 1. Conveying roller B | 7. Original eject table     |
| 2. Conveying pulley   | 8. Switchback guide         |
| 3. DP base            | 9. Switchback roller        |
| 4. Eject roller       | 10. Switchback pulley       |
| 5. Eject pulley       | 11. Switchback pulley mount |
| 6. PF housing         | 12. Switchback tray         |




**Figure 2-1-32 Original switchback/eject sections block diagram**

This page is intentionally left blank.

## 2-2-1 Electrical parts layout

### (1) PWBs




**Figure 2-2-1 PWBs**

- |                                      |  |
|--------------------------------------|--|
| 1. Control PWB (CONPWB).....         | Main controller: Controls the software such as the print data processing and provides the interface with computers.<br>Engine: Controls machine hardware such as high voltage/bias output control, paper conveying system control, and fuser temperature control, etc. |
| 2. Power source PWB (PSPWB) .....    | After full-wave rectification of AC power source input, switching for converting to 24 V DC for output. Controls the Fuser heater.   |
| 3. High voltage PWB (HVPWB) .....    | Generates main charging, developing bias and transfer bias.  |
| 4. Operation panel PWB (OPPWB) ..... | Consists the LCD, LED indicators and key switches.   |
| 5. APC PWB (APCPWB) .....            | Generates and controls the laser beam.   |
| 6. PD PWB (PDPWB) .....              | Controls horizontal synchronizing timing of laser beam.  |
| 7. Zener PWB (ZEPWB) .....           | Adjusts the drum surface potential.  |
| 8. Scanner PWB (SCPWB).....          | Controls the scanner section.  |
| 9. CCD PWB (CCDPWB).....             | Reads the image of originals.  |
| 10. LED drive PWB (LEDDRPWB) .....   | Controls the exposure lamp.  |
| 11. FAX control PWB (FCPWB).....     | Modulates, demodulates, compresses, decompresses and smoothes out image data, and converts resolution of image data.   |
| 12. LED PWB (LEDPWB) .....           | Exposes originals.   |
| 13. RFID PWB (RFPWB).....            | Reads the container information.   |

**List of correspondences of PWB names**

<b>No.</b>	<b>Name used in service manual</b>	<b>Name used in parts list</b>
<b>1</b>	Control PWB	PARTS MAIN PWB ASSY FS SP
<b>1</b>	Control PWB	PARTS MAIN PWB ASSY FS SP EU
<b>2</b>	Power source PWB	PARTS SWITCHING REGULATOR 120V SP
<b>2</b>	Power source PWB	PARTS SWITCHING REGULATOR 230V SP
<b>3</b>	High voltage PWB	HIGH VOLTAGE UNIT
<b>4</b>	Operation panel PWB	PARTS PANEL PWB ASSY SP
<b>5</b>	APC PWB	-
<b>6</b>	PD PWB	-
<b>7</b>	Zener PWB	-
<b>8</b>	Scanner PWB	PARTS SCANNER PWB ASSY SP
<b>9</b>	CCD PWB	-
<b>10</b>	LED drive PWB	-
<b>11</b>	FAX control PWB	PARTS MAIN FAX ASSY U SP
<b>11</b>	FAX control PWB	PARTS MAIN FAX ASSY E SP
<b>12</b>	LED PWB	-
<b>13</b>	RFID PWB (RFPWB)	PARTS PWB RFID ASSY SP


## (2) Switches and sensors



**Figure 2-2-2 Switches and sensors**

- |                                     |   |
|-------------------------------------|---|
| 1. Power switch (MSW).....          | Switches of main body operation.  |
| 2. Interlock switch (ILSW) .....    | Shuts off 24 V DC power line when the front cover is opened.  |
| 3. Cassette switch (COCSW).....     | Detects open/close cassette.  |
| 4. Registration sensor (RS).....    | Detects the timing of primary paper feed.   |
| 5. Paper sensor (PS) .....          | Detects the presence of paper in the cassette.  |
| 6. MP paper sensor (MPPS) .....     | Detects the presence of paper on the MP tray.   |
| 7. Exit sensor (ES) .....           | Detects paper jam in the fuser or duplex conveying section.   |
| 8. Home position sensor (HPS) ..... | Detects the ISU in the home position.   |
| 9. Toner sensor (TS) .....          | Detects the quantity of toner in a toner container.   |
| 10. Waste toner sensor (WTS).....   | Detects when the waste toner reservoir (Drum unit) is full.   |
| 11. Fuser thermistor (FTH) .....    | Measures the heat roller temperature.   |
| 12. Fuser thermostat (FTS).....     | Shuts off the power source to the Fuser heater when the heat roller reaches extremely high temperature. |


### (3) Other electrical components



**Figure 2-2-3 Other electrical components**

- |  |   |
|--|---|
| 1. Main motor (MM).....                  | Drives the paper feed/conveying section and fuser unit.       |
| 2. Polygon motor (PM) .....              | Drives the polygon mirror.                                    |
| 3. ISU motor (ISUM) .....                | Drives the ISU.   |
| 4. Right cooling fan motor (RFM).....    | Cools the interior of machine.                                |
| 5. Left cooling fan motor (LFM).....     | Cools the interior of machine.                                |
| 6. Registration clutch (RCL).....        | Controls the secondary paper feed.                            |
| 7. Paper feed clutch (PFCL) .....        | Controls the paper cassette paper feed.                       |
| 8. Developing clutch (DEVCL) .....       | Controls the toner feed.                                      |
| 9. Duplex solenoid (DUCL) .....          | Controls the paper conveying at the duplex conveying section. |
| 10. MP paper feed solenoid (MPPFSOL) ... | Controls the MPF bottom plate of the MP tray.                 |
| 11. Fuser heater (FH) .....              | Heats the heat roller.  |
| 12. Cleaning lamp (CL) .....             | Eliminates the residual electrostatic charge on the drum.     |
| 13. Speaker (SP).....                    | Outputs buzzer, monitoring and speaker sounds.                |



**(4) Document processor****Figure 2-2-4 Document processor**

1. DP drive PWB (DPDPWB)..... Consists the solenoids and clutch driver circuit and wiring relay circuit.
2. DP original sensor (DPOS) ..... Detects the presence of an original.
3. DP timing sensor (DPTS)..... Detects the original scanning timing.
4. DP open/close sensor (DPOCS)..... Detects the opening/closing of the DP.
5. DP paper feed motor (DPPFM)..... Drives the original feed section.
6. DP paper feed clutch (DPPFCL)..... Controls the drive of the forwarding pulley and feed pulley.
7. DP switchback solenoid (DPSBSOL).... Operates the switchback guide.
8. DP pressure solenoid (DPPRSOL) ..... Operates the switchback pulley.

**List of correspondences of PWB names**

No.	Name used in service manual	Name used in parts list
1	DP drive PWB	PARTS DRIVER PWB ASSY SP

This page is intentionally left blank.

## 2-3-1 Power source PWB




Figure 2-3-1 Power source PWB block diagram





Figure 2-3-2 Power source PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
<b>YC101</b> Connected to the AC inlet	1	NEUTRAL	I	120 V AC 220 - 240 V AC	AC power input
	2	LIVE	I	120 V AC 220 - 240 V AC	AC power input
<b>YC102</b> Connected to the Fuser heater	1	LIVE	O	120 V AC 220 - 240 V AC	Fuser heater output
	2	NEUTRAL	O	120 V AC 220 - 240 V AC	Fuser heater output
<b>YC103</b> Connected to the high voltage PWB	1	+24V0	O	24 V DC	24 V DC power source
	2	SGND	-	-	Ground
	3	FAN	I	0/24 V DC	Left cooling fan motor: On/Off
	4	THERM	O	Analog	Fuser thermistor detection voltage
	5	+3.3V1E	I	3.3 V DC	3.3 V DC power source
	6	HEATN	I	0/3.3 V DC	Fuser heater: On/Off
	7	SLEEP	I	0/3.3 V DC	Sleep mode signal: On/Off
	8	ZCROSS	O	0/3.3 V DC (pulse)	Zero cross signal
	9	+24V0IL	O	24 V DC	24 V DC power source (via interlock switch)
	10	+24V0IL	O	24 V DC	24 V DC power source (via interlock switch)
	11	PGND	-	-	Ground
	12	PGND	-	-	Ground
<b>YC104</b> Connected to the left cooling fan motor	1	+24V0	O	24 V DC	24 V DC power source
	2	FAN	O	0/24 V DC	Left cooling fan motor: On/Off
<b>YC105</b> Connected to the fuser thermistor	1	+3.3V1E	O	3.3 V DC	3.3 V DC power source
	2	N.C.	-	-	Not used
	3	THERM	I	Analog	Fuser thermistor detection voltage
<b>YC106</b> Connected to the scanner PWB	1	+24V0F	O	24 V DC	24 V DC power source
	2	N.C.	-	-	Not used
	3	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
YC108	1	-	-	-	Frame ground (Control PWB)
Connected to the ground terminals	2	-	-	-	Frame ground (Frame)
	3	-	-	-	Frame ground (Frame)

## 2-3-2 Control PWB



**Figure 2-3-3 Control PWB block diagram**




Figure 2-3-4 Control PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
<b>YC3</b> Connected to USB host	1	VBUS	O	5 V DC	5 V DC power source
	2	DATA -	I/O	-	USB data signal
	3	DATA +	I/O	-	USB data signal
	4	GND	-	-	Ground
<b>YC6</b> Connected to the scanner PWB	1	+12V3	O	12 V DC	12 V DC power source
	2	GND	-	-	Ground
	3	HPSW	O	0/3.3 V DC	Home position sensor: On/Off
	4	GND	-	-	Ground
	5	NC	-	-	Not used
	6	LAMP	I	0/24 V DC	Exposure lamp drive signal
<b>YC7</b> Connected to the opera- tion panel PWB	1	GND	-	-	Ground
	2	PANCTS	I	0/3.3 V DC (pulse)	Transmitting enable signal
	3	PANRTS	O	0/3.3 V DC (pulse)	Receiving enable signal
	4	+3.3V1C	O	0/3.3 V DC	Home position sensor: On/Off
	5	PANRXD	I	0/3.3 V DC (pulse)	Operation panel PWB receiving data
	6	PANTXD	O	0/3.3 V DC (pulse)	Operation panel PWB transmitting data
	7	FPRSTN	O	3.3/0 V DC	Operation panel PWB reset signal
	8	GND	-	-	Ground
	9	POWERKEY	I	3.3/0 V DC	Power key input signal
	10	+5V1C	O	5 V DC	5 V DC power source
<b>YC8</b> Connected to the CCD PWB	1	LAMP	O	0/24 V DC	Exposure lamp drive signal
	2	NC	-	-	Not used
	3	GND	-	-	Ground
	4	GND	-	-	Ground
	5	HPSW	I	0/3.3 V DC	Home position sensor: On/Off
	6	+3.3V3C	O	3.3 V DC	3.3 V DC power source
	7	NC	-	-	Not used
	8	CCDRSN	O	LVDS	CCD reset signal (-)
	9	CCDRSP	O	LVDS	CCD reset signal (+)
	10	NC	-	-	Not used
	11	CCDCLPP	O	LVDS	CCD reset signal (-)
	12	CCDCLPN	O	LVDS	CCD reset signal (+)
	13	NC	-	-	Not used
	14	CCDPH1N	O	LVDS	CCD shift register clock signal (-)
	15	CCDPH1P	O	LVDS	CCD shift register clock signal (+)
	16	NC	-	-	Not used



Connector	Pin	Signal	I/O	Voltage	Description
<b>YC8</b>	17	CCDPH2P	O	LVDS	CCD shift register clock signal (-)
Connected to the CCD PWB	18	CCDPH2N	O	LVDS	CCD shift register clock signal (+)
	19	NC	-	-	Not used
	20	CCDSH	O	LVDS	CCD shift gate signal (-)
	21	CCDSW	O	LVDS	CCD color/BW change signal (+)
	22	GND	-	-	Ground
	23	CCDDATAR	I	LVDS	CCD image output signal (Red)
	24	GND	-	-	Ground
	25	CCDDATAG	I	LVDS	CCD image output signal (Green)
	26	GND	-	-	Ground
	27	CCDDATAB	I	LVDS	CCD image output signal (Blue)
	28	GND	-	-	Ground
	29	+12V3	O	12 V DC	12 V DC power source (For exposure lamp)
	30	GND	-	-	Ground
	31	+5V3E2	O	5 V DC	5 V DC power source
	32	+5V3E2	O	5 V DC	5 V DC power source
<b>YC9</b>	1	GND	-	-	Ground
Connected to the scanner PWB	2	+3.3V3C	O	3.3 V DC	3.3 V DC power source
	3	CPUCLK	I	0/3.3 V DC (pulse)	Serial communications clock signal
	4	CPUSI	I	0/3.3 V DC (pulse)	Serial communications data input
	5	CPUSO	O	0/3.3 V DC (pulse)	Serial communications data output
	6	CPUSEL	I	0/3.3 V DC	Communications select signal
	7	CPURDY	O	0/3.3 V DC	Communications ready signal
	8	OVANOHL	O	0/3.3 V DC	Communications ready signal
	9	PAGESET	O	0/3.3 V DC	Vertical synchronizing monitor signal
	10	SEGSO	I	0/3.3 V DC	Vertical synchronizing signal
	11	SSCKN	O	0/3.3 V DC (pulse)	Serial communications clock
	12	SEGS	O	0/3.3 V DC (pulse)	Serial communications data input
	13	SSBSY	I	0/3.3 V DC	Impossible transmission/Completion notice signal
	14	SSDIR	I	0/3.3 V DC	Serial communications T/R switching signal
	15	SEGIR	I	0/3.3 V DC	Serial communications interruption demand signal

Connector	Pin	Signal	I/O	Voltage	Description
<b>YC10</b> Connected to the laser scanner unit	1	+24V4IL	O	24 V DC	24 V DC power source
	2	GND	-	-	Ground
	3	PLGDRN	O	0/3.3 V DC	Polygon motor: On/Off
	4	PLGRDY	I	0/3.3 V DC	Polygon motor ready signal
	5	PLGCLK	O	0/3.3 V DC (pulse)	Polygon motor clock signal
	6	PDN	I	0/3.3 V DC (pulse)	Horizontal synchronizing signal
	7	GND	-	-	Ground
	8	VDON	O	0/3.3 V DC (pulse)	Video data signal (+)
	9	VDOP	O	0/3.3 V DC (pulse)	Video data signal (-)
	10	OUTPEN	O	0/3.3 V DC	Laser output enable signal
	11	SAMPLEN	O	0/3.3 V DC	Sample/hold timing switching signal
	12	+3.3V4A	O	3.3 V DC	3.3 V DC power source
<b>YC12</b> Connected to the speaker	1	OUT-	O	Analog	Speaker sound signal (-)
	2	OUT+	O	Analog	Speaker sound signal (+)
<b>YC16</b> Connected to the MP paper sensor	1	PILED	O	3.3 V DC	3.3 V DC power source
	2	GND	-	-	Ground
	3	HANDSN	I	0/3.3 V DC	MP paper sensor: On/Off
<b>YC17</b> Connected to the main motor	1	+24V4IL	O	24 V DC	24 V DC power source
	2	GND	-	-	Ground
	3	MMOTRDYN	I	0/3.3 V DC	Main motor ready signal
	4	MMOTCLK	O	0/3.3 V DC (pulse)	Main motor clock signal
	5	REMOTEN	O	0/3.3 V DC	Main motor: On/Off
<b>YC18</b> Connected to the paper sensor	1	PILED	O	3.3 V DC	3.3 V DC power source
	2	GND	-	-	Ground
	3	PAPER	I	0/3.3 V DC	Paper sensor: On/Off
<b>YC19</b> Connected to the exit sensor	1	-	-	-	Not used
	2	PILED	O	3.3 V DC	3.3 V DC power source
	3	GND	-	-	Ground
	4	EXITN	I	0/3.3 V DC	Exit sensor: On/Off

Connector	Pin	Signal	I/O	Voltage	Description
<b>YC20</b> Connected to the registration clutch, paper feed clutch and developing clutch	1	+24V4IL	O	24 V DC	24 V DC power source
	2	REGDRN	O	0/24 V DC	Registration clutch: On/Off
	3	+24V4IL	O	24 V DC	24 V DC power source
	4	FEDDRN	O	0/24 V DC	Paper feed clutch: On/Off
	5	+24V4IL	O	24 V DC	24 V DC power source
	6	DLPDRN	O	0/24 V DC	Developing clutch: On/Off
<b>YC21</b> Connected to the MP paper feed solenoid	1	+24V4IL	O	24 V DC	24 V DC power source
	2	MPFDRN	O	0/24 V DC	MP paper feed solenoid: On/Off
<b>YC23</b> Connected to the high voltage PWB	1	+24V0	I	24 V DC	24 V DC power source
	2	+3.3V1E	O	3.3 V DC	3.3 V DC power source
	3	ZCROSS	I	0/3.3 V DC (pulse)	Zero cross signal
	4	FAN	O	0/24 V DC	Left cooling fan motor: On/Off
	5	HEATN	O	0/3.3 V DC	Fuser heater: On/Off
	6	SLEEP	O	0/3.3 V DC	Sleep mode signal: On/Off
	7	MHVDR	O	0/3.3 V DC	Main charger output signal: On/Off
	8	RTHVDR	O	0/3.3 V DC	Transfer (reverse) bias output signal: On/Off
	9	PSEL1	O	0/3.3 V DC	Transfer (reverse) bias control signal: On/Off
	10	HVCLK	O	0/3.3 V DC (pulse)	Developing bias clock signal
	11	REGN	I	0/3.3 V DC	Registration sensor: On/Off
	12	TCNT	O	PWM	Transfer current control signal
	13	MCNT	O	PWM	Main charger output control signal
	14	THVDR	O	0/3.3 V DC	Transfer bias output signal: On/Off
	15	CASE	I	Analog	Cassette switch: On/Off
	16	THERM	I	Analog	Fuser thermistor detection voltage
	17	+24V4ILR	O	24 V DC	24 V DC power source
	18	SGND	-	-	Ground
	19	SEPA	-	-	-
<b>YC24</b> Connected to the waste toner sensor	1	+3.3V1E	O	3.3 V DC	3.3 V DC power source
	2	TNFULL	I	0/3.3 V DC	Waste toner full detection signal
	3	SGND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
<b>YC25</b> Connected to the high voltage PWB	1	+24V0IL	I	24 V DC	24 V DC power source
	2	+24V0IL	I	24 V DC	24 V DC power source
	3	PGND	-	-	Ground
	4	PGND	-	-	Ground
<b>YC26</b> Connected to the toner sensor	1	+3.3V1E	O	3.3 V DC	3.3 V DC power source
	2	EMPTY	I	0/3.3 V DC	Toner quantity detection signal
	3	SGND	-	-	Ground
<b>YC27</b> Connected to the right cooling fan motor	1	+24V0	O	24 V DC	24 V DC power source
	2	FAN	O	0/24 V DC	Right cooling fan motor: On/Off
<b>YC28</b> Connected to the eraser lamp	1	ERASER	O	0/24 V DC	Eraser lamp: On/Off
	2	ERASRW	O	24 V DC	24 V DC power source
<b>YC29</b> Connected to the duplex solenoid	1	DUDR1	O	0/24 V DC	Duplex solenoid (activate): On/Off
	2	COMMON	O	24 V DC	24 V DC power source
	3	DUDR2	O	0/24 V DC	Duplex solenoid (return): On/Off
<b>YC30</b> Connected to the optional paper feeder (PF main PWB)	1	+24V4IL	O	24 V DC	24 V DC power source
	2	PGND	-	-	Ground
	3	PFSI	I	0/3.3 V DC (pulse)	Serial communication data input signal
	4	PFSO	O	0/3.3 V DC (pulse)	Serial communication data output signal
	5	PSEL	O	0/3.3 V DC	Paper feeder selection signal
	6	+3.3V1	O	3.3 V DC	3.3 V DC power source
<b>YC32</b> Connected to the power switch	1	POWERSW	I	0/3.3 V DC	Power switch: On/Off
	2	NC	-	-	Not used
	3	GND	-	-	Ground

## 2-3-3 Scanner PWB




Figure 2-3-5 Scanner PWB block diagram




Figure 2-3-6 Scanner PWB silk-screen diagram

Connector	Pin	Signal	I/O	Voltage	Description
<b>YC101</b> Connected to the power source PWB	1	+24V0F	O	24 V DC	24 V DC power source
	2	N.C.	-	-	Not used
	3	GND	-	-	Ground
<b>YC102</b> Connected to the control PWB	1	SEGIR	O	0/3.3 V DC	Serial communications interruption demand
	2	SSDIR	O	0/3.3 V DC	Serial communications trans./recep. change
	3	SSBSY	O	0/3.3 V DC	Impossible transmission/Completion notice
	4	SEGSi	I	0/3.3 V DC (pulse)	Serial communications data output
	5	SSCKN	I	0/3.3 V DC (pulse)	Serial communications clock
	6	SEGSO	O	0/3.3 V DC	Vertical synchronizing signal
	7	PAGESET	I	0/3.3 V DC	Vertical synchronizing monitor signal
	8	OVMONOUT	I	0/3.3 V DC	Communications ready signal
	9	CPURDY	I	0/3.3 V DC	Communications ready signal
	10	CPUSEL	O	0/3.3 V DC	Communications select signal
	11	CPUSO	I	0/3.3 V DC (pulse)	Serial communications data input
	12	CPUSi	O	0/3.3 V DC (pulse)	Serial communications data output
	13	CPUCLK	O	0/3.3 V DC (pulse)	Serial communications clock signal
	14	+3.3V3C	I	3.3 V DC	3.3 V DC power source
	15	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
<b>YC103</b>	1	+12V	I	12 V DC	12 V DC power source
Connected to the control PWB	2	GND	-	-	Ground
	3	HPSW	I	0/3.3 V DC	Home position sensor: On/Off
	4	GND	-	-	Ground
	5	NC	-	-	Not used
	6	LAMP	I	0/24 V DC	Exposure lamp drive signal
<b>YC104</b>	1	SCMOT1A	O	0/24 V DC (pulse)	ISU motor drive pulse
Connected to the ISU motor	2	SCMOT2A	O	0/24 V DC (pulse)	ISU motor drive pulse
	3	SCMOT1B	O	0/24 V DC (pulse)	ISU motor drive pulse
	4	SCMOT2B	O	0/24 V DC (pulse)	ISU motor drive pulse
<b>YC105</b>	1	+3.3V3C	O	3.3 V DC	3.3 V DC power source
Connected to the DP driver PWB	2	GND	-	-	Ground
	3	TIMSWN	I	0/3.3 V DC	DP timing sensor: On/Off
	4	ORGSWN	I	0/3.3 V DC	DP original sensor: On/Off
	5	OPSWN	I	0/3.3 V DC	DP open/close sensor: On/Off
	6	DPDETN	I	0/3.3 V DC	DP installation detection signal
	7	RELSOLN	O	0/24 V DC	DP switchback pressure solenoid: (Release) On/Off
	8	PRESOLN	O	0/24 V DC	DP switchback pressure solenoid (Press.): On/Off
	9	REVSOL	O	0/24 V DC	DP switchback feedshift solenoid: On/Off
	10	FEEDCL	O	0/24 V DC	DP paper feed clutch: On/Off
<b>YC108</b>	1	MOT1A	O	0/24 V DC (pulse)	DP paper feed motor drive pulse
Connected to the DP driver PWB	2	MOT2A	O	0/24 V DC (pulse)	DP paper feed motor drive pulse
	3	MOT1B	O	0/24 V DC (pulse)	DP paper feed motor drive pulse
	4	MOT2B	O	0/24 V DC (pulse)	DP paper feed motor drive pulse
	5	+24V3	O	24 V DC	24 V DC power source
	6	GND	-	-	Ground
<b>YC109</b>	1	+24V3	O	24 V DC	24 V DC power source
Connected to the DP driver PWB	2	GND	-	-	Ground

## 2-3-4 DP drive PWB




Figure 2-3-7 DP drive PWB silk-screen diagram





Connector	Pin	Signal	I/O	Voltage	Description
<b>YC1</b> Connected to scanner PWB	1	MOT1A	I	0/24 V DC (pulse)	DPPFM drive control signal
	2	MOT2A	I	0/24 V DC (pulse)	DPPFM drive control signal
	3	MOT1B	I	0/24 V DC (pulse)	DPPFM drive control signal
	4	MOT2B	I	0/24 V DC (pulse)	DPPFM drive control signal
	5	+24V3	I	24 V DC	24 V DC power from MPWB
	6	GND	-	-	Ground
<b>YC2</b> Connected to DP open/close sensor, DP original sensor and DP timing sensor	1	PILED	O	3.3 V DC	3.3 V DC power to DPOCS
	2	GND	-	-	Ground
	3	OPSWN	I	0/3.3 V DC	DPOCS: On/Off
	4	PILED	O	3.3 V DC	3.3 V DC power to DPOS
	5	GND	-	-	Ground
	6	ORGSWN	I	0/3.3 V DC	DPOS: On/Off
	7	PILED	O	3.3 V DC	3.3 V DC power to DPTS
	8	GND	-	-	Ground
	9	TIMSWN	I	0/3.3 V DC	DPTS: On/Off
<b>YC3</b> Connected to DP paper feed motor	1	DPMOT1A	O	0/24 V DC (pulse)	DPPFM drive control signal
	2	DPMOT2A	O	0/24 V DC (pulse)	DPPFM drive control signal
	3	DPMOT1B	O	0/24 V DC (pulse)	DPPFM drive control signal
	4	DPMOT2B	O	0/24 V DC (pulse)	DPPFM drive control signal
<b>YC4</b> Connected to DP pressure solenoid	1	+24V3	O	24 V DC	24 V DC power to DPPRSOL
	2	PRESOLN	O	0/24 V DC	DPPRSOL: ON (Press)/Off
	3	RELSOLN	O	0/24 V DC	DPPRSOL: On (Release)/Off
<b>YC5</b> Connected to DP switch-back solenoid	1	+24V3	O	24 V DC	24 V DC power to DPSBSOL
	2	REVSOL	O	0/24 V DC	DPSBSOL: On/Off
<b>YC6</b> Connected to DP paper feed clutch	1	+24V3	O	24 V DC	24 V DC power to DPPFCL
	2	FEEDCL	O	0/24 V DC	DPPFCL: On/Off
<b>YC7</b> Connected to scanner PWB	1	+24V3	I	24 V DC	24 V DC power from SCPWB
	2	GND	-	-	Ground

Connector	Pin	Signal	I/O	Voltage	Description
<b>YC8</b>	1	+3.3V3C	I	3.3 V DC	3.3 V DC power from MPWB
Connected to scanner PWB	2	GND	-	-	Ground
	3	TIMSWN	O	0/3.3 V DC	DPTS: On/Off
	4	ORGSWN	O	0/3.3 V DC	DPOS: On/Off
	5	OPSWN	O	0/3.3 V DC	DPOCS: On/Off
	6	DPDETN	O	0/3.3 V DC	DP set signal
	7	RELSOLN	I	0/24 V DC	DPPRSOL: On (Release)/Off
	8	PRESOLN	I	0/24 V DC	DPPRSOL: ON (Press)/Off
	9	REVSOL	I	0/24 V DC	DPSBSOL: On/Off
	10	FEEDCL	I	0/24 V DC	DPPFCL: On/Off


## 2-4-1 Appendixes

### (1) Wiring diagram





**(2) Repetitive defects gauge**



\* : The repetitive marks interval may vary depending on operating conditions.

**(3) Maintenance parts list**

Maintenance part name		Part No.	Alternative part No.
Name used in service manual	Name used in parts list		
Maintenance kit (For 30ppm, 100,000page)	MK-1130/MAINTENANCE KIT (OPTION) DK-150 DV-132(U)	1702MJ0NL0	072MJ0NL
	MK-1132/MAINTENANCE KIT (OPTION) DK-150 DV-130(E)	1702MJ0KL0	072MJ0KL
	MK-1134/MAINTENANCE KIT (OPTION) DK-150 DV-134(AO)	1702MJ0AS0	072MJ0AS
Maintenance kit (For 35ppm, 100,000page)	MK-1140/MAINTENANCE KIT (OPTION) DK-150 DV-132(U)	1702ML0NL0	072ML0NL
	MK-1142/MAINTENANCE KIT (OPTION) DK-150 DV-130(E)	1702ML0KL0	072ML0KL
	MK-1144/MAINTENANCE KIT (OPTION) DK-150 DV-134(AO)	1702ML0AS0	072ML0AS

## (4) Firmware Environment Commands

The printer maintains a number of printing parameters in its memory. These parameters may be changed permanently with the FRPO (Firmware RePrOgram) commands.

This section provides information on how to use the FRPO command and its parameters using examples.

### Using FRPO Commands for Reprogramming Firmware

The current settings of the FRPO parameters are listed as optional values on the service status page.

Note: Before changing any FRPO parameter, print out a service status page, so you will know the parameter values before the changes are made. To return FRPO parameters to their factory default values, send the FRPO INIT (FRPO-INITialize) command.(!R! FRPO INIT; EXIT;)

The FRPO command is sent to the printer in the following sequence:

!R! FRPO parameter, value; EXIT;

Example: Changing emulation mode to PC-PR201/65A

!R! FRPO P1, 11; EXIT;

### FRPO Parameters

Environment	Parameter	Values	Factory setting
Top margin	A1	Integer value in inches	0
	A2	Fraction value in 1/100 inches	0
Left margin	A3	Integer value in inches	0
	A4	Fraction value in 1/100 inches	0
Page length	A5	Integer value in inches	13
	A6	Fraction value in 1/100 inches	61
Page width	A7	Integer value in inches	13
	A8	Fraction value in 1/100 inches	61
Default pattern resolution	B8	0: 300 dpi 1: 600 dpi	0
Copy count	C0	Number of copies to print:1-999	1
Page orientation	C1	0: Portrait 1: Landscape	0
Default font No. *	C2	Middle two digits of power-up font	0
	C3	Last two digits of power-up font	0
	C5	First two digits of power-up font	0
PCL font switch	C8	0:HP compatibility mode (Characters higher than 127 are not printed.) 32:Conventional mode (Characters higher than 127 are printed. Supported symbol sets: ISO-60 Norway [00D], ISO-15 Italian [00I], ISO-11 Sweden [00S], ISO-6 ASCII [00U], ISO-4 U.K. [01E], ISO-69 France [01F], ISO-21 Germany [01G], ISO-17 Spain [02S], Symbol [19M] <sup>a</sup> )	0
Total host buffer size	H8	0 to 99 in units of the size defined by FRPO S5	5
Form feed time-out value	H9	Value in units of 5 seconds (0 to 99).	6
KIR mode	N0	0: Off 2: On	2

Environment	Parameter	Values	Factory setting
Duplex binding	N4	0: Off 1: Long edge 2: Short edge	0
Sleep timer time-out time	N5	1 to 240 minutes [0: Off]	15
Ecoprint level	N6	0:Off 2:On	0
Printing resolution	N8	0: 300dpi 1: 600dpi 3: 1200dpi	1
Default emulation mode	P1	0: Line Printer 1: IBM Proprinter X24E 2: Diablo 630 5: Epson LQ-850 6: PCL 6 9: KPDL	9 (U.S.A) or 6 (Euro and other)
Carriage-return action *	P2	0: Ignores 0x0d 1: Carriage-return 2: Carriage-return+linefeed	1
Linefeed action *	P3	0: Ignores 0x0d 1: Linefeed 2: Linefeed+carriage-return	1
Automatic emulation sensing (For KPDL3)	P4	0:AES disabled 1:AES enabled	1 (U.S.A) or 0 (Euro and other)
Alternative emulation (For KPDL3)	P5	Same as the P1 values except that 9 is ignored.	6
Automatic emulation switching trigger (For KPDL3)	P7	0: Page eject commands 1: None 2: Page eject and Prescribe EXIT 3: Prescribe EXIT 4: Formfeed (^L) 6: Page eject, Prescribe EXIT and formfeed 10: Page eject commands; if AES fails, resolves to KPDL	11 (U.S.A) or 10 (Euro and other)
Command recognition character	P9	ASCII code of 33 to 126	82 (R)



Environment	Parameter	Values	Factory setting
Default paper size	R2	0: Size of the default paper cassette (See R4.) 1: Monarch (3-7/8 × 7-1/2 inches) 2: Business (4-1/8 × 9-1/2 inches) 3: International DL (11 × 22 cm) 4: International C5 (16.2 × 22.9 cm) 5: Executive (7-1/4 × 10-1/2 inches) 6: US Letter (8-1/2 × 11 inches) 7: US Legal (8-1/2 × 14 inches) 8: A4 (21.0 × 29.7 cm) 9: B5 (18.2 × 25.7 cm) 13: A5 14: A6 (10.5 × 14.8 cm) 15: B6 (12.8 × 18.2 cm) 16: Commercial #9 (3-7/8 × 8-7/8 inches) 17: Commercial #6 (3-5/8 × 6-1/2 inches) 18: B5 (17.6 × 25 cm) 19: Custom (11.7 × 17.7 inches)f 20: B4 A4 reduces 21: A3 A4 reduces 22: A4 A4 98% reduces 23: Stock form A4 reduces 31: Hagaki (10 × 14.8 cm)f 32: Ofuku-Hagaki (14.8 × 20 cm)f 33: Officio II 40: 16K 42: 21.6 × 34 cm 50: Statement 51: Folio 52: Youkei 2 53: Youkei 4	0
Default cassette	R4	0: Multi-purpose tray 1 1: Cassette 1 2: Cassette 2 3: Cassette 3	1
MP tray paper size	R7	Same as the R2 values except: 0	6 (U.S.A) or 8 (Euro and other)
Daisywheel data length	R8	7:7-bit 8:8-bit	7
A4/letter equation	S4	0:Off 1:On	1
Host buffer size	S5	0: 10kB (x H8) 1: 100kB (x H8) 2: 1024kB (x H8)	1
RAM disk size	S6	1 to 1024 MB	400

Environment	Parameter	Values	Factory setting
RAM disk mode	S7	0: Off 1: On	0
Cassette 1 paper size	T1	4: International C5 (16.2 × 22.9 cm) 5: Executive (7-1/4 × 10-1/2 inches) 6: US Letter (8-1/2 × 11 inches) 7: US Legal (8-1/2 × 14 inches) 8: A4 (21.0 × 29.7 cm) 9: B5 (18.2 × 25.7 cm) 13: A5 14: A6 (10.5 × 14.8 cm) 18: B5 (17.6 × 25 cm) 19: Custom (11.7 × 17.7 inches)f 33: Officio II 40: 16K 42:216x340 50: Statement 51: Folio	6 (U.S.A) or 8 (Euro and other)
Cassette 1 paper size	T2	4: International C5 (16.2 × 22.9 cm) 5: Executive (7-1/4 × 10-1/2 inches) 6: US Letter (8-1/2 × 11 inches) 7: US Legal (8-1/2 × 14 inches) 8: A4 (21.0 × 29.7 cm) 9: B5 (18.2 × 25.7 cm) 13: A5 18: B5 (17.6 × 25 cm) 19: Custom (11.7 × 17.7 inches)f 33: Officio II 40: 16K 42:216x340 51: Folio	6 (U.S.A) or 8 (Euro and other)
Cassette 1 paper size	T3	Same as above.	6 (U.S.A) or 8 (Euro and other)
Wide A4	T6	0:Off 1:On	0
Line spacing *	U0	Lines per inch (integer value)	6
Line spacing *	U1	Lines per inch (fraction value)	0
Character spacing *	U2	Characters per inch (integer value)	10
Character spacing *	U3	Characters per inch (fraction value)	0

Environment	Parameter	Values	Factory setting
Country code	U6	0: US-ASCII 1: France 2: Germany 3: UK 4: Denmark 5: Sweden 6: Italy 7: Spain 8: Japan 9: US Legal 10: IBM PC-850 (Multilingual) 11: IBM PC-860 (Portuguese) 12: IBM PC-863 (Canadian French) 13: IBM PC-865 (Norwegian) 14: Norway 15: Denmark 2 16: Spain 2 17: Latin America 21: US ASCII (U7=50 SET) 77: HP Roman-8 (U7=52 SET)	41
Code set at power up in daisywheel emulation	U7	0: Same as the default emulation mode (P1) 1: IBM 6: IBM PC-8 50: US ASCII (U6=21 SET) 52: HP Roman-8 (U6=77 SET)	53
Font pitch for fixed pitch scalable font	U8	Integer value in cpi: 0 – 99	10
	U9	Fraction value in 1/100 cpi: 0 – 99	0
Font height for the default scalable font *	V0	Integer value in 100 points: 0–9	0
	V1	Integer value in points: 0–99	12
	V2	Fraction value in 1/100 points: 0, 25, 50, 75	0
Default scalable font *	V3	Name of typeface of up to 32 characters, enclosed with single or double quotation marks	Courier
Default weight (courier and letter Gothic)	V9	0: Courier = darkness Letter Gothic = darkness 1: Courier = regular letter Gothic = darkness 4: Courier = darkness Letter Gothic = regular 5: Courier = regular letter Gothic = regular	5

Environment	Parameter	Values	Factory setting
Paper type for the MP tray	X0	1: Plain 1 2: Transparency 3: Preprinted 4: Label 5: Bond 6: Recycle 7: Vellum 9: Letterhead 10: Color 11: Prepunched 12: Envelope 13: Cardstock 16: Thick 17: High Quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1
Paper type for paper cassettes 1	X1	1: Plain 3: Preprinted 5: Bond 6: Recycled 9: Letterhead 10: Color 11: Prepunched 17: High Quality 21: Custom1 22: Custom2 23: Custom3 24: Custom4 25: Custom5 26: Custom6 27: Custom7 28: Custom8	1

Environment	Parameter	Values	Factory setting
Paper type for paper cassettes 2 to 4	X2	1: Plain	1
	X3	3: Preprinted	
		5: Bond	
		6: Recycled	
		9: Letterhead	
		10: Color	
		11: Prepunched	
		17: High Quality	
		21: Custom1	
		22: Custom2	
		23: Custom3	
		24: Custom4	
		25: Custom5	
		26: Custom6	
		27: Custom7	
		28: Custom8	
PCL paper source	X9	0: Performs paper selection depending on media type. 1: Performs paper selection depending on paper sources.	0
Automatic continue for 'Press GO'	Y0	0:Off 1:On	0
Automatic continue timer	Y1	number from 0 to 99 in increments of 5 seconds	6 (30seconds)

Environment	Parameter	Values	Factory setting
Error message for device error	Y3	0:Not Detect 1:Detect	127
Duplex operation for specified paper type (Prepunched, Preprinted and Letter-head)	Y4	0:Off 1:On	0
Default operation for PDF direct printing	Y5	0: Enlarges or reduces the image to fit in the current paper size. Loads paper from the current paper cassette. 1: Through the image. Loads paper which is the same size as the image. 2: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the image size. 3: Through the image. Loads Letter, A4 size paper depending on the image size. 8: Through the image. Loads paper from the current paper cassette. 9: Through the image. Loads Letter, A4 size paper depending on the image size. 10: Enlarges or reduces the image to fit in the current paper size. Loads Letter, A4 size paper depending on the imagesize.	0

- a. Characters higher than 127 are printed regardless of the C8 value. However, setting C8 to 0 does not print character code 160.

\*. Ignored in some emulation modes.

## (5) Maintenance Commands

This section provides information on how to use the maintenance command and its parameters using examples.

### Adjusting the print start timing (alternative command for the maintenance mode U034)

#### Description

Adjusts the leading edge registration or left edge.

#### Purpose



Make the adjustment if there is a regular error between the leading edges of the copy image and original.

Make the adjustment if there is a regular error between the left edges of the copy image and original.

Format	!R! KCFG“PFRC”,#1 ,#2 ,#3;	
Parameter	#1	Paper source number 0: MP tray 2-6 : Cassette2-6 100: Duplex (e.g. landscape images short-edge bind) 200: Rotated duplex (e.g. portrait images long-edge bind)
	#2	Edge to adjust 1: Leading edge 2: Left edge
	#3	Adjustable range (-128 to +127) number of dot in 600dpi

#### Example: Set the leading edge of MP tray to +30 dots

!R! KCFG “PFRC”,0,1,30;EXIT;



**Adjusting the scanner magnification (alternative command for the maintenance mode U065)****Description**

Adjusts the magnification of the original scanning.

**Purpose**


Make the adjustment if the magnification in the main scanning direction is incorrect.

Make the adjustment if the magnification in the auxiliary scanning direction is incorrect.



<b>Format</b>	!R! KCFG "SCAN",8, #1,#2;EXIT;	
<b>Parameter</b>	#1	1: Y SCAN ZOOM Scanner magnification in the main scanning direction 2: X SCAN ZOOM Scanner magnification in the auxiliary scanning direction
	#2	#1=1: Adjustable range: -32 to 127 (in 0.1% increment) (0: default) #2=2 : Adjustable range: -25 to 25 (in 0.1% increment) (0: default)

**Example: Y SCAN ZOOM set to 55, X SCAN ZOOM set to 10**


!R! KCFG "SCAN",8,1,55; KCFG "SCAN",8,2,10;EXIT;





Original

Copy  
example 1Copy  
example 2

Magnified in the main  
scanning direction



Original

Copy  
example 1Copy  
example 2

Magnified in the auxiliary  
scanning direction



**Adjusting the scanner leading edge registration (alternative command for the maintenance U066)****Description**

Adjusts the scanner leading edge registration of the original scanning.


**Purpose**

Make the adjustment if there is a regular error between the leading edges of the copy image and original.

<b>Format</b>	!R! KCFG "SCAN",5,#1,#2;;EXIT;	
<b>Parameter</b>	#1	1: Scanner leading edge registration 2: Scanner leading edge registration of rotated scan
	#2	Adjustable range: -45 to 45 (in 0.086mm increment) (0: default)

**Example: Scanner leading edge registration set to 10 to increase 0.86mm**

!R! KCFG "SCAN",5,1,"10";EXIT;



**Adjusting the scanner center line (alternative command for the maintenance mode U067)****Description**

Adjusts the scanner center line of the original scanning.

**Purpose**


Make the adjustment if there is a regular error between the center lines of the copy image and original.

<b>Format</b>	!R! KCFG "SCAN",6, #1;#2;EXIT;	
<b>Parameter</b>	#1	1: Scanner center line 2: Scanner center line of rotated scan
	#2	#1=1: Adjustable range: -70 to 70 (in 0.086mm increment) (0: default) #1=2: Adjustable range: -40 to 40 (in 0.086mm increment) (0: default)

**Example: Scanner leading edge registration set to 20 to increase 1.72mm**

!R! KCFG "SCAN",6,1,20;EXIT;

Scanner center line (within  $\pm 2.0$  mm)



## Adjusting the scanning position for originals from the DP (alternative command for the maintenance mode U068)

### Description

Adjusts the position for scanning originals from the DP. Performs the test copy at the four scanning positions after adjusting.

### Purpose

Used when the image fogging occurs because the scanning position is not proper when the DP is used. Execute KCFG "EESS",4, 107, 1, "#1"; command to adjust the timing of DP leading edge when the scanning position is changed.

<b>Format</b>	!R! KCFG "SCAN",9, #1,#2;EXIT;	
<b>Parameter</b>	#1	1: DP READ Starting position adjustment for scanning originals 2: BLACK LINE Scanning position for the test copy originals
	#2	#1=1: Adjustable range: -33 to 33 (in 0.086mm increment) (0: default) #1=2: Adjustable range: 0 to 3 (in 0.22mm increment) (0: default)

### Example: DP READ set to 15, BLACK LINE set to 3

!R! KCFG "SCAN",9,1,15; KCFG "SCAN",9,2,3;EXIT;

**Adjusting the DP magnification (alternative command for the maintenance mode U070)****Description**

Adjusts the DP original scanning speed.


**Purpose**

Make the adjustment if the magnification is incorrect in the auxiliary scanning direction when the DP is used.



<b>Format</b>	!R! KCFG "SCAN",4, #1;#2;EXIT;	
<b>Parameter</b>	#1	2: CONVEYING SPEED Magnification in the auxiliary scanning direction
	#2	Adjustable range: --25 to 25 (in 0.1% increment) (0: default)

**Example: DP scanning magnification set to 20 to increase 2%**

!R! KCFG "SCAN",4,2,20;EXIT;

**Leading edge registration**

Original

Copy  
example 1Copy  
example 2

## Adjusting the DP scanning timing (alternative command for the maintenance mode U071)

### Description

Adjusts the DP original scanning timing.

### Purpose


Make the adjustment if there is a regular error between the leading or trailing edges of the original and the copy image when the DP is used.

Format	!R! KCFG "SCAN",2,#1,#2;EXIT;	
Parameter	#1	1: FRONT HEAD Leading edge registration (first page) 2: FRONT TAIL Trailing edge registration (first page) 3: BACK HEAD Leading edge registration (second page) 4: BACK TAIL Trailing edge registration (second page) 5: ROTATE Leading edge registration (rotate scan)
	#2	#1=1: Adjustable range: -32 to 32 (in 0.196mm increment) (0: default) #1=2: Adjustable range: -32 to 32 (in 0.196mm increment) (0: default) #1=3: Adjustable range: -45 to 45 (in 0.196mm increment) (0: default) #1=4: Adjustable range: -45 to 45 (in 0.196mm increment) (0: default) #1=5: Adjustable range: -128 to 128 (in 0.196mm increment) (0: default)


**Example: FRONT HEAD set to 10, FRONT TAIL set to 15, BACK HEAD set to 10, BACK TAIL 15**

!R! KCFG "SCAN",2,1,10; KCFG "SCAN",2,2,15; KCFG "SCAN",2,3,10; KCFG "SCAN",2,4,15;EXIT;


### Leading edge registration



Original




Copy  
example 1




Copy  
example 2

### Trailing edge registration



Original



Copy  
example 1



Copy  
example 2

**Adjusting the DP center line (alternative command for the maintenance mode U072)****Description**

Adjusts the scanning center line for the DP original.


**Purpose**

Make the adjustment if there is a regular error between the centers of the original and the copy image when the DP is used.



<b>Format</b>	!R! KCFG "SCAN",3, #1,#2;EXIT;	
<b>Parameter</b>	#1	1: FRONT Center line (first page) 2: BACK Center line (second page) 3: ROTATE Center line (rotated scan)
	#2	Setting range: -39 to 39 (in 0.086mm increment) (initial: 0)

**Example: FRONT set to 15, BACK set to 3**

!R! KCFG "SCAN",3,1,15; KCFG "SCAN",3,2,3;EXIT;

**DP center line**


Original

Copy  
example 1Copy  
example 2

# **INSTALLATION GUIDE FOR PAPER FEEDER**

# PF-120


安装手册  
 インストールガイド  
 Installation Guide  
 Guide d'installation  
 Guía de instalación  
 Installationsanleitung  
 Guida all'installazione




[120 V specifications only]  
**NOTICE**  
 This accessory is for use only with the following Applicant's Listed Machine. Refer to the supplied guide to install the accessory in the field.  
 Machine: FS-1030MFP, FS-1130MFP, FS-1035MFP, FS-1135MFP

PF-120的安装  
 PF-120の設置  
 Installation of PF-120  
 Installation de PF-120  
 Instalación de PF-120  
 Installation von PF-120  
 Installazione di PF-120


1




2




3




4




5



6



7





纸张大小的调整  
用紙サイズの調整

Adjustment of paper size


Ajustement de format papier

Ajuste del tamaño del papel


Justage des Papierformats

Registrazione del formato carta


8



9




10




Folio / Oficio II


(1)




(2)



(3)



Legal



装紙

用紙のセット

Loading paper


Papier de chargement

Papel del cargamento


Ladenpapier

Carta da caricamento


11



12



13



取出卡紙

紙づまりの処理


Removing Paper Jams

Solution pour les bourrages papier

Eliminación de los atascos de papel

Entfernen von Papierstaus

Rimozione degli inceppamenti carta



关于纸张的规格，请参阅机器的操作手册。  
用紙の仕様については、本体使用説明書を参照してください。

For paper specification, refer to the machine's Operation Guide.

Avec les spécifications de papier, référez-vous au guide de l'opération de machine.

Para la especificación de papel, refiera a la guía de la operación de máquina.

Für Papierspezifikation beziehen Sie sich den auf Führer Rechneroperation.

Per la specifica di carta, riferiscasi alla guida di funzionamento della macchina.

**KYOCERA Document Solutions America, Inc.****Headquarters**

225 Sand Road,  
Fairfield, New Jersey 07004-0008, USA  
Phone: +1-973-808-8444  
Fax: +1-973-882-6000

**Latin America**

8240 NW 52nd Terrace Dawson Building, Suite 100  
Miami, Florida 33166, USA  
Phone: +1-305-421-6640  
Fax: +1-305-421-6666

**KYOCERA Document Solutions Canada, Ltd.**

6120 Kestrel Rd., Mississauga, ON L5T 1S8,  
Canada  
Phone: +1-905-670-4425  
Fax: +1-905-670-8116

**KYOCERA Document Solutions  
Mexico, S.A. de C.V.**

Calle Arquimedes No. 130, 4 Piso, Colonia Polanco  
Chapultepec, Delegacion Miguel Hidalgo,  
Distrito Federal, C.P. 11560, México  
Phone: +52-555-383-2741  
Fax: +52-555-383-7804

**KYOCERA Document Solutions Brazil, Ltda.**

Alameda África, 545, Pólo Empresarial Consbrás,  
Tamboré, Santana de Parnaíba-SP, CEP 06543-306,  
Brazil  
Phone: +55-11-4195-8496  
Fax: +55-11-4195-6167

**KYOCERA Document Solutions Chile SpA**

Jose Ananias 505, Macul. Santiago, Chile  
Phone: +562-2350-7000  
Fax: +562-2350-7150

**KYOCERA Document Solutions  
Australia Pty. Ltd.**

Level 3, 6-10 Talavera Road North Ryde N.S.W, 2113,  
Australia  
Phone: +61-2-9888-9999  
Fax: +61-2-9888-9588

**KYOCERA Document Solutions  
New Zealand Ltd.**

Ground Floor, 19 Byron Avenue, Takapuna, Auckland,  
New Zealand  
Phone: +64-9-415-4517  
Fax: +64-9-415-4597

**KYOCERA Document Solutions Asia Limited**

16/F., Mita Centre, 552-566, Castle Peak Road  
Tsuenwan, NT, Hong Kong  
Phone: +852-2610-2181  
Fax: +852-2610-2063

**KYOCERA Document Solutions  
(China) Corporation**

8F, No. 288 Nanjing Road West, Huangpu District,  
Shanghai, 200003, China  
Phone: +86-21-5301-1777  
Fax: +86-21-5302-8300

**KYOCERA Document Solutions  
(Thailand) Corp., Ltd.**

335 Ratchadapisek Road, Bangsue, Bangkok 10800,  
Thailand  
Phone: +66-2-586-0333  
Fax: +66-2-586-0278

**KYOCERA Document Solutions  
Singapore Pte. Ltd.**

12 Tai Seng Street #04-01A,  
Luxasia Building, Singapore 534118  
Phone: +65-6741-8733  
Fax: +65-6748-3788

**KYOCERA Document Solutions  
Hong Kong Limited**

16/F., Mita Centre, 552-566, Castle Peak Road  
Tsuenwan, NT, Hong Kong  
Phone: +852-3582-4000  
Fax: +852-3185-1399

**KYOCERA Document Solutions  
Taiwan Corporation**

6F., No.37, Sec. 3, Minquan E. Rd.,  
Zhongshan Dist., Taipei 104, Taiwan R.O.C.  
Phone: +886-2-2507-6709  
Fax: +886-2-2507-8432

**KYOCERA Document Solutions Korea Co., Ltd.**

18F, Kangnam bldg, 1321-1,  
Seocho-Dong, Seocho-Gu, Seoul, Korea  
Phone: +822-6933-4050  
Fax: +822-747-0084

**KYOCERA Document Solutions  
India Private Limited**

Second floor, Centrum Plaza, Golf Course Road,  
Sector-53, Gurgaon, Haryana 122002, India  
Phone: +91-0124-4671000  
Fax: +91-0124-4671001

**KYOCERA Document Solutions Europe B.V.**

Bloemlaan 4, 2132 NP Hoofddorp,  
The Netherlands  
Phone: +31-20-654-0000  
Fax: +31-20-653-1256

**KYOCERA Document Solutions Nederland B.V.**

Beechavenue 25, 1119 RA Schiphol-Rijk,  
The Netherlands  
Phone: +31-20-5877200  
Fax: +31-20-5877260

**KYOCERA Document Solutions (U.K.) Limited**

Eldon Court, 75-77 London Road,  
Reading, Berkshire RG1 5BS,  
United Kingdom  
Phone: +44-118-931-1500  
Fax: +44-118-931-1108

**KYOCERA Document Solutions Italia S.p.A.**

Via Verdi, 89/91 20063 Cernusco s/N.(MI),  
Italy  
Phone: +39-02-921791  
Fax: +39-02-92179-600

**KYOCERA Document Solutions Belgium N.V.**

Sint-Martinusweg 199-201 1930 Zaventem,  
Belgium  
Phone: +32-2-7209270  
Fax: +32-2-7208748

**KYOCERA Document Solutions France S.A.S.**

Espace Technologique de St Aubin  
Route de l'Orme 91195 Gif-sur-Yvette CEDEX,  
France  
Phone: +33-1-69852600  
Fax: +33-1-69853409

**KYOCERA Document Solutions Espana, S.A.**

Edificio Kyocera, Avda. de Manacor No.2,  
28290 Las Matas (Madrid), Spain  
Phone: +34-91-6318392  
Fax: +34-91-6318219

**KYOCERA Document Solutions Finland Oy**

Atomitie 5C, 00370 Helsinki,  
Finland  
Phone: +358-9-47805200  
Fax: +358-9-47805390

**KYOCERA Document Solutions****Europe B.V., Amsterdam (NL) Zürich Branch**

Hohlstrasse 614, 8048 Zürich,  
Switzerland  
Phone: +41-44-9084949  
Fax: +41-44-9084950

**KYOCERA Document Solutions****Deutschland GmbH**

Otto-Hahn-Strasse 12, 40670 Meerbusch,  
Germany  
Phone: +49-2159-9180  
Fax: +49-2159-918100

**KYOCERA Document Solutions Austria GmbH**

Eduard-Kittenberger-Gasse 95, 1230 Vienna,  
Austria  
Phone: +43-1-863380  
Fax: +43-1-86338-400

**KYOCERA Document Solutions Nordic AB**

Esbogatan 16B 164 75 Kista, Sweden  
Phone: +46-8-546-550-00  
Fax: +46-8-546-550-10

**KYOCERA Document Solutions Norge Nuf**

Postboks 150 Oppsal, 0619 Oslo,  
Norway  
Phone: +47-22-62-73-00  
Fax: +47-22-62-72-00

**KYOCERA Document Solutions Danmark A/S**

Ejby Industrivej 60, DK-2600 Glostrup,  
Denmark  
Phone: +45-70223880  
Fax: +45-45765850

**KYOCERA Document Solutions Portugal Lda.**

Rua do Centro Cultural, 41 (Alvalade) 1700-106 Lisboa,  
Portugal  
Phone: +351-21-843-6780  
Fax: +351-21-849-3312

**KYOCERA Document Solutions****South Africa (Pty) Ltd.**

KYOCERA House, Hertford Office Park,  
90 Bekker Road (Cnr. Allandale), Midrand, South Africa.  
Phone: +27-11-540-2600  
Fax: +27-11-466-3050

**KYOCERA Document Solutions Russia LLC.**

Building 2, 51/4, Schepkina St., 129110, Moscow,  
Russia  
Phone: +7(495)741-0004  
Fax: +7(495)741-0018

**KYOCERA Document Solutions Middle East**

Dubai Internet City, Bldg. 17,  
Office 157 P.O. Box 500817, Dubai,  
United Arab Emirates  
Phone: +971-04-433-0412

**KYOCERA Document Solutions Inc.**

2-28, 1-chome, Tamatsukuri, Chuo-ku  
Osaka 540-8585, Japan  
Phone: +81-6-6764-3555  
<http://www.kyoceradocumentsolutions.com>