



D067/D068/D069/D072 SERVICE MANUAL

004356MIU

LANIER RICOH 52VIII



D067/D068/D069/D072 SERVICE MANUAL

LANIER RICOH Savin



D067/D068/D069/D072 SERVICE MANUAL

004356MIU

LANIER RICOH SAVIN

It is the reader's responsibility when discussing the information contained within this document to maintain a level of confidentiality that is in the best interest of Ricoh Americas Corporation and its member companies.

NO PART OF THIS DOCUMENT MAY BE REPRODUCED IN ANY FASHION AND DISTRIBUTED WITHOUT THE PRIOR PERMISSION OF RICOH AMERICAS CORPORATION.

All product names, domain names or product illustrations, including desktop images, used in this document are trademarks, registered trademarks or the property of their respective companies.

They are used throughout this book in an informational or editorial fashion only and for the benefit of such companies. No such use, or the use of any trade name, or web site is intended to convey endorsement or other affiliation with Ricoh products.

© 2009 RICOH Americas Corporation. All rights reserved.

WARNING

The Service Manual contains information regarding service techniques, procedures, processes and spare parts of office equipment distributed by Ricoh Americas Corporation. Users of this manual should be either service trained or certified by successfully completing a Ricoh Technical Training Program.

Untrained and uncertified users utilizing information contained in this service manual to repair or modify Ricoh equipment risk personal injury, damage to property or loss of warranty protection.

Ricoh Americas Corporation

LEGEND

PRODUCT	COMPANY			
CODE	GESTETNER	LANIER	RICOH	SAVIN
D067*	MP 171		Aficio MP 171	
D068	MP 171F	LD 117F	Aficio MP 171F	917F
D069	MP 171SPF	LD 117SPF	Aficio MP 171SPF	917SPF
D072	MP 171	LD 117	Aficio MP 171	917

^{*} D067 Ricoh Latin America Only

DOCUMENTATION HISTORY

REV. NO.	DATE	COMMENTS
*	03/2009	Original Printing

DO67/D068/D069/D072

TABLE OF CONTENTS

PRODUCT INFORMATION

1. PRODUCT INFORMATION	1-1
1.1 SPECIFICATIONS	1-1
1.2 MACHINE CONFIGURATION	1-2
1.2.1 MAINFRAME (BASIC: D067/D072)	1-2
1.2.2 MAINFRAME (F/SPF: D068/D069)	1-3
1.2.3 SYSTEM COMPONENTS (FOR D068/D069)	1-4
1.3 OVERVIEW	1-6
1.3.1 COMPONENT LAYOUT	1-6
Mainframe	1-6
ARDF	1-8
1.3.2 ELECTRICAL COMPONENTS	1-9
Electrical Components 1	1-9
Electrical Components 2	1-10
ARDF	1-11
1.3.3 PAPER PATH	1-12
1.3.4 DRIVE LAYOUT	1-13
Mainframe	1-13
ARDF	1-14
1.4 GUIDANCE FOR THOSE WHO ARE FAMILIAR WITH PREDECE	SSOR
PRODUCTS	1-15
INSTALLATION	
2. INSTALLATION	2-1
2.1 INSTALLATION CAUTIONS	2-1
2.2 INSTALLATION REQUIREMENTS	2-2
2.2.1 ENVIRONMENT	2-2
2.2.2 MACHINE LEVEL	2-2
2.2.3 MINIMUM OPERATIONAL SPACE REQUIREMENTS	2-3

i

2.2.4 POWER REQUIREMENTS	2-4
2.3 COPIER	2-5
2.3.1 ACCESSORY CHECK	2-5
Basic Model (D067/D072)	2-5
Fax Model (D068)/ Printer/Scanner and Fax Model (D069)	2-5
Installation Procedure	2-6
For D068/D069: Interface settings	2-11
For D068/D069: Copier settings	2-11
For D068/D069: Fax Settings	2-12
2.3.2 OPTIONAL HANDSET (ONLY FOR D068/D069)	2-12
Accessory Check	2-12
Installation Procedure	2-13
2.4 PAPER TRAY UNIT	2-15
2.4.1 ACCESSORY CHECK	2-15
2.4.2 INSTALLATION PROCEDURE	2-16
2.5 PAPER TRAY UNIT HEATER	2-18
2.5.1 ACCESSORY CHECK	2-18
2.5.2 INSTALLATION PROCEDURE	2-19
2.6 ARDF (B872)	2-25
2.6.1 ACCESSORY CHECK	2-25
2.6.2 INSTALLATION PROCEDURE	2-26
2.7 USB 2.0/SD SLOT TYPE B	2-32
2.7.1 ACCESSORY CHECK	2-32
2.7.2 INSTALLATION PROCEDURE	2-33
When Installing the Handset	2-36
2.7.3 TESTING THE SD CARD/USB SLOT	2-38
2.8 OPTIONAL PAPER TRAY GRIP HANDLE	2-39
2.8.1 ACCESSORIES	2-39
Installation Procedure	2-39
2.9 PRINTER/SCANNER UNIT	2-41
2.9.1 ACCESSORY CHECK	2-41
2.9.2 INSTALLATION PROCEDURE	2-43
2.10 CONTROLLER OPTIONS	2-48
2.10.1 OVERVIEW	2-48
2.10.2 POSTSCRIPT3 INSTALLATION	2-49
Accessories	2-49

Inst	allation Procedure	2-49
2.10.3	WIRELESS LAN (IEEE 802.11A/G) INSTALLATION	2-50
Acc	cessories	2-50
Inst	allation Procedure	2-50
SP	Mode Settings for IEEE 802.11a/g Wireless LAN	2-51
2.10.4	IEEE 1284 INSTALLATION	2-52
Acc	essories	2-52
Inst	allation Procedure	2-52
2.10.5	VM CARD TYPE L (D467)	2-53
Acc	essories	2-53
Inst	allation	2-53
2.10.6	GIGABIT ETHERNET	2-54
2.10.7	HDD OPTION (D467, ONLY FOR D067/D068)	2-55
Cor	nponent Check	2-55
Inst	allation Procedure	2-56
Afte	er Installing the HDD	2-57
2.10.8	DATAOVERWRITESECURITY UNIT TYPE I (D362)	2-57
	ore You Begin the Procedure	
Sea	al Check and Removal	2-58
Inst	allation Procedure	2-58
2.10.9	HDD ENCRYPTION UNIT (D377)	2-60
	ore You Begin the Procedure	
	al Check and Removal	
	allation Procedure	
	covery from a Device Problem	
	storing the Encryption key	
	aring the NVRAM	
	EY COUNTER (CARD) INTERFACE TYPE A	
	essory Check	
Inst	allation Procedure	2-64
PREVENT	IVE MAINTENANCE	
3. PREVEN	NTIVE MAINTENANCE	3-1
	ENANCE TABLES	
	O CLEAR THE PM COUNTER	

REPLACEMENT AND ADJUSTMENT

4. REPLACEMENT & ADJUSTMENT	4-1
4.1 PRECAUTIONS	4-1
4.1.1 GENERAL	4-1
4.1.2 LITHIUM BATTERIES	4-1
4.1.3 HALOGEN-FREE CABLE	4-1
4.2 SPECIAL TOOLS AND LUBRICANTS	4-2
4.3 EXTERIOR COVERS AND OPERATION PANEL	4-3
4.3.1 REAR COVER	4-3
4.3.2 COPY TRAY	4-4
4.3.3 SCALE PLATE (D067 ONLY)	4-5
4.3.4 OPERATION PANEL AND UPPER COVERS	4-5
4.3.5 RIGHT DOOR	4-6
4.3.6 BYPASS TRAY	4-6
4.3.7 PLATEN COVER SENSOR	4-7
4.4 SCANNER UNIT	4-8
4.4.1 EXPOSURE GLASS	4-8
4.4.2 LENS BLOCK	
4.4.3 EXPOSURE LAMP, LAMP STABILIZER BOARD	
4.4.4 SCANNER MOTOR	4-11
4.4.5 SCANNER HP SENSOR	
4.4.6 SCANNER ALIGNMENT ADJUSTMENT	4-13
4.5 FUSING	4-15
4.5.1 FUSING UNIT	4-15
4.5.2 EXIT SENSOR	
4.5.3 HOT ROLLER STRIPPER PAWLS	4-17
4.5.4 HOT ROLLER AND FUSING LAMP	4-18
4.5.5 THERMOSWITCHES AND THERMISTOR	4-19
4.5.6 PRESSURE ROLLER	4-20
4.5.7 CHECKING THE NIP BAND	4-21
4.6 PCU AND QUENCHING LAMP	4-22
4.6.1 PCU	4-23
4.6.2 QUENCHING LAMP	4-24
4 7 FXHAUST FAN AND MAIN MOTOR	4-25

4745	NAME OF TANK	4.05
	XHAUST FAN	
	MAIN MOTOR	
	R FEED	
	PAPER FEED ROLLER AND FRICTION PAD	
4.8.2 F	PAPER END SENSOR	4-28
4.8.3 F	REGISTRATION SENSOR	4-29
4.8.4 E	SYPASS PAPER END SENSOR	4-30
4.8.5 E	SYPASS FEED ROLLER	4-31
4.8.6 E	SYPASS FEED CLUTCH AND FRICTION PAD	4-32
4.8.7 F	PAPER FEED AND REGISTRATION CLUTCHES	4-33
4.9 IMAGE	TRANSFER	4-35
4.9.1 T	RANSFER ROLLER	4-35
4.9.2 II	O SENSOR AND DUPLEX ROLLER	4-36
4.9.3 E	DISCHARGE PLATE	4-37
4.10 BIC	CU AND CONTROLLER BOARD	4-38
4.10.1	BICU	4-39
	paration	
	ocedure	
4.10.2	CONTROLLER BOARD (F/SPF MODELS: D068/D069)	4-41
	paration:	
	ocedure	
	en replacing the NVRAM on the controller board	
	en Installing the Printer/Scanner Unit (D468)	
	HER REPLACEMENTS	
	DUPLEX MOTOR	
4.11.2	HIGH-VOLTAGE POWER SUPPLY BOARD	
4.11.3	PSU	
	CONTACT-RELEASE SOLENOID	
	TONER SUPPLY CLUTCH	
	FCU (FOR D068/D069)	
	nium Batteries	
	cedure	
	SER UNIT	
	LOCATION OF THE CAUTION DECAL	
	LASER UNIT	
	LD UNIT AND POLYGON MIRROR MOTOR	
4 . 1∠.3		4 -53

4.13 ARDF	4-54
4.13.1 ARDF	4-54
4.13.2 DF REAR COVER	4-55
4.13.3 ORIGINAL FEED UNIT	4-56
4.13.4 SEPARATION ROLLER	4-56
4.13.5 DF DRIVE BOARD	4-57
4.13.6 ORIGINAL SET AND DF INVERTER SENSOR	4-57
4.13.7 DF REGISTRATION AND DF EXIT SENSOR	4-58
DF Registration Sensor Reflector	4-59
4.13.8 DF FEED MOTOR	4-59
4.13.9 DF TRANSPORT MOTOR	4-60
4.13.10 DF FEED CLUTCH	4-60
4.14 ADJUSTING COPY IMAGE AREA	4-61
4.14.1 PRINTING	4-61
Adjusting Registration	4-61
Adjusting Blank Margin	4-62
Adjusting Main-Scan Magnification	4-63
4.14.2 SCANNING	4-64
Adjusting Registration	4-64
Adjusting Magnification	4-65
Scan Auto Adjustment	4-66
4.14.3 DF IMAGE ADJUSTMENT	4-67
TROUBLESHOOTING	
5. TROUBLESHOOTING	5-1
5.1 SERVICE CALL CONDITIONS	
5.2 ELECTRICAL COMPONENT DEFECTS	5-2
5.3 CARD SAVE FUNCTION	5-3
5.3.1 OVERVIEW	5-3
Card Save:	5-3
5.3.2 PROCEDURE	5-4
Error Messages	5-5
5.4 FAX TROUBLESHOOTING GUIDE (ONLY FOR D068/D069)	5-6

SYSTEM MAINTENANCE REFERENCE

6. SYSTEM MAINTENANCE REFERENCE	6-1
6.1 SERVICE PROGRAM	6-1
6.1.1 SP TABLES	6-1
6.1.2 USING SP AND SSP MODES	6-1
Starting SP Mode	6-2
Selecting Programs	6-2
Specifying Values	6-2
Activating Copy Mode	6-2
Quitting Programs/Ending (S) SP Mode	6-3
Conventions used in the tables:	6-3
6.2 USING SP MODE (F/SPF: D068/D069)	6-4
6.2.1 NVRAM DATA UPLOAD/DOWNLOAD	6-4
Uploading Content of NVRAM to an SD card	6-4
Downloading an SD Card to NVRAM	6-5
6.2.2 FIRMWARE UPDATE PROCEDURE	6-6
Before You Begin	6-6
Firmware Update Procedure	6-7
6.2.3 TEST PATTERN PRINT (SP5-902-001)	6-12
Executing Test Pattern Printing	
Test Patterns	6-12
6.2.4 MEMORY CLEAR	6-15
GW Machine	6-15
Exceptions	
Memory Clear Procedure	
6.2.5 MACHINE NO. SETTING (SP5-811-001)	6-17
Specifying Characters	
GW Machine	
Serial Number and NVRAM	
6.2.6 SMC PRINT (SP5-990)	
6.2.7 ID SENSOR ERROR ANALYSIS (SP2-221)	
6.3 USING SP MODE (BASIC: D067/D072)	
6.3.1 NVRAM DATA UPLOAD/DOWNLOAD (SP5-824/825)	
Overview	
NVRAM Upload (SP5-824-001)	6-19

vii

NVRAM Download (SP5-825-001)	6-20
6.3.2 FIRMWARE UPDATE PROCEDURE	6-21
6.3.3 TEST PATTERN PRINT (SP5-902-001)	6-23
Executing Test Pattern Printing	6-23
Test Patterns	6-23
6.3.4 SMC PRINT (SP5-990)	6-26
6.3.5 SERIAL NUMBER INPUT (SP5-811-001)	6-26
Specifying Characters	6-26
Serial Number and NVRAM	6-26
6.3.6 MEMORY CLEAR	6-27
Basic and GDI Model	6-27
Exceptions	6-27
Initializing Memory Data	6-27
Executing Memory Clear	6-27
6.3.7 ID SENSOR ERROR ANALYSIS (SP2-221)	6-28
6.4 FAX SERVICE TABLES (ONLY FOR D068/D069)	6-29

M018/M019 SERVICE MANUAL APPENDICES

SEE M018/M019 SERVICE MANUAL APPENDICES SECTION FOR DETAILED TABLE OF CONTENTS

PAPER TRAY UNIT (B421)

SEE SECTION B421 FOR DETAILED TABLE OF CONTENTS

ARDF DF1000 (B872)

SEE SECTION B872 FOR DETAILED TABLE OF CONTENTS

PRODUCT INFO	ORMATION	
	APPENDIX: \$	SPECIFICATIONS
		ARDF DF1000 (B872)
INICTAL LATION		
INSTALLATION		
	APPENDIX: I	PREVENTIVE MAINTENANCE
		PAPER TRAY UNIT (B421)
PREVENTIVE N	MAINTENANC	E
	APPENDIX: \$	SERVICE CALL CONDITIONS
REPLACEMEN	T AND ADJUS	STMENT
	APPENDIX: I DEFECTS	ELECTRICAL COMPONENT
TROUBLESHO	OTING	
	APPENDIX: \$	SP MODE TABLES
SYSTEM MAIN	TENANCE RE	FERENCE
	APPENDIX: I	FAX TROUBLESHOOTING GUIDE
	APPENDIX: I	FAX SERVICE PROGRAM
'		

Read This First

Important Safety Notices

Prevention of Physical Injury

- Be sure that the power cord is unplugged before disassembling or assembling parts of the copier or peripherals.
- 2. The wall outlet should be near the copier and easily accessible.
- 3. Note that electrical voltage is supplied to some components of the copier and the paper tray unit even while the main power switch is off.
- If any adjustment or operation check has to be made with exterior covers off or open while the main switch is turned on, keep hands away from electrified or mechanically driven components.
- If you start a job before the copier completes the warm-up or initializing period, keep hands away from the mechanical and electrical components until job execution has started. The copier will start making copies as soon as warm-up or initialization is finished.
- 6. The inside and the metal parts of the fusing unit become extremely hot while the copier is operating. Be careful to avoid touching those components with your bare hands.

Health Safety Conditions

Toner and developer are nontoxic, but getting either of these into your eyes may cause temporary eye discomfort. Try to remove with eye drops or flush with water. If material remains in eye or if discomfort continues, get medical attention.

Observance of Electrical Safety Standards

The copier and its peripherals must be installed and maintained by a customer service representative who has completed the training course on those relevant models.

MWARNING

 Keep the machine away from flammable liquids, gases, and aerosols. A fire or an explosion might occur if this precaution is not observed.

Lithium Batteries

Incorrect replacement of lithium battery(s) on the FCU, controller board and memory board unit may pose risk of explosion. Replace only with the same type or with an equivalent type recommended by the manufacturer. Discard used batteries in accordance with the manufacturer's instructions.

Safe and Ecological Disposal

- Do not incinerate toner bottles or used toner. Toner dust may ignite suddenly if exposed to an open flame.
- 2. Dispose of used toner, developer, and organic photoconductors in accordance with local regulations. (These are nontoxic supplies.)
- 3. Dispose of replaced parts in accordance with local regulations.
- 4. When keeping used lithium batteries in order to dispose of them later, do not put more than 100 batteries per sealed box. Storing larger numbers or not sealing them apart may lead to chemical reactions and heat build-up.

Laser Safety

The Center for Devices and Radiological Health (CDRH) prohibits the repair of laser-based optical units in the field. The optical housing unit can only be repaired in a factory or at a location with the requisite equipment. The laser subsystem is replaceable in the field by a qualified Customer Engineer. The laser chassis is not repairable in the field. Customer engineers are therefore directed to return all chassis and laser subsystems to the factory or service depot when replacement of the optical subsystem is required.

∴WARNING

 Use of controls not specified in this manual, or performance of adjustments or procedures not specified in this manual, may result in hazardous radiation exposure.

MARNING FOR LASER UNIT



Turn off the main switch before attempting any of the procedures in the Laser
 Unit section. Laser beams can seriously damage your eyes.


CAUTION MARKING:




Symbols and Abbreviations

This manual uses several symbols and abbreviations. The meaning of those symbols and abbreviations is as follows:

•	See or Refer to		
⟨₹⟩	Clip ring		
C	E-ring		
F	Screw		
	Connector		
Ţ	Clamp		
SEF	Short Edge Feed		
LEF	Long Edge Feed		
_	Core Technology manual		





Short Edge Feed (SEF)

Long Edge Feed (LEF)

Cautions, Notes, etc.

The following headings provide special information:

⚠WARNING

• Failure to obey warning information could result in serious injury or death.

CAUTION

• Obey these guidelines to ensure safe operation and prevent minor injuries.



• This information provides tips and advice about how to best service the machine.

PRODUCT INFORMATION

REVISION HISTORY				
Page Date Added/Updated/New				
		None		

1. PRODUCT INFORMATION

1.1 SPECIFICATIONS


See "Appendices" for the following information:

- General Specifications
- Supported Paper Sizes

SM 1-1 D067/D068/D069/D072

1.2 MACHINE CONFIGURATION

1.2.1 MAINFRAME (BASIC: D067/D072)




	Standard Component	Machine Code	Remarks
1	Copier [A]	D067/D072	-

	Optional Components	Machine Code	Remarks
2	500-Sheet Paper Feed Unit [B]	B421	Two can be used.

	Standard/Optional Component	Machine Code	Remarks
3	ARDF [C]	B872	Standard for D072Optional for basic


1.2.2 MAINFRAME (F/SPF: D068/D069)



	Standard Component	Machine Code	Remarks
1	Copier [A]	D068/D069	-
2	GW Controller Board [C]	-	-
3	ARDF [D]	B872	-
4	Fax Unit [E]	-	-

	Optional Components	Machine Code	Remarks
5	500-sheet Paper Feed Unit [B]	B421	Two can be used.
6	Handset [F]	B433	NA only

1.2.3 SYSTEM COMPONENTS (FOR D068/D069)



Item	Machine Code		Remarks
Controller Box	-	[A]	Standard
USB2.0/SD Slot	D467	[B]	Option only for D069
Printer/Scanner unit	D468	[C]	SD card for the Printer/Scanner Unit Standard only for D069
HDD Encryption Unit	D377	[C]	
PostScript 3	D468	[C]	One from the three
Data Overwrite Security Unit	D362	[C]	


VM Card	D467	[D]	-
IEEE 1284	B679	[E]	
Wireless LAN	M344	[E]	One from the three
Gigabit Ethernet Board	G874	[E]	
RAM DIMM	G332	[F]	Distributed with the printer/scanner unit
HDD	D362	[G]	-

SM 1-5 D067/D068/D069/D072

1.3 OVERVIEW

1.3.1 COMPONENT LAYOUT


Mainframe



1. Exposure Lamp	20. ID (Image Density) Sensor
2. 1st Scanner	21. Registration Roller
3. CCD (on SBU)	22. Registration Sensor
4. Lens Block	23. Bypass Tray
5. 2nd Scanner	24. Bypass Paper Feed Roller
6. 2nd Mirror	25. Bypass Paper End Sensor
7. 3rd Mirror	26. Bypass Friction Pad

	T
8. Platen Cover Sensor	27. Mixing Augers
9. Exposure Glass	28. (Main) Friction Pad
10. Exit Roller	29. Paper Feed Roller
11. Exit Sensor	30. Paper End Sensor
12. Scanner Motor	31. TD (Toner Density) Sensor
13. Hot Roller	32. Bottom Plate
14. Pressure Roller	33. Polygon Mirror Motor
15. Cleaning Blade	34. Laser Unit
16. OPC Drum	35. Toner Supply Bottle (or THM)
17. Discharge Plate	36. Toner Collection Coil
18. Transfer Roller	37. Scanner HP Sensor
19. Development Roller	


ARDF



1. Separation Roller	7. Exit Roller
2. Paper Feed Roller	8. Exit Sensor
3. Pick-up Roller	9. Registration Sensor
4. Original Set Sensor	10. Registration Roller
5. Inverter Roller	11. Inverter Sensor
6. Junction Gate	12. Transport Roller

1.3.2 ELECTRICAL COMPONENTS


Electrical Components 1



1. Lens Block	11. ID (Image Density) Sensor
2. Exposure Lamp	12. Registration Sensor
3. Lamp Stabilizer Board	13. Paper End Sensor
4. Scanner HP Sensor	14. Toner Density Sensor
5. Platen Cover Sensor	15. Bypass Paper End Sensor
6. Scanner Motor	16. Right Door Safety Switch


7. Mechanical Counter	17. Front Door Safety Switch
8. Polygon Mirror Motor	18. Quenching Lamp
9. LD Unit	19. High-Voltage Power Supply Board
10. Exit Sensor	20. Operation Panel Board

Electrical Components 2




1. Duplex Motor	7. Paper Feed Clutch
2. Exhaust Fan	8. Toner Supply Clutch
3. PSU	9. Bypass Feed Clutch
4. Controller Board (GW)	10. Registration Clutch
5. BICU	11. Fusing Solenoid
6. Main Motor	

ARDF



1. DF Feed Clutch	6. DF Feed Motor
2. Registration Sensor	7. Inverter Sensor
3. Exit Sensor	8. DF Drive Board
4. Left Cover Sensor	9. Junction Gate Solenoid
5. DF Transport Motor	10. Original Set Sensor


1.3.3 PAPER PATH



- 1. Original Registration Sensor (Document Feeder)
- 2. Exit Senor (Document Feeder)
- 3. Inverter Sensor (Document Feeder)
- 4. Original Set Sensor (Document Feeder)
- 5. Exit Sensor
- 6. Paper Path Sensor
- 7. Registration Sensor
- 8. By-pass Paper End Sensor
- 9. Paper Feed Sensor (Optional Tray)
- 10. Paper End Sensor (Optional Tray)
- 11. Paper End Sensor


1.3.4 DRIVE LAYOUT

Mainframe



1. Scanner Motor	7. Bypass Feed Clutch (By-pass Tray)
2. Duplex motor	8. Registration Clutch
3. Exit Roller	9. Developer Driver Gear
4. Toner Bottle Clutch	10. Drum Drive Gear
5. Main Motor	11. One-way Gear (Duplex Unit)
6. Paper Feed Clutch	12. Fusing Drive Gear

ARDF



1. DF Feed Motor	6. Separation Roller
2. Feed Roller	7. Transport Roller
3. Pick-up Roller	8. DF Transport Motor
4. Inverter Roller	9. Exit Roller
5. DF Feed Clutch	10. Registration Roller

- DF Feed Motor: Drives the feed, separation, pick-up, and transport and inverter rollers.
- DF Transport Motor: Drives the registration and exit rollers.

1.4 GUIDANCE FOR THOSE WHO ARE FAMILIAR WITH PREDECESSOR PRODUCTS

The D067/D068/D069/D072 range of machines is the successor model to the B262/B292/B284/B288 range of machines. If you have experience with the predecessor line, the following information may be of help when you read this manual. Differences from Predecessor Products

	D067/D068/D069/D072	B262/B292/B284/B288
Controller Option	Following controller options were added. HDD (80GB) USB2.0/SD Slot Gigabit Ethernet	-
SD Card Slots	2 slots	3 slots
Copying Speed	17ppm: Memory copy 16ppm: ADF 1 to 1	16ppm

SM 1-15 D067/D068/D069/D072

INSTALLATION

REVISION HISTORY		
Page Date Added/Updated/New		
57	05/21/2009	Updated Information - Installing HDD Procedure altered.
57	07/30/2009	Updated Information - Installing HDD Procedure altered.
64 ~ 66	07/17/2009	New Information – Key Counter (Card) Interface Type A

2. INSTALLATION

2.1 INSTALLATION CAUTIONS

CAUTION


- Before installing an optional unit, do the following:
- Print out all messages stored in the memory, all user-programmed items, and a system parameter list.
- If there is a printer option on the machine, print out all data in the printer buffer.
- Turn off the main switch and disconnect the power cord, the telephone line, and the network cable.

SM 2-1 D067/D068/D069/D072

2.2 INSTALLATION REQUIREMENTS

2.2.1 ENVIRONMENT

-Temperature and Humidity Chart-




- Temperature Range: 10°C to 32°C (50°F to 89.6°F)
- Humidity Range: 15% to 80% RH
- Ambient Illumination: Less than 1,500 lux (Do not expose to direct sunlight.)
- Ventilation: Room air should turn over at least 3 times/hr/person
- Ambient Dust: Less than 0.1 mg/m³
- Do not install the machine where it will be exposed to direct sunlight or to direct airflow (from a fan, air conditioner, air cleaner, etc.).
- Do not install the machine where it will be exposed to corrosive gas.
- Place the machine on a firm and level base.
- Do not install the machine where it may be subjected to strong vibration.

2.2.2 MACHINE LEVEL

Front to back:	Within 5 mm (0.2") of level
Right to left:	Within 5 mm (0.2") of level

2.2.3 MINIMUM OPERATIONAL SPACE REQUIREMENTS

Place the machine near the power source, providing clearance as shown.



A: Front – 750 mm (29.6")

B: Left – 100 mm (3.9")

C: Rear - 100 mm (3.9")

D: Right - 100 mm (3.9")

E: Depth – 450 mm (17.7")

F: Width – 485 mm (19.1")



- The 750-mm front space indicated above is sufficient to allow the paper tray to be pulled out. Additional space is required to allow an operator to stand at the front of the machine.
- Actual minimum space requirement for left, rear, and right sides is 10mm (0.4")
 each, but note that this will not allow room for opening of the bypass tray, right door,
 platen cover, or ARDF unit.

2.2.4 POWER REQUIREMENTS

CAUTION

- Make sure that the wall outlet is near the machine and easily accessible. After completing installation, make sure the plug fits firmly into the outlet.
- Avoid multiple connections to the same power outlet.
- Be sure to ground the machine.

Input voltage:

North America:	110 – 120 V, 60 Hz, 8 A
Europe:	220 – 240 V, 50/60 Hz, 4 A

Image quality guaranteed at rated voltage \pm 10%.

Operation guaranteed at rated voltage \pm 15%.

2.3 COPIER

2.3.1 ACCESSORY CHECK

Basic Model (D067/D072)

Description	Q'ty
NECR (-15, -27)	1
EU Safety Sheet (-27)	1
Paper Size Decal (-15, -27)	1
Operating Instructions – Book: Fax (-15, -27)	1 set
Operating Instructions – Book (-15, -27)	1 set
Operating Instructions – CD ROM (-15, -27)	1 set
EMC caution Sheet (-27)	1

Fax Model (D068)/ Printer/Scanner and Fax Model (D069)

Description	Q'ty
NECR (-17)	1
EU Safety Sheet (-27)	1
Paper Size Decal (-17, -27, -29)	1
Operating Instructions – Book (-17, -27, -29)	1 set
Operating Instructions – CD ROM (-17, -27, -29)	1 set
Handset Bracket (-17)	1
Screw for Handset Bracket (-17)	2


Copier

Description	Q'ty
Modular Cable (-17)	1
Operating Instructions – Book: Fax (-17, -27, -29)	1 set
Connecter Cover for TEL (-17)	1
Ferrite Core for TEL Line	1
Ferrite Core (-17, -27, -29)	1
EMC Caution Sheet (-27)	1
EULA Sheet (-17, -27, -29)	1
Caution Decal (-17, -27, -29)	1


Installation Procedure




Make sure that the copier remains unplugged during installation.



- 1. Remove the all strips of tape.
- 2. Remove the bag [A], SMC and A3 sheet of paper on the exposure glass.




3. Remove the spacing wedge [B].




- 4. Remove the three scanner lock pins. (A tag is hanging from each pin.) To remove: Grasp the base of the pin [C], turn the pin 90 degrees, and pull it down and out.
- 5. Remove the tags from the pins.
- 6. Break each pin off the base [C].
- 7. Discard the pin part [D].
- 8. Set each base [C] back into its original hole, turning it 90° to lock it into place. (Be sure to do this for all three pins.)

Copier



- 9. Open the front door [E].
- 10. Lift lever [F], press in on latch [G] and pull the bottle holder [H] out. (You do not need to pull it completely out of the machine.)
- 11. Take a new bottle of toner, and shake it several times.




12. Remove the outer cap [I].



- Do not remove the inner cap [J].
- 13. Load the bottle on the holder.




- Do not forcefully turn the toner bottle on the holder. After you turn on the main power switch, the copier sets the bottle in place.
- 14. Push the bottle holder back into the machine.
- 15. Press the latch [K] down to lock the holder.



- 16. Remove the padding [L].
- 17. Pull each tabbed strip [M] out of the PCU with one hand, supporting the PCU with the other.




- Do not pull both strips at the same time, as this could damage the PCU.
- 18. Close the front door.




- 19. Pull out the paper tray, and remove the tape securing the end fence in the compartment.
- 20. Push the bottom plate down, and then load the paper.
- 21. Adjust the side fences. If you load paper shorter than A4, set the end fence in the correct position.
- 22. Push the tray back into the copier.

Copier



- 23. Attach the appropriate Brand Decal to the center [N] of the front door if necessary.
- 24. Attach the appropriate tray number decal and paper-size decal to the paper tray [O].
- 25. Install optional units (if any).



- 26. Attach the ferrite core [A] to the network cable when connecting the cable.
- 27. Attach the ferrite core to the telephone line in the same manner as step 26 (only for D068/D069).
- 28. Connect the telephone line to the "LINE" jack (only for D068/D069).



- The end of the ferrite core must be about 10 cm (4") from the end of the cable.
- 29. Plug in the machine and turn on the main power switch.
- 30. Select the language used in the operation panel as necessary (> Language).

For D068/D069: Interface settings

D068 (F):

- 1. Start the SP mode.
- 2. Select SP5-985-001 (NIC setting) and change the setting value to "0" (OFF).
- 3. Select SP5-985-002 (USB setting) and change the setting value to "0" (OFF).
- 4. Turn the main switch off and on.

D069 (SPF):

- 1. Start the SP mode.
- 2. Select SP5-985-001 (NIC setting) and change the setting value to "1" (ON).
- Select SP5-985-002 (USB setting) and change the setting value to "1" (ON).
- 4. Turn the main switch off and on.

For D068/D069: Copier settings

- 1. Start the SP mode.
- 2. Select SP5-801-001 and execute the initialization.
- 3. Exit the SP mode, and then start the UP mode.
- Select the "@Remote Service" ("User Tool" > "System Settings > Administrator Tools" > "Extended Security" > @Remote Service") and select "Prohibit."
- 5. Exit the UP mode, and then start the SP mode.
- 6. Select SP5-870-003 and execute initialization for @Remote.
- 7. Select SP5-907-001 and specify the "Plug & Play."
- 8. Select SP5-870-001 and execute writing certification for @Remote S.
- 9. Select SP5-302-002 and specify the time zone.
- 10. Select SP5-307-001, 003, and 004 and specify the daylight-saving-time settings.
- 11. Exit the SP mode and turn the main switch off and on.
- 12. Start the UP mode.
- Specify the date and time with "Set Date" or "Set Time" (User Tool" > "System Settings" > "Set Date" or "Set Time").
- 14. Turn the main switch off and on.
- 15. Check the operations.
- 16. Make a full size copy, and check if the side-to-side and leading edge registrations are correct. If they are not, adjust the registrations.

For D068/D069: Fax Settings

Initializing the Fax unit

When you press the Fax key for the first time after installation, the error "SRAM problem occurred / SRAM was formatted" will show on the LCD for initializing the program of the fax unit. Turn the main power switch off/on to clear the error display.



- If another error occurs after initialization, this can be a functional problem.
- 1. Select fax SP1-101-016 and specify the country code.
- 2. Select fax SP3-101-001 and specify the service station.

2.3.2 OPTIONAL HANDSET (ONLY FOR D068/D069)


Accessory Check

Check that you have the components and accessories.


No.	Description	Q'ty
1	Handset	1
2	Handset cradle	1
3	Screws	2
4	Handset manual	1



The handset bracket is not included in the optional handset kit. The bracket is provided as an accessory of the copier.



Installation Procedure






d068i011

- 1. Attach the handset bracket [A] (x 2)
- 2. Remove the label from the handset cradle [B].
- 3. Attach the cradle [B] to the handset bracket (\mathscr{F} x 2).
- 4. Attach the cradle to the bracket (x 2) same as step 3.
- 5. Reattach the label.

Copier



- ↓ Note
 - The bracket is an accessory of the copier.
- 6. Set the handset on the cradle.
- 7. Connect the handset cable to the "TEL" jack and set the telephone cable [A] as shown above.

2.4 PAPER TRAY UNIT

2.4.1 ACCESSORY CHECK

Confirm that you have these accessories.


Description	Q'ty
Paper-size decals	1 sheet
2. Installation Procedure (for service technicians)	1
3. Installation Procedure (for users)	1

SM 2-15 D067/D068/D069/D072


2.4.2 INSTALLATION PROCEDURE

▲CAUTION

Unplug the main machine's power cord before starting the following procedure.



- 1. Remove the tape at [A], and the tape and cardboard at [B].
- 2. Pull the paper tray part way out of the unit, remove the tape and cardboard at [C], and push the tray back in.




3. Set the machine on the paper tray unit.



 When installing a second paper tray unit, place on the first paper tray unit before placing the copier onto the pair of paper tray units

- 4. Remove the paper(s) tray from the paper tray unit(s).
- 5. Load paper into the paper tray(s). Adjust the side and end fences as necessary. If loading $8^{1}/2$ "x 14" paper, remove the end fence and set it into the special compartment.
- 6. Set the paper tray(s) back into the paper tray unit(s).



7. Stick on the appropriate tray-number decal(s) and paper-size decal(s), at the locations indicated in the illustration.

SM 2-17 D067/D068/D069/D072


2.5 PAPER TRAY UNIT HEATER

The paper tray unit heater is installed only for the first paper tray unit.

2.5.1 ACCESSORY CHECK

Confirm that you have the accessories listed below.


Description	Q'ty
1. Grounding wire	1
2. Relay harness	1
3. Clamps	2
4. Ferrite core	1
5. Heater fastening screws	2
6. PTU fastening screws	3
7. Grounding screw	1
8. Decal for copier	1
9. Decal for paper tray unit	1
10. Tie wrap	1



2.5.2 INSTALLATION PROCEDURE

CAUTION

- Unplug the main machine's power cord before starting the following procedure.
- 1. Remove the paper tray unit from the copier if it is already installed.
- 2. Remove the paper trays from the copier and from the paper tray unit.




- 3. Remove the ground screw [1] at the rear of the paper tray unit.
- 4. Fasten the heater [2] and the supplied ground wire [3] to the paper tray unit (x 3).

Paper Tray Unit Heater


Note that [1] is the ground screw you removed in the previous step and [4] and [5] are the two supplied heater fastening screws.




Be sure to position the ground wire [3] and heater harness [6] so that they are out of the way of the copier when you set it on the paper tray unit.




- 5. Set the copier on the paper tray unit.
- 6. Screw the paper tray unit into place using three supplied PTU fastening screws.



- 7. Open the front door and remove the copy tray [7] ($\mathscr{F} \times 1$).
- 8. Close the front door.




- 1. Open the right cover
- 2. Remove the interface cover [8] ($\ensuremath{\mathscr{F}}$ x 1).
- 3. Remove the rear cover [9] (x 5).




- 4. For D068/D069: Remove the upper left cover [10].
- 5. For D068/D069: Remove the controller box [11] ($\mathbb{P} \times 1, \ \mathcal{F} \times 6).$


Paper Tray Unit Heater



6. Remove the support bracket [12] (*x 3).




- 7. Pass the heater harness through the hole [15] at the rear of the copier.
- 8. Pass relay harness [16] through the opening [17] (at the rear of the PSU) and through the other opening [15].
- 9. Connect the relay harness to the heater's harness [18].



- 10. Pull the relay harness back into the copier.
- 11. Attach the ferrite core [19] over the relay harness.
- 12. Push the ferrite core back so that it is over the heater's harness.
- 13. Wrap the heater's harness once around the ferrite core [20].
- 14. Locate the ferrite core at the rear [24] of the copier behind the rear clamps.
- 15. Secure the ferrite core with the supplied tie wrap [21].
- 16. Clip off the excess length of the tie wrap.
- 17. Connect the relay harness connector [22] to the large connector at the front center of the PSU.
- 18. Screw the ground wire [23] to the PSU bracket with the included grounding screw.
- 19. Attach the clamps [24] to the PSU bracket.
- 20. Attach the heater harness though the clamps.
- 21. Position the harness so that the front clamp is between the two bindings [25] on the harness.
- 22. Fasten the clamps.


Paper Tray Unit Heater



23. Pull the excess length of the heater's harness out the opening at the rear.



- Be sure that the harness passes on the side of the grounding plate at the bottom of the opening. (The front of the grounding plate must remain clear.)
- 24. Arrange the excess harness length so that it sits beneath the FCU cover plate.
- 25. Attach the caution decals to the locations shown in the illustration.




- 26. Reassemble the copier.
- 27. Plug in the power cord, and check the operation.

2.6 ARDF (B872)

This procedure explains how to install the ARDF for the Basic model: D067.

2.6.1 ACCESSORY CHECK


Description	Q'ty
1. Stud Screw	1
2. Screw	1
3. Clamp	1
4. DF Exposure Glass with Mylar	1
5. Left Scale Guide	1
Platen Sheet	1
Installation Procedure	1




2.6.2 INSTALLATION PROCEDURE

CAUTION


Unplug the main machine's power cord before starting the following procedure.




1. Unpack the ARDF and remove the packing tape from the bottom of the ARDF body.



- 2. Open the right door [A].
- 3. Remove the interface cover [B] (\mathscr{F} x 1) and rear cover [C] (\mathscr{F} x 5).



4. Remove the left guide [D] (x 2) and scanner left cover [E] (hook x 2).




5. Place the DF exposure glass [F] on the glass holder.




- When installing the DF exposure glass, make sure that the side of the DF exposure glass with two black points faces down.
- Do not hold the Mylar strip when installing the DF exposure glass.
- Make sure that there is no gap between the two Mylar strips and the scanner frame. If there is any gap between them, dust may fall into the scanner unit.


ARDF (B872)




6. Peel off the backing [G] of the double-sided tape attached to the rear side of the left scale guide [H], then install it (x 2 removed in step 4).



- 7. Remove the two platen stays [I] and bracket (x 1 each).
- 8. The bracket is attached to the platen stay of the rear left side. Make sure to remove the bracket at this time.



9. Mount the DF [J] on the copier as shown.




- 10. Secure the screw [K].
- 11. Attach the clamp [L].
- 12. Connect two I/F cables [M] to CN109 and CN110 on the BICU, and secure the ground cable [N] (x 1, 🖳 x 2).




- Make sure that the I/F cable of ARDF is clamped between the two binds [O].
- Reinstall the scanner left side cover removed in step 4.


ARDF (B872)



- 13. Cut the cutout [P] with nippers.
- 14. Reinstall the rear cover and connector cover (x 6).
- 15. Close the right door.



- 16. Open the ARDF.
- 17. Place platen sheet [Q] on the exposure glass.
- 18. Line up the rear left corner of the platen sheet flush against corner [R] on the exposure glass.
- 19. Close the ARDF.



20. Check that the groove [S] of the ARDF is aligned with the groove [T] of the left scale on the scanner.



- The difference in position between [S] and [T] must be within \pm 0.5 mm.
- 21. Reinstall the platen sheet if both grooves are not aligned correctly.
- 22. Plug in and turn on the main power switch.
- 23. Check the ARDF operation.
- 24. Make a full size copy. Then check to make sure the side-to-side and leading edge registrations are correct. If they are not, adjust the side-to-side and leading edge registration (refer to "DF Image Adjustment" in the section "Replacement and Adjustment").

2.7 USB 2.0/SD SLOT TYPE B


This procedure explains how to install the USB 2.0/SD Slot for the SPF model (D069).

2.7.1 ACCESSORY CHECK

Check the quantity and condition of the accessories against the following list.


No.	Description	Q'ty
1	USB2.0/SD Slot	1
2	Ground Plate	1
3	USB Cable	1
4	Screw: M3 x 6 blue	1
5	Screw: M3 x 8	2
6	Screw:	1
7	Clamp	1
8	Decal	1

2.7.2 INSTALLATION PROCEDURE




d068i001

1. Remove the USB connect cover [A].



d068i002

2. Remove the interface cover [A].




- 3. Open the right door [A].
- 4. Rear cover [B] (x 5)





d068i003


5. Remove the upper left cover [A] as shown above.



6. Make three holes in the upper left cover with a screwdriver as shown above.



• Smooth the three holes in the upper left cover.





d068i005

7. Attach the ground plate [A].

8. Secure the USB2.0/SD Slot [B] with the upper left cover as shown above (x 1: M3 x 6 blue, x 2: M3 x 8).





d068i006


9. Make a clamp hole the upper left cover with a screwdriver as shown above.



• Smooth the hole in the upper left cover.



- 10. Attach the upper left cover [A] to the mainframe.
- 11. Attach the rear cover.




12. Attach the cable clamp [A] to the upper left cover (x 1) as shown above.

USB 2.0/SD Slot Type B



- 13. Connect the USB cable [A] to USB-A.
- 14. Attach the interface cover.
- 15. Plug in and turn on the main machine.
- 16. Enter the Scanner SP mode, and then change the setting of SP1013-001 from "0" to "1."



17. Attach the decal [A] to the USB2.0/SD Slot as shown above.

When Installing the Handset

1. Do steps 1 to 8 in "installation procedure."







d068i010

2. Make two holes the upper left cover with a screwdriver as shown above.




Smooth the holes in the upper left cover.





d068i011

- 3. Attach the handset bracket [A] (x 2)
- 4. Attach the cradle [B] to the handset bracket (x 2)



- 5. Set the handset on the handset bracket.
- 6. Connect the handset cable to the "TEL" jack and set the telephone cable [A] as shown above.
- 7. Do steps 13 to 17 in "installation procedure."

2.7.3 TESTING THE SD CARD/USB SLOT

1. Insert an SD card or USB memory device in the slot.

You can connect only one removable memory device at a time.

2. Close the media slot cover.

If you leave the cover open, static electricity conducted through an inserted SD card could cause the machine to malfunction.

3. Make sure that no previous settings remain.

If a previous setting remains, press the [Clear Modes] key.

- 4. Place an original on the exposure glass.
- 5. Press [Store File].
- 6. Press [Store to Memory Device].
- 7. Press [OK].
- 8. Press the [Start] key.

When writing is complete, a confirmation message appears.

- 9. Press [Exit].
- 10. Remove the memory device from the media slot.

Do not remove the memory device while writing is in process.


2.8 OPTIONAL PAPER TRAY GRIP HANDLE

The following procedure is for the paper tray for the main copier or optional paper tray unit.


2.8.1 ACCESSORIES

Check the accessories and their quantities against the table below.

No.	Description	Q'ty
1	Grip Handle	1
2	Screw (M3 x 10)	2




Installation Procedure



1. Remove the paper tray [A] from the main copier.

Optional Paper Tray Grip Handle



- 2. Turn the paper tray over to the opposite side.
- 3. Lower the paper tray grip handle [B] into the paper tray slot as shown, with the arrow in the above illustration.
- 4. Attach the grip handle to the paper tray (x 2).



- When attaching auxiliary handle (two screws attached from bottom), hold handle against front of paper drawer (as screws are tightened) to ensure there is the smallest gap between back of handle and front of paper drawer.
- 5. Put the paper tray back into the machine.

2.9 PRINTER/SCANNER UNIT


This procedure explains how to install the printer/Scanner unit for the basic models (D067/D072).

2.9.1 ACCESSORY CHECK

No.	Description	Q'ty
1	Screw M3 x 6	7
2	Controller Box	1
3	Printer Panel: NA (-15)	1
	Printer Panel: EU (-27)	1
4	Multi-function Panel	1
5	Security Reference (-15)	1
	Quick Reference Printer Guide (-15, -27)	1
	Quick Reference Scanner Guide (-15, -27)	1
6	CD-ROM: Printer (-15)	1
	CD-ROM: Scanner (-15, -27)	1
7	Interface Cover	1
8	FCC Decal (-15)	1
9	Ferrite Core	1
-	Installation Procedure	1
-	Sheet: EULA	1
-	Sheet: CAUTION	1
-	Decal - Power Source : OFF	1

SM 2-41 D067/D068/D069/D072


Printer/Scanner Unit




2.9.2 INSTALLATION PROCEDURE

ACAUTION

Unplug the machine power cord before starting the following procedure.



- 1. Open the right door [A].
- 2. Remove the interface cover [B] (F x 1)
- 3. Remove the rear cover [C] (\mathscr{F} x 5).
- 4. Remove the bracket [D] at the rear left frame of the mainframe ($\hat{\mathcal{F}} \times 2$).
- 5. Remove the scanner upper left cover [E].




6. Cut the opening [F] on the rear cover. This opening is for the network interfaces and the SD card slot and the LAN cable.



• Do not cut the topmost opening [G].

Printer/Scanner Unit




7. Install the ground plate [A] (F x 2).




- Insert the upper and lower hooks in the openings [B], and fasten the upper screw first.
- 8. Install the controller box [C] (x 6).




- Insert the bracket [D] into the frame. The connector on the controller box engages with the connector on the BICU.
- 9. Install PostScript 3 as necessary.



- 10. Remove the front left cover [A] (F x 2).
- 11. Retain the screws and use them in the next step.
- 12. Install the multi-function panel [B] (□ x 1, F x 2).




- 13. Remove the panel cover [A].
- 14. Install the printer panel [B].



15. For the North America model only:

Attach the FCC decal [A] at the right-hand side of the USB connector on the controller box

16. Reassemble the whole copier.



17. Attach the ferrite core [A] to the network cable and attach the cable to the copier if a network cable is used.



- The ferrite core must be attached next to the network cable connector [B].
- 18. Attach the "Power Source: OFF" decal [C] to the under of main power switch at the left side of the machine as shown above.
- 19. Plug in the power cord, and turn on the main switch.
- 20. For the North America model only: Perform the interface settings.
 - 1) Start the SP mode.
 - 2) Select SP5-985-001 (NIC setting) and change the setting value to "1" (ON).
 - 3) Select SP5-985-002 (USB setting) and change the setting value to "1" (ON).
 - 4) Turn the main switch off and on.
- 21. Perform the Printer/Scanner settings.
 - 1) Start the SP mode.
 - 2) Select SP5-801-001 and execute the initialization.
 - 3) Exit the SP mode, and then start the UP mode.
 - 4) Select the "@Remote Service" ("User Tool" > "System Settings > Administrator Tools" > "Extended Security" > @Remote Service") and select "Prohibit."
 - 5) Exit the UP mode, and then start the SP mode.
 - 6) Select SP5-870-003 and execute initialization for @Remote.
 - 7) Select SP5-907-001 and specify the "Plug & Play."
 - 8) Select SP5-870-001 and execute writing certification for `Remote.
 - 9) Select SP5-302-002 and specify the time zone.
 - 10) Select SP5-307-001, 003, and 004 and specify the daylight-saving-time settings.

SM


- 11) Exit the SP mode and turn the main switch off and on.
- 12) Start the UP mode.
- 13) Specify the date and time with "Set Date" or "Set Time" (User Tool" > "System Settings" > "Set Date" or "Set Time").
- 22. Turn the main switch off and on.
- 23. Check the operations.

SM 2-47 D067/D068/D069/D072

2.10 CONTROLLER OPTIONS

2.10.1 OVERVIEW

This machine has I/F card slots and SD card slots for optional I/F connections and applications.



d068i014

I/F Card Slot

 Slot [A] is used for one of the optional I/F connections: (IEEE1284, IEEE802.11a/g (Wireless LAN) or Gigabit Ethernet).

SD Card Slot

- Slot [1] is used for options provided on SD cards. The application SD card (HDD Encryption unit, Overwrite Security Unit or PostScript3) should be installed in Slot 1. If more than one application is to be used, move the applications to the same SD card with SP5873.
- Slot [2] is used for options provided on SD cards and servicing. The VM card must be installed in Slot 2.

SM

2.10.2 POSTSCRIPT3 INSTALLATION

CAUTION

Unplug the machine power cord before starting the following procedure.

Accessories

Check the accessories and their quantities against the table below. Accessories

No.	Description	Q'ty
1	PostScript 3 Emulation SD Card (D468)	1
2	Decal	1

Installation Procedure



d068i016

- 1. Install the PostScript3 SD card [A] into slot 1.
- 2. Turn on the main power switch.
- 3. Print out the configuration page (User Tools/ Counter > Printer Features > List/ Test Print), and then check that this device is detected.
- 4. Attach the "Adobe PostScript3" decal to the front cover of the machine.

2.10.3 WIRELESS LAN (IEEE 802.11A/G) INSTALLATION

CAUTION

Unplug the machine power cord before starting the following procedure.


Accessories

Check the accessories and their quantities against the table below. Accessories

No.	Description	Q'ty
1	Wireless Adapter	1
2	Wireless LAN Card	1
3	LAN Card Cover	4
4	Caution Sheet	1
5	Label	1

Installation Procedure





d068i017

- 1. Remove the interface cover [A] (x 2).
- 2. Install the Wireless adaptor into I/F slot [B] (x 2).
- 3. Install the Wireless LAN card in the wireless adaptor.
- 4. Attach the antenna cap to the wireless LAN card.
- 5. Turn on the main power switch.

6. Print out the configuration page (User Tools/Counter > Printer Features > List/Test Print), and then check that this device is detected.

If reception is poor, you may need to move the machine:

- Make sure that the machine is not located near an appliance or any type of equipment that could generate a strong magnetic field.
- Position the machine as close as possible to the access point.

SP Mode Settings for IEEE 802.11a/g Wireless LAN

The following SP commands can be set for IEEE 802.11a/g

SP No.	Name	Function
5840 004	SSID	Used to confirm the current SSID setting.
5840 006	Channel MAX	Sets the maximum range of the channel settings for the country.
5840 007	Channel MIN	Sets the minimum range of the channel settings allowed for your country.
5840 011	WEP Key Select	Used to select the WEP key (Default: 00).
5840 018	SSID Check	Used to check the SSID.
5840 020	WEP Mode	Used to display the maximum length of the string that can be used for the WEP Key entry.

SM 2-51 D067/D068/D069/D072

2.10.4 IEEE 1284 INSTALLATION

CAUTION

Unplug the machine power cord before starting the following procedure.


Accessories

Check the accessories and their quantities against the table below. Accessories

No.	Description	Q'ty
1	IEEE1284 Interface Ass'y	1
2	UL Sheet	1
3	Caution Sheet	1

Installation Procedure





d068i017

- 1. Remove the interface cover [A] (x 2).
- 2. Install the IEEE 1284 board into I/F slot [B] (x 2).
- 3. Turn on the main power switch.
- 4. Print out the configuration page (User Tools/Counter > Printer Features > List/Test Print), and then check that this device is detected.


2.10.5 VM CARD TYPE L (D467)

Accessories

Check the accessories and their quantities against the table below. Accessories

No.	Description	Q'ty
1	VM SD Card	1
2	Decal	1

Installation



d068i019

- 1. Switch the machine off.
- 2. Insert the SD card [A] into SD Slot 2 (lower).




• This SD card must be inserted into Slot 2, the lower slot.


SM 2-53 D067/D068/D069/D072

2.10.6 GIGABIT ETHERNET

CAUTION


Unplug the main machine power cord before you do the following procedure.





d068i017

- 1. Remove the I/F-slot cover [A] (x 2).
- 2. Install the Gigabit Ethernet board (Knob-screw x 2) into the I/F-slot [B].



d067r113


- 3. Attach one ferrite core [A] to the Ethernet interface cable, and then attach the other ferrite core [B] about 10cm from the end of the Ethernet interface cable.
- Connect the Ethernet interface cable to the Gigabit Ethernet port.
 Make sure that the machine can recognize this option (see 'Check All Connections' at the

end of this section).


2.10.7 HDD OPTION (D467, ONLY FOR D067/D068)

Component Check


No.	Description	Q'ty
1	HDD Unit	1
2	Screw	3
3	Keytop: Copy (Not used)	2
	Keytop: Document Server (Not used)	2
-	Knob Screw (Not used)	3



Installation Procedure



Controller box cover [A] (x 13)







d068r028

- 1. Remove the screw [A] on the controller board.
- 2. Install the HDD unit [B] in the controller board ($\ensuremath{\mathscr{F}}$ x 3).



- The screw [A] is used in this step.
- 3. Reinstall the controller board in the machine.

After Installing the HDD

- 1. Do SP5832-001 to format the hard disk.
- ⇒ 2. Turn the main power switch OFF/ON.

2.10.8 DATAOVERWRITESECURITY UNIT TYPE I (D362)

Before You Begin the Procedure


- Confirm that the DataOverwriteSecurity unit SD card is the correct type for the machine. The correct type for this machine is "Type I."
- 2. Make sure that the following settings are not at their factory default values:
 - Supervisor login password
 - Administrator login name
 - Administrator login password

If any of these settings is at a factory default value, tell the customer these settings must be changed before you do the installation procedure.

- 3. Make sure that "Admin. Authentication" is ON.
 - [System Settings] [Administrator Tools] [Administrator Authentication Management]
 - [Admin. Authentication]
 - If this setting is OFF, tell the customer this setting must be ON before you do the installation procedure.
- 4. Make sure that "Administrator Tools" is enabled (selected).
 - $[System\ Settings] [Administrator\ Tools] [Administrator\ Authentication\ Management]$
 - [Available Settings]
 - If this setting is disabled (not selected), tell the customer this setting must be enabled (selected) before you do the installation procedure.

SM 2-57 D067/D068/D069/D072

Seal Check and Removal



ACAUTION

- You must check the box seals to make sure that they were not removed after the items were sealed in the box at the factory before you do the installation.
- 1. Check the box seals [A] on each corner of the box.
 - Make sure that a tape is attached to each corner.
 - The surfaces of the tapes must be blank. If you see "VOID" on the tapes, do not install the components in the box.
- 2. If the surfaces of the tapes do not show "VOID", remove them from the corners of the box.
- 3. You can see the "VOID" marks [B] when you remove each seal. In this condition, they cannot be attached to the box again.


Installation Procedure



Unplug the main machine power cord before you do the following procedure.



- You must install the DataOverwriteSecurity unit in SD Card slot 1. However, the Postscript option and others are also installed in SD Card slot 1. You must do the "SD Card Appli Move" procedure first if you want to install the Data Overwrite Security unit.
- 1. Turn off the main power switch if the machine is turned on.
- 2. Disconnect the network cable if it is connected.



- d068i016
- 3. Turn the SD-card label face [A] to the rear of the machine. Then push it slowly into slot 1 until you hear a click.
- 4. Connect the network cable if it needs to be connected.
- 5. Turn on the main power switch.
- 6. Input a machine serial number with SP 5811-001.
- 7. Go into the SP mode and push "EXECUTE" with SP5-878-001.
- 8. Exit the SP mode and turn off the operation switch. Then turn off the main power switch.
- 9. Turn on the machine power.
- 10. Go into the User Tools mode, and select System Settings> Administrator Tools> Auto Erase Memory Setting> On.
- 11. Exit the User Tools mode.

2.10.9 HDD ENCRYPTION UNIT (D377)

Before You Begin the Procedure

- 1. Make sure that the following settings are not at the factory default settings:
 - Supervisor login password
 - Administrator login name
 - Administrator login password



- These settings must be set up by the customer before the HDD Encryption unit can be installed.
- 2. Confirm that "Admin. Authentication" is on:

[User Tools] > "System Settings"> "Administrator Tools"> "Administrator Authentication Management"> "Admin. Authentication"> "On"

If this setting is "Off", tell the customer that this setting must be "On" before you can do the installation procedure.

3. Confirm that "Administrator Tools" is selected and enabled:


[User Tools]> "System Settings"> "Administrator Tools"> "Administrator Authentication Management"> "Available Settings"



"Available Settings" is not displayed until Step 2 is done.

If this setting is not selected, tell the customer that this setting must be selected before you can do the installation procedure.


Seal Check and Removal





- You must check the box seals to make sure that they were not removed after the items were sealed in the box at the factory before you do the installation.
- 1. Check the box seals [A] on each corner of the box.
 - Make sure that a tape is attached to each corner.
 - The surfaces of the tapes must be blank. If you see "VOID" on the tapes, do not install the components in the box.
- 2. If the surfaces of the tapes do not show "VOID", remove them from the corners of the box.
- 3. You can see the "VOID" marks [B] when you remove each seal. In this condition, they cannot be attached to the box again.


Installation Procedure



d068i016

- 1. Turn the SD-card label to face [A] the rear of the machine. Then push it slowly into slot 1 until you hear a click.
- 2. Turn on the main power switch, and then enter the SP mode.
- 3. Select SP5878-002, and then press "Execute" on the LCD.
- 4. Exit the SP mode after "Completed" is displayed on the LCD.
- 5. Turn off the main power switch.
- 6. Remove the SD card from slot 1.

Recovery from a Device Problem



Restoring the Encryption key

When replacing the controller board for a model in which the HDD encryption unit has been installed, updating the encryption key is required.

- 1. Prepare an SD card which is initialized.
- 2. Make the "restore key" folder in the SD card.
- 3. Make an "nvram_key.txt" file in the "restore_key" folder in the SD card.
- 4. Ask an administrator to input the encryption key (this has been printed out earlier by the user) into the "nvram_key.txt" file.
- 5. Remove only the HDD unit (HDD).
- 6. Turn on the main power switch.
- 7. Confirm that the prompt on the LCD tells you to install the SD card (storing the encryption key) in the machine.
- 8. Turn off the main power switch.
- 9. Insert the SD card that contains the encryption key into slot 1.
- 10. Turn on the main power switch, and the machine automatically restores the encryption key in the flash memory on the controller board.
- 11. Turn off the main power switch after the machine has returned to normal status.
- 12. Remove the SD card from slot 1.
- 13. Reinstall the HDD unit.

Clearing the NVRAM

When replacing the controller board for a model in which the HDD encryption unit has been installed and a customer has lost the encryption key, clearing the NVRAM is required to recover the HDD encryption unit.

- 1. Prepare an SD card which is initialized.
- 2. Make the "restore_key" folder in the SD card.
- 3. Make an "nvram_key.txt" file in the "restore_key" folder in the SD card.
- 4. Input "nvclear" into the "nvram key.txt" file.
- 5. Turn on the main power switch.
- 6. Confirm that the prompt on the LCD tells you to install the SD card (storing the encryption key) in the machine.
- 7. Turn off the main power switch.
- 8. Insert the SD card that contains "nvclear" into slot 1.
- Turn on the main power switch, and the machine automatically restores the encryption key in the flash memory on the controller board.
- 10. Turn off the main power switch after the machine has returned to normal status.
- 11. Remove the SD card from slot 1.
- 12. Turn on the main power switch.
- 13. Initialize the NVRAM (SP5801-001) and HDD unit (SP5832-001) with SP mode.
- 14. The user must enable the HDD encryption unit with a user tool.

⇒2.11 KEY COUNTER (CARD) INTERFACE TYPE A

Installation Procedure for the Key Counter (Card) Interface Type A (20 pins)

2.11.1 ACCESSORY CHECK

No.	Description		
1.	MKB (bridge board)		
2.	BRACKET:MKB	B2621310	
3.	SCREW:M3X6	03530060 F	
4.	CLAMP:LWS-0711Z	11050508	

2.11.2 INSTALLATION PROCEDURE


- 1. Remove the rear cover.
- 2. Remove the cut-out in the rear cover (circled in red in the photo).









3. Attach the MKB bracket and harness clamp to the MKB (3 x 🖗).



- Attach the MKB + bracket to the copier
 (2 x §²).
- Connect one end of the MKB harness to CN3
 (13 pins) on the MKB.
- Connect the other end of the MKB harness to CN149 (13 pins) on the BICU.





SM 2-65 D067/D068/D069/D072



- 7. Connect the vendor's harness for the external key counter device to CN4 (20 pins) on the MKB.
- 8. Reattach the rear cover.

IMPORTANT: Pass the vendor's harness through the cut-out hole from Step 2.



PREVENTIVE MAINTENANCE

REVISION HISTORY		
Page	Date	Added/Updated/New
		None

3. PREVENTIVE MAINTENANCE


3.1 MAINTENANCE TABLES

See "Appendices" for the following information:

PM tables

3.2 HOW TO CLEAR THE PM COUNTER

Reset the PM counter after your maintenance work.



- 1. Activate the SP mode.
- 2. Select SP7-804-001.
- 3. Press the EXECUTE key [A]. The message "Completed" is displayed when the program ends normally. An error message is displayed if the program ends abnormally.
- 4. Press the Escape key [B] to end the program.

REPLACEMENT & ADJUSTMENT

REVISION HISTORY			
Page	Date	Added/Updated/New	
		None	

4. REPLACEMENT & ADJUSTMENT

4.1 PRECAUTIONS

4.1.1 GENERAL

∴ CAUTION

 Turn off the main power switch and unplug the machine before starting replacement.

Before turning off the main power switch, check that no mechanical component is operating. Mechanical components may stop out of their home positions if you turn off the main power switch while they are operating. The component may be damaged if you try to remove it when it is not in the home position.

4.1.2 LITHIUM BATTERIES

∴CAUTION

• Incorrect replacement of lithium battery(s) on the controller or on the fax unit poses risk of explosion. Replace only with the same type or with an equivalent type recommended by the manufacturer. Discard used batteries in accordance with the manufacturer's instructions.

4.1.3 HALOGEN-FREE CABLE

ACAUTION

Use extreme caution while handling cables.

To comply with local regulations, halogen-free cables are used in this machine.

Halogen-free cables are environment-friendly, but no stronger than conventional cables.

These cables may be damaged in any of the following cases:

- The cable is caught between hard objects such as brackets, screws, PCBs, and exterior covers.
- The cable is rubbed on a hard object such as brackets, screws, PCBs, and exterior covers.
- The cable is scratched with a hard object such as brackets, screws, PCBs, exterior covers, screwdrivers, and fingernails.


SM 4-1 D067/D068/D069/D072

4.2 SPECIAL TOOLS AND LUBRICANTS

Part Number	Description	Q'ty
A1849501	Optics Adjustment Tools (2 pcs/set)	1 set
A2929500	Test Chart – S5S (10 pcs/set)	1 set
VSSM9000	Digital Multimeter – Fluke 87	1
N8036701	Flash Memory Card (4MB)	1
N8031000	Case for Flash Memory Card	1
A2579300	Grease Barrierta – S552R	1
52039502	Silicon Grease 501	1

4.3 EXTERIOR COVERS AND OPERATION PANEL

4.3.1 REAR COVER




- 1. Open the right door [A].
- 2. Interface cover [B] (x 1)
- 3. Rear cover [C] (x 5)

SM 4-3 D067/D068/D069/D072

4.3.2 COPY TRAY

ACAUTION

• Make sure that the cables under the copy tray are in place before reassembling the copier. If these cables are caught between the copy tray and the inner cover, they may be severely damaged.




- 1. Open the front door [A].
- 2. Copy tray [B] (x1)

Reassembling:

There are several cables under the front end of the copy tray. To set these cables in place, gently pull these cables to the left-hand side (toward the PSU) and hold them there as you attach the copy tray.


Replacement & Adjustment

4.3.3 SCALE PLATE (D067 ONLY)



1. Scale plate [A] (x 2)

4.3.4 OPERATION PANEL AND UPPER COVERS




1. Remove the ARDF.



- For D072: Remove the ARDF, if it has been installed.
- 2. Rear cover (Rear Cover")
- 3. Slide the upper left cover [A] to the rear.
- 4. Rear scale [B] (x 3)
- 5. Slide the upper right cover [C] to the rear.
- 6. Front left cover [D] (x 2)
- 7. Operation panel [E] (x 4, 🔎 x 1)


8. Front right cover [F]

4.3.5 RIGHT DOOR



- 1. Open the right door [A].
- 2. Release the strap [B].
- 3. Right door (x 1)


4.3.6 BYPASS TRAY



1. Press the stopper rails [A] inward.

Replacement & Adjustment

4.3.7 PLATEN COVER SENSOR



b262r505

- 1. Rear cover ("Rear Cover")
- 2. Rear scale ("Operation Panel and Upper Covers")
- 3. Platen cover sensor [A] (x 1, hook)


SM 4-7 D067/D068/D069/D072

4.4 SCANNER UNIT

To clean the mirrors and lenses, use a blower brush or wet cotton.

4.4.1 EXPOSURE GLASS

To clean the exposure glass, use alcohol or glass cleaner.



Non-ARDF machines

- 1. Rear cover (Rear Cover")
- 2. Scale plate ("Operation Panel and Upper Covers")
- 3. Exposure glass [A]

ARDF-equipped machines

- 1. Rear cover (Rear Cover")
- 2. Rear scale, upper right cover ("Operation Panel and Upper Covers")
- 3. Exposure glass [A]

Reassembling

Make sure that the marking on the glass is at the rear left corner, and that the left edge of the glass is aligned flush against the support ridge [B] on the frame.


Adjustment

When replacing the white plate, perform the "Scan Auto Adjustment" (SP4-428-001).

4.4.2 LENS BLOCK

ACAUTION

- Do not disassemble the lens block. The lens block is precision adjusted before shipment.
- Do not touch the screws on the CCD. The CCD is precision adjusted before shipment.




- 1. Exposure glass (**☞** "Exposure Glass")
- 2. Front left cover, operation panel ("Operation Panel and Upper Covers")
- 3. Release the cable from the four clamps [A].
- 4. Lens block [B] (x 4, 1 flat cable)



- Do not loosen the paint-locked screws holding the lens unit in place.
- After installing a new lens block, carry out copy adjustments ("Adjusting Copy Image Area").

4.4.3 EXPOSURE LAMP, LAMP STABILIZER BOARD


Do not fold the exposure cable on the exposure lamp.




- 1. Exposure glass ("Exposure Glass")
- 2. Front left cover, operation panel ("Operation Panel and Upper Covers")
- 3. Slide the first scanner to a position where the lamp and scanner are clear of the metal lids.
- 4. Disconnect the lamp connector [A].
- 5. Remove either or both of the following:
 - Exposure lamp [B] (x 1)
 - Lamp stabilizer board [C] (x 2, 1 flat cable)

4.4.4 SCANNER MOTOR

- 1. Rear cover (Rear Cover")
- 2. Rear scale, upper right cover ("Operation Panel and Upper Covers")



3. Remove the right platen stay holder [A] (x 3).




4. Scanner motor [B] (x 3, 1 spring, 3 screw holders, 1 x 1)

Reinstalling

When reinstalling, fasten the screws loosely, set the spring in place, and tighten up the screws.

4.4.5 SCANNER HP SENSOR



b262r506


- 1. Rear cover (Rear Cover")
- 2. Front left cover ("Operation Panel and Upper Covers")
- 3. Scale plate ("Scale Plate")
- 4. Scanner HP sensor [A] (x 1, hook)



• Move the first scanner from the home position if you have difficulty removing the sensor.

4.4.6 SCANNER ALIGNMENT ADJUSTMENT


- 1. Rear cover (Rear Cover")
- 2. Rear scale, upper right cover, front left cover, operation panel ("Operation Panel and Upper Covers")
- 3. Exposure glass (** "Exposure Glass")
- 4. Loosen the 2 screws holding the 1st and 2nd scanner belts in place.



- 5. Slide the 1st and 2nd scanners so that all four of the following are roughly aligned on both the front and back sides:
 - The hole in the copier's lid
 - The hole in the 1st scanner
 - The right corner hole in the 2nd scanner
 - The hole at the base of the scanner

SM 4-13 D067/D068/D069/D072

Scanner Unit




- 6. Insert the two optics adjustment tools [A], and adjust the scanners as necessary so that the tools go through all four holes.
- 7. Tighten the two screws that you loosened at step 2 above, so that the belts are firmly clamped into place.
- 8. Remove the adjustment tools.

4.5 FUSING

4.5.1 FUSING UNIT

△CAUTION

 Before handling the fusing unit, make sure that the unit is cool enough. The fusing unit can be very hot.



b130r950


- 1. Copy tray (Topy Tray")
- 2. Open the right door.
- 3. Connector cover [A] (x 1)



- When reinstalling, attach the ground wire.
- 4. Fusing unit [B] (x 2, 4)

Fusing

4.5.2 EXIT SENSOR




- 1. Fusing unit ("Fusing Unit")
- 2. Exit sensor [A] (x 1)

4.5.3 HOT ROLLER STRIPPER PAWLS



Take care not to damage the hot roller stripper pawls and the tension springs.



- 1. Fusing unit ("Fusing Unit")
- 2. Separate the fusing unit into two sections: the hot roller section [A] and the pressure roller section [B] (x 2).

After removing the screws, lower the pressure roller section about halfway and then slide it toward the front side to detach it.

- 3. Support rollers [C]
- 4. Hot roller stripper pawls [D]




■ Remove the spacer [E] (x 1) if you are removing the hot roller assembly (Hot Roller & Fusing Lamp").

SM 4-17 D067/D068/D069/D072

4.5.4 HOT ROLLER AND FUSING LAMP

CAUTION


Do not touch the fusing lamp and rollers with your bare hands.



- 1. Hot roller stripper pawls and spacers ("Hot Roller Stripper Pawls")
- 2. Hot roller assembly [A] (x 2)
- 3. Fusing lamp [B]



• When reassembling, check that the direction of the fusing lamp is correct.




4. Hot roller [C] (2 C-rings, 1 spacer, 1 gear, 2 bushings, 1 cover [D])

Reassembling

Be sure that:

- The fusing lamp is positioned correctly.
- The fusing lamp does not touch the internal part of the hot roller.

4.5.5 THERMOSWITCHES AND THERMISTOR



- 1. Hot roller assembly (* "Hot Roller & Fusing Lamp")
- 2. Thermoswitches (F x 2 for each)
- 3. Thermistor (F x 1)

Reassembling

Make sure of the following:


- That the thermistor is in contact with the hot roller.
- That the hot roller turns smoothly.




Do not recycle a thermoswitch that is already opened. Safety is not guaranteed if you do this.

SM 4-19 D067/D068/D069/D072

4.5.6 PRESSURE ROLLER



- 1. Separate the fusing unit into two sections ("Hot Roller Stripper Pawls").
- 2. Fusing entrance guide [A]



- 3. Two springs [B][C]
- 4. Two pressure arms [D][E]
- 5. Bushing [F]
- 6. Pressure roller [G]

4.5.7 CHECKING THE NIP BAND

You can check the nip band to see if the fusing unit is in a good condition—especially, if the hot roller and pressure roller are correctly installed.

- 1. Activate the SP mode.
- 2. Select SP1-109-001.
- 3. Specify "1."
- 4. Press the OK key.
- 5. Press the key. The copy mode is activated.
- 6. Place an OHP sheet on the by-pass tray.
- 7. Press the New Yellow New Yello
- 8. Wait until the OHP sheet is output.
- 9. Press the \$ key.
- 10. Make sure SP1-109-001 is selected.
- 11. Specify "0."
- 12. Press the OK key.
- 13. Quit the SP mode.

You see an opaque stripe on the OHP sheet. This is the trace of the nip band. The normal nip band is symmetrical on the OHP sheet. Both ends are slightly thicker than the center.



There are no specifications or standards for the nip band of this copier.


SM 4-21 D067/D068/D069/D072

4.6 PCU AND QUENCHING LAMP

When handling the photo conductor unit (PCU), use caution:

- Do not touch the OPC drum with your bare hands. When the OPC drum is unclean, clean it with dry cloth, or clean it with wet cotton and wipe it with dry cloth.
- Do not use alcohol or any other chemicals to clean the OPC drum. These substances damage the OPC-drum surface.
- Keep PCUs in a cool, dry place.
- Do not expose the OPC to any corrosive gas such as ammonia.
- Do not shake a used PCU. Remaining toner and developer may spill out.
- Dispose of used PCUs in accordance with local regulations.

4.6.1 PCU



1. Open the right door.



- The PCU may become stuck if you try to remove it while the right door is closed.
- 2. Open the front door.
- 3. Remove the toner bottle holder.




- Clean all spilled toner off the toner bottle area and the inside of the front door.
- 4. Pull out the PCU [A] (x 1).
- 5. When having installed a new PCU, remove the Styrofoam and tags ("Installation Procedure" in the chapter "Installation").

Initialization

After you turn on the main power switch, the copier automatically initializes the new PCU. When the copier is executing initialization, it is important that you:

- Do not turn off the main power switch.
- Do not open or remove exterior covers.


4.6.2 QUENCHING LAMP



- 1. PCU ("PCU")
- 2. Quenching lamp [A] (x 1)

4.7 EXHAUST FAN AND MAIN MOTOR

4.7.1 EXHAUST FAN




- 1. Rear cover (Rear Cover")
- 2. Exhaust fan [A] (x 2, 1 x 1)

Reassembling


Make sure that the arrow [B] on the frame points to the rear side. The arrow indicates the direction of airflow.

SM 4-25 D067/D068/D069/D072

4.7.2 MAIN MOTOR



- 1. Rear cover (☞ "Rear Cover")
- 2. High-voltage power supply board ("High-Voltage Power Supply Board")
- 3. Ground plate [A] (x 1)
- 4. Main motor with the gear cover [B] (x 1, F x 7, C x 2, 2 bushings)



- 5. All gears [C]
- 6. Main motor [D] (x 4)

Reassembling


Attach the main motor before attaching the gears.

4.8 PAPER FEED

4.8.1 PAPER FEED ROLLER AND FRICTION PAD

When handling the paper tray or the paper feed roller, use caution:


- Do not touch the surface of paper feed rollers.
- To avoid paper jams, correctly set the side and end fences in the paper tray.



- 1. Paper tray
- 2. Shaft [A] ((() x 1)
- 3. Remove either or both of the following:
 - Paper feed roller [B]
 - Friction pad [C]


SM 4-27 D067/D068/D069/D072

4.8.2 PAPER END SENSOR



- 1. Paper tray
- 2. Open the right door.
- 3. PCU (** "PCU")
- 4. Paper end sensor [A] (x 1)

4.8.3 REGISTRATION SENSOR



- 1. Paper tray
- 2. Open the right door.
- 3. Open the paper guide [A].




- Remove the paper guide (Clip x 1) if you have difficulty removing the registration sensor.
- 4. Registration sensor feeler [B]
- 5. Registration sensor [C] (x 1)



 Disconnect the connector (BICU CN127 [D]) if you have difficulty removing the registration sensor.


SM 4-29 D067/D068/D069/D072

4.8.4 BYPASS PAPER END SENSOR




- 1. Right door (Right Door")
- 2. Sensor compartment [A]
- 3. Bypass paper end sensor [B] (x 1)

4.8.5 BYPASS FEED ROLLER




- 1. Right door (Right Door")
- 2. Turn the feed roller housing upside down [A] (x 2).




- 3. Feed roller shaft [B] (2 snap pawls [C], 1 spacer [D])
- 4. Bypass feed roller [E]

SM 4-31 D067/D068/D069/D072

4.8.6 BYPASS FEED CLUTCH AND FRICTION PAD




- 1. Rear cover ("Rear Cover")
- 2. Right door ("Right Door")
- 3. Disconnect the bypass feed clutch connector [A] (CN93).
- 4. Bypass feed roller housing [B] (x 2)
- 5. Bypass feed clutch [C] (© x 1)



6. Bypass friction pad [D]

4.8.7 PAPER FEED AND REGISTRATION CLUTCHES




- 1. Paper tray
- 2. High-voltage power supply board ("High-Voltage Power Supply Board")
- 3. Ground plate [A] (x 1)
- 4. Gear cover [B] (x 1, F x 7, C x 2, 2 bushings)



• Do not remove the main motor from the gear cover.

SM 4-33 D067/D068/D069/D072

Paper Feed




- 5. Ground plate [C] (x 1)
- 6. Slowly push the clutch holder [D] and remove the registration clutch [E] (♥ x 1, ♥ x 1).
- 7. Paper feed clutch [F]

4.9 IMAGE TRANSFER

4.9.1 TRANSFER ROLLER

▲CAUTION

- Do not touch the transfer roller with your bare hands.
- Do not scratch the transfer roller. The transfer roller is easily damaged.




- 1. Right door (Right Door")
- 2. Raise the levers [A],[B] at the ends of the image transfer roller.
- 3. Release the image transfer roller [C].

Reassembling


Make sure that the springs [D] are in the original positions.

SM 4-35 D067/D068/D069/D072

4.9.2 ID SENSOR AND DUPLEX ROLLER




- 1. Right door (Right Door")
- 2. Lower guide [A]
- 3. Idle roller holders [B][C]
- 4. Idle roller [D]
- 5. Roller guide [E]
- 6. Transfer unit [F]
- 7. One-way gear [G] (© x 1)
- 8. Duplex roller [H] (© x 1, 3 bushings)



9. ID sensor [I] (x 1)

4.9.3 DISCHARGE PLATE



- 1. Right door (Right Door")
- 2. Discharge plate [A]

SM 4-37 D067/D068/D069/D072

4.10 BICU AND CONTROLLER BOARD

CAUTION

- Turn off the main power switch and unplug the machine before starting replacement.
- Before turning off the main power switch, check that no mechanical component is operating. Mechanical components may stop out of their home positions if you turn off the main power switch while they are operating. The component may be damaged if you try to remove it when it is not in the home position.

For basic models (D067/D072):

The table lists the components and necessary maintenance work


Model	BICU NVRAM	Controller Box	Controller NVRAM	Maintenance Work
Basic	Installed	None	None	Save the data from the NVRAM to a memory card before replacing the NVRAM.

4.10.1 BICU

Preparation

- Before replacing the NVRAM, be sure to save the NVRAM data.
- Saving from the BICU NVRAM to an SD card ("NVRAM Data Upload/Download (SP5-824/825)" in the "System Service Mode" of the appendices of the this manual.)


Procedure



- 1. Rear cover (Rear Cover")
- 2. Scanner upper left cover ("Operation Panel and Upper Covers")

SM 4-39 D067/D068/D069/D072

BICU and Controller Board



- 4. Ground plate [B] (x 2)
- 5. BICU [C] (all , 2 flat cables, F x 6)



- When replacing the BICU, remove the NVRAM [D] from the board. Install the NVRAM to the new board.
- 6. After replacing the NVRAM, copy the saved data to the NVRAM.
 - From an SD card to the NVRAM ("NVRAM Data Upload/Download (SP5-824/825)" in the "System Service Mode" of the appendices of the this manual.)


4.10.2 CONTROLLER BOARD (F/SPF MODELS: D068/D069)

Preparation:

- Before replacing the controller board, be sure to print out SMC or save the NVRAM data
- Saving from the Controller NVRAM to an SD card ("NVRAM Data Upload/Download (SP5-824/825)" in the "System Service Mode" of the appendices of the this manual.)

Procedure


- 1. Rear cover (Rear Cover")
- 2. Scanner upper left cover (**►** "Operation Panel and Upper Covers")
- 3. FCU ("FCU")




d068r020

- 4. Remove the printer/scanner SD card.
- 5. Remove I/F cover [A] (or I/F options if they have been installed) (x 2).
- 6. Remove the bracket [B] (x 1).
- 7. Remove the USB cap [C].

BICU and Controller Board



- 8. Remove the relay connector [A].
- 9. Remove the ground plate [B] (x 1).
- 10. Remove the controller board with the rails [C] ($\ensuremath{\mathscr{F}}$ x 6).




11. Release the hooks, and then pull out the rails [A].

12. Remove the DIMM [B] if it has been installed.



When replacing the controller board, remove the NVRAMs from the board.
 Install the NVRAMs to the new board.

When replacing the NVRAM on the controller board



- 1. When you replace the NVRAM [A], make sure that the NVRAM is correctly installed.
- 2. The mark [B] on the NVRAM should be directed to the down side (seem from the back side of the machine).
- 3. Reassemble the machine.
- 4. Copy the old NVRAM data to the new NVRAM with SP5-825 or input the SMC data in the machine. (For details, refer to the "NVRAM Data Upload/Download [SP5-824/825]" in the "System Service Mode" of the appendices of the this manual)


When Installing the Printer/Scanner Unit (D468)

Refer to procedure "Controller Board (F/SPF models: D068/D069)" in this section, and carry out the steps (without step 3).

SM 4-43 D067/D068/D069/D072


4.11 OTHER REPLACEMENTS

4.11.1 DUPLEX MOTOR



- 1. Rear cover (Rear Cover")
- 2. Duplex motor [A] (🗐 x 1, 🖗 x 2)

4.11.2 HIGH-VOLTAGE POWER SUPPLY BOARD




- 1. Rear cover (Rear Cover")
- 2. High-voltage power supply board [A] (all , \mathcal{F} x 4)




Remove the insulating sheet [B] if you are going to remove the contact-release solenoid ("Contact-Release Solenoid") or the gear cover ("Paper Feed and Registration Clutches").

SM 4-45 D067/D068/D069/D072

4.11.3 PSU




- 1. Open the front door.
- 2. Copy tray ("Copy Tray")
- 3. PSU assembly [A] (x 4, F x 8)



4. PSU [B] (🕮 x 4, 🖗 x 6)


4.11.4 CONTACT-RELEASE SOLENOID



- 1. Rear cover ("Rear Cover")
- 2. High-voltage power supply board ("High-Voltage Power Supply Board")
- 3. Contact-release solenoid [A] (1 spring, ₱ x 1)

SM 4-47 D067/D068/D069/D072

4.11.5 TONER SUPPLY CLUTCH



- 1. Toner bottle holder
- 2. Copy tray (Copy Tray")
- 3. Rear cover (Rear Cover")
- 4. Disconnect the connector on C19 on the BICU.
- 5. Push the clutch coupler [A] to the rear side, and remove the clip ring [B] from the back of the copier.
- 6. Coupler and spring [C]
- 7. Lift the toner supply clutch [D] and remove it.



When removing, note how the wire goes through a clamp, and also note where it passes through the rear of the machine.


4.11.6 FCU (FOR D068/D069)

Lithium Batteries



• Incorrect replacement of lithium battery(s) on the controller or on the fax unit poses risk of explosion. Replace only with the same type or with an equivalent type recommended by the manufacturer. Discard used batteries in accordance with the manufacturer's instructions.


Procedure




- 1. Open the right door [A].
- 2. Rear cover [B] (x 5).
- 3. Scanner upper left cover [C]


SM 4-49 D067/D068/D069/D072

Other Replacements



4. Controller box cover [A] (x 13)





d068r026

- 5. FCU [A] (x 4, □ x 1)
- 6. When you replace the FCU board, remove the MBU board from the old FCU board and install it on the new FCU board.
- 7. Set the correct date and time with the User Tools: User Tools> System Settings> Timer Setting> Set Date/Time



- Do not turn off the battery switch (SW1).
- Do SP6-101 in the "Fax SP" to print the system parameters, and check the settings.

4.12 LASER UNIT


∴WARNING

Turn off the main power switch and unplug the copier before starting replacement.
 The laser beam can damage your eyes severely.

▲CAUTION


- Do not touch the screws on the LD board on the LD unit. Do not try to adjust any part of the LD unit. The LD unit is precision adjusted before shipment.
- Do not touch the polygon mirror, shield glass, or lenses with your bare hands.

4.12.1 LOCATION OF THE CAUTION DECAL




SM 4-51 D067/D068/D069/D072

4.12.2 LASER UNIT




- 1. PSU assembly ("PSU")
- 2. Toner bottle holder
- 3. Laser unit [A] (x 3, 1 x 2)

Reassembling



Make sure that the cable [B] passes under the unit.

4.12.3 LD UNIT AND POLYGON MIRROR MOTOR



- 1. Laser unit ("Laser Unit")
- 2. Laser unit cover [A] (x 2, 1 grounding plate)
- 3. LD unit [B] (x 2)
- 4. Polygon mirror motor [C] (x 4)


Reassembling

Check that the polygon mirror and toroidal lens are clean. Dust or other foreign substances may interfere with the operation of the LD unit.

4.13 ARDF


4.13.1 ARDF

1. Rear cover (Rear Cover")




- 3. Remove the ground cable [B] (x 1).
- 4. Remove the stud screw [C].
- 5. Remove the ARDF [D].

4.13.2 DF REAR COVER




- 1. Open the ARDF [A].
- 2. Release the three hooks



- 3. Open the DF left cover [B].
- 4. Open the original tray [C].
- 5. DF rear cover [D] (\mathscr{F} x 1, hook x 4)


4.13.3 ORIGINAL FEED UNIT

1. Open the DF left cover.



4.13.4 SEPARATION ROLLER


- 1. Open the DF left cover.
- 2. Original feed unit ("Original Feed Unit")



- 3. Separation roller cover [A] (hook x 2)
- 4. Separation roller stopper [B] (hook)
- 5. Separation roller [C]

4.13.5 DF DRIVE BOARD


1. DF rear cover ("DF Rear Cover")



2. DF drive board [A] (x 2, I x 4, ground cable x 1)

4.13.6 ORIGINAL SET AND DF INVERTER SENSOR


- 1. Open the DF left cover.
- 2. Original feed unit ("Original Feed Unit")
- 3. DF feed clutch ("DF Feed Clutch")




- 4. Original feed-in guide plate [A] (x 2).
- 5. Original set sensor [B] (x 1, hook)
- 6. DF inverter sensor [C] (x 1, hook)

4.13.7 DF REGISTRATION AND DF EXIT SENSOR

- 1. Open the DF left cover.
- 2. Original feed unit ("Original Feed Unit")
- 3. DF feed clutch ("DF Feed Clutch")
- 4. Original feed-in guide plate ("Original Set and Inverter Sensor")
- 5. DF feed motor (TP Feed Motor")
- 6. DF transport motor (TP Transport Motor")



- 7. DF transport roller [A] (\mathbb{C} x 2, gear x 2, bushing x 2)
- 8. DF separation roller unit [B] (© x 2, gear x 1, bushing x 2)
- 9. Inverter upper guide plate [C] (x 4, 🛍 x 3, 🗐 x 4)




- 10. Inverter lower guide plate [D] (hook x 2)
- 11. DF registration sensor [E] (x 1, hook)

12. DF exit sensor [F] (x 1, hook)

DF Registration Sensor Reflector






b262r508

Clean the SD registration sensor reflector [A] as necessary.

4.13.8 DF FEED MOTOR


1. DF rear cover ("DF Rear Cover")



- 2. Inner cover [A] (x 1)
- 3. DF feed motor with bracket [B] (x 2, 🖨 x 4, 🟴 x 3, timing belt)
- 4. DF feed motor [C] (F x 2)


4.13.9 DF TRANSPORT MOTOR

- 1. DF rear cover ("DF Rear Cover")
- 2. DF feed motor (TP Feed Motor")



- 3. DF transport motor with bracket [A] (x 2, spring x 1, timing belt)
- 4. DF transport motor [B] (x 2)

4.13.10 DF FEED CLUTCH



- 1. Open the DF left cover.
- 2. DF front cover [A] (x 1)
- 3. Bracket [B] (x 1, 🗐 x 1)
- 4. DF feed clutch [C] (x 1)

4.14 ADJUSTING COPY IMAGE AREA

Adjust the copy image area under any of the following conditions:

- 1. After clearing engine data (SP5-801-002 or SP5-998-001).
- 2. After replacing any of the following components:
 - First scanner or second scanner
 - Lens block
 - Scanner motor
 - Polygon mirror motor
 - Paper tray


4.14.1 PRINTING

Make sure that the paper is correctly loaded in each paper tray before starting the adjustment procedures in this section.

Adjusting Registration

Use the Trimming Area Pattern (SP5-902-001 > 10) for this adjustment.

- 1. Print out the test pattern with the paper fed from the regular paper tray.
- 2. Print out the test pattern with the paper fed from the by-pass tray.
- 3. Print out the test pattern by selecting duplex printing.



4. Measure the distance between the leading edge of the image area and the leading edge of the paper [A].



The diagram shows the paper on the copy tray. Note that the paper is output with the face down.

SM 4-61 D067/D068/D069/D072

SP	Specification
SP1-001-001 (All Trays)	0 ± 2 mm
SP1-001-002 (By-pass)	0 ± 2 mm
SP1-001-003 (Duplex)	0 ± 4 mm

- 5. Adjust the leading edge registration (SP1-001).
- 6. Measure the distance between the side edge of the image area and the side edge of the paper [B].


SP	Specification
SP1-002-001 (1st tray)	0 ± 2 mm
SP1-002-002 (2nd tray)	0 ± 2 mm
SP1-002-005 (By-pass)	0 ± 4 mm
SP1-002-006 (Duplex)	0 ± 4 mm

- 7. Adjust the side-to-side registration (SP1-002).
- 8. Specify "0" (zero) in SP5-902-001 after finishing the adjustment procedure.

Adjusting Blank Margin

Use the Trimming Area Pattern (SP5-902-001 > 10) for this adjustment.

1. Print out the test pattern.



2. Measure the distance between the four edges of the image area and the four edges of the paper [A][B][C][D].



- The diagram shows the paper on the copy tray. Note that the paper is output with the face down.
- 3. Adjust the blank margin (SP2-101).

SP	Specification
SP2-101-001 (Leading Edge) [A]	2 ± 1.5 mm
SP2-101-002 (Trailing Edge) [B]	2 +2.5/-1.5 mm
SP2-101-003 (Left Side) [C]	2 ± 1.5 mm
SP2-101-004 (Right Side) [D]	2 +2.5/-1.5 mm



- The "Left Side" and "Right Side" comes to your left-hand side and right-hand side respectively when you view the copied image with the leading edge upwards.
- 4. Specify "0" (zero) in SP5-902-001 after finishing the adjustment procedure.

Adjusting Main-Scan Magnification

Use the Grid Pattern (Single Dot) (SP5-902-001 > 5) for this adjustment.

SP	Specification	
SP2-998-001 (Main Mag-print)	100 ± 1%	

- 1. Print out the test pattern.
- 2. Measure the sides of squares. Each side should be 2.7-mm long.)
- 3. Adjust the main-scan magnification (SP2-998-001: Main Mag-print).
- 4. Specify "0" (zero) in SP5-902-001 after finishing the adjustment procedure.


4.14.2 SCANNING

Preparation:

- Before adjusting scanning, adjust printing (Printing in this section).
- To adjust scanning, use the A4 test chart.

Adjusting Registration

- 1. Place the test chart on the exposure glass. Make sure that the test chart is aligned with the rear and left scales on the exposure glass.
- 2. Make a copy.



3. Measure the distance between the leading edge of the image area and the leading edge of the paper [A].




- The diagram shows the paper on the copy tray. Note that the paper is output with the face down.
- 4. Adjust the leading-edge scan registration. (SP4-010-001).

SP	Specification
SP4-010-001 (LE Scan Regist)	$0\pm2~\text{mm}$

- 5. Measure the distance between the side edge of the image area and the side edge of the paper [B].
- 6. Adjust the side-to-side registration (SP4-011-001).

SP	Specification	
SP4-011-001 (S-to-S Scan Regist)	0 ± 2 mm	

Adjusting Magnification



- 1. Place the test chart on the exposure glass. Make sure the test chart is aligned with the rear and left scales on the exposure glass.
- 2. Make a copy.
- 3. Compare the copy with the original.
- 4. Adjust the main-scan and sub-scan magnifications. The original image [A] is magnified in the main-scan direction [B] or in the sub-scan direction [C] when you specify a larger value.



The diagrams show the paper on the copy tray. Note that the paper is output with the face down.

SP	Specification
SP4-009-001 (Main Scan Mag)	± 1.0%
SP4-008-001 (Sub Scan Mag)	± 1.0%

SM 4-65 D067/D068/D069/D072

Scan Auto Adjustment


This procedure adjusts the standard white density level. Adjust the standard white density after any of the following maintenance work:

- Replacing the standard white plate
- Replacing the BICU
- Replacing the lens block
- Executing the memory clear (SP5-801-002 [basic model], SP5-998-001 [other models]).
- 1. Place 10 sheets of new A4 paper on the exposure glass.
- 2. Close the platen cover.
- 3. Activate the SP mode.
- 4. Select Copy SP4-428.
- 5. Specify "1" and press the OK key. The copier automatically adjusts the standard white density.

4.14.3 DF IMAGE ADJUSTMENT




 Perform the adjustment procedure in this section only when the ARDF is installed on the copier.



b130r967

- Make a temporary test chart as shown in the above diagram. Use the "A4/8.5 x 11" paper to make it.
- 2. Place the temporary test chart on the ARDF.
- 3. Make a copy.



- 4. Measure the distance between the side edge of the image area and the side edge of the paper [A].
 - (The diagram shows the paper on the copy tray. Note that the paper is output with the face down.)
- 5. Adjust the side-to-side registration (S to S/Front Regist: SP6-006-001, S to S/Rear Regist: SP6-006-004). The image area moves to the rear side of the copier when you specify a larger value.
- 6. Measure the distance between the leading of the image area and the leading edge of the paper [B].
- 7. Adjust the leading edge registration (Leading Regist: SP6-006-002). The image area moves to the right side of the copier when you specify a larger value.

Adjusting Copy Image Area

- 8. Measure the distance between the trailing edge of the image area and the trailing edge of the paper [C].
- 9. Adjust the erased area on the trailing edge (Trailing Erase: SP6-006-003).
- 10. Compare the copy with the original.
- 11. Adjust the sub-scan magnification (SP6-006-005). The specification is $\pm 1.0\%$.

TROUBLESHOOTING

REVISION HISTORY			
Page	e Date Added/Updated/New		
		None	

5. TROUBLESHOOTING

5.1 SERVICE CALL CONDITIONS

For "SC Table" information, see "Appendices."

SM 5-1 D067/D068/D069/D072

5.2 ELECTRICAL COMPONENT DEFECTS

See "Appendices" for the following information:

- Sensor/Switch
- Blown Fuse Conditions (Power Supply Unit)
- BICU LED Display

5.3 CARD SAVE FUNCTION

5.3.1 OVERVIEW

Card Save:

- The Card Save function is used to save print jobs received by the printer on an SD card with no print output. Card Save mode is toggled using printer Bit Switch #1 bit number 4. Card Save will remain enabled until the SD card becomes full, or until all file names have been used.
- Captures are stored on the SD card in the folder /prt/cardsave. File names are assigned sequentially from PRT00000.prn to PRT99999.prn. An additional file PRT.CTL will be created. This file contains a list of all files created on the card by the card save function.
- Previously stored files on the SD card can be overwritten or left intact. Card Save SD has "Add" and "New" menu items.
 - Card Save (Add): Appends files to the SD Card. Does not overwrite existing files. If the card becomes full or if all file names are used, an error will be displayed on the operation panel. Subsequent jobs will not be stored.
 - Card Save (New): Overwrites files in the card's /prt/cardsave directory.

Limitation:

 Card Save cannot be used with PJL Status Readback commands. PJL Status Readbacks will not work. In addition they will cause the Card Save to fail.


SM 5-3 D067/D068/D069/D072

5.3.2 PROCEDURE

- 1. Turn the main power switch OFF.
- 2. Insert the SD card into the service slot of the controller board. Then turn the power ON.



- To determine which slot is the service slot, please see the service manual.
- Enter SP mode.
- 4. Select "Printer SP."
- 5. Select "Service Mode" and press "OK" button.
- 6. Select "1.001 Bit Switch" and press "OK" button.




d068t102

7. Press "OK" button again.

```
1. 001. <u>001</u> Bit Switch 1
    (7) 00000000 (0) [10]
       (00000000)
```


d068t103

8. Use the numeric key "4" to turn bit 4 ON. The result should look like: 00010000. By doing this Card Save option will appear in "List/Test Print."



d068t104

- 9. Press the "Return" button several times to exit SP Mode.
- 10. Press the " button.
- 11. Use the arrow key and select "Printer Features."



d045t105

12. Use the arrow key and select "List/Test Print."

Print Features	
List/Test Print	
Maintenance	
System	

d045t106

13. Use the arrow key and select "Cardsave (ADD) or Cardsave (New).

List Test Prnt
Cardsave (ADD)
Cardsave (New)

d045t107

- 14. To enable the newly configured settings, select "switch" button and then press the "Return" button to exit the "List/Test Print" menu.
- 15. Send a job to the printer.
- 16. As soon as the printer receives the data, it will be stored on the SD card automatically with no print output. Nothing is displayed on the screen indicating that a Card Save operation was successful.
- 17. Press the "Return" button to exit Card Save mode.
- 18. Change the Bit Switch Settings back to the default 00000000.
- 19. Remove the SD card after main power switch is turned off.

Error Messages

Card Save error messages:

- Init error: A card save process (i.e. card detection, change to kernel mode) failed to initialize.
- Card not found: Card cannot be detected in the slot.
- No memory: Insufficient working memory to process the job.
- Write error: Failed to write to the card.
- Other error: An unknown error occurred.

If an error occurs, pressing "OK" will cause the device to discard the job and return to the ready state.

SM 5-5 D067/D068/D069/D072

5.4 FAX TROUBLESHOOTING GUIDE (ONLY FOR D068/D069)

See "Appendices" for the following information:

- Fax Error Codes
- IFAX Troubleshooting
- IP-Fax Troubleshooting

SYSTEM MAINTENANCE REFERENCE

REVISION HISTORY		
Page Date Added/Updated/New		
4 ~ 5	05/21/2009	Updated Information - (NVRAM Data Upload/Download)
19 ~ 20	05/21/2009	Updated Information - (NVRAM Data Upload/Download)

6. SYSTEM MAINTENANCE REFERENCE

6.1 SERVICE PROGRAM

★ Important

 Do not let the user access the SP mode or the SSP mode. Only service representatives are allowed to access these modes. The machine operation is NOT guaranteed after any person other than service representatives accesses the SP mode.

6.1.1 SP TABLES


See "Appendices" for the following information:

- Service Program Mode Tables for F/SFP models (D068/D069)
- Service Program Mode Tables for Basic models (D067/D072)

6.1.2 USING SP AND SSP MODES

The following two modes are available:

- SP Mode (Service Program Mode): The SP Mode includes the programs that are necessary for standard maintenance work.
- SSP Mode (Special SP Mode): The SSP Mode includes SP-Mode programs and some special programs. You need some extra knowledge to use these special programs. For details, consult your supervisor.



SM 6-1 D067/D068/D069/D072

Starting SP Mode

- 2. Press the (about 3 seconds).

Selecting Programs

- When a blinking underscore (or several blinking underscores) is displayed, you can type a number from the numeric keypad [D].
- When the sign "→ /OK" [A] is displayed upper right corner, you can scroll through the menu by pressing the left-arrow key [B] or the right-arrow key [C]. To select program, press the OK key [F].

Specifying Values

- After locating a program, press the OK key. A blinking underscore (or several blinking underscores) indicates which value you can change. The value in parentheses is the default value of the menu.
- 2. Type a necessary value from the numeric keypad. To switch between positive (plus) and negative (minus) values, press the key.
- 3. To validate the value, press the OK key. To cancel the value, press the escape key [E].

Activating Copy Mode

You can activate the copy mode while the SP mode is running. When you do so, the copier outputs images or patterns that help you adjust the SP setting.

- 1. Press the [®] key. The copy mode is activated.
- 2. Specify copy settings and press the (*) key.
- 3. To return to the SP mode, press the key.



You cannot end the SP mode while the copy mode is activated.

Quitting Programs/Ending (S) SP Mode

Press the key or the escape key to quit the program. You can end the SP mode by pressing one of these keys several times.

Conventions used in the tables:

- Asterisk (*): The settings are saved in the NVRAM. Most of them return to the default values when you execute SP5-801-002. CTL indicates that the data is contained in NVRAM on the controller board.
- DFU: The program is for design/factory use only. Do not change the settings.
- Brackets ([]): The brackets enclose the setting rage, default value, and minimum step with unit ([Minimum to Maximum / Default / Step]).

SM 6-3 D067/D068/D069/D072

6.2 USING SP MODE (F/SPF: D068/D069)

6.2.1 NVRAM DATA UPLOAD/DOWNLOAD

The content of the NVRAM can be uploaded to and downloaded from an SD card.

⇒ IMPORTANT NOTE:

The following data stored in the NVRAM will **not** be saved to the SD Card when you perform an NVRAM data upload (SP5824).

- Total Counter value
- C/O, P/O Counter values
- Duplex, A3/DLT/Over 420 mm, Stapler, and Scanner Counter values
- Engine SP Data

Therefore, whenever you perform an NVRAM Upload/Download, make sure to print out the SP Data List **before** you perform SP5801-001 (Memory Clear: All Clear) or SP5801-002 (Memory Clear: Engine).

NVRAM Upload/Download Procedure:

- 1) Print out the SP Data List from SP5990-002.
- 2) Perform the NVRAM data upload (To the SD Card) according to the procedure in the Service Manual.
- 3) Perform the Memory Clear (SP5801-001 or -002)
- 4) Perform the NVRAM Data Download (from the SD Card) according to the procedure in the Service Manual.
- 5) Manually input the data listed above.

Uploading Content of NVRAM to an SD card

Follow this procedure to upload SP code settings from NVRAM to an SD card.



- This data should always be uploaded to an SD card before the NVRAM is replaced.
- 1. Before switching the machine off, execute SP 5990-1 (SMC Print). You will need a record of the NVRAM settings if the upload fails.
- 2. Turn off the main power of the copier.
- 3. Remove the interface cover (x 1).
- 4. Insert the SD card into the service slot 2, then turn on the main power of the copier.
- 5. Execute SP 5824-1 (NVRAM Data Upload) then press the "Execute" key.
 - When uploading is finished, a file is coped to an NVRAM folder on the SD card.

 The file is saved to the path and filename:

NVRAM¥<serial number>.NV

Here is an example with Serial Number "B0700017":

NVRAM¥B0700017.NV

6. In order to prevent an error during the download, be sure to mark the SD card that holds the uploaded (saved) data with the number of the machine from which the data was uploaded (saved).



- NVRAM data from more than one machine can be uploaded (saved) to the same SD card.
- 7. Turn off the main power, and then remove the SD card from the slot 2.
- 8. Reassemble the machine.

Downloading an SD Card to NVRAM

Follow this procedure to download (save) SP data from an SD card to the NVRAM in the machine.

- If the SD card with the NVRAM data is damaged, or if the connection between the controller and BICU is defective, the NVRAM data download may fail.
- If the download fails, repeat the download procedure.
- If the second attempt fails, enter the NVRAM data manually using the SMC print you created before uploading the NVRAM data. (** above procedure)
- 1. Turn off the main power of the copier.
- 2. Remove the interface cover 2 (F x 1).
- 3. Insert the SD card with the NVRAM data into the service slot 2.
- 4. Turn on the main power of the copier.
- 5. Execute SP 5825-1 (NVRAM Data Download) and press the "Execute" key.
- 6. Turn off the main power of the copier, and then remove the SD card from the slot 2.
- 7. Reassemble the machine.



In order for the NVRAM data to download successfully, the serial number of the file on the SD card must match the serial number of the machine. If the serial numbers do not match, the download will fail.

This procedure downloads (saves) the following data to the NVRAM:

- Total Count
- C/O, P/O Count

SM 6-5 D067/D068/D069/D072

6.2.2 FIRMWARE UPDATE PROCEDURE

This section illustrates how to update the firmware of the GW machine (the machine with the optional controller box).

To update the firmware for the GW machine, you must have the new version of the firmware downloaded onto an SD (Secure Digital) Card. The SD Card is inserted into the uppermost slot on the right side of the controller box, viewed from the back of the machine.

Before You Begin...

An SD card is a precision device, so always observe the following precautions when handling SD cards:

- Always switch the machine off before inserting an SD card. Never insert the SD card into the slot with the power on.
- When the power is switched on, never remove the SD card from the service slot.
- Never switch the machine off while the firmware is downloading from the SD card.
- Store SD cards in a safe location where they are not exposed high temperature, high humidity, or exposure to direct sunlight.
- Always handle SD cards with care to avoid bending or scratching them. Never drop an SD card or expose it to other shock or vibration.

Keep the following points in mind while you are using the firmware update software:

- "Upload" means to send data from the machine to the SD card, and "download" means to send data from the SD card to the machine.
- To select an item on the LCD screen, press the appropriate key on the operation panel, or press the appropriate number key on the 10-key pad of the operation panel.
- Before starting the firmware update procedure, always make sure that the machine is disconnected from the network to prevent a print job for arriving while the firmware update is in progress.

Firmware Update Procedure



 Before beginning the following, first confirm which firmware version(s) are currently installed in the machine with SP7-801-255.

-SD Card Preparation-

- 1. Format an SD card with, for example, SD Formatter v1.1.
- 2. Create a "romdata" folder on the card.
- 3. Create the following folders within the "romdata" folder: D067, D068, D069, D072.
- 4. Download the firmware from the server and store the files in the folder with the corresponding model code on the SD card.

Example:

File D067550B should be stored in the "D067" folder, whereas files D4685528B, D4685540A, and D4685525B should be stored in the "D468" folder.


-Firmware Update-




- Do not put multiple machine firmware programs on the same SD card. Copy the only model firmware you want.
- 1. Turn off the main power switch.
- 2. If the machine is connected to a network, disconnect the network cable from the copier.
- 3. Remove the interface cover (x 1)
- 4. With the label on the SD card facing the rear side of the machine, insert the SD card into the slot 2 on the controller box. Slowly push the SD card into the slot so it locks in place.
- Make sure the SD card is locked in place.
 (To remove the SD card, push it in to unlock the spring lock and then release it so it pops out of the slot.)
- Switch the main power switch on. After about 5 seconds, the LCD will display "Please wait..." Then, about 60 seconds later, the LCD will display "Program UpDate Menu P.01" on the first line and the name of the firmware on the second line (e.g. System/Copy).

SM 6-7 D067/D068/D069/D072

Using SP Mode (F/SPF: D068/D069)



- 7. Press the "OK" key to select a module.
 - To scroll through the menus, press the △ or ▽ keys [A].




- To view the firmware version, press the right key. "ROM" is the information on the current firmware. "NEW" is the information on the firmware in the SD card.
- To return to the menu, press the < key.
- To select the module, press the OK key.
- To scroll through the module name, the serial number, and the version, press the

 ⟨ key or ▷ key.
- If you wish to install the following firmware simultaneously, press the START key. The scroll keys can be used to confirm that this firmware has been selected (highlighted with a dark background).

[Engine, FCU, Scanner, Printer, Printer Font, Security Module]



- Please note that the following firmware cannot be updated simultaneously. The update procedure must be repeated for each individually.
- System/Copy, ServiceCardNetFile, ServiceCardNIB, ServiceCardFAX, ServiceCardWebSystem.




- When you have selected a module, the text lines are highlighted, and the "Verify" key and the "Update" key are displayed.
- 8. Select a module and press the "Update" key.



- Do NOT press the "Verify" key.
- 9. The firmware update program starts and the message "Loading" is displayed.
 - The update will begin, and then will take a few minutes to complete. The LCD will initially display, "Updating...

 ***------."
 - When the update is completed, the LCD display will change to "Update done" or "Updated / Power Off On."




10. Check that the message "Update Done" is displayed.

-Confirmation-

- 1. Turn the main power switch off and on.
 - The LCD will display "Please wait..." for about 60 seconds, after which it will return to the "Program UpDate Menu" screen.
- 2. Repeat Steps 1-8 above until all firmware updates are complete.
- 3. Turn the main power switch off.
- 4. Remove the SD card from the lower slot on the controller by pushing on the card to release the spring lock.

SM 6-9 D067/D068/D069/D072

Using SP Mode (F/SPF: D068/D069)



If an error occurs, the error code is displayed. For a list of information on error codes, see the following table.

Code	Cause	Necessary Action	
E20	Physical address mapping error	Insert the SD card correctly.Use another SD card	
E22	Decompression error	Store correct data in the SD card.	
E23	Update program error	Update controller program.Replace the controller.	
E24	SD card access error	Insert the SD card correctly.Use another SD card.	
E31	Download data inconsistency*	 Insert the SD card that was used when the previous update procedure is interrupted. 	
E32	Download data inconsistency*	Insert the SD card that stores the correct data.	
E33	Version data error	Store the correct data in the SD card.	
E34	Locale data error	Store the correct data in the SD card.	
E35	Machine model data error	Store the correct data in the SD card.	
E36	Module data error	Store the correct data in the SD card.	
E40	Engine program error**	Store the correct data in the SD card.Replace BICU.	

Code	Cause	Necessary Action	
E42	Operation panel program error*	Store the correct data in the SD card.Replace the operation panel board.	
E44	Controller program error*	Store the correct data in the SD card.Replace the controller board.	
E50	Authentication error	Store the correct data in the SD card.	

^{*}You need to reinstall the program.

If the firmware update program is interrupted (for example, by a power failure), keep the SD card inserted and turn the mains switch off and on. The firmware update program restarts. If you do not do so, the message "Reboot after Card insert" is displayed when you turn the main switch on.

6.2.3 TEST PATTERN PRINT (SP5-902-001)

Executing Test Pattern Printing

- 1. Specify the pattern number and press the OK key.
- 2. Press the copy start key. The copy mode is activated ("Using SP and SSP Modes" in this section).
- 3. Specify copy settings and press the ® key.
- 4. To return to the SP mode, press the \$ key.

Test Patterns

Test Patterns Using VCU		
No.	Pattern	
0	(No print)	
1	Vertical Lines (Single Dot)	
2	Horizontal Lines (Single Dot)	
3	Vertical Lines (Double Dot)	
4	Horizontal Lines (Double Dot)	
5	Grid Pattern (Single Dot)	
6	Grid Pattern (Double Dot)	
7	Alternating Dot Pattern	
8	Isolated One Dot	
9	Black Band (Horizontal)	
10	Trimming Area	
11	Argyle Pattern (Single Dot)	
12	Grayscales (Horizontal)	
13	Grayscales (Vertical)	

14	Grayscales (Vertical/Horizontal)
15	Grayscales (Vertical/Horizontal Overlay)
16	Grayscales With White Lines (Horizontal)
17	Grayscales with White Lines (Vertical)
18	Grayscales with White Lines (Vertical/Horizontal)

Test Patterns Using IPU		
No.	Pattern	
30	Vertical Lines (Single Dot)	
31	Horizontal Lines (Single Dot)	
32	Vertical Lines (Double Dot)	
33	Horizontal Lines (Double Dot)	
34	Isolated Four Dots	
35	Grid Pattern (Double Dot)	
36	Black Band (Vertical, 1024 Dots)	
37	Grayscales (Horizontal, 512 Dots)	
38	Grayscales (Vertical, 256 Dots)	
39	ID Patch	
40	Cross	
41	Argyle Pattern (128-Dot Pitch)	
42	Square Gradation (64 Grades)	
43	Square Gradation (256 Grades)	
44	Grayscales (Horizontal, 32-Dot Width)	
45	Grayscales (Vertical, 32-Dot Width)	

SM 6-13 D067/D068/D069/D072

Using SP Mode (F/SPF: D068/D069)

47	A4 Gradation Patches 1 (128 Grades)
48	A4 Gradation Patches 2 (128 Grades)
49	Trimming Area (A4)

	Test Patterns Using SBU	
No.	Pattern	
51	Grid Pattern (double dot)	
52	Gray Scale 1 (256 grades)	
53	Gray Scale 2 (256 grades)	

	Test Patterns Using PCI*1
No.	Pattern
61	S2M: Grid Pattern
62	S2M: Argyle Pattern
63	S2M: Argyle Pattern
64	S2M: Argyle Pattern + Image* ²
65	S2M: Grid Pattern
66	S2M: Grid Pattern + Image
67	S2M: Argyle Pattern
68	S2M: Argyle Patten + Image
69	Engine: Grid Pattern
70	Engine: Argyle Pattern

^{*1:} The PCI is available to the models with the controller box.

 $^{^{\}star 2:}$ The original image on the exposure glass is printed behind the test pattern.

6.2.4 MEMORY CLEAR

GW Machine

The GW machine (the machine with the optional controller box) stores the engine data in the NVRAM on the BICU, and stores the other data in the NVRAM on the optional controller. To distinguish between the engine data and the other data, see SP5-801-003 through 015. This service program (SP5-801) handles the controller data. Any data that is not handled by SP5-801 is the engine data. The data in the BICU NVRAM (engine data) is cleared by SP5-998-001 while the data in the controller NVRAM (controller data) is cleared by SP5-801-xxx (for exceptions, see "Exceptions" as described below).

Machine	Data	NVRAM	Cleared by	Remarks
GW	Engine data	BICU	SP5-998-001	Any data other than controller data
	Controller data	Controller	SP5-801-xxx	SCS, IMH, MCS, Copier application, Fax application, Printer application, Scanner application, Web service/network application, NCS, R-Fax, DCS, UCS

Exceptions

SP5-998-001 clears most of the settings and counters stored in the NVRAM on the BICU (the values return to their default values). However, the following settings are not cleared:

- SP5-807 (Area Selection)
- SP5-811-001 (Serial Num Input [Code Set])
- SP5-811-003 (Serial Num Input [ID2 Code Display])
- SP5-812-001 (Service TEL [Telephone])
- SP5-812-002 (Service TEL [Facsimile])
- SP5-907 (Plug & Play)
- SP7 (Data Log)
- SP8 (History)

Use SP5-998-001 after you have replaced the BICU NVRAM or when the BICU NVRAM data is corrupted. When the program ends normally, the message "Completed" is displayed.

SM 6-15 D067/D068/D069/D072

Using SP Mode (F/SPF: D068/D069)

When you have replaced the controller NVRAM or when the controller NVRAM data is corrupted, use SP5-801-001. The message is the same as the basic machine.

Memory Clear Procedure

- 1. Print out all SMC data lists ("SMC Print").
- 2. Do SP5-998-001.
- 3. Press the OK kev.
- 4. Select "Execute." The messages "Execute?" followed by "Cancel" and "Execute" are displayed.
- 5. Select "Execute."
- 6. When the program has ended normally, the message "Completed" is displayed. If the program has ended abnormally, an error message is displayed.
- 7. Turn the main switch off and on.
- 8. Adjust the printer and scanner registration and magnification (* "Copy Adjustment" in the chapter "Replacement and Adjustment").
- 9. Refer to the SMC lists, and enter any values that differ from the factory settings. Double-check the values for SP4-901.
- 10. Adjust the standard white level (SP4-428).
- 11. Initialize the TD sensor (SP 2-214).
- 12. Check the copy quality and the paper path.

6.2.5 MACHINE NO. SETTING (SP5-811-001)

Specifying Characters

SP5-811-001 specifies the serial number. For the machine with the optional controller, you use the numeric keypad and the optional operation panel.

GW Machine

You can use the numeric keypad to type numbers. In addition, you can use the operation panel to type other characters. When you press the "ABC" key, the letter changes as follows: $A \to B \to C$. To input the same letter two times, for example "AA," you press the "ABC" key, the "Space" key, and the "ABC" key. To switch between uppercase letters and lowercase letters, press the "Shift" key.

Serial Number and NVRAM

Serial numbers are stored in the NVRAM before shipment and are not cleared. You must specify a serial number after you replace the NVRAM.

6.2.6 SMC PRINT (SP5-990)

SP5-990 outputs machine status lists.

- 1. Select SP5-990.
- 2. Select a menu:
 - GW machine: 001 All (Data List), 002 SP (Mode Data List), 003 User Program, 004 Logging Data, 005 Diagnostic Report, 006 Non-Default, 007 NIB Summary, 008 Net File Log, 021 Copier User Program, 022 Scanner SP, 023 Scanner User Program, 040 Parts Alarm Counter Print, 064 Normal Count Print, 065 User Code Counter, 066 Key Operator Counter, 067 Contact List Print, 069 Heading1 print, 071 Heading3 print, 072 Group List Print, 128 ACC Pattern, 129 User Color Pattern, or 160:ACC Pattern Scan



- The output given by the menu "Big Font" is suitable for faxing.
- 3. Press the "Execute" key.
 - GW machine: The machine status list is output.
- 4. To return to the SP mode, press the \$\partial \text{key.}

SM 6-17 D067/D068/D069/D072

6.2.7 ID SENSOR ERROR ANALYSIS (SP2-221)

The image quality may become very bad when the ID sensor does not operate properly. However, there is no such SC code that indicates ID-sensor malfunction; instead, SP2-221 shows you some information on the ID sensor. Check this information when the image quality is not very good.

The table lists the information shown with SP2-221 (ID Sensor Error Analysis).

SP	Error condition	Possible cause	Remarks
SP2-221-1 Vsg (VG in the display)	Vsg < 2.5V or (Vsg – Vsp) < 1.00V	ID sensor defectiveID sensor dirtyDrum not charged	-
SP2-221-2 Vsp (VP in the display)	Vsp > 2.5V or (Vsg – Vsp) < 1.00V	Toner density very lowID sensor pattern not created	-
SP2-221-3 Power (PW in the display)	Vsg < 3.5V when maximum power (979) is applied	ID sensor defectiveID sensor dirtyDrum not get charged	Power source for the ID-sensor light
SP2-221-4 Vsdp	No Error Conditions		-
SP2-221-5 Vt	Vt > 4.5V or Vt < 0.2V	TD sensor defective	-
SP2-221-6 Vts	-	-	-

System Maintenance Reference

6.3 USING SP MODE (BASIC: D067/D072)

6.3.1 NVRAM DATA UPLOAD/DOWNLOAD (SP5-824/825)

The content of the NVRAM can be uploaded to and downloaded from an SD card.

⇒ IMPORTANT NOTE:

The following data stored in the NVRAM will **not** be saved to the SD Card when you perform an NVRAM data upload (SP5824).

- Total Counter value
- C/O, P/O Counter values
- Duplex, A3/DLT/Over 420 mm, Stapler, and Scanner Counter values
- Engine SP Data

Therefore, whenever you perform an NVRAM Upload/Download, make sure to print out the SP Data List **before** you perform SP5801-001 (Memory Clear: All Clear) or SP5801-002 (Memory Clear: Engine).

NVRAM Upload/Download Procedure:

- 6) Print out the SP Data List from SP5990-002.
- 7) Perform the NVRAM data upload (To the SD Card) according to the procedure in the Service Manual.
- 8) Perform the Memory Clear (SP5801-001 or -002)
- 9) Perform the NVRAM Data Download (from the SD Card) according to the procedure in the Service Manual.
- 10) Manually input the data listed above.

ACAUTION

• Make sure that you turn off the main power switch before inserting or removing a flash memory card. Data in the memory may be corrupted if you insert or remove the memory card with the main power switch on.

This section illustrates how to copy the data from the BICU NVRAM to a memory card ("NVRAM Data Upload/Download" writing onto open space on card) or from a memory card to the BICU NVRAM ("NVRAM Data Upload/Download").

Overview

You can copy the data from the NVRAM to a flash memory card (NVRAM Upload) or from a flash memory card to the NVRAM (NVRAM download).

SP5-824-1 (NVRAM Upload)	From the BICU to a flash memory card
SP5-825-1 (NVRAM Download)	From a flash memory card to the BICU

SM 6-19 D067/D068/D069/D072

Using SP Mode (Basic: D067/D072) Rev. 05/21/2009

You should execute NVRAM Upload before replacing the NVRAM or before executing SP5-801-002 (Memory Clear > Engine). You can copy back the data from the flash memory card to the NVRAM as necessary.

NVRAM Upload (SP5-824-001)

- 1. Turn off the main switch.
- 2. Remove the interface cover (F x 1).
- 3. Turn the face of the flash memory card to the rear of the copier, and insert it into the card slot 2.
- 4. Turn on the main power switch.
- Activate the SP mode and select SP5-824-001.
- The copier overwrites the data in the memory card with the data in the NVRAM. This takes about 20 seconds. If uploading fails, an error message appears. If an error message appears, retry the upload procedure.
- 7. Turn off the main power switch.
- 8. Remove the memory card.

NVRAM Download (SP5-825-001)

SP5-825-001 copies the data from a flash memory card to the NVRAM. Most of the data in the NVRAM is overwritten. The following data in the NVRAM remains unchanged (these are not overwritten):


- SP8-221-001 (ADF Original Feed > Front)
- SP8-381-001 (Total: Total Printer Pages)
- SP8-382-001 (Copy Application: Total Print Pages)
- SP8-411-001 (Prints/Duplex)
- 1. Turn off the main power switch.
- 2. Remove the interface cover (x 1).
- 3. Turn the face of the flash memory card to the rear of the copier, and insert it into the card slot 2.
- 4. Turn on the main switch.
- 5. Activate the SP mode and select SP5-825-001.
- 6. The copier overwrites the data in the NVRAM with the data in the memory card. This takes about one second. If downloading fails, an error message appears. If an error message appears, retry the download procedure.
- 7. Turn off the main power switch.
- 8. Remove the memory card.

System Maintenance Reference

6.3.2 FIRMWARE UPDATE PROCEDURE

This section illustrates how to update the firmware.

- 1. Turn the main power switch off.
- 2. Remove the interface cover (F x 1).
- 3. Turn the face of the flash memory card to the rear of the copier, and insert it into the card slot 2.
- 4. Press down the power switch on the operation panel and hold it, and turn on the main power switch.



5. Press the "Execute" key [D]. The program starts running.



6. Do not touch any key while the message "Load Status..." is displayed. This message indicates that the program is running.

SM 6-21 D067/D068/D069/D072



- 7. Check that the message "End Sum..." is displayed. This message indicates that the program has ended normally.
- 8. Turn off the main power switch.
- 9. Remove the flash memory card.
- 10. Attach the interface cover.
- 11. Turn the main power switch on, and check the operation.

6.3.3 TEST PATTERN PRINT (SP5-902-001)

Executing Test Pattern Printing

- 1. Specify the pattern number and press the OK key.
- 2. Press the copy start key. The copy mode is activated ("Using SP and SSP Modes" in this section).
- 3. Specify copy settings and press the <a> key.
- 4. To return to the SP mode, press the \$ key.

Test Patterns

Test Patterns Using VCU		
No.	Pattern	
0	(No print)	
1	Vertical Lines (Single Dot)	
2	Horizontal Lines (Single Dot)	
3	Vertical Lines (Double Dot)	
4	Horizontal Lines (Double Dot)	
5	Grid Pattern (Single Dot)	
6	Grid Pattern (Double Dot)	
7	Alternating Dot Pattern	
8	Isolated One Dot	
9	Black Band (Horizontal)	
10	Trimming Area	
11	Argyle Pattern (Single Dot)	
12	Grayscales (Horizontal)	
13	Grayscales (Vertical)	

System Maintenance Reference

SM 6-23 D067/D068/D069/D072

14	Grayscales (Vertical/Horizontal)	
15	Grayscales (Vertical/Horizontal Overlay)	
16	Grayscales With White Lines (Horizontal)	
17	Grayscales with White Lines (Vertical)	
18	Grayscales with White Lines (Vertical/Horizontal)	

	Test Patterns Using IPU
No.	Pattern
30	Vertical Lines (Single Dot)
31	Horizontal Lines (Single Dot)
32	Vertical Lines (Double Dot)
33	Horizontal Lines (Double Dot)
34	Isolated Four Dots
35	Grid Pattern (Double Dot)
36	Black Band (Vertical, 1024 Dots)
37	Grayscales (Horizontal, 512 Dots)
38	Grayscales (Vertical, 256 Dots)
39	ID Patch
40	Cross
41	Argyle Pattern (128-Dot Pitch)
42	Square Gradation (64 Grades)
43	Square Gradation (256 Grades)
44	Grayscales (Horizontal, 32-Dot Width)
45	Grayscales (Vertical, 32-Dot Width)

47	A4 Gradation Patches 1 (128 Grades)
48	A4 Gradation Patches 2 (128 Grades)
49	Trimming Area (A4)

	Test Patterns Using SBU		
No.	Pattern Grid Pattern (double dot) Gray Scale 1 (256 grades)		
51			
52			
53	Gray Scale 2 (256 grades)		

	Test Patterns Using PCI*1	
No.	Pattern	
61	S2M: Grid Pattern	
62	S2M: Argyle Pattern	
63	S2M: Argyle Pattern	
64	S2M: Argyle Pattern + Image* ²	
65	S2M: Grid Pattern	
66	S2M: Grid Pattern + Image	
67	S2M: Argyle Pattern	
68	S2M: Argyle Patten + Image	
69	Engine: Grid Pattern	
70	Engine: Argyle Pattern	

^{*1:} The PCI is available to the models with the controller box.

SM 6-25 D067/D068/D069/D072

^{*2:} The original image on the exposure glass is printed behind the test pattern.

6.3.4 SMC PRINT (SP5-990)

SP5-990 outputs machine status lists.

- 1. Select SP5-990.
- 2. Select a menu:
 - 001 All, 002 SP, 003 User Program, 004 Logging Data, or 005 Big Font



- The output given by the menu "Big Font" is suitable for faxing.
- 3. Press the "Execute" key.
 - The copy mode is activated ("Using SP and SSP Modes" in this section").
 Specify copy settings and press the key. The machine status lists its output.
- 4. To return to the SP mode, press the \$ key.

6.3.5 SERIAL NUMBER INPUT (SP5-811-001)

Specifying Characters

SP5-811-001 specifies the serial number. For the basic model (the machine without the controller box), you use the numeric keypad.

A serial number consists of 11 characters. You can change each character by pressing one of the first 11 keys on the numeric keypad.

You can specify a digit ("0" to "9") or a capital letter ("A" to "Z") for the first four characters of a serial number, and you can specify a digit in the other seven characters (not capital letters).

Serial Number and NVRAM

Serial numbers are stored in the NVRAM before shipment and are not cleared by any program. You must specify a serial number after you replace the NVRAM.

SM

System Maintenance Reference

6.3.6 MEMORY CLEAR

Basic and GDI Model

This model (the machine without the controller box) stores all the data in the NVRAM on the BICU. The data is cleared by SP5-801-002 (for exceptions, see "").

Exceptions

SP5-801-002 clears most of the settings and counters stored in the NVRAM on the BICU (the values return to their default values). However, the following settings are not cleared:

- SP5-807 (Area Selection)
- SP5-811-001 (Serial Num Input > Code Set)
- SP5-812-001 (Service TEL > Telephone)
- SP5-812-002 (Service TEL > Facsimile)
- SP5-907-001 (Plug & Play)
- SP7 (Data Log)
- SP8 (History)

Initializing Memory Data

Use SP5-801-002 after you have replaced the BICU NVRAM or when the BICU NVRAM data is corrupted. When the program ends normally, the message "Completed" is displayed. When you have replaced the controller NVRAM or when the controller NVRAM data is corrupted, use SP5-801-001.

Executing Memory Clear

- Upload the NVRAM data to a flash memory card ("NVRAM Data Upload/Download").
- 2. Print out all SMC data lists ("SMC Print").



- Be sure to print out all the lists. You have to manually change the SP settings if the NVRAM data upload ends abnormally.
- 3. Select SP5-801-002.
- 4. Press the OK key.
- 5. Select "Execute." The messages "Execute?" followed by "Escape" and "Execute" are displayed.
- 6. Select "Execute."

SM 6-27 D067/D068/D069/D072

- 7. When the program has ended normally, the message "Completed" is displayed. If the program has ended abnormally, an error message is displayed.
- 8. Press the escape key.
- 9. Turn the main switch off and on.
- 10. Download the NVRAM data from a flash memory card ("NVRAM Data Upload/Download").

6.3.7 ID SENSOR ERROR ANALYSIS (SP2-221)

The image quality may become very bad when the ID sensor does not operate properly. However, there is no such SC code that indicates ID-sensor malfunction; instead, SP2-221 shows you some information on the ID sensor. Check this information when the image quality is not very good.

The table lists the information shown with SP2-221 (ID Sensor Error Analysis).

SP	Error condition	Possible cause	Remarks
SP2-221-1 Vsg (VG in the display)	Vsg < 2.5V or (Vsg – Vsp) < 1.00V	ID sensor defectiveID sensor dirtyDrum not charged	1
SP2-221-2 Vsp (VP in the display)	Vsp > 2.5V or (Vsg – Vsp) < 1.00V	Toner density very lowID sensor pattern not created	-
SP2-221-3 Power (PW in the display)	Vsg < 3.5V when maximum power (979) is applied	ID sensor defectiveID sensor dirtyDrum not get charged	Power source for the ID-sensor light
SP2-221-4 Vsdp	No Error Conditions		-
SP2-221-5 Vt	Vt > 4.5V or Vt < 0.2V	TD sensor defective	-
SP2-221-6 Vts	-	-	-

System Maintenance Reference

6.4 FAX SERVICE TABLES (ONLY FOR D068/D069)

See "Appendices" for the following information:

- System Service Mode
- Bit Switches
- NCU Parameters
- Dedicates Transmission Parameters
- Service RAM Addresses

SM 6-29 D067/D068/D069/D072

DO67/D068/D069/D072 SERVICE MANUAL APPENDICES

DO67/D068/D069/D072 APPENDICES

TABLE OF CONTENTS

1. APPENDIX: SPECIFICATIONS	1-1
1.1 SPECIFICATIONS	1-1
1.1.1 COPIER	1-1
1.1.2 PRINTER	1-4
1.1.3 SCANNER	1-6
1.1.4 FAX	1-7
General	1-7
IFAX Specifications	1-9
IP-FAX Specifications	
Fax Unit Configuration	1-12
1.1.5 ARDF	1-13
1.1.6 PAPER TRAY UNIT	1-14
1.2 SUPPORTED PAPER SIZES	1-15
1.2.1 ORIGINAL PAPER SIZES	1-15
1.2.2 PAPER FEED	1-17
2. APPENDIX: PREVENTIVE MAINTENANCE TABLES	2-1
2.1 MAINTENANCE TABLES	2-1
3. APPENDIX: SERVICE CALL CONDITIONS	3-1
3.1 SC TABLES (F/SPF: D068/D069)	3-1
3.1.1 SUMMARY	3-1
3.1.2 ENGINE SC CODE DESCRIPTIONS	3-2
3.1.3 GW SC CODE DESCRIPTIONS	3-13
SC6xx	3-13
SC8xx	3-17
SC9xx	3-32
3.2 SC TABLES (BASIC: D067/D072)	3-35
3.2.1 SUMMARY	3-35
3.2.2 ENGINE SC CODE DESCRIPTIONS	3-36

4.	APPENDIX: ELECTRICAL COMPONENT DEFECTS	4-1
	4.1 ELECTRICAL COMPONENT DEFECTS	4-1
	4.1.1 SENSOR/SWITCH	4-1
	4.1.2 BLOWN FUSE CONDITIONS	4-3
	4.1.3 BICU LED DISPLAY	4-3
5.	APPENDIX: SP MODE TABLES	5-1
	5.1 SYSTEM SERVICE MODE (F/SPF: D068/D069)	5-1
	5.1.1 SERVICE MODE TABLES	5-1
	SP1-XXX (Feed)	5-1
	SP2-XXX (Drum)	5-5
	SP4-XXX (Scanner)	5-11
	SP5-XXX (Mode)	5-26
	SP6-XXX (Peripherals)	5-92
	SP7-XXX (Data Log)	5-94
	SP8-XXX (History)	5-103
	5.1.2 INPUT CHECK (SP5-803)	5-130
	Conducting Input Check	5-130
	Input Check Table	5-130
	5.1.3 OUTPUT CHECK (SP5-804)	5-132
	Conducting Output Check	5-132
	Output Check Table	5-132
	5.1.4 PRINTER SERVICE MODE	5-134
	Service Mode Table	5-134
	SP Modes Related to Printer Controller	5-139
	5.1.5 SCANNER PROGRAM MODE TABLE	5-140
	Service Table Key	5-140
	5.2 SYSTEM SERVICE MODE (BASIC: D067/D072)	5-142
	5.2.1 SERVICE MODE TABLES	5-142
	SP1-XXX (Feed)	5-142
	SP2-XXX (Drum)	5-146
	SP4-XXX (Scanner)	5-153
	SP5-XXX (Mode)	5-163
	SP6-XXX (Peripherals)	5-168
	SP7-XXX (Data Log)	5-170
	SP8-XXX (History)	5-177

5.2.2 INPUT CHECK (SP5-803)	5-181
Conducting Input Check	5-181
Input Check Table	5-181
5.2.3 OUTPUT CHECK (SP5-804)	5-183
Conducting Output Check	5-183
Output Check Table	5-183
5.2.4 PRINTER SERVICE PROGRAM MODE TABLE	5-185
5.2.5 SCANNER PROGRAM MODE TABLE	5-186
Service Table Key	5-186
6. APPENDIX: FAX TROUBLESHOOTING GUIDE (ONL	Y FOR
D068/D069)	
6.1 FAX ERROR CODES	
6.2 IFAX TROUBLESHOOTING	6-27
6.3 IP-FAX TROUBLESHOOTING	
6.3.1 IP-FAX TRANSMISSION	6-30
Cannot send by IP Address/Host Name	6-30
Cannot send via VoIP Gateway	6-32
Cannot send by Alias Fax number	6-33
6.3.2 IP-FAX RECEPTION	6-35
Cannot receive by IP Address/Host name	6-35
Cannot receive by VoIP Gateway	6-36
Cannot receive by Alias Fax number	6-37
7. APPENDIX: FAX SERVICE PROGRAM (ONLY FOR	₹
D068/D069)	7-1
7.1 SYSTEM SERVICE MODE	
7.1.1 SP1-XXX (BIT SWITCHES)	
7.1.2 SP2-XXX (RAM DATA)	
7.1.3 SP3-XXX (TEL LINE SETTINGS)	
7.1.4 SP4-XXX (ROM VERSIONS)	
7.1.5 SP5-XXX (INITIALIZING)	
7.1.6 SP6-XXX (REPORTS)	
7.1.7 SP7-XXX (TEST MODES)	
7.2 BIT SWITCHES	
7.2.1 SYSTEM SWITCHES	
7.2.2 I-FAX SWITCHES	7-25

7.2.3 PRINTER SWITCHES	7-33
7.2.4 COMMUNICATION SWITCHES	7-40
7.2.5 G3-1 SWITCHES	7-48
7.2.6 IP FAX SWITCHES	7-60
7.3 NCU PARAMETERS	7-70
7.4 DEDICATED TRANSMISSION PARAMETERS	7-86
7.4.1 PROGRAMMING PROCEDURE	7-86
7.4.2 PARAMETERS	7-87
Fax Parameters	7-87
E-mail Parameters	7-93
7.5 SERVICE RAM ADDRESSES	7-97

APPENDIX: SPECIFICATIONS

REVISION HISTORY		
Page	Date	Added/Updated/New
		None

1. APPENDIX: SPECIFICATIONS

1.1 SPECIFICATIONS

1.1.1 COPIER

Configuration:	Desktop
Copy Process:	Laser beam scanning and electro-photographic printing
Originals:	Sheet/Book/Object
Original Size:	Maximum A4 / 8 ¹ / ₂ " x 14" A4 / 8 ¹ / ₂ " x 14" (ARDF)
Copy Paper Size:	Maximum A4 SEF / $8^1/_2$ " x 11" SEF (Copier's paper tray) A4 SEF / $8^1/_2$ " x 14" SEF (Bypass) A4 SEF / $8^1/_2$ " x 14" SEF (Optional paper tray) A4 SEF / $8^1/_2$ " x 14" SEF (Duplex) Minimum A5 LEF / $8^1/_2$ " x 51/2" LEF (Copier's paper tray) A6 SEF/ $8^1/_2$ " x 51/2" (Bypass) A4 SEF / $8^1/_2$ " x 11" SEF (Optional paper tray unit) A4 SEF / $8^1/_2$ " x 11" SEF (Duplex) Custom sizes in the bypass tray: Width: 90 – 216 mm (3.5" – 8.5") Length: 139 – 600mm (5.48" – 23.62")
Copy Paper Weight:	Standard paper tray; optional paper tray: 60 – 90 g/m², 16 – 24 lb. Bypass: 60 – 157 g/m², 16 – 42 lb. Duplex: 64 – 90 g/m², 20 – 24 lb.

		A4 V	ersion	LT Version	
	Enlargement		0% 1%	155% 129%	
Reproduction Ratios:	Full Size	10	0%	100%	
	Reduction	7′	3% 1% 0%	93% 78% 65%	
Zoom:	50% to 200%, in	1% steps			
Power Source:	120 V, 60 Hz or 2	220 – 240 V, 5	50/60 Hz		
	Maximum:	900 W or les	900 W or less (EU), 1000 W or less (NA)		
	Energy Saver:	F/SPF (D068/D069): 35 W or less Basic (D067/D072): 25 W or less			
Power Consumption:	Sleep Mode:	F/SPF (D068/D069): 10 W or less Basic (D067/D072): None			
	Off Mode: F/SPF (D068/D069): None Basic (D067/D072): 1 W or less				
	Sound Power Level				
Noise Emission:	Standby		40 dB(A) or less		
Troise Emission.	Operating (copier only)		62 dB(A) or less		
	Operating (full-system)		66 dB(A) or less		
Dimensions (W x D x H)	Copier: 485 x 450 x 371 mm (19.4" x 18" x 14.8") With optional paper tray unit: 485 x 454 x 511 mm (18.4" x 17.7" x 20.1")				
Weight:	 F/SPF (D068/D069): 29 kg (66 lb.) or less Basic (D067): 22 kg (48.5 lb.) or less Basic with ARDF (D072): 27 kg (59.4 lb.) or less 				

Resolution:	600 dpi	
Copying Speed in Multicopy Mode (copies/minute):	Memory Copy: 17cpm (A4 / 8 ¹ / ₂ " x 11"; 100%) DF 1 to 1: 16cpm	
Warm-up Time:	 F/SPF (D068/D069): 30 seconds or less (at 20°C [68°F]) Basic (D067/D072): 10 seconds or less (at 20°C [68°C]) 	
First Copy Time:	 7.5 seconds or less Note: Measurement conditions From the ready state, with the polygonal mirror motor spinning. A4/LT copying From copier's paper tray 100% size 	
Copy Number Input:	Numeric keypad, 1 to 99 (increment, decrement)	
Manual Image Density:	5 steps	
Auto Off Timer	Default: 1 minute Range: 1 to 240 minutes	
Energy Saver Timer:	Default: 1 minute Rage: 1 to 240 minutes	
Copy Paper Capacity:	Paper Tray: 250 sheets Optional Paper Tray Unit: 500 sheets x 1 Bypass Tray: 100 sheets	
Copy-Tray Capacity	250 sheets	
Toner Replenishment:	Cartridge replacement (230 g/cartridge)	
Toner Yield	7k copies /toner bottle (A4, 6% full black)	
Optional Equipment:	Auto reverse document feeder Paper tray unit Anti-condensation heater for paper tray unit	

1.1.2 PRINTER

	F/SPF (D068/D069)	Basic (D067/D072)
Resolution:	600 dpi (PCL 6/PCL5e/PS3/RPCS) 300 dpi (PCL5e/PS3) 600 dpi (RPCS (XPS))	600 dpi
Printing speed:	17 cpm (A4, 8 1/2" x 11")	
Interface:	USB 2.0 interface, Ethernet interface (100BASE-TX/10BASE-T) IEEE1284 IEEE802.11a/g (Wireless LAN) (option) Gigabit Ethernat (option)	USB 2.0 interface, Ethernet interface (100BASE-TX/10BASE-T)
Network protocol:	TCP/IP (IPv4, IPv6), IPX/SPX, AppleTalk, RHPP	
Printer language:	PJL PCL5e/XL RPCS (XPS) Adobe PS3/PDF (option)	Host-Based Printing
Resident Fonts:	PCL: 45 fonts 13 International fonts PCL option: OCR, Barcode Adobe PS3/PDF: 136 fonts Summary: 4 Arial	-
Memory:	640 MB	-
Operating systems	Windows 2000/XP/Server	-

	F/SPF (D068/D069)	Basic (D067/D072)
supported by this machine:	2003/Vista/Server2008 MacOS8.6 to 9, MacOSX10.1 or later	
Required network cable:	100BASE-TX/10BASE-T shielded twisted-pair (STP, Category/Type5) cable. Gigabit Ethernet- Category6 cable	

1.1.3 SCANNER

	F/SPF (D068/D069)	Basic (D067/D072)	
Scan method	Flatbed scanning		
Scan speed *1	B/W: 20 pages/ min. [Scan Size: A4 SEF, compression, Resolution 200 dpi] ITU-T No.1 Chart Full Color: 9 pages/ min. [Scan Size: A4 SEF, compression (level3), Resolution 200 dpi] ISO/JIS-SCID N5 Chart	Approx. 18 pages/minute [Scan size: A4SEF, Colors/Gradations: Binary, Resolution: 200dpi, Select device data compression (Binary/Halftone): Data compression (MMR), Document feeder: ARDF, ITU-T No.1 Chart]	
Maximum power consumption	Less than 900 W		
Image sensor type	CCD Image Sensor		
Scan types	Sheet, book		
Interface	Ethernet interface (10BASE-T or 100BASE-TX) IEEE1284 IEEE 802.11a/g (Wireless LAN),	USB interface, Ethernet interface (10BASE-T or 100BASE-TX)	
Resolution B/W: 600 dpi Full color: 300 dpi - 600 dpi			
Variable range of scan resolution Setting range: 100 dpi - 600 dpi		pi	

^{*1} Scanning speeds vary according to machine operating conditions, computer (specifications, network traffic, software, etc.), and original types.

1.1.4 FAX

General

Type:	Desktop type transceiver
Circuit:	PSTN PBX
Connection:	Direct couple
Original Size:	Book (Face down): Maximum Width: 216 mm [8.5 inch] ARDF (Face up): (Single-sided document) Length: 139 - 1200 mm [5.5 - 47.2 inch] Width: 139 - 216 mm [5.5 - 8.5 inch] (Double-sided document) Length: 160 - 356 mm [6.3 - 14.0 inch] Width: 139 - 216 mm [5.5 - 8.5 inch]
Scanning Method:	Flat bed, with CCD
Resolution:	G3 8 x 3.85 lines/mm (Standard) 8 x 7.7 lines/mm (Detail) 8 x 15.4 line/mm (Fine) 200 x 100 dpi (Standard) 200 x 200 dpi (Detail)
Transmission Time:	G3: 3 at 28.8Kbps; Measured with G3 ECM using memory for an ITU-T #1 test document (Slerexe letter) at standard resolution
Data Compression:	MH, MR, MMR, JBIG
Protocol:	Group 3 with ECM
Modulation:	V.34, V.33, V.17 (TCM), V.29 (QAM), V.27ter (G3), V.8, V.21 (G3)

Specifications

Data Rate:	G3: 33600/31200/28800/26400/24000/21600/ 19200/16800/14400/12000/9600/7200/4800/2400 bps Automatic fallback
I/O Rate:	With ECM: 0 ms/line Without ECM: 2.5, 5, 10, 20, or 40 ms/line
Memory Capacity:	ECM: 128 KB SAF Standard: 4 MB Page Memory: Standard: 4 MB (Print: 2 MB + Scanner: 2 MB)

IFAX Specifications

Connectivity:	Local area network Ethernet 100base-Tx/10base-T IEEE1394 (IP over 1394) IEEE802.11b (wireless LAN)
Resolution:	Main scan: 400 dpi, 200 dpi Sub scan: 400 dpi, 200 dpi, 100 dpi To use 400 dpi, IFAX SW01 Bit 4 must be set to "1".
Transmission Time:	1 s (through a LAN to the server) Condition: ITU-T #1 test document (Selerexe Letter) MTF correction: OFF TTI: None Resolution: 200 x 100 dpi Communication speed: 10 Mbps Correspondent device: E-mail server Line conditions: No terminal access
Document Size:	Maximum message width is A4/LT. ■ To use B4 and A3 width, IFAX SW00 Bit 1 (B4) and/or Bit 2 (A3) must be set to "1".
E-mail File Format:	Single/multi-part MIME conversion Image: TIFF-F (MH, MR, MMR)
Protocol:	Transmission: SMTP, TCP/IP Reception: POP3, SMTP, IMAP4, TCP/IP
Data Rate:	100 Mbps(100base-Tx) 10 Mbps (10base-T)
Authentication	SMTP-AUTH

Specifications

Method:	POP before SMTP A-POP
Remark:	The machine must be set up as an e-mail client before installation. Any client PCs connected to the machine through a LAN must also be e-mail clients, or some features will not work (e.g. Autorouting).

IP-FAX Specifications

Network:	Local Area Network Ethernet/10base-T, 100base-TX IEEE1394 (IP over 1394) IEEE802.11b (wireless LAN)
Scan line density:	8 x 3.85 lines/mm, 200 x 100dpi (standard characters) 8 x 7.7lines/mm, 200 x 200dpi (detailed characters)
Original size:	Maximum A3 or 11"x 17" (DLT)
Maximum scanning size:	Standard: A3, 297mm x 432mm Irregular: 297mm x 1200mm
Transmission protocol:	Recommended: T.38 Annex protocol, TCP, UDP/IP communication
Compatible machines:	IP-Fax compatible machines
IP-Fax transmission function:	Specify IP address and send fax to an IP-Fax compatible fax through a network. Also capable of sending fax from a G3 fax connected to the public telephone lines via a VoIP gateway.
IP-Fax reception function:	Receive a fax sent from an IP-Fax compatible fax through a network. Also capable of receiving fax from a G3 fax connected the public telephone lines via a VoIP gateway.

Fax Unit Configuration

Component	Code	No.	Remarks
FCU		-	
мви	-	-	Standard for B284/288
Speaker		-	
Handset Type 1018	B433	-	NA only. Common with PG-C1

1.1.5 ARDF

	Standard:	A4 to A5; 8 ¹ / ₂ " x 14" to 8 ¹ / ₂ " x 5 ¹ / ₂ "		
	Custom (Simplex):	Width: 139 mm to 216 mm Length: 139 mm to 1260 mm		
Original Size:	Custom (Duplex):	Width: 139 mm to 216 mm Length: 160 mm to 356*1 mm		
	*1: When you use 310 mm or more originals, originals weighing 55k (17 lb. / 64 g/m²) or less cannot be used in duplex scanning mode.			
Original Weight:	52–105 g/m ² (14–28 lb.)			
Table Capacity:	50 sheets (80 g/m², 21 lb.)			
Original Standard Position:	Center			
Separation:	FRR			
Transport:	Roller transport			
Feed Order:	Top first			
Reproduction Range:	50–200%			
Power Source:	24 and 5 Vdc from the copier			
Power Consumption:	Operating: 50 W or less On standby: 1.2 W or less			
Dimensions (W x D x H):	485 x 360 x 120 mm (19.1" x 14.2" x 4.72")			
Weight:	4.9 kg (10.8 lb) (excluding the original table and platen cover)			

1.1.6 PAPER TRAY UNIT

Paper Sizes:	A4 SEF, 8½" x 11" SEF, 8½" x 13" SEF, 8½" x 14" SEF
Paper Weight:	60 – 90 g/m², 16 – 24 lb.
Tray Capacity:	500 sheets (80 g/m², 21 lb.) x 1 tray
Paper Feed System:	Feed roller and friction pad
Power Source:	24 Vdc and 5 Vdc, from copier. If optional tray heater is installed, the copier also supplies Vac (120 Vac or 220 – 240 Vac).
Power Consumption:	Maximum: 15 W (excluding optional tray heater)
Average:	14 W (excluding optional tray heater)
Weight:	Not above 6 kg (13.2. lb.)
Size (W x D x H):	430 x 414 x 140 mm (16.9" x 16.3" x 5.5")



Two can be installed.

1.2 SUPPORTED PAPER SIZES

1.2.1 ORIGINAL PAPER SIZES

The copier and ARDF do not detect original paper sizes. The following table lists the paper sizes that the ARDF can transport.

Paper	Size (W x L)	Book	ARDF	
i apei	SIZE (VV X L)	DOOK	Simpl.	Dupl.
A3 SEF	297 x 420 mm	_	-	-
B4 SEF	257 x 364 mm	_	-	-
A4 SEF	210 x 297 mm	Х	Х	Х
A4 LEF	297 x 210 mm	_		
B5 SEF	182 x 257 mm	Х	Х	Х
B5 LEF	257 x 182 mm	_		
A5 SEF	148 x 210 mm	Х	Х	Х
A5 LEF	210 x 148 mm	Х	Х	
B6 SEF	128 x 182 mm	_		
B6 LEF	182 x 128 mm	_		
A6 SEF	105 x 148 mm	_		
8K SEF	267 x 390 mm	_		
16K SEF	195 x 267 mm	Х	Х	Х
16K LEF	267 x 195 mm	_		
DLT SEF	11.0" x 17.0"	_		
LG SEF	8.5" x 14.0"	X* ¹	Х	X* ²

Supported Paper Sizes

Paper	Size (W x L)	Book	ARDF	
r aper	SIZE (VV X E)	Book	Simpl.	Dupl.
LT SEF	8.5" x 11.0"	Х	Х	Х
LT LEF	11.0" x 8.5"	-		
Executive SEF	7.25" x 10.5"	_	Х	Х
HLT SEF	5.5" x 8.5"	Х	Х	Х
HLT LEF	8.5" x 5.5"	Х	Х	
F/GL (F4) SEF	8.0" x 13.0"	X* ¹	Х	X* ²
Foolscap SEF	8.5" x 13.0"	X* ¹	Х	X* ²
Folio SEF	8.25" x 13.0"	X* ¹	Х	X* ²
Government	8.25" x 14"	X* ¹	Х	X* ²
USB4 SEF	10.0" x 14.0"	-		
Eng Quarto SEF	8.0" x 10.0"	-	Х	X* ²
Eng Quarto LEF	10.0" x 8.0"	_		
Custom:	Width 139-216 mm Length 139-356 mm	-	X* ³	X* ^{2, 4}

Symbol meanings:

X: Can use

-: Cannot use

*1: Can be used when the ARDF is installed

*2: 55k (17 lb./ 64 g/m²) or less original cannot be used.

*3: Width: 139-216 mm, Length: 139-1260 mm

*4: Width 139-216 mm, Length: 160-356 mm

1.2.2 PAPER FEED

The copier and optional paper feed unit do not detect paper sizes. The following table lists the paper sizes that the copier and optional paper feed unit can transport.

Paper	Size (W x L)	Regular	By-pass	Duplex	Optional PFU
A3 SEF	297 x 420 mm	_	_	_	-
B4 SEF	257 x 364 mm	_	_	_	-
A4 SEF	210 x 297 mm	Х	Х	Х	Х
A4 LEF	297 x 210 mm	_	-	-	-
B5 SEF	182 x 257 mm	Х	Х	Х	-
B5 LEF	257 x 182 mm	_	1	ı	-
A5 SEF	148 x 210 mm	_	Х	1	-
A5 LEF	210 x 148 mm	Х	Х	-	-
B6 SEF	128 x 182 mm	_	ı	ı	-
B6 LEF	182 x 128 mm	_	1	ı	1
A6 SEF	105 x 148 mm	_	I	1	1
8K SEF	267 x 390 mm	_	I	ı	1
16K SEF	195 x 267 mm	Х	X	X	1
16K LEF	267 x 195 mm	_	I	1	1
DLT SEF	11.0" x 17.0"	_	I	ı	1
LG SEF	8.5" x 14.0"	_	X	Х	Х
LT SEF	8.5" x 11.0"	Х	Х	Х	Х
LT LEF	11.0" x 8.5"	_	_	_	-
Executive SEF	7.25" x 10.5"	_	Х	-	-

Supported Paper Sizes

Paper	Size (W x L)	Regular	By-pass	Duplex	Optional PFU
HLT SEF	5.5" x 8.5"	_	Х	1	-
HLT LEF	8.5" x 5.5"	Х	Х	-	-
F/GL (F4) SEF	8.0" x 13.0"	_	Х	-	-
Foolscap SEF	8.5" x 13.0"	_	Х	Х	Х
Folio SEF	8.25" x 13.0"	_	Х	Х	Х
Government	8.25" x 14"	_	Х	Х	Х
Com 10 SEF	4.124" x 9.5"	_	Х	-	-
Monarch SEF	3.875" x 7.5"	_	Х	_	-
C5	162 x 229 mm	_	Х	-	-
C6	114 x 162 mm	_	Х	-	-
DL Env	110 x 220 mm	_	Х	_	-
Custom: Leading edge 90–216 mm Side edge 139–356 mm		_	Х	_	-

Symbol meanings:

X: Can transport

-: Cannot transport

APPENDIX: PREVENTIVE MAINTENANCE TABLES

REVISION HISTORY			
Page	age Date Added/Updated/New		
		None	

2. APPENDIX: PREVENTIVE MAINTENANCE TABLES

2.1 MAINTENANCE TABLES

Reset the PM counter (SP7-804-001) after doing maintenance work.

Key: AN: As necessary, C: Clean, R: Replace, I: Inspect

	Every 45k	Every 90k	AN	NOTE			
OPTICS							
Reflector	С		С	Optics cloth			
1st mirror	С		С	Optics cloth			
2nd mirror	С		С	Optics cloth			
3rd mirror	С		С	Optics cloth			
Platen cover	С		С	Dry cloth			
Exposure glass	С		С	Dry cloth			
Toner shield glass	С		С	Dry cloth			
DRUM AREA							
PCU	R			Clean toner-bottle holder.			
Transfer roller		R					
Discharge plate		R					
PAPER FEED							
Paper feed roller		R	С	Water or alcohol.			
Friction pad		R	С	Dry cloth			
Bottom-plate pad	С		С	Water or alcohol.			
Registration roller	С		С	Water or alcohol.			

Maintenance Tables

	Every 45k	Every 90k	AN	NOTE				
FUSING UNIT	FUSING UNIT							
Hot roller		R						
Pressure roller		R						
Hot roller bearings		R						
Pressure-roller bushings		I						
Inlet guide		С						
Outlet guide		С						
Hot roller stripper pawls		R						
Thermistor		С						

	Every 90k	AN	NOTE
ARDF			
Separation roller	R	С	Water or alcohol
Pick-up roller	R	С	Water or alcohol
Feed roller	R	С	Water or alcohol
White plate		С	Water or alcohol
DF exposure glass		С	Water
Rollers R0, R1, R2		С	Water or alcohol
Registration sensor reflector		С	Water or alcohol

	Every 120k	AN	NOTE			
PAPER TRAY UNIT						
Paper feed roller	R					
Bottom-plate pad		С	Dry cloth			
Friction pad	R					

APPENDIX: SERVICE CALL CONDITIONS

REVISION HISTORY				
Page	e Date Added/Updated/New			
		None		

3. APPENDIX: SERVICE CALL CONDITIONS

3.1 SC TABLES (F/SPF: D068/D069)

3.1.1 SUMMARY

There are four levels of service call conditions.

Level	Definition	Reset Procedure
A	To prevent possible damage, the machine does not operate until the service representative resets the SC code.	Activate the SP mode, and turn the main power switch off and on.
В	Turning the main power switch off and on resets the SC code if the error is caused by incorrect sensor detection.	Turn the main power switch off and on.
С	The machine operates as usual excluding the unit related to the service call.	Turn the main power switch off and on.
D	The SC history is updated. The machine operates as usual.	No SC code is displayed. Only the SC history is updated.



- If a problem involves circuit boards, see if you can solve the problem by disconnecting and reconnecting all connectors before deciding to replace a circuit board.
- If a problem involves a motor lock, check the mechanical load before deciding to replace a motor or sensor.
- If working on a fax-equipped machine, switching power off and on may cause loss of data stored in the memory.

3.1.2 ENGINE SC CODE DESCRIPTIONS

No.		Symptom	Possible Cause		
		Exposure Lamp Error			
101	В	The scanner has scanned the white plate, but cannot detect the white level.	 Defective exposure lamp Defective exposure lamp stabilizer Defective exposure lamp connector Unclean scanner mirror Scanner mirror out of position Defective SBU board Defective SBU connector Lens block out of position Incorrect position or width of white plate scanning (SP4-015) 		
		Scanner home position error 1			
120	В	The scanner home position sensor does not detect the scanner leaving the home position.	 Defective scanner home position sensor Defective scanner drive motor Defective scanner home position sensor connector Defective scanner drive motor connector Defective BICU board 		

No.		Symptom	Possible Cause	
		Scanner home position error 2		
121	В	The scanner home position sensor does not detect the scanner coming back to the home position.	 Defective scanner home position sensor Defective scanner drive motor Defective scanner home position sensor connector Defective scanner drive motor connector Defective BICU board 	
		SBU black level correction error		
141	В	 The automatic SBU adjustment has failed to correct the black level three times at the pre-offset adjustment. The automatic SBU adjustment has failed to correct the black level ten times at the PGA adjustment. The automatic SBU adjustment has failed to correct the black level ten times at the offset adjustment. 	■ Defective SBU board	
		SBU white/black level correction error		
142	В	The automatic SBU adjustment has failed to correct the white level ten times at the PGA adjustment.	 Defective exposure lamp Unclean white plate Incorrect position or width of white plate scanning (SP4-015) Defective SBU board 	

SM Appendix 3-3 D067/D068/D069/D072

No.		Symptom	Possible Cause	
		Communication Error between BICU	and SBU	
144	В	The BICU cannot correctly establish communication with the SBU.	 Loose connection of the flat cable between the BICU and the SBU Defective flat cable between the BICU and the SBU Defective BICU Defective SBU 	
		Automatic SBU adjustment error		
145	D	The white levels of the white plate and the white paper are extraordinarily different during the Scan Auto Adjustment (CSP4-428-001).	 Defective exposure lamp Unclean white plate Incorrect position or width of white plate scanning (SP4-015) Defective BICU board Defective SBU board 	
		Image transfer error		
193	В	Scanned images are not transferred to the controller memory within one minute.	Defective BICU boardDefective controller board	
		Memory address error		
198	В	The BICU does not receive the memory address report from the controller within one minute.	 Inconsistency between the BICU firmware and the controller firmware Defective BICU Defective controller 	

No. Definit		Symptom	Possible Cause
		Charge roller current leak	
302	В	The polling module detects a current leak of the charge roller.	 Defective charge roller Defective high voltage supply board Loose connection of the PCU
		Polygonal mirror motor error	
320	В	The polygon mirror motor does not reach the operating speed within 10 seconds. Or, the polygon mirror motor remains out of the operating speed for 0.2 second after reaching the operating speed.	 Defective polygon mirror motor Loose connection between the polygonal mirror motor and the BICU Defective cable between the BICU and the polygon mirror motor Defective BICU
		No laser writing signal (F-GATE) erro)r
321	В	The polling module does not detect the laser writing signal (F-GATE) asserting after the laser crosses 5 mm from the start point on the drum surface.	 Defective BICU Loose connection on the fax controller or the printer controller Defective fax controller or printer controller

SM Appendix 3-5 D067/D068/D069/D072

No.		Symptom	Possible Cause
		Laser synchronization error	
322	В	The main scan synchronization detector does not detect the laser signal for 0.5 second.	 Toner bottle not installed Loose connection between the LD unit and the BICU Defective cable between the BICU and LD unit LD unit out of position Defective LD unit Defective BICU
		TD sensor error	
390	В	The BICU detects the TD sensor outputting extraordinary voltage (less than 0.2 V or more than 4.0 V) 10 times consecutively.	 Defective TD sensor Loose connection of the PCU
		Development bias leak	
391	В	The polling module detects a current leak of the development bias.	Loose connection of the PCUDefective high voltage supply board
		Developer initialization error	
392	В	The ID sensor does not detect a correct pattern during developer initialization (© 2-214-001).	 Defective ID sensor Insufficient developer Defective drum operation Defective development roller operation Loose connection of the PCU Insufficient voltage for the charge roller

No. Definit		Symptom	Possible Cause
		Transfer roller leak error (positive ele	ectrode)
401	В	The feedback voltage of the transfer roller is insufficient.	 Defective high voltage supply board Loose connection of the PCU Incorrect installation of the transfer unit or the separation unit Defective transfer roller
		Transfer roller leak error (negative el	ectrode)
402	В	The feedback voltage of the transfer roller is insufficient.	 Defective high voltage supply board Loose connection of the PCU Incorrect installation of the transfer unit or the separation unit Defective transfer roller
		Main motor error	
500	В	The main motor does not reach its operation speed within 0.7 second. Or, the main motor remains out of its operation speed for 0.7 second after reaching the operation speed.	OverloadDefective main motor
		Fusing thermistor open error	
541	А	The fusing temperature remains lower than the specified temperature by 20 degrees Celsius.	 Defective thermistor Incorrect installation of the thermistor Defective power supply unit Loose connectors

SM Appendix 3-7 D067/D068/D069/D072

No.		Symptom	Possible Cause
		Fusing temperature warm-up error	
542	Α	The fusing temperature rises 7 degrees or less in two seconds; and this continues 5 times consecutively. Or, the fusing temperature is not detected within 25 or 35 seconds.	 Defective thermistor Incorrect installation of the thermistor Defective fusing lamp Defective power supply unit
		Fusing overheat error 1	
543	Α	The fusing temperature detected by the thermistor is 230°C or higher for one second.	Defective thermistorDefective power supply unit
		Fusing overheat error 2	
544	Α	The fusing temperature detected by the monitor circuit is 250°C or higher for one second.	Defective thermistorDefective power supply unit
		Fusing lamp overheat error	
545	Α	After the fusing temperature reaches the target, the fusing lamp remains on for 12 seconds.	 Defective thermistor Incorrect installation of the thermistor Defective power supply unit
		Unstable fusing temperature	
546	Α	While the fusing lamp is on, the fusing temperature varies 50°C or more within one second; and this occurs two consecutive times.	 Defective thermistor Incorrect installation of the thermistor Defective power supply unit

No. Definition		Symptom Possible Cause		Possible Cause
		Zero cross signal malfunction		
547	В	The zero cross signal is not detected within five seconds after the main power switch is turned on. Or, the zero cross signal is not detected within one second after operation begins.	•	Defective power supply unit Defective BICU
		Consecutive fusing jam		
559	Α	The paper jam counter for the fusing unit reaches 3 times. The paper jam counter is cleared if the paper is fed correctly. This SC is activated only when SP1159-001 is set to "1" (default "0").	•	Paper jam in the fusing unit.
		Exhaust fan motor error		
590	В	The exhaust fan motor is locked for five seconds.		Loose connection of the exhaust fan motor Overload
		ADF gate error 1		
760	В	The ADF sends the FGATE signal before it is requested to scan originals.	•	Defective ADF board Defective input/output board Loose connection
		ADF gate abnormal 2		
761	В	The ADF does not send the FGATE signal within 30 seconds after the ADF starts scanning.	•	Defective ADF connector Defective SBU board

SM Appendix 3-9 D067/D068/D069/D072

No.		Symptom		Possible Cause
		ADF gate abnormal 3	_	
762	В	The ADF continues to send the FGATE signal for more than 60 seconds after the ADF starts scanning.	•	Defective ADF connector Defective SBU board
		Mechanical total counter error		
901	В	The polling module does not detect the mechanical total counter.		Defective mechanical total counter Defective BICU Loose connection
		Engine total counter error		
903	В	The checksum of the total counter is not correct.	•	Defective NVRAM on the BICU
		Printer application program error		
954	В	The printer application program does not become ready when the printer application program is necessary.	•	Defective application program
		Image transfer error		
955	В	The BICU requests the controller to transfer image data; but the controller does not become ready.	•	Defective application program
		Status error (laser optics housing uni	it)	
964	В	The optics-housing unit does not become ready within 17 seconds after a request.	•	Defective software

No. Definition		Symptom	Possible Cause
		Controller-engine inconsistency	
980	В	The controller is incompatible with the engine.	One of the following controllers is installed to the basic model: The controller of the MFP model The controller of the copier/facsimile model The controller of the printer/scanner/copier model The controller of the optional printer/scanner is installed to one of the following models: The MFP model The copier/facsimile model The printer/scanner/copier model
		NVRAM error	
981	В	An error occurs during engine NVRAM check.	 Defective NVRAM Loose connection between the BICU and the NVRAM Incorrect installation of the NVRAM Defective BICU
		Localization error	
982	В	The localization information in the nonvolatile ROM and in the NVRAM is different (CSP5-807-001).	 Localization setting not specified (The main power switch is turned on for the first time after the NVRAM is replaced.) Incorrect localization setting Defective NVRAM

SM Appendix 3-11 D067/D068/D069/D072

SC Tables (F/SPF: D068/D069)

No. Definition		Symptom	Possible Cause
		Print image transfer error	
984	В	Print images are not transferred.	 Defective controller Defective BICU Loose connection between the controller and the BICU

3.1.3 GW SC CODE DESCRIPTIONS

SC6xx

No. Definition		Symptom	Possible Cause/Countermeasure
		MF accounting device error 1	
632	С	The machine sends a data frame. → No normal end signal returns. → This symptom happens three times.	Defective or broken line between machine and device
		MF accounting device error 2	
633	С	The machine is communicating with the accounting device. → The break signal returns.	Defective or broken line between machine and device
		MF accounting device error 3	
634	С	A backup RAM error is reported from the accounting device.	 Defective accounting device controller Defective battery in the accounting device
		MF accounting device error 4	
635	С	A battery voltage error is reported from the accounting device.	 Defective accounting device controller Defective battery in the accounting device

No. Definition		Symptom	Ро	ssible Cause/Countermeasure
636	SDO	Card Error		
		Expanded authentication module err	or	
-001	В	There is no expanded authentication module in the machine. The SD card or the file of the expanded authentication module is broken. There is no DESS module in the machine.	1.	Install the correct SD card or the file of the expanded authentication module. Install the DESS module.
-002	В	Version error The version of the expanded	1.	Install the correct file of the
		authentication module is not correct.		expanded authentication module.
650	Com	munication error of the remote servic	e mo	odem (Cumin-M)
		Authentication error		
-001	С	The authentication for the Embedded RCG-M fails at a dial up connection.	1.	Check and set the correct user name (SP5816-156) and password (SP5816-157).
		Incorrect modem setting		
-004	С	Dial up fails due to the incorrect modem setting.	1.	Check and set the correct AT command (SP5819-160).

No. Definition		Symptom	Possible Cause/Countermeasure	
		Communication line error		
-005	С	The supplied voltage is not sufficient due to the defective communication line or defective connection.	Consult with the user's local telephone company.	
	Inco	rrect dial up connection		
651	An unexpected error occurs when the modem (RCG-M) tries to call the center with a dial up connection.			
-001	D	Program parameter error	Software bug.	
-002	D	Program execution error	 No action required because this SC does not interfere with operation of the machine. 	
		Engine startup error		
670	В	Just after the main power is turned on or the machine is recovering from auto off mode, the engine ready signal assertion fails. Just after the main power is turned on, the engine does not respond.	 Poor connection between the BICU and controller board Defective BICU Defective controller board 	

No. Definition		Symptom	Possible Cause/Countermeasure
672	В	Controller-to-operation panel communication between the	 Controller stalled Controller board installed incorrectly Defective controller board Operation panel connector loose or defective
072	B	controller and operation panel does not begin, or the communication is interrupted after a normal startup.	 Poor connection of DIMM and optional boards on the controller board Check the setting of SP5875-001. If the setting is set to "1 (OFF)", change it to "0 (ON)".

SC8xx

No. Definition		Symptom	Pos	ssible Cause/Countermeasure
	Mon	itor Error		
817	В	This is a file detection and electronic file signature check error when the boot loader attempts to read the self-diagnostic module, system kernel, or root system files from the OS Flash ROM, or the items on the SD card in the controller slot are false or corrupted.		OS Flash ROM data defective; change the controller firmware SD card data defective; use another SD card
	Kerr	nel stop		
819	Due to a control error, a RAM overfl processing. One of the following me operation panel.			• •
[5032]	В	HAIC-P2 error		
[6261]	В	init died		System program defective
[0696e]	В	Process error	•	Controller board defective
[0766d]	В	VM full error	1.	Optional board defective Replace controller firmware
[554C]	В	USB error		
[]	В	The others		

820	Self-	-Diagnostic Error: CPU		
		• [0001-0015] [000A-000D]:	Deta	ailed error code
	В	During the boot monitor program and self-diagnostic, any exception or cut-in are not supposed to happen. If these happen, it is defined as SC.	1. 2.	Defective CPU device Defective boot monitor program or self-diagnostic program Replace the controller board. Reinstall the system firmware.
		[00FF]: Detailed error code		
	В	Cache access error in the CPU	1. 2. 3.	Defective CPU Defective local bus Turn the main power switch off and on. Reinstall the system program. Replace the controller board.
		[0601, 0602, 0605, 0606, 0607,	060	09]: Detailed error code
	В	Exceptional command does not operate even though it is executed on purpose.	1.	Defective CPU devices Replace the controller board.
		[060A-060E]: Detailed error coo	de	
	В	Cut-in command does not operate when it is executed.	• • 1.	Defective CPU devices Defective ASIC devices Replace the controller board.
	В	[0610]: Detailed error code		
		Timer cut-in does not operate even though it is set.	• 1.	Defective CPU devices Replace the controller board.
	В	[0612]: Detailed error code		

В	Cut-in in ASIC occurs. [06FF]: Detailed error code The pipeline clock frequency rate is different from the prescribed value.	1.	Defective ASIC Defective devices in which ASIC detects cut-in. Replace the controller board. Defective CPU devices Mode bit data error, which is used for initializing CPU. Replace the controller board.
	[0702]: Detailed error code		
В	The result when the program is executed in the command cache is different from desirable value.	1. 2.	Insufficient CPU cache Insufficient memory process speed Replace the controller board. Replace the RAM DIMM.
	[0709, 070A]: Detailed error cod	de	
В	Even you write the data in the only cache of memory, the data is actually written in another area (not cache) of memory.	• • 1. 2.	Defective CPU devices Incorrect SPD Boot mode setting error Replace the controller board. Replace the RAM DIMM.
	[0801, 0804, 0807, 0808, 0809,	80	A]: Detailed error code
В	An error occurs when checking the TLB.	■ 1.	Defective CPU devices Replace the controller board.
	[4002-4005]: Detailed error cod	е	
В	The calculation error in the CPU occurs.	■ 1.	Defective CPU Replace the CPU.

821	Self-	-Diagnostic Error: ASIC			
		ASIC error			
[0B00]	В	The write-&-verify check error has occurred in the ASIC.	■ 1.	Defective controller board Replace the controller.	
		ASIC not detected			
[0B06]	В	The ASIC of the I/O is not detected.	• •	ASIC (controller board defective) Poor connection between North Bridge and PCI I/F. Replace controller board.	
		Timer error between ASIC and CPU			
[0D05]	В	The CPU checks if the ASIC timer works properly compared with the CPU timer. If the ASIC timer does not function in the specified range, this SC code is displayed.	1. 2.	System firmware problem Defective RAM-DIMM Defective controller Reinstall the controller system firmware. Replace the RAM-DIMM. Replace the controller board.	
		Video bridge device (ASIC) erro	r 1		
[50A1]	В	The CPU does not detect the video bridge device.	1.	Defective I/F between the video bridge device and i-controller Replace the i-controller.	
		Video bridge device (ASIC) regi	ster	error 1	
[50A2]	В	The CPU detects the video bridge device, but detects error data from the video bridge device.	1.	Defective I/F between the video bridge device and i-controller Replace the i-controller.	

822	Self-diagnostic error: HDD (Hard Disk Drive) [XXXX]: Detailed error code			
		en the main switch is turned on one of the specified time or n	r starting the self-diagnostic, the HDD nore.	
[3003]	С	Timeout error	 Loose connection 	
[3004]	С	Command error	 Defective HDD Defective controller Check that the HDD is correctly connected to the controller. Replace the HDD. Replace the controller. 	
823	Self	elf-diagnostic Error: NIB		
		MAC address check sum error		
[6101]	С	The result of the MAC address check sum does not match the check sum stored in ROM.	Defective controller1. Replace the controller.	
		PHY IC error		
[6104]	С	The PHY IC on the controller cannot be correctly recognized.	Same as SC823-[6101]	
		PHY IC loop-back error		
[6105]	С	An error occurred during the loop-back test for the PHY IC on the controller.	Same as SC823-[6101]	

		Self-diagnostic Error: NVRAM		
824 [1401]	В	The controller cannot recognize the standard NVRAM installed or detects that the NVRAM is defective.	 Loose connection Defective standard NVRAM Defective controller Check the standard NVRAM is firmly inserted into the socket. Replace the NVRAM. Replace the controller 	
		Self-diagnostic Error: RTC/Opti	onal NVRAM	
	В	[1501]: Clock error		
826		 An RTC device is recognized, and the difference between the RTC device and the CPU exceeds the defined limit. No RTC device is recognized. 	RTC defective1. Replace the RTC device.	
	В	[15FF]: RTC not detected		
		The RTC device is not detected.	 NVRAM without RTC installed Backup battery discharged Replace the NVRAM with another NVRAM with an RTC device. 	

827	Self-	Self-diagnostic Error: RAM		
		Verification error		
[0201]	В	Error is detected during a write/verify check for the standard RAM (SDRAM DIMM).		Loose connection Defective SDRAM DIMM Defective controller 1. Replace the SDRAM DIMM. 2. Replace the controller.
		Resident memory error		
[0202]	В	The SPD values in all RAM DIMM are incorrect or unreadable.	• • 1.	Defective RAM DIMM Defective SPD ROM on RAM DIMM Defective 12C bus Replace the RAM DIMM.
828	Self-	-diagnostic Error: ROM		
[0101]	В	Boost lap code error The boot monitor and OS program stored in the ROM DIMM is checked. If the check sum of the program is incorrect, this SC code is displayed.	-	Defective ROM DIMM Defective controller 1. Replace the ROM DIMM. 2. Replace the controller.

SM Appendix 3-23 D067/D068/D069/D072

		Self-diagnostic Error: Optional RAM				
		Verify error for optional RAM.				
829	В	[0301] Verification error (Slot 1)	Make sure that the resident RAM is installed in the correct			
		[0302] Composition error (Slot 1)	slot. • Make sure the optional RAM is installed in the correct slot (Slot 0)			
835	Self	-diagnostic error: Centronic devid	ce			
[1102]	С	Loopback connector is connected but check results in an error.	 IEEE1284 connector error Centronic loopback connector defective Replace the controller board. 			
[110C]	С	Loopback connector is connected but check results in an error.	 ASIC device error IEEE1284 connector error Centronic loopback connector defective Replace the controller board. 			
[1120]	С	Centronic loopback connector is not connected for detailed self-diagnostic test.	 Centronic loopback connector not connected correctly Centronic loopback connector defective ASIC device defective Replace the controller board. 			
		Self-diagnostic Error: Clock Ge	enerator			
838 [2701]	В	A verify error occurred when setting data was read from the clock generator via the I2C bus.	 Defective clock generator Defective I2C bus Defective I2C port on the CPU Replace the controller board. 			

839	USE	NAND Flash ROM error			
[9101]	В	The ID of the USB NAND Flash ROM cannot be read.	•	Defective i-controller board	
[9110]	В	The USB NAND Flash ROM is disconnected.	1.	Replace the i-controller board.	
		Wireless card startup error			
853	С	The machine starts up. → The IEEE802 11b card connection board is recognized. → The wireless LAN card or bluetooth card is not recognized.	•	Loose connection between the wireless card and the connection board	
		Wireless card access error			
854	С	The machine has been reading the data from the card. → The machine loses access to the card; the wireless LAN card or bluetooth card connection board is still recognized.	•	Loose connection between the wireless card and the connection board	
		Wireless card error			
855	С	Some illegal data is found in the card.	•	Defective wireless card	
		Wireless card connection board error			
856	С	An error is detected in the wireless LAN card or bluetooth card connection board.		Defective wireless card connection board	

		USB I/F Error			
857	С	USB interface error is detected.	1. 2.	Defective controller Check the USB connections, and make sure that they are securely connected. Replace the controller board.	
	HDE	D Encryption unit error 1			
858		rious error occurs when data is e the HDD encryption unit.	ncry	pted to update an encryption key	
[0]		Encryption key acquisition error: The controller fails to get a new encryption key.	1.	Defective controller board Replace the controller board.	
[1]		Encryption key setting for HDD error: The controller fails to copy a new encryption key to the HDD.	1.	Defective SATA chip on the controller board Replace the controller board.	
[2]	А	NVRAM data encryption error 1: An error occurs while the NVRAM data is encrypted.	1.	Defective NVRAM on the controller board Replace the NVRAM.	
[30]		NVRAM data encryption error 2: An error occurs before the NVRAM data is encrypted.	1.	Defective controller board Replace the controller board.	
[31]		Other error: A serious error occurs while the data is encrypted.	•	Same as SC991	

	HDD Encryption unit error 2				
859	A serious error occurs when the HDD data is encrypted to update an encryption key with the HDD encryption unit.				
[8]	С	HDD check error: The HDD is not correctly installed.	1. 2.	No HDD installed Unformatted HDD The encryption key on the controller is different from the one on the HDD Install the HDD correctly. Initialize the HDD.	
[9]		Power failure during the data encryption: The data encryption (NVRAM and HDD) has not been completed.	1.	Power failure during the data encryption Initialize the HDD.	
[10]		Data read/write error: The DMAC error is detected twice or more.	•	Same as SC863	
	HDE): Initialization error			
860	В	The controller detects that the hard disk fails.	1.	HDD not initialized Defective HDD Reformat the HDD. Replace the HDD.	
	Bad sector number error				
862	В	The number of bad sectors in the HDD (image data area) goes over 101.	1. 2.	Defective HDD Format the HDD with SP5-832-002. Replace the HDD.	

	HDE): Read error			
863	С	The data stored in the HDD cannot be read correctly.	1. 2.	Defective HDD Defective controller Replace the HDD. Replace the controller.	
	HDE): CRC error			
864	С	While reading data from the HDD or storing data in the HDD, data transmission fails.	1.	Defective HDD Replace the HDD.	
	HDD: Access error				
865	С	An error is detected while operating the HDD.	1 .	Defective HDD Replace the HDD.	
		SD card authentication error			
866	С	A digital license error of an SD card application is detected.	•	SD card data has corrupted. 1. Store correct data in the SD card.	
867		SD card error			
	В	An application SD card is removed from the boot slot while an application is activated.	•	An application SD card is ejected.	

868	В	SD card access error			
		(-13 to -3: File system error, other number: Device error)			
		An error report is sent from the SD card reader.	1. 2. 3. 4. 5.	SD card not inserted correctly SD card defective Controller board defective For a file system error, format the SD card on PC. For a device error, turn the main switch off and on. Remove and re-install the SD card. Replace the SD card. Replace the controller.	
		Address book data error			
870	С	The address book in the hard disk is accessed. → An error is detected in the address book data is not read; or data is not written into the address book. ■ To recover from the error, do any of the following countermeasures: ■ Format the address book by using SP5-846-050 (all data in the address book—including the user codes and counters—is initialized).	1.	Data corruption Defective hard disk Defective controller software Replace the hard disk (the user codes and counters are recovered when the main switch is turned on if those data are stored in Smart Device Monitor for Admin).	

SM Appendix 3-29 D067/D068/D069/D072

	Log Data Error			
876	An error was detected in the handling of the log data at power on or during machine operation. This can be caused by switching the machine off while it is operating.			
-001	С	Log Data Error 1	 Damaged log data file in the HDD Initialize the HDD with SP5832-004. 	
-002	С	Log Data Error 2	 An encryption module not installed Disable the log encryption setting with SP9730-004 ("0" is off.) Install the DESS module. 	
-003	С	Log Data Error 3	 Invalid log encryption key due to defective NVRAM data Initialize the HDD with SP5832-004. Disable the log encryption setting with SP9730-004 ("0" is off.) 	
-004	С	Log Data Error 4	 Unusual log encryption function due to defective NVRAM data Initialize the HDD with SP5832-004. 	

-005	С	Log Data Error 5	1.	Installed NVRAM or HDD which is used in another machine Reinstall the previous NVRAM or HDD. Initialize the HDD with SP5832-004.
-099	С	Log Data Error 99	1 .	Other than the above causes Ask your supervisor.
	TPM system authentication error			
878	С	The system firmware is not authenticated by TPM (security chip).	1.	Incorrect updating for the system firmware Defective flash ROM on the controller board Replace the controller board.
		File Format Converter (MLB) en	ror	
880	В	A request to get access to the MLB was not answered within the specified time.	•	MLB defective

SM Appendix 3-31 D067/D068/D069/D072

SC Tables (F/SPF: D068/D069)

SC9xx

	00 B	Electronic total counter error			
900		The value of the total counter is out of the normal range.	•	Defective NVRAM	
		Printer error			
920	С	An application error that stops the machine operation is detected.	1 .	Defective software Unexpected hardware resource (e.g., memory shortage)	
		Printer font error			
921	С	A necessary font is not found in the SD card when the printer application starts.	• 1.	A necessary font is not found in the SD card. The SD card data is corrupted. Check that the SD card stores correct data.	
	Net file error				
925	С	The management file for net files is corrupted; net files are not normally read. Netfiles: Jobs to be printed from the document server using a PC and the DeskTopBinder software		Defective hardware Data corruption Defective software	

		Software performance error		
990	В	The software attempted to perform an unexpected operation. Note When this error occurs, the file name, address, and data will be stored in NVRAM. This information can be checked by using SP7-403. See the data and the situation in which this SC occurs. Then report the data and conditions to your technical control center.		Software defective Internal parameter incorrect Insufficient working memory
991	D	Software continuity error The software attempted to perform an unexpected operation. However, unlike SC990, the process can keep on running.		Logged only; the machine can continue to operate
		Undefined error		
992	В	An error not controlled by the system occurred (the error does not come under any other SC code).	•	Defective software program

		Application function selection error			
997	С	The application selected by a key press on the operation panel does not start or ends abnormally.	 Software for that application is defective An option required by the application (RAM, DIMM, board) is not installed. Too complicated nest of the fax group address As for the fax operation problem, simplify the nest of the fax group address. 		
		Application start error			
998	В	After switching the machine on, the application does not start within 60 s. (No applications start or end normally.)	 Software for that application is defective An option required by the application (RAM, DIMM, board) is not installed. Check the setting of SP5875-001. If the setting is set to "1 (OFF)", change it to "0 (OFF)". 		

3.2 SC TABLES (BASIC: D067/D072)

3.2.1 SUMMARY

There are four levels of service call conditions.

Level	Definition	Reset Procedure
A	To prevent possible damage, the machine does not operate until the service representative resets the SC code.	Activate the SP mode, and turn the main power switch off and on.
В	Turning the main power stitch off and on resets the SC code if the error is caused by incorrect sensor detection.	Turn the main power switch off and on.
С	The machine operates as usual excluding the unit related to the service call.	Turn the main power switch off and on.
D	The SC history is updated. The machine operates as usual.	No SC code is displayed. Only the SC history is updated.



- If a problem involves circuit boards, see if you can solve the problem by disconnecting and reconnecting all connectors before deciding to replace a circuit board.
- If a problem involves a motor lock, check the mechanical load before deciding to replace a motor or sensor.
- If working on a fax-equipped machine, switching power off and on may cause loss of data stored in the memory.

SC Tables (Basic: D067/D072)

3.2.2 ENGINE SC CODE DESCRIPTIONS

No. Definition		Symptom	Possible Cause
		Exposure Lamp Error	
101	В	The scanner has scanned the white plate, but cannot detect the white level.	 Defective exposure lamp Defective exposure lamp stabilizer Defective exposure lamp connector Unclean scanner mirror Scanner mirror out of position Defective SBU board Defective SBU connector Lens block out of position Incorrect position or width of white plate scanning (**SP4-015)
		Scanner home position error 1	
120	В	The scanner home position sensor does not detect the scanner leaving the home position.	 Defective scanner home position sensor Defective scanner drive motor Defective scanner home position sensor connector Defective scanner drive motor connector Defective BICU board

	o. nition	Symptom	Possible Cause
		Scanner home position error 2	
121	В	The scanner home position sensor does not detect the scanner coming back to the home position.	 Defective scanner home position sensor Defective scanner drive motor Defective scanner home position sensor connector Defective scanner drive motor connector Defective BICU board
		SBU black level correction error	
141	В	 The automatic SBU adjustment has failed to correct the black level three times at the pre-offset adjustment. The automatic SBU adjustment has failed to correct the black level ten times at the PGA adjustment. The automatic SBU adjustment has failed to correct the black level ten times at the offset adjustment. 	■ Defective SBU board
		SBU white/black level correction error	-
142	В	The automatic SBU adjustment has failed to correct the white level ten times at the PGA adjustment.	 Defective exposure lamp Unclean white plate Incorrect position or width of white plate scanning (SP4-015) Defective SBU board

SM Appendix 3-37 D067/D068/D069/D072

	o. nition	Symptom	Possible Cause	
		Communication Error between BICU and SBU		
144	В	The BICU cannot correctly establish communication with the SBU.	 Loose connection of the flat cable between the BICU and the SBU Defective flat cable between the BICU and the SBU Defective BICU Defective SBU 	
		Automatic SBU adjustment error		
145	D	The white levels of the white plate and the white paper are extraordinarily different during the Scan Auto Adjustment (CSP4-428-001).	 Defective exposure lamp Unclean white plate Incorrect position or width of white plate scanning (CSP4-015) Defective BICU board Defective SBU board 	
		Image transfer error		
193	В	Scanned images are not transferred to the controller memory within one minute.	Defective BICU boardDefective controller board	
		Memory address error		
198	В	The BICU does not receive the memory address report from the controller within one minute.	 Inconsistency between the BICU firmware and the controller firmware Defective BICU Defective controller 	

No. Definition		Symptom	Possible Cause
		Charge roller current leak	
302	В	The polling module detects a current leak of the charge roller.	 Defective charge roller Defective high voltage supply board Loose connection of the PCU
		Polygonal mirror motor error	
320	В	The polygon mirror motor does not reach the operating speed within 10 seconds. Or, the polygon mirror motor remains out of the operating speed for 0.2 second after reaching the operating speed.	 Defective polygon mirror motor Loose connection between the polygonal mirror motor and the BICU Defective cable between the BICU and the polygon mirror motor Defective BICU
		No laser writing signal (F-GATE) error	
321	В	The poling module does not detect the laser writing signal (F-GATE) asserting after the laser crosses 5 mm from the start point on the drum surface.	 Defective BICU Loose connection on the fax controller or the printer controller Defective fax controller or printer controller

N Defin		Symptom	Possible Cause	
		Laser synchronization error		
322	В	The main scan synchronization detector does not detect the laser signal for 0.5 second.	 Toner bottle not installed Loose connection between the LD unit and the BICU Defective cable between the BICU and LD unit LD unit out of position Defective LD unit Defective BICU 	
		TD sensor error		
390	В	The BICU detects the TD sensor outputting extraordinary voltage (less than 0.2 V or more than 4.0 V) 10 times consecutively.	 Defective TD sensor Loose connection of the PCU 	
		Development bias leak		
391	В	The polling module detects a current leak of the development bias.	Loose connection of the PCUDefective high voltage supply board	
		Developer initialization error		
392	В	The ID sensor does not detect a correct pattern during developer initialization (2-214-001).	 Defective ID sensor Insufficient developer Defective drum operation Defective development roller operation Loose connection of the PCU Insufficient voltage for the charge roller 	

	o. nition	Symptom	Possible Cause	
		Transfer roller leak error (positive electrode)		
401	В	The feedback voltage of the transfer roller is insufficient.	 Defective high voltage supply board Loose connection of the PCU Incorrect installation of the transfer unit or the separation unit Defective transfer roller 	
		Transfer roller leak error (negative ele	ectrode)	
402	В	The feedback voltage of the transfer roller is insufficient.	 Defective high voltage supply board Loose connection of the PCU Incorrect installation of the transfer unit or the separation unit Defective transfer roller 	
		Main motor error		
500	В	The main motor does not reach its operation speed within 0.7 second. Or, the main motor remains out of its operation speed for 0.7 second after reaching the operation speed.	OverloadDefective main motor	
		Fusing thermistor open error		
541	А	The fusing temperature remains lower than the specified temperature by 20 degrees Celsius.	 Defective thermistor Incorrect installation of the thermistor Defective power supply unit Loose connectors 	

SM Appendix 3-41 D067/D068/D069/D072

	o. nition	Symptom	Possible Cause			
		Fusing temperature warm-up error				
542	А	The fusing temperature rises 7 degrees or less in two seconds; and this continues 5 times consecutively. Or, the fusing temperature is not detected within 25 or 35 seconds.	 Defective thermistor Incorrect installation of the thermistor Defective fusing lamp Defective power supply unit 			
		Fusing overheat error 1				
543 A		The fusing temperature detected by the thermistor is 230°C or higher for one second.	Defective thermistorDefective power supply unit			
		Fusing overheat error 2				
544	А	The fusing temperature detected by the monitor circuit is 250°C or higher for one second.	Defective thermistorDefective power supply unit			
		Fusing lamp overheat error				
545	A	After the fusing temperature reaches the target, the fusing lamp remains on for 12 seconds.	 Defective thermistor Incorrect installation of the thermistor Defective power supply unit 			
		Unstable fusing temperature				
546	A	While the fusing lamp is on, the fusing temperature varies 50°C or more within one second; and this occurs two consecutive times.	 Defective thermistor Incorrect installation of the thermistor Defective power supply unit 			

No. Definition		Symptom		Possible Cause			
		Zero cross signal malfunction					
547	В	The zero cross signal is not detected within five seconds after the main power switch is turned on. Or, the zero cross signal is not detected within one second after operation begins.		Defective power supply unit Defective BICU			
		Consecutive fusing jam					
559	Α	The paper jam counter for the fusing unit reaches 3 times. The paper jam counter is cleared if the paper is fed correctly. This SC is activated only when SP1159-001 is set to "1" (default "0").	•	Paper jam in the fusing unit.			
		Exhaust fan motor error					
590	В	The exhaust fan motor is locked for five seconds.		Loose connection of the exhaust fan motor Overload			
		Accounting error 1					
632	С	An error occurs during communication with the MF accounting device.	•	Defective accounting device Loose connection			
		Accounting RAM error					
634	С	An error occurs in the backup RAM for the MF accounting device.	•	Defective accounting device			

	o. nition	Symptom		Possible Cause		
		Accounting battery error				
635	С	An error occurs in the battery of the MF accounting device.	•	Defective accounting device		
		Printer board communication error				
692	С	 BICU does not get a signal from the printer board for 1.5 seconds or more. BICU gets a break-signal after completing the communication with the printer board and does not get a signal from the printer board for 10 seconds or more. 	•	Defective communication between BICU and printer board		
		Scanner board communication error				
694	С	 BICU does not get a signal from the scanner board for 1.5 seconds or more. BICU gets a break-signal after completing the communication with the scanner board and does not get a signal from the scanner board for 10 seconds or more. 	•	Defective communication between BICU and scanner board		
		ADF gate error 1				
760	В	The ADF sends the FGATE signal before it is requested to scan originals.		Defective ADF board Defective input/output board Loose connection		

	o. nition	Symptom	Possible Cause			
		ADF gate abnormal 2				
761	В	The ADF does not send the FGATE signal within 30 seconds after the ADF starts scanning.	Defective ADF connectorDefective SBU board			
		ADF gate abnormal 3				
762 B		The ADF continues to send the FGATE signal for more than 60 seconds after the ADF starts scanning.	Defective ADF connectorDefective SBU board			
	В	Mechanical total counter error				
901		The polling module does not detect the mechanical total counter.	 Defective mechanical total counter Defective BICU Loose connection 			
		Engine total counter error				
903	В	The checksum of the total counter is not correct.	■ Defective NVRAM on the BICU			
		Memory error				
928	В	An error occurs during the memory check conducted when the main power switch is turned on or when the copier is recovering from the energy saver mode.	 Defective memory Defective BICU Loose connection between the BICU and the memory 			

	o. nition	Symptom	Possible Cause	
		IMAC hardware error		
929	В	A memory control job is not completed within a certain period.	Defective IMACDefective BICULoose connection	
		NVRAM error		
981	B An error occurs during engine NVRAM check.		 Defective NVRAM Loose connection between the BICU and the NVRAM Incorrect installation of the NVRAM Defective BICU 	
		Localization error		
982	B The localization information in the nonvolatile ROM and in the NVRAM is different (SP5-807-001).		 Localization setting not specified (The main power switch is turned on for the first time after the NVRAM is replaced.) Incorrect localization setting Defective NVRAM 	

APPENDIX: ELECTRICAL COMPONENT DEFECTS

REVISION HISTORY				
Page Date Added/Updated/New				
		None		

Appendix: Electrical Component Defects

4. APPENDIX: ELECTRICAL COMPONENT DEFECTS

4.1 ELECTRICAL COMPONENT DEFECTS

4.1.1 SENSOR/SWITCH

Sensor	Connector	Message	Remarks	
Registration	CN127	Paper jam	_	
Sensor	SN	i apoi jaiii		
Paper End Sensor	CN129	Load paper	_	
T apor Ena concor	SN	2000 рарог		
Bypass Paper	CN130	(None)	The machine cannot detect	
End Sensor	SN	(None)	paper on the bypass tray.	
Paper Path	CN128	Paper jam	_	
Sensor	SN	т ары јаш		
Exit Sensor	CN128	Paper jam	_	
LAIT GENSOI	SN	т арст јаш		
Image Density	CN132	(None)	Print quality may become	
(ID) Sensor	SN	(None)	worse.	
Toner Density (TD) Sensor	CN123	SC901	The connector is shared with the mechanical total counter.	
(12) 0011001	PCU	Reset PCU correctly	-	
Scanner HP	CN126	SC120	-	
Sensor	SN	SC120	-	

Electrical Component Defects

Sensor	Connector	Message	Remarks
	CN126	SC120	-
Platen Cover Sensor	SN	(None)	The copier does not warm up when you open the platen cover.
DF Guide Open	DF CN103	Paper jam	-
Sensor	SN	(None)	-
DF Original Set	DF CN103	Paper jam	-
Sensor	Sensor	(None)	Originals are not detected.
DF Registration	DF CN103		-
Sensor	SN	Paper jam	Originals are correctly transported.
Inverter Sensor	DF CN103	Paper jam	-
inverter ochsor	SN	(None)	-
Exit Sensor	DF CN103	Paper jam	-
LAIT OCHSOI	SN	т арст јатт	-
	CN114	Right door open	-
Front Door Switch	SW	Front/Right door open	The message depends on which circuit is open (white \rightarrow front; blue \rightarrow right).
Right Door Switch	CN114	Right door open	-
Tagne Book Ownor	SW	Right door open	-

CNxxx: The connector on the BICU board.

DF CNxxx: The connector on the DF connection board.

SN: The connector on the sensor. SW: The connector on the switch.

Appendix: Electrical Component Defects

PCU: The connector on the PCU.

4.1.2 BLOWN FUSE CONDITIONS

All of these fuses are on the power supply unit.

Fuse	Rat	ing	At main switch ON
	120 V	220 – 240 V	, a main switch on
FU1	15A/125V	8A/250 V	No response
FU2	5A/125V	2.5A/250V	No response

4.1.3 BICU LED DISPLAY

Number	Function
LED2	LED2 blinks in normal operation.

APPENDIX: SP MODE TABLES

REVISION HISTORY			
Page Date Added/Updated/New			
45	05/21/2009	Updated Information - SP 5801 (D068/D069)	
86	03/17/2009	Updated Information - SP 5873	
138	05/19/2009	Updated Information – SP1001	
164	05/21/2009	Updated Information - SP 5801 (D067/D072)	

Appendix: SP Mode Tables

5. APPENDIX: SP MODE TABLES

5.1 SYSTEM SERVICE MODE (F/SPF: D068/D069)

5.1.1 SERVICE MODE TABLES

SP1-XXX (Feed)

1001*	LE Registration	[-9.0 to 9.0 / 0.0 / 0.1 mm/step]
1001 1	All Trays	Adjusts the leading-edge registration
1001 2	By-pass	("Adjusting Copy Image Area" in the section
1001 3	Duplex	"Replacement and Adjustment").

1002*	S-to-S Regist	[-9.0 to 9.0 / 0.0 / 0.1 mm/step]
1002 1	1st Tray	djusts the side-to-side registration
1002 2	2nd Tray	("Adjusting Copy Image Area" in the section "Replacement and Adjustment"). SP1-002-001
1002 3	3rd Tray	is applied to all trays. SP1-002-002, 003 and
1002 5	By-pass	005 adjusts the difference from SP1-002-001.
1002 6	Duplex	Adjusts the side-to-side registration of the 2nd side in duplex copying. The 1st side is adjusted by SP1-002-001 through 005.

1003*	Paper Feed Timing	Adjusts the amount of paper buckle on the registration roller.
1003 1	1st tray	[0 to 10 / 5 / 1 mm/step]
1003 3 Bank Trays	[0 to 10 / 5 / 1 mm/step]	
1003 4	By-pass	[0 to 10 / 5 / 1 mm/step]
1003 5	Duplex	[0 to 20 / 5 / 1 mm/step]

1103*	Fusing Idling		[0 = No / 1 = Yes]	
	Enables or disables the contact-release control. The following table lists the results.			e following table lists the
4400.4	Setting		0 = No	1 = Yes
1103 1	C-R control		Works	Does not work
	Idling time		Shorter	Longer
	Fusing quality		Lower	Higher

1105*	Fusing Temp Adj			
	Adjusts the target fusing temperature. Note that the thermistor is at the center of the hot roller.			
1105 1 Warm Up-Center		[140 to 180 / 160 / 1°C/step]		
1105 3	Standby-Center	[140 to 160 / 150 / 1°C/step]		
1105 5	Copying-Center	[140 to 180 / 160 / 1°C/step]		
1105 7	Low Level 2-Center	[0 to 80 / 60 / 1°C/step]		
1105 9	Thick-Center	[140 to 185 / 165 / 1°C/step]		

1106	Display Fusing	
1106 1	(Center) Displays the fusing temperature.	

	Fusing Soft Start DFU			
1107*	Adjusts the number of zero-cross cycles of the fusing lamp AC supply needed to bring the fusing lamp power to 100% while bringing the lamp up to the standby temperature or while copying. Increase this value if the machine is experiencing sudden power dropouts.			
1107 1	Warm Up Soft Start	[0 = 10 times / 1 = 20 times / 2 = 50 times]		
1107 2	Other Soft Start	[0 = 10 times / 1 = 20 times / 2 = 50 times / 3 = 1 time]		
1107 3	Soft Stop Setting	[0: No / 1: Yes]		

1108*	Set-Fusing Start	[0 = 1s / 1 = 1.5s / 2 = 2s]
1108 1	Specifies the interval for fusi	ng-temperature control.

1109	Nip Band Check	
1109 1	Conducts the nip band check ("Adjusting Nip Band" in the section "Replacement and Adjustment").	

1110*	Fan Control Timer	[30 to 60 / 30 / 1 s/step]
1110 1		e. The fan motor keeps its operating speed for the ng the speed or stopping. The fan control timer m suddenly stopping. This function protects the

1159*	Fusing Jam SC	[0 = No / 1 = Yes]
1159 1	set to "1" (default: 0), consec	utive jam detection at the fusing unit. If this SP is cutive fusing jam alarm occurs (SC559) when the ecutive paper jams at the fusing unit.

1902	Display-AC Freq.	
1902 1	Displays the fusing lamp power control frequency (as detected by the zero cross signal generator). The displayed value is 1/5 the actual frequency: 10 and lower = 50 Hz, 11 and higher = 60 Hz.	

1911*	By-pass Envelope	[0 = No / 1= Yes]
1911 1	The program dedicated to en program (SP1-911-001) and by-pass tray (System Bypass Tray).	nvelope printing runs when you enable this you select "Thick Paper" as the paper type of the Settings > Tray Paper Settings > Paper Type:

SP2-XXX (Drum)

2001*	CR Bias Adj	
	Printing	[-2100 to -1500 / -1650 / 1 V/step]
Adjusts the voltage applied to the charge roller for printing. The changes automatically as charge-roller voltage control works. is the base value for the charge-roller voltage control.		harge-roller voltage control works. The value here
	ID sensor pattern	[0 to 400 / 300 / 1 V/step]
2001 2	Adjusts the voltage applied to the charge roller for the ID sensor pattern (as part of charge-roller voltage correction). The charge-roller voltage is obtained by adding SP2-001-002 to the value of SP2-001-001.	

2101*	Erase Margin Adj	Adjusts the width of the erased area ("Adjusting Copy Image Area" in the section "Replacement and Adjustment").
2101 1	Leading Edge	[0.0 to 9.0 / 3.0 / 0.1 mm/step] Specification: 2 ± 1.5 mm
2101 2	Trailing Edge	[0.0 to 9.0 / 4.0 / 0.1 mm/step] Specification: 2 +2.5/–1.5 mm
	The rear trailing edge is this value plus 1.2 mm.	
2101 3	Left side	[0.0 to 9.0 / 2.0 / 0.1 mm/step] Specification: 2 ± 1.5 mm
	The rear left edge is this value plus 0.3 mm.	
2101 4	Right side	[0.0 to 9.0 / 2.0 / 0.1 mm/step] Specification: 2 +2.5/–1.5 mm
	The rear right edge is this value plus 0.3 mm.	

SM Appendix 5-5 D067/D068/D069/D072

2201*	Dv Bias Adj	
	Printing	[-1500 to -200 / -650 / 1 V/step]
2201 1	Adjusts the voltage applied to the development roller for printing. Image density becomes higher when you specify a smaller value (a greater absolute). Image density becomes lower when you specify a greater value smaller absolute value).	
	ID sensor pattern	[-2 = LL (220 V) / -1 = L (260 V) / 0 = N (300 V) / 1 = H (340 V) / 2 = HH (380 V)]
2201 2	Adjusts the voltage applied to the development roller for the ID sensor pattern. The voltage applied is obtained by adding SP2-201-002 to SP2-201-1. The setting affects ID sensor pattern density, which in turn affects the toner supply.	

2213*	Outputs After NE	
2213 1	[0 = 50 pages / 1 = 20 sheets] Sets the number of copy/print/fax pages that can be made after toner near-end has been detected. Reduce the number of pages if the user normally makes copies with a high image ratio.	

2214	Develpr Initialize
2214 1	Initializes the TD sensor toner supply target voltage and the TD sensor gain value. Execute this SP replacing the developer or the TD sensor.

2221	ID Error Analysis ("ID Sensor Error Analysis (SP2-221)")	
2221 1	Vsg	Displays the Vsg value.
2221 2	Vsp	Displays the Vsp value.
2221 3	PWM	Displays the PWM value.
2221 4	Vsdp	Displays the Vsdp value.
2221 5	Vt	Displays the Vt value.
2221 6	Vts	Displays the Vts value.

2301*	Tr Current Adj ("Image]	Fransfer Current").
	Normal paper	$[-2 = -4 \mu A / -1 = -2 \mu A / 0 = 0 \mu \mathbf{A} / 1 = 2 \mu A / 2$ = +4 \mu A]
2301 1	Adjusts the current applied to the transfer roller when feeding from a paper tray. Use a high setting if the user normally feeds relatively thick paper (within spec) from a paper tray	
	Thick/Special	$[-2 = -4 \mu A / -1 = -2 \mu A / 0 = 0 \mu \mathbf{A} / 1 = 2 \mu A / 2$ = +4 \(\mu A\)
2301 2	Adjusts the current applied to the transfer roller when feeding from the by-pass tray. Use a high setting (a) if the user normally feeds relatively thick paper from the by-pass tray, or (b) if waste toner is re-attracted from the drum (which can occur when using transparencies).	
2301 3	Duplex	$[-2 = -4 \mu A / -1 = -2 \mu / 0 = 0 \mu \mathbf{A} / 1 = 2 \mu A / 2 = +4 \mu A]$
	Adjusts the current applied to the transfer roller when carrying out a duplex job. Use this SP if there is poor image transfer on the rear side of duplex copies.	

	Cleaning	[–10 to 1 / –1 / 1 μA/step]
2301 4		to the transfer roller for roller cleaning. Increase on the roller after cleaning. (Remaining toner may the rear side.)

2802	Forced Develpr Churn
2802 1	Initializes the developer and checks the TD sensor output (Vt). The machine mixes the developer for 2 minutes while reading and displaying the Vt value. The machine does not initialize the TD sensor output. If the machine has not been used for a long period, prints may have a dirty background. In a case like this, use this SP to mix the developer. The message "Completed" is displayed when the program ends normally.

2906*	Tailing Crctn	
	Shift value [0.0 to 1.0 / 0.0 / 0.1 mm/step]	
2906 1	Shifts the image position at the intervals specified by SP2-906-002. When the copier is continuously printing vertical lines (such as in tables), the paper may not separate correctly. This SP can prevent this.	
2906 2	[1 to 10 / 1 / 1 page/step]	
2000 2	Changes the interval of the image position shift specified by SP2-906-001.	

2908	Forced Toner Supp	
2908 1	Supplies the toner to the development unit. The processing stops under either of the following conditions: The toner density in the development unit reaches the standard level. The processing has continued for two 2 minutes.	

2915*	Polygon Idling	[0 = None / 1 = 15 s / 2 = 25 s]
2915 1	Specifies the polygon mirror motor idlistants its operation when an original is cover or DF is opened. The motor stoffor the specified time. When you set "copier is in the standby status.	s set, a key is pressed, or the platen ops if no manual operation is performed

2921*	Toner Supply Mode
2921 1	[0 = Sensor 1 / 1 = Sensor 2 (DFU)] Selects the toner supply mode. Keep the default setting as long as the TD sensor is working.

2922*	Toner Supply Time	[0.1 to 5.0 / 0.6 / 0.1 s/step]
2922 1	specified time. To validate this se	ne toner supply motor remains on for the etting, select "0" in SP2-921-001. Specify a make many copies having high proportions

2926	6*	Standard Vt	[0.00 to 5.00 / 2.50 / 0.01 V/step] DFU
29	926 1	·	developer). The TD sensor output is TD sensor initial setting process. This SP is is "0", "1", or "2".

2927*	ID Sensor Control	[0 = No / 1 = Yes]
2927 1	Determines whether the ID sens density control. Keep the default	or signal is referenced or not for the toner value in usual operations.

2928	Toner End Clear
2928 1	Clears the following messages and counters without supplying the toner: Toner near end message Toner end message Toner near end counter Toner end counter Toner end counter Do not use this SP in usual operations. When the toner in the development unit is abnormally insufficient, the drum may attract the toner carrier to its surface. The toner carrier damages the drum surface

2929*	Vref Limits	Adjust the upper or lower Vref limit.
2929 1	Upper	[0.50 to 3.50 / 3.20 / 0.01V/step] DFU
2929 2	Lower	[0.50 to 3.50 / 0.70 / 0.01V/step] DFU

2994*	ID Detect Temp	[30 to 90 / 30 / 1 °C/step]
2994 1	Adjusts the temperature threshold. The when the fusing temperature is at the s copier is recovering or starting up.	•

2996*	T Roller Cleaning	[0 = No / 1 = Yes]
2996 1	backside of the paper becomes uncle	copy when you select "1". If you select

2998*	Main Mag- print	[-0.5 to +0.5 / 0.0 / 0.1%/step]
2998 1	Adjusts the magnification ("Adjusting Copy Image Area" in the section "Replacement and Adjustment"). The specification is 100 ± 1.0%.	

SP4-XXX (Scanner)

4008*	SubScan Mag (Scanner)	[-0.9 to +0.9 / 0.0 / 0.1%/step]
4008 1	Adjusts the sub-scan magnification ("Adjusting Copy Image Area" in the section "Replacement and Adjustment").	

4009*	Main Scan Mag (Scanner)	[-0.9 to +0.9 / 0.0 / 0.1%/step]
4009 1	Adjusts the main-scan magnification (section "Replacement and Adjustment").	

4010*	LE Scan Regist	[-5.0 to +5.0 / 0.0 / 0.1 mm/step]
4010 1	Adjusts the leading edge registration (section "Replacement and Adjustment"	

4011*	S-to-S Scanner Registration	[-2.0 to +2.0 / 0.0 / 0.1 mm/step]
4011 1	Adjusts the side-to-side registration for scanning in platen mode ("Adjusting Copy Image Area" in the section "Replacement and Adjustment").	

4012*	Scan Erase Margin	[0 to 9.0 / 1.0 / 0.1 mm/step]
4012 1	Leading Edge	
4012 2	Trailing Edge	Adjusts the scanning margin. Generally, the scanning margin should be as little as possible. To adjust the image area, use SP2-101.
4012 3	Left Side	
4012 4	Right Side	

4013	Scanner Free Run
4013 1	Conducts the scanner free run with the exposure lamp on.

SM Appendix 5-11 D067/D068/D069/D072

4015*	White Plate Scan	
	Start position	[-3.0 to +6.0 / 0.0 / 0.1 mm/step]
4015 1	Adjusts the scanning start position on the white plate. The base value is mm from the scanner home position. This SP specifies the offset from the base value.	
	Scanning Length	[-3.0 to +6.0 / 0.0 / 0.1 mm/step]
4015 2	Adjusts the distance of the white plate scan. The scan begins from the position (SP4-015-001) and ends at the specified distance. The base 2.0 mm. This SP decides the offset from this base value. Specify 0 (z larger value.	

4428	Scan Auto Adj
4428 ^	Conducts the automatic scanner adjustment. Use this SP after replacing the white plate ("Scanning" in the section "Replacement and Adjustment").

4606	SBU Offset-Target	
4607 1	EVEN	
4607 2	ODD	[0 to 63 / 10 / 1 /step]
4607 3	RED	Adjusts the target black level for each signal.
4607 4	GREEN	These are used for offset adjustment in the SBU.
4607 5	BLUE	

4607	SBU Gain-Target	
4607 1	EVEN	
4607 2	ODD	[0 to 255 / 180 / 1 /step]
4607 3	RED	Adjusts the target white level for each signal.
4607 4	GREEN	These are used for gain adjustment in the SBU.
4607 5	BLUE	

4623	SBU Offset-Result	
4623 1	EVEN	
4623 2	ODD	[0 to 255 / 0 / 1 /step]
4623 3	RED	Displays the result value of the offset adjustment
4623 4	GREEN	in the SBU.
4623 5	BLUE	

4628	SBU Gain-Result	
4628 1	EVEN	
4628 2	ODD	[0 to 255 / 0 / 1 /step]
4628 3	RED	Displays the result value of the gain adjustment
4628 4	GREEN	in the SBU.
4628 5	BLUE	

4640	SBU Offset-Loop	
4640 1	EVEN	
4640 2	ODD	[0 to 10 / 0 / 1 /step]
4640 3	RED	Displays the number of the offset adjustment in
4640 4	GREEN	the SBU.
4640 5	BLUE	

4641	SBU Gain-Loop	
4641 1	EVEN	
4641 2	ODD	[0 to 10 / 0 / 1 /step]
4641 3	RED	Displays the number of the gain adjustment in
4641 4	GREEN	the SBU.
4641 5	BLUE	

4642	SBU Offsetpre-Loop	
4642 1	EVEN	
4642 2	ODD	[0 to 3 / 0 / 1 /step]
4642 3	RED	Displays the number of the pre-offset adjustment
4642 4	GREEN	in the SBU.
4642 5	BLUE	

4646	SBU Adj Error	
4646 1	Offsetpre-Mono	
4646 2	Offsetpre-Color	
4646 3	Offset-Mono	[0 = Success / 1 = Failure]
4646 4	Offset-Color	Displays the result of SBU adjustment.
4646 5	Gain-Mono	
4646 6	Gain-Color	

4654*	SBU Offset-Adjust	
4654 1	EVEN	
4654 2	ODD	[0 to 255 / - / 1 /step]
4654 3	RED	Displays the offset value of the offset adjustment
4654 4	GREEN	in the SBU.
4654 5	BLUE	

4658*	SBU Gain-Adjust	
4658 1	EVEN	
4658 2	ODD	[0 to 511 / - / 1 /step]
4658 3	RED	Displays the gain value of the gain adjustment i
4658 4	GREEN	the SBU.
4658 5	BLUE	

4685*	Gray Balance-Book	
4685 1	RED	[128 to 383 / 256 / 1 /step]
4685 2	GREEN	Adjusts the coefficient of the gray balance
4685 3	BLUE	adjustment for the book scanning.

4686*	Gray Balance-DF	
4686 1	RED	[128 to 383 / 256 / 1 /step]
4686 2	GREEN	Adjusts the coefficient of the gray balance
4686 3	BLUE	adjustment for the DF scanning.

4687*	White Balance	
4687 1	Adjust	[222 to 281 / 256 / 1 /step] Adjust the correction value for the white plate adjustment.
4687 2	Result	Displays the current value of the white plate adjustment. If SP4-428 has not been done, this value is "0".

4690	White Peek Init	
4658 1	EVEN	
4658 2	ODD	[0 to 255 / - / 1 /step]
4658 3	RED	Displays the white offset value of the pre-offset
4658 4	GREEN	adjustment in the SBU.
4658 5	BLUE	

4693	Black Ave Init	
4658 1	EVEN	
4658 2	ODD	[0 to 255 / - / 1 /step]
4658 3	RED	Displays the black offset value of the pre-offset adjustment in the SBU.
4658 4	GREEN	
4658 5	BLUE	
4902*	Exposure Lamp ON	[0 : OFF / 1: ON]
4902 1	Turns the exposure lamp on or off. To turn on the exposure lamp, specify "1 to turn it off specify "0".	

4903*	ADS Level	[0 to 255 / 252 / 1/step]
4903 1	Adjusts the ADS level.	

4904*	ADS Lower Limit	[0 to 255 / 80 / 1/step]
4904 1	Adjusts the ADS lower limit.	

4905*	ADS Area Select	[0 = All / 1 = One]
4905 1	Checks the whole area (0 = ADS level. The specific area = ARDF: ±37.5 mm from = Platen Cover: 15 to 90	the center

4921*	Image Adj Selec	
	Сору	[0 to 10 / 0 / 1]
001	Selects which mode the settings from SP4-922 to SP4-932 are used for. 0 = None, 1 = Text 1, 2 = Text 2, 3 = Photo 1, 4 = Photo 2, 5 = Photo 3, 6 = Special 1, 7 = Special 2, 8 = Special 3, 9 = Special 4, 10 = Special 5	
	Fax	[0 to 5 / 0 / 1]
002	Selects which mode the settings from SP4-922 to SP4-932 are used for. 0 = None, 1 = Text 1, 2 = Text 2, 3 = Photo 1, 4 = Photo 2, 5 = Special 1	
	Scanner (Mono)	[0 to 4 / 0 / 1]
003	Selects which mode the settings from SP4-922 to SP4-932 are used for. 0 = None, 1 = Text 1, 2 = Text 2, 3= Photo 1, 4 = Photo 2	
	Scanner (Color)	[0 to 2 / 0 / 1]
004	Selects which mode the setting of SP4-935 is used for. 0 = None, 1 = Color Text, 2 = Color Photo	
	Scanner (Gray Scale)	[0 or 1 / 0 / -]
005	Selects which mode the setting of SP4-936 is used for. 0 = None, 1 = Gray Scale	

	Scanner Gamma	
Selects "text" or "photo" as the priority output mode. all image processing modes of SP4-921.		
001	Сору	[0 =System default/ 1=Text/ 2=Photo]
002	Fax	
003	Scanner	

	Notch Selection	
4923*	 Selects the value of the center ID adjustment notch for the ID adjustment LEDs. Normally the center notch is 3 (range 1-5). If -1 is selected, each notch shifts down (becomes lighter). If +1 is selected, each notch shifts up (becomes darker). This setting is applied to all image processing modes of SP4-921. 	
001	Сору	
002	Fax	[–1 = Light / 0 = Normal / +1 = Dark]
003	Scanner	

	Texture Removal	
Adjusts the texture removal level that is used with error diffusion. 0: The default value for each mode is used. Text 1, Photo 2, Special 2, and Special 4926* have a default of 3 and Photo 1-3 have a default of 1. 1: No removal applied. 2 to 5: Removal applied at the level specified here. The higher the setting (level), the less clear the image will become (more texture removal). The setting is only applied to the originals in SP4-921.		e is used. Text 1, Photo 2, Special 2, and Special 5 to 1-3 have a default of 1. the level specified here. The higher the setting age will become (more texture removal). This
001	Сору	
002	002 Fax [0 to 6 / 0 / 1/step]	[0 to 6 / 0 / 1/step]
003	Scanner	

Line Width		
4927*	Adjusts the line width correction algorithm. Positive settings produce thicker lines; negative settings produce thinner lines. This setting is only applied to the originals in SP4-921.	
001	Сору	
002	Fax	[-2 to 2 / 0 / 1/step]
003	Scanner	

	Independent Dot Erase	
4928*	Selects the dot erase level. Higher settings provide greater erasure. This setting is only applied to the originals in SP4-921.	
001	Сору	
002	Fax	[-2 to 2 / 0 / 1/step]
003	Scanner	

	Positive/Negative	[0 = No , 1 = Yes]
4929*	Inverts white and black. This setting is only applied to the originals in SP4-921.	
001	Сору	
002	Fax	

4930*	Sharpness-Edge	[-2 to 2 / 0 / 1/step]
Adjust the clarity. This setting is only applied to the originals in SP4-9		g is only applied to the originals in SP4-921.
001	Сору	
002	Fax	
003	Scanner	

4931*	Sharpness-Solid	[-2 to 2 / 0 / 1/step]
Adjust the clarity. This setting is only applied to the originals in SP4		g is only applied to the originals in SP4-921.
001	Сору	
002	Fax	
003	Scanner	

4932*	Sharpness-Low ID	[-2 to 2 / 0 / 1/step]
	Adjust the clarity. This setting is only applied to the originals in SP4-921.	
001	Сору	
002	Fax	
003	Scanner	

4935*	Color Image Adjust	
	Main Scan MTF Level	[0 to 3 / 0 / 1/step]
001	Adjust the MTF level for the main scan. This setting is only activated for the specified mode with SP4-921-004. 0: None, 1: Weak, 2: Middle, 3: Strong	
	Main Scan MTF Strength	[0 to 5 / 0 / 1/step]
002	Adjust the MTF strength for the main scan. This setting is only activated for the specified mode with SP4-921-004. 0: 1, 1: 1/32, 2: 1/16, 3: 1/8, 4: 1/4, 5: 1/2	
	Sub Scan MTF Level	[0 or 1 / 0 / 1/step]
003	Turns on or off the MTF for the sub scan. This setting is only activated for the specified mode with SP4-921-004. 0: No, 1: Yes	
	Sub Scan MTF Strength	[0 to 5 / 0 / 1/step]
004	Adjust the MTF strength for the sub scan. This setting is only activated for the specified mode with SP4-921-004. 0: 1, 1: 1/32, 2: 1/16, 3: 1/8, 4: 1/4, 5: 1/2	

	Smooth Level	[0 to 2 / 0 / 1/step]
005	Adjust the smooth level. This setting is only activated for the specified mode with SP4-921-004. 0: None, 1: Weak, 2: Strong	
	Brightness	[0 to 255 / 128 / 1/step]
006	Adjust the brightness level. This setting is only activated for the specified mode with SP4-921-004.	
	Contrast	[0 to 255 / 128 / 1/step]
007	Adjust the contrast level. This setting is only activated for the specified mode with SP4-921-004.	

4936*	Gray Scale Image Adjust	
	Main Scan MTF Level	[0 to 15 / 0 / 1/step]
Adjust the MTF level for the main scan. This setting is only as specified mode with SP4-921-004. 0: None, 1: Level 1 to 15: Level 15		04.
	Main Scan MTF Strength	[0 to 5 / 0 / 1/step]
Adjust the MTF strength for the main scan. This setting is only at the specified mode with SP4-921-004. 0: 1, 1: 1/32, 2: 1/16, 3: 1/8, 4: 1/4, 5: 1/2		21-004.
	Sub Scan MTF Level	[0 to 13 / 0 / 1/step]
003	Adjust the MTF level for the sub scan. This setting is only activated for the specified mode with SP4-921-004. 0: No, 1: Level 1 to 13: Level 13	

	Sub Scan MTF Strength	[0 to 5 / 0 / 1/step]
004	Adjust the MTF strength for the sub scan. This setting is only activated for specified mode with SP4-921-004. 0: 1, 1: 1/32, 2: 1/16, 3: 1/8, 4: 1/4, 5: 1/2	
	Smooth Level	[0 to 7 / 0 / 1/step]
005	Adjust the smooth level. This setting is only activated for the specified mode with SP4-921-004. 0: None, 1: Level 1 to 7: Level 7	
	Brightness	[0 to 255 / 128 / 1/step]
006	Adjust the brightness level. This setting is only activated for the specified mode with SP4-921-004.	
007	Contrast	0 to 255 / 128 / 1/step]
	Adjust the contrast level. This setting is only activated for the specified mode with SP4-921-004.	

4941*	White Line Erase [0 to 2 / 1	/ 1/step]
4941 1	instead·	

4942*	Black Line Erase	[0 to 3 / 2 / 1/step]
4942 1	Selects the black line erase level. This setting is effective only when originals are scanned by the DF. [0 = No / 1 = Very weak / 2 = Weak / 3 = Strong] This setting is applied regardless of what mode has been selected in SP4-921.	
4943*	WhitePapDetect BiLv	
4943 1	Gray Scale	[0 to 255 / 64 / 1/step]
4943 1	Color2	[0 to 255 / 128 / 1/step]
4943 1	Color3	[0 to 255 / 128 / 1/step]

SP5-XXX (Mode)

5001	All Indicators On
5001 1	Turns on all LEDs. The LCDs turn on and off every 3 seconds. Press the reset key to end this program.

5024*	mm/inch Selection
001	Selects whether mm or inches are used in the display. Note After selecting the number, you must turn the main power switch off and on. Europe/Asia model: [0: mm / 1: inch] American model: [0: mm / 1: inch]

5045*	According Counter		
5045 1	Counter Method	Displays the number of the installed counter. [0 to 2 / 0 / 1 /step] 0: 1 counter (Total) 1: 2 counters (Total and Prints) 2: 2 counters GPC	

5055	Display IP address		
001	Display IP address	CTL	Displays or does not display the IP address on the LCD. [0 or 1 / 0 / -] 0: No (Not display), 1: Yes (Display)

5056	Coverage Counter		
001	Coverage Counter	CTL	Displays or does not display the coverage counter on the LCD. [0 or 1 / 0 / -] 0: Not display, 1: Display

5062	Part Replacement		
001	PCU	CTL	Displays or does not display the PCU yield on the LCD. [0 or 1 / 0 / -] 0: Not display, 1: Display

5066	PM Parts Display		
001	PM Parts Display	CTL	Displays or does not display the PM part button on the LCD. [0 or 1 / 0 / -] 0: Not display, 1: Display

5067	Part Replacement Ope		
001	PCU	CTL	Selects the service maintenance or user maintenance for PCU. [0 or 1 / 0 / -] 0: Service, 1: User

5113	Optional Counter Type		
001	Opt Cnt Type 1	CTL	This program specifies the counter type. 0: None 1: Key card (RK 3, 4) 2: Key card (down) 3 to 10: (Japan only) 11: Exp. Key card (Add) 12: Exp. Key card (Deduct)
002	Opt Cnt Type 2	CTL	This program specifies the external counter type. 0: None 1: Expansion Device type 1 2: Expansion Device type 2 3: Expansion Device type 3

5114	Optional Counter I/F	CTL	[0: Not installed/ 1: Installed (scanning accounting)]
001	MF Key Card Ext. Japan	use	

5118	Disable Copying	CTL	[0 : Not disabled/ 1: Disabled]
001	This program disables copyi	ng.	

5120*	Clr For Cut Remove [0=Ye	es / 1=Standby only / 2=No]
5120 1	removed. O: Y = Yes: The settings are 1: StdBy = Standby only: The removed at the end of a job 2: N = No: The settings are	the copy job settings when the key counter is e cleared when the counter is removed. The settings are cleared when the counter is co. In not cleared under either condition. Settings are always preserved regardless of

5121*	Counter Up Timing [0 = Feed In / 1 = Exit]	
Selects the count-up timing.		
5121 1	0 = Feed: At each paper feed 1= Exit: At each paper exit	

		Fax Prnt Cnt Off			
516	Enables or disables the automatic print out without an accounting device. SP is used when the receiving fax is accounted by an external accounting device.				
	001	Fax Prnt Cnt Off	CTL	[0 or 1 / 0 / –] 0: Automatic printing 1: No automatic printing	

	CE Login		
If you change the this SP before you			ches, you must 'log in' to service mode with inter SP mode.
001	CE Login	CTL	[0 or 1 / 0 / -] 0: Disabled 1: Enabled

5188	Copy NV Version		
001	Copy NV Version	CTL	Displays the NVRAM version in the controller board.

	Set Time			
5302	`	,	time setting for the local time zone. enter 540 (9 hours x 60 min.)	
002	Time Difference	CTL #	[-1440 to 1440 / Area / 1 min./step]	

5307	Summer Time					
001	ON/OFF	-	[0 or 1 / NA , EU , ASIA / 1 /step] 0: Disabled 1: Enabled NA and EUR: 1, ASIA: 0			
331	Enables or disables the summer time mode. Note Make sure that both SP5-307-3 and -4 are correctly set. Otherwise, this SP is not activated even if this SP is set to "1".					
	Start	-	-			
003	Specifies the start setting for the summer time mode. There are 8 digits in this SP. For months 1 to 9, the "0" cannot be input in the first digit, so the eight-digit setting for -2 or -3 becomes a seven-digit setting. 1st and 2nd digits: The month. [1 to 12] 3rd digit: The week of the month. [1 to 5] 4th digit: The day of the week. [0 to 6 = Sunday to Saturday] 5th and 6th digits: The hour. [00 to 23] 7th digit: The length of the advanced time. [0 to 9 / 1 hour /step] 8th digit: The length of the advanced time. [0 to 5 / 10 minutes /step] For example: 3500010 (EU default) The timer is advanced by 1 hour at am 0:00 on the 5th Sunday in March The digits are counted from the left.					
	Make sure that SP5-307-1 is set to "1".					

SM Appendix 5-31 D067/D068/D069/D072

	End	1	-
004	Specifies the end setting for There are 8 digits in this Sill 1st and 2nd digits: The moderate 3rd digit: The week of the result of the digit: The day of the week 5th and 6th digits: The hour The 7th and 8th digits must be a The digits are counted Make sure that SP5-30	P. Inth. [1 the month. Interest in [0 the set Interest in the set Interest in [1] Interest in	to 12] [0 to 5] [0 to 5] [0 6 = Sunday to Saturday] [0 23] [1 to "00". [1 to le left.

	Access Control				
5401	When installing the SDK application, SAS (VAS) adjusts the following settings. DFU				
103	DocAcl	CTL			
104	Authentication Time	CTL	[0 to 255 / 0 / 1 /step]		
162	Extend Certification	CTL	Selects the log out type for the extend authentication device. Bit 0: Log-out without an IC card. 0: Not allowed (default) 1: Allowed		
200	SDK1 Unique ID	CTL			
201	SDK1 Certification Method	CTL	"SDK" is the "software		
210	SDK2 Unique ID	CTL	development kit". This data can be converted from SAS (VAS) when		
211	SDK2 Certification Method	CTL	installed or uninstalled. (DFU)		
220	SDK3 Unique ID	CTL			

221	SDK3 Certification Method	CTL	
230	SDK Cert	CTL	
240	Detail Option	CTL	Enables or disables the log-out confirmation option. Bit0: Log-out confirmation option 0: Enable (default), 1: Disable Selects the automatic log-out time. Bit1 and 2: Automatic log-out timer reduction 00: 60 seconds (default), 01:10 seconds, 10: 20seconds, 11: 30 seconds

5404 User Code Clear	
001	Clears the counts for the user codes assigned by the key operator to restrict the use of the machine. Press [Execute] to clear.

5411	LDAP Certification
	Easy Certification
004	Determines whether easy LDAP certification is done. [0 to 1/1/1] 1: On 0: Off
	Password Null Not Permit
005	This SP is referenced only when SP5411-4 is set to "1" (On). [0 to 1/ 0 /1] 0: Password NULL not permitted. 1: Password NULL permitted.

5413 Lockout Setting			
	Lockout On/Off		
001	Switches on/off the lock on the local address book account. [0 to 1/ 0 /1] 0: Off 1: On		
Lockout Threshold Our Sets a limit on the frequency of lockouts for account lockouts. [1 to 10/5/1]			
	Cancel On/Off		
003	Determines whether the system waits the prescribed time for input of a correct user ID and password after an account lockout has occurred. [0 to 1/ 0 /1] 0: Off (no wait time, lockout not cancelled) 1: On (system waits, cancels lockout if correct user ID and password are entered.		
	Cancel Time		
004	Determines the length of time that the system waits for correct input of the user ID and password after a lockout has occurred. This setting is used only if SP5413-3 is set to "1" (on). [1 to 999/60/1 min.]		

5414	Access Mitigation			
	Mitigation On/Off			
001	Switches on/off masking of continuously used IDs and passwords that are identical. [0 to 1/ 0 /1] 0: Off 1: On			
	Mitigation Time			
002	Sets the length of time for excluding continuous access for identical user IDs and passwords. [0 to 60/15/1 min.]			

5415	Password Attack		
	Permissible Number		
001	Sets the number of attempts to attack the system with random passwords to gain illegal access to the system. [0 to 100/30/1 attempt]		
	Detect Time		
002	Sets the time limit to stop a password attack once such an attack has been detected. [1 to 10/5/1 sec.]		

SM Appendix 5-35 D067/D068/D069/D072

5416	Access Info			
	User Max Num			
001	Limits the number of users used by the access exclusion and password attack detection functions. [50 to 200/ 200 /1 users]			
	Password Max Num			
002	Limits the number of passwords used by the access exclusion and password attack detection functions. [50 to 200/ 200 /1 passwords]			
	Monitor Interval			
003	Sets the processing time interval for referencing user ID and password information. [1 to 10/3/1 sec.]			

5417	Access Attack			
	Permissible Num			
Oo1 Sets a limit on access attempts when an excessive number of attempth detected for MFP features. [0 to 500/100/1]				
	Attack Detect Time			
002	Sets the length of time for monitoring the frequency of access to MFP features. [10 to 30/10/1 sec.]			

	Cert Waite			
003	Sets the wait time to slow down the speed of certification when an excessive number of access attempts have been detected. [0 to 9/3/1 sec.]			
	Attack Max Num			
004	Sets a limit on the number of requests received for certification in order to slow down the certification speed when an excessive number of access attempts have been detected. [50 to 200/200/1 attempt]			

5420	User Auth			
	These settings should be done with the System Administrator. Note: These functions are enabled only after the user access feature has been enabled.			
	Сору			
001	Determines whether certification is required before a user can use the copy applications. [0 to 1/ 0 /1] 0: On 1: Off			
	DS			
011	Determines whether certification is required before a user can use the document server. [0 to 1/ 0 /1] 0: On 1: Off			

SM Appendix 5-37 D067/D068/D069/D072

	Fax			
021	Determines whether certification is required before a user can use the fax application. [0 to 1/ 0 /1] 0: On 1: Off			
	Scanner			
031	ether certification is required before a user can use the scan			
	Printer			
041	Determines whether certification is required before a user can use the printer applications. [0 to 1/ 0 /1] 0: On 1: Off			
051	SDK1	[0 or 1/ 0 / 1] 0: ON. 1: OFF		
061	SDK2	Determines whether certification is required before a user can		
071	SDK3	use the SDK application.		

5431	External Auth User CTL -			
010	Tag			
011	Entry			
012	Group			
020	Mail			
030	Fax			
031	Fax Sub Folder Protect Code Smtp Auth			
032				
033				
034				
035	Lsap Auth			
036	Smb Ftp Fldr Auth			
037	Acut Acl			
038				
040				

5481	Authentication Error Code		
	These SP codes determine how the authentication failures are displayed.		
	System Log Disp		
001	Determines whether an error code appears in the system log after a user authentication failure occurs. [0 to 1/0/1] 0: Off 1: On		
002	Panel Disp Determines whether an error code appears on the operation panel after a user authentication failure occurs. [0 to 1/1/1] 1: On 0: Off		

	MF Keycard Japan Only
	Job Permit Setting
5490	Sets up operation of the machine with a keycard. [0 to 1/0/1] 0: Disabled. Cancels operation if no code is input. 1: Enabled. Allows operation if another code is input and decrements the counter once for use of the entered code.

5501	PM Alarm Interval	CTL	-
001	Printout	[0 to 9999 / 0 / 1 /step] 0: Alarm off 1 to 9999: Alarm goes off when the PM counter reaches the specified value (1 to 9999) x 1000.	
002	ADF	[0 or 1 / 1 / −] 0: No alarm sounds 1: Alarm sounds after the number of originals passing through the A(R)DF ≥ 10,000	

5	504	Jam Alarm	CTL	-
	001	not included). [0 to 3 / 3 / 1 /step]		specified jam level (document misfeeds are), 2: Medium (3K jams), 3: High (6K jams)

5505*	Error Alarm
001	Sets the error alarm level. The error alarm counter counts "1" when any SC is detected. However, the error alarm counter decreases by "1" when any SC is not detected during specified sheets of copies (for example, default 1500 sheets). The error alarm occurs when the SC error alarm counter reaches "5". [0 to 255 / 10 / 100 copies per step]

SM Appendix 5-41 D067/D068/D069/D072

5507	Supply Alarm	CTL	-
001	Paper Size	0: Off , 1	: On,
003	Toner	0: Off , 1	: On,
005	Drum	0: Off , 1	: On,
080	Toner Call Timing		r is replaced (default) near end or end
128	Interval :Others		
132	Interval :A3	[250 to 10000 / 1000 / 1 /step]	
133	Interval :A4		
134	Interval :A5		
141	Interval :B4		10000 / 1000 / 1 /step]
142	Interval :B5		100007 10007 170top1
160	Interval :DLT		
164	Interval :LG		
166	Interval :LT		
172	Interval :HLT		

SM Appendix

5508*	Auto Call Setting	CTL	-		
001*	Jam Remains	0: Disable, 1: Enable			
001	Enables/disables initiating a	call for a	n unattended paper jam.		
002*	Frequent Jams	0: Disab	le, 1 : Enable		
002	Enables/disables initiating a	Enables/disables initiating a call for consecutive paper jams.			
003*	Door Open	0: Disab	le, 1 : Enable		
003	Enables/disables initiating a call when the front door remains open.				
	Jam Remains: Time	[03 to 3	0 / 10 / 1 minute /step]		
011*	Sets the time a jam must remain before it becomes an "unattended paper jam". This setting is enabled only when SP5508 004 is set to 1.				
	Freq Jam: # of Time	[02 to 1	0 / 5 / 1 /step]		
012*	O12* Sets the number of consecutive paper jams required to initiate a call. The setting is enabled only when SP5508 004 is set to 1.		•		
	Door Open: Time	[03 to 3	0 / 10 / 1 minute/step]		
013*	Sets the length of time the d call. This setting is enabled only		ins open before the machine initiates a 5508 004 is set to 1.		

SM Appendix 5-43 D067/D068/D069/D072

	SC/Alarm Setting	CTL	-
5515	With @Remote in use, these SP codes can be set to issue an SC call when SC error occurs. If this SP is switched off, the SC call is not issued when an SC error occurs.		
001	SC Call		
002	Service Parts Near End		
003	Service Parts End		
004	User Call	[0 or 1 / 1 / -] 0: Off, 1: On	
006	Communication Test		
007	Machine Information		
008	Alarm Notice		
010	Supply Automatic Order	[0 or 1 /	0 / -] 0: Off,1: On
011	Supply Management Report	[0 01 17 0 7 -] 0. 011, 1. 011	• / 10. Oii, i. Oii
012	Jam/Door Open Call	[0 or 1 /	1 / -] 0: Off,1: On

5801	[Memory Clear] (Refer to IMPORTANT NOTE is Sect 6.2) Before executing any of these SP codes, print an SMC Report.			
	All Clear			
001	Initializes items SP5801 Turn the main power sw		14 below. Id on after executing this SP.	
003	scs	-	-	
	Clears the system settin	gs.		
004	ІМН	-	-	
004	Clears IMH data. DFU	Clears IMH data. DFU		
005	MCS	-	-	
000	Clears MCS data. DFU			
006	Copier	-	-	
000	Clears the copy application settings.			
007	Fax	-	-	
001	Clears the fax application	n settings	s.	
008	Printer	-	-	
000	Clears the printer application settings.			
009	Scanner	-	-	
003	Clears the scanner application settings.			
	GWWS	-	-	
010	Delete the netfile application initializes the job login IE		agement files and thumbnails, and	

SM Appendix 5-45 D067/D068/D069/D072

	NCS	-	-		
011	Initializes the system default and interface settings (IP address also), SmartNetMonitor for Admin, WebImageMonitor settings, and the TELNET settings. • Note • The name of Apple talk is not cleared only if this SP is executed. Turns off and on after executing this SP.				
	R-FAX	-	-		
012	Initializes the job login II storage file numbers.	Initializes the job login ID, SmartNetMonitor for Admin, job history, and local storage file numbers.			
014	Clear DCS Setting	-	-		
	Initializes the DCS (Deli	very Cont	rol Service) settings.		
015	CIr UCS Setting	-	-		
	Initializes the UCS (User Information Control Service) settings.				
016	MIRS Setting	-	-		
	Initializes the MIRS (Machine Information Report Service) settings.				
017	ccs	-	-		
	Initializes the CCS (Certification and Charge-control Service) settings.				
018	SRM Memory Clr	-	-		
	Initializes the SRM (System Resource Manager) settings.				
019	LCS	-	-		
	Initializes the LCS (Log Count Service) settings.				
020	Web Apli	-	-		
	Initializes Web application settings.				

5802	Machine Free Run	[0 or 1 / 0 / -] 0: No, 1: Yes
5802 1	press "O" key. Press "O	run (including the scanner unit). Set "1" and then)" key again to start "Free Run". When this SP is set rates normally even "O" key is pressed.

5803	Input Check
	"Input Check" in this chapter.

5804	Output Check
	"Output Check" in this chapter.

5807*	Area Selection
5807 1	Selects the display language. 2 North America, 3 Europe, 5 Asia, 6 China SP5-807-001 is not cleared by SP5-801-002. NOTE: SC982 is displayed if you specify a language that is inconsistent with your local model.

5811*	Machine No. Setting	
001	Code Set	
	"Machine No. Setting" in this section.	

5812	Service TEL			
	Telephone	CTL	-	
001	Sets the telephone number for a service representative. This number is printed on the Counter List, which can be printed with the user's "Counter" menu. This can be up to 20 characters (both numbers and alphabetic characters can be input).			
	Facsimile	CTL	-	
002	Sets the fax or telephone number for a service representative. This number is printed on the Counter List. This can be up to 20 characters (both numbers and alphabetic characters can be input).			
	Supply	CTL	-	
003	Use this to input the telephone number of your supplier for consumables. Enter the number and press"StringIn" key. Press the "Clear modes" key to delete the telephone number.			
004	Sales	CTL	-	
	Use this to input the telephone number of your sales agency. Enter the number and press #. Press the "Clear modes" key to delete the telephone number.			

5816	[NRS Function]	CTL	-
001	I/F Setting	[0 to 2 / 0: Remo	the remote service setting. 2 / 1 /step] te service off remote service on mote service on
002	CE Call	service. [0 or 1 /	s the CE Call at the start or end of the 0 / 1 /step] of the service, 1: End of the service This SP is activated only when SP 5816-001 is set to "2".
003	Function Flag	[0 or 1 /	or disables the remote service function. 0 / 1 /step] led, 1: Enabled
007	SSL Disable	when ca [0 or 1 / 0: Uses	does not use the RCG certification by SSL alling the RCG. 0 / 1 /step] the RCG certification no use the RCG certification
008	RCG Connect T/O	the RCC	s the connect timeout interval when calling 6. / 10 / 1 second/step]
009	RCG Write Timeout	RCG.	s the write timeout interval when calling the 0 / 60 / 1 second/step]

010	RCG Read Timeout	Specifies the read timeout interval when calling the RCG. [1 to 100 / 60 / 1 second/step]
011	Port 80	Enables/disables access via port 80 to the SOAP method. [0 or 1 / 0 / –] 0: Disabled, 1: Enabled
013	RFU Timing	Selects the timing for the remote firmware updating. [0 or 1 / 0 / –] 0: Any status of a target machine 1: Sleep or panel off mode only
	Install Status	
022	This SP displays the RC 0: RCG device not regist 1: RCG device registered 2: Device registered	
	Connect Mode (N/M)	
023	This SP displays and sel 0: Internet connection 1: Dial-up connection	lects the embedded RCG connection method.
061	NotiTime ExpTime DFU	
	Proximity of the expiration of the certification.	
	HTTP Proxy Use	
062	This SP setting determin	es if the proxy server is used when the machine service center.

	HTTP Proxy Host
063	This SP sets the address of the proxy server used for communication between embedded RCG-N and the gateway. Use this SP to set up or display the customer proxy server address. The address is necessary to set up embedded RCG-N. Note The address display is limited to 127 characters. Characters beyond the 127th character are ignored. This address is customer information and is not printed in the SMC report.
	HTTP Proxy Port
064	This SP sets the port number of the proxy server used for communication between embedded RCG N and the gateway. This setting is necessary to set up embedded RCG-N. Note This port number is customer information and is not printed in the
	SMC report.
	HTTP Proxy Aut Usr
065	This SP sets the HTTP proxy authentication user name. The length of the name is limited to 31 characters. Any character beyond the 31st character is ignored. This name is customer information and is not printed in the SMC report.
	HTTP Proxy Aut Pass
066	 This SP sets the HTTP proxy authentication password. Note The length of the password is limited to 31 characters. Any character beyond the 31st character is ignored. This name is customer information and is not printed in the SMC report.

SM Appendix 5-51 D067/D068/D069/D072

	Cer Updt Cond		
	Displays the status of the certification update.		
	0	The certification used by embedded RCG is set correctly.	
	1	The certification request (setAuthKey) for update has been received from the GW URL and certification is presently being updated.	
	2	The certification update is completed and the GW URL is being notified of the successful update.	
	3	The certification update failed, and the GW URL is being notified of the failed update.	
	4	The period of the certification has expired and a new request for an update is being sent to the GW URL.	
067	11	A rescue update for certification has been issued and a rescue certification setting is in progress for the rescue GW connection.	
	12	The rescue certification setting is completed and the GW URL is being notified of the certification update request.	
	13	The notification of the request for certification update has been completed successfully, and the system is waiting for the certification update request from the rescue GW URL	
	14	The notification of the certification request has been received from the rescue GW controller, and the certification is being stored.	
	15	The certification has been stored, and the GW URL is being notified of the successful completion of this event.	
	16	The storing of the certification has failed, and the GW URL is being notified of the failure of this event.	

067	17	The certification update request has been received from the GW URL, the GW URL was notified of the results of the update after it was completed, but a certification error has been received, and the rescue certification is being recorded.
	18	The rescue certification of No. 17 has been recorded, and the GW URL is being notified of the failure of the certification update.
	Cer /	Abnml Cause
	-	lays a number code that describes the reason for the request for update e certification.
	0	Normal. There is no request for certification update in progress.
	1	Request for certification update in progress. The current certification has expired.
068	2	An SSL error notification has been issued (after the certification has expired).
	3	Notification of shift from a common authentication to an individual certification.
	4	Notification of a common certification without ID2.
	5	Notification that no certification was issued.
	6	Notification that GW URL does not exist.
069	Cer:	Updtt ReqID
	The	ID of the request for certification.
083	Firm	Updating
	Disp	lays the status of the firmware update.

085	Firm Up Usr Conf
	This SP setting determines if the operator can confirm the previous version of the firmware before the firmware update execution. If the option to confirm the previous version is selected, a notification is sent to the system manager and the firmware update is done with the firmware files from the URL.
	Firmware Size
086	Allows the service technician to confirm the size of the firmware data files during the firmware update execution.
087	CERT: Macro Vsn
	Displays the macro version of the @Remote certification.
088	CERT: PAC Vsn
	Displays the PAC version of the @Remote certification.
	CERT: ID2 Code
089	Displays ID2 for the @Remote certification. Spaces are displayed as underscores (_). Asterisks (*) indicate that no @Remote certification exists.
	CERT: Subject
090	Displays the common name of the @Remote certification subject. CN = the following 17 bytes. Spaces are displayed as underscores (_). Asterisks (*) indicate that no DESS exists.
	CERT: Seri Num
091	Displays serial number for the @Remote certification. Asterisks (*) indicate that no DESS exists.
	CERT: Issuer
092	Displays the common name of the issuer of the @Remote certification. CN = the following 30 bytes. Asterisks (*) indicate that no DESS exists.

	CERT: St ExpTime
093	Displays the start time of the period for which the current @Remote certification is enabled.
	CERT: End ExpTime
094	Displays the end time of the period for which the current @Remote certification is enabled.
	Ins Country
150	Select from the list the name of the country where embedded RCG-M is installed in the machine. After selecting the country, you must also set the following SP codes for embedded RCG-M: SP5816-153 SP5816-154 SP5816-161 USA, 2: Canada, 3: UK, 4: Germany, 5: France Italy, 7: Netherlands, 8: Belgium, 9: Luxembourg, 10: Spain
	Aut Line Detect
151	Press [Execute]. Setting this SP classifies the telephone line where embedded RCG-M is connected as either dial-up or push type, so embedded RCG-M can automatically distinguish the number that connects to the outside line. The current progress, success, or failure of this execution can be displayed with SP5816 152. If the execution succeeded, SP5816 153 will display the result for confirmation and SP5816 154 will display the telephone number for the connection to the outside line.

SM Appendix 5-55 D067/D068/D069/D072

Line Detect Rst

Displays a number to show the result of the execution of SP5816 151. Here is a list of what the numbers mean.

- 0: Success
- 1: In progress (no result yet). Please wait.
- 152
- 2: Line abnormal
 - 3: Cannot detect dial tone automatically
 - 4: Line is disconnected
 - 5: Insufficient electrical power supply
 - 6: Line classification not supported
 - 7: Error because fax transmission in progress ioctl() occurred.
 - 8: Other error occurred
 - 9: Line classification still in progress. Please wait.

Dial/Push Select

This SP displays the classification (tone or pulse) of the telephone line to the access point for embedded RCG-M. The number displayed (0 or 1) is the result of the execution of SP5816 151. However, this setting can also be changed manually.

153 [0 to 1 / **0** / 1 /step]

- 0: Tone Dialing Phone
- 1: Pulse Dialing Phone

Inside Japan "2" may also be displayed:

- 0: Tone Dialing Phone
- 1: Pulse Dialing Phone 10PPS
- 2: Pulse Dialing Phone 20PPS

	Outline Phone #	
154	 The SP sets the number that switches to PSTN for the outside connection for embedded RCG-M in a system that employs a PBX (internal line). If the execution of SP5816-151 has succeeded and embedded RCG-M has connected to the external line, this SP display is completely blank. If embedded RCG-M has connected to an internal line, then the number of the connection to the external line is displayed. If embedded RCG-M has connected to an external line, a comma is displayed with the number. The comma is inserted for a 2 sec. pause. The number setting for the external line can be entered manually (including commas). 	
156	Dial Up User Use this SP to set a user name for access to remote dial up. Follow these rules when setting a user name: Name length: Up to 32 characters Spaces and # allowed but the entire entry must be enclosed by double quotation marks (").	
157	Dial Up Password Use this SP to set a password for access to remote dial up. Follow these rule when setting a user name: Name length: Up to 32 characters Spaces and # allowed but the entire entry must be enclosed by double quotation marks (").	
161	Phone Number Use this SP to set the telephone number of the line where embedded RCG-M is connected. This number is transmitted to and used by the Call Center to return calls. Limit: 24 numbers (numbers only)	

SM Appendix 5-57 D067/D068/D069/D072

162	Ans Timing Adj
	When the Call Center calls out to a embedded RCG-M modem, it sends a repeating ID tone (*#1#). This SP sets the time the line remains open to send these ID tones after the number of the embedded RCG-M modem is dialed up and connected. [0 to 24/ 1 /1 /step] The actual amount of time is this setting + 2 sec. For example, if you set "2" the line will remain open for 4 sec.
	Access Point
163	This is the number of the dial-up access point for embedded RCG-M. If no setting is done for this SP code, then a preset value (determined by the country selected) is used. Default: 0 Allowed: Up to 16 alphanumeric characters
	Comm Line
	This SP sets the connection conditions for the customer. This setting dedicates the line to embedded RCG-M only, or sets the line for sharing between embedded RCG-M and a fax unit. [0 or 1 / 0 / -]
164	1: Line dedicated to embedded RCG-M only
	 If this setting is changed, the copier must be cycled off and on. SP5816 187 determines whether the off-hook button can be used to interrupt an embedded RCG-M transmission in progress to open the line for fax transaction.
173	Modem Serial Number
173	This SP displays the serial number registered for the embedded RCG-M.

	Lmt Resend Cncl
174	Normally, it is best to allow unlimited time for certification and ID2 update requests, and for the notification that the certification has been completed. However, embedded RCG-M generates charges based on transmission time for the customer, so a limit is placed upon the time allowed for these transactions. If these transactions cannot be completed within the allowed time, do this SP to cancel the time restriction.
186	RCG-C M Debut Bit SW DFU
187	This SP determines whether pushing the off-hook button will interrupt an embedded RCG-M transmission in progress to open the line for fax transaction. This SP can be used only if SP5816-164 is set to "0". [0 or 1/ 0 / -] 0: Disable. Setting the fax unit off-hook does not interrupt a fax transaction in progress. If the off-hook button is pushed during a embedded RCG-M transmission, the button must be pushed again to set the fax unit on-hook after the embedded RCG-M transmission has completed. 1: Enable. When embedded RCG-M shares a line with a fax unit, setting the fax unit off-hook will interrupt a embedded RCG-M transmission in progress and open the line for a fax transaction.
200	Polling Man Exc Executes the polling test.

SM Appendix 5-59 D067/D068/D069/D072

	Instl: Condition
	Displays a number that indicates the status of the @Remote service device. 0: Neither the registered device by the external RCG nor embedded RCG device is set.
201	The embedded RCG device is being set. Only Box registration is completed. In this status the this unit cannot answer a polling request from the external RCG.
	2: The embedded RCG device is set. In this status the external RCG unit cannot answer a polling request.
	3: The registered device by the external RCG is being set. In this status the embedded RCG device cannot be set.4: The registered module by the external RCG has not started.
202	Instl: ID#
202	Allows entry of the number of the request needed for the embedded RCG.
203	Instl: Reference
	Executes the inquiry request to the @Remote GateWay URL.
	Instl: Ref Rslt
	Displays a number that indicates the result of the inquiry executed with SP5816-203.
204	0: Succeeded 1: Inquiry number error 2: Registration in progress 3: Proxy error (proxy enabled)
	4: Proxy error (proxy disabled) 5: Proxy error (Illegal user name or password)
	6: Communication error
	7: Certification update error 8: Other error
	9: Inquiry executing

	Instl: Ref Section	
205	Displays the result of the notification sent to the device from the GW URL in answer to the inquiry request. Displayed only when the result is registered at the GW URL.	
206	Instl: Rgstltn	
200	Executes Embedded RCG Registration.	
	Instl: Rgstltn Rst	
207	Displays a number that indicates the registration result. 0: Succeeded 2: Registration in progress 3: Proxy error (proxy enabled) 4: Proxy error (proxy disabled) 5: Proxy error (Illegal user name or password) 6: Communication error 7: Certification update error 8: Other error 9: Registration executing	

	Instl Error Code			
	Displays a number that describes the error code that was issued when either SP5816 204 or SP5816 207 was executed.			
	Cause	Code	Meaning	
	Illegal Modem Parameter	-11001	Chat parameter error	
000		-11002	Chat execution error	
208		-11003	Unexpected error	
	Operation Error, Incorrect Setting	-12002	Inquiry, registration attempted without acquiring device status.	
		-12003	Attempted registration without execution of an inquiry and no previous registration.	
		-12004	Attempted setting with illegal entries for certification and ID2.	

		-2385	Attempted dial up overseas without the correct international prefix for the telephone number.	
		-2387	Not supported at the Service Center	
		-2389	Database out of service	
		-2390	Program out of service	
	Error Caused by	-2391	Two registrations for same device	
208	Response from GW URL	-2392	Parameter error	
		-2393	External RCG not managed	
		-2394	Device not managed	
		-2395	Box ID for external RCG is illegal	
		-2396	Device ID for external RCG is illegal	
		-2397	Incorrect ID2 format	
		-2398	Incorrect request number format	
209	Instl Clear			
	Releases a machine from its embedded RCG setup.			
250	Print Com Log			
230	Prints the communication log.			

5821	NRS Address		
002	RCG IP Address	Sets the IP address of the RCG (Remote Communication Gate) destination for call processing at the remote service center. [00000000h to FFFFFFFh / 1 /step]	

5824	NVRAM Upload	
5824 1	"NVRAM Upload/Download" in this section.	

5825	NVRAM Download	
5825 1	■ "NVRAM Upload/Download" in this section.	

5828	Network Setting	CTL	
050	1284 Compatibility (Centro)	[0 or 1 / 1	or disables 1284 Compatibility. / 1 / step] ed, 1: Enabled
052	ECP (Centro)	[0 or 1 / 1 0: Disable NOTE: T	or disables ECP Compatibility. 1 / 1 / step] ed, 1: Enabled his SP is activated only when -50 is set to "1".
065	Job Spooling	[0 or 1 / 0	disables Job Spooling. 0 / 1 / step] ed, 1: Enabled
066	Job Spooling Clear: Start Time	power on 0: ON (Da	nt of the job when a spooled job exists at
069	Job Spooling (Protocol)	for each post validate to the control of the contro	es ates R P D B B B B B B B B B B B B B B B B B B

SM Appendix 5-65 D067/D068/D069/D072

090	TELNET (0: OFF 1: ON)	Enables or disables the Telnet protocol. [0 or 1 / 1 / -] 0: Disable, 1: Enable		
091	Web (0: OFF 1: ON)	Enables or disables the Web operation. [0 or 1 / 1 / –] 0: Disable, 1: Enable		
	Active IPv6 Link			
145	(802.11b) in the format: "Link Local Address" + "Pr	k Local Address" + "Prefix Length" IPv6 address consists of a total of 128 bits configured in 8 blocks of 16		
147	Active IPv6 Status Address 1			
149	Active IPv6 Status Address 2	These SPs are the IPv6 status addresses (1 to 5) referenced on the Ethernet or wireless LAN		
151	Active IPv6 Status Address 3	(802.11b) in the format: "Status Address" + "Prefix Length"		
153	Active IPv6 Status Address 4	The IPv6 address consists of a total of 128 bits configured in 8 blocks of 16 bits each.		
155	Active IPv6 Status Address 5			
	IPv6 Manual Setting Address			
156	This SP is the IPv6 manually set address referenced on Ethernet or wireless LAN (802.11b) in the format: "Manual Set Address" + "Prefix Length" The IPv6 address consists of a total of 128 bits configured in 8 blocks of 16 bits each.			

	IPv6 Gateway Address			
158	This SP is the IPv6 gateway address referenced on Ethernet or wireless LAN (802.11b). The IPv6 address consists of a total of 128 bits configured in 8 blocks of 16 bits each.			
	IPv6 Stateless Auto Setting			
161	Enables/disables the stateless automatic setting for Ethernet/wireless LAN operation. [0 to 1/1/1] 1: Enable 0: Disable			
	Web Item Invisible			
236	Determines whether each item can be set in Websys. [0x0000 to 0xffff/0xffff] Bit 1: NetRICOH Bit2: Vendor for consumables Bit2-15: Reserved			
Web Shopping Link Invisible Determines whether the NetRICOH link is displayed on the Websys to and link page. [0 to 1/1/1] 1: Display 0: No display				
238	Web Supplies Link Invisible Determines whether the consumable vendor link is displayed on the Websys top page and link page. [0 to 1/1/1] 1: Display 0: No display			

239	Web Link 1 Name Determines whether a name entered for "URL1" is displayed on the Websys link page. The name length is limited to 31 characters.	
240	Web Link 1 URL Sets the URL referenced for URL1 linked to the Websys linked page. The link name is limited to 127 characters.	
241	Web Link 1 Visible Determines whether the link for URL1 is displayed on the Websys top page. [0 to 1/1/1] 1: Display 0: No display	
242	Web Link 2 Name Determines whether a name entered for "URL2" is displayed on the Websys link page. The name length is limited to 31 characters.	
243	Web Link 2 URL Sets the URL referenced for URL2 linked to the Websys linked page. The link name is limited to 127 characters.	
244	Web Link 2 Visible Determines whether the link for URL2 is displayed on the Websys top page. [0 to 1/1/1] 1: Display 0: No display	

	HDD		
5832	Enter the SP number for the partition to initialize, then press #. When the execution ends, cycle the machine off and on.		
001	HDD Formatting (All)		
002	HDD Formatting (IMH)		
003	Format Thumbnail		
004	Format Job Log		
005	Format Font		
006	Format User Info		
007	Format Rec Mail		
008	Format Sed Mail		
009	Format DFU data		
010	Format All Log		
011	Format Ridoc I/F		

5840	IEEE 802.11			
	Channel MAX	CTL	[1 to 11 or 13 / 11 or 13 / 1 /step] Europe: 1 to 13, default: 13 NA/ Asia: 1 to 11, default: 11	
006	Sets the maximum number of channels available for data transmission via wireless LAN. The number of channels available varies according to location. The default settings are set for the maximum end of the range for each area. Adjust the upper 4 bits to set the maximum number of channels. DFU Note Do not change the setting.			

SM Appendix 5-69 D067/D068/D069/D072

	Channel MIN	CTL	[1 to 11 or 13 / 1 / 1 /step] Europe: 1 to 13 NA/ Asia: 1 to 11
Sets the minimum number of channels available for data transmission wireless LAN. The number of channels available varies according to I The default settings are set for the minimum end of the range for each Adjust the lower 4 bits to set the minimum number of channels. DFU Note Do not change the setting.			nnels available varies according to location. e minimum end of the range for each area. ninimum number of channels. DFU
011	WEP Key Select	CTL	[00 to 11 / 00 / 1 binary] 00: Key #1 01: Key #2 (Reserved) 10: Key #3 (Reserved) 11: Key #4 (Reserved)
	Selects the WEP key.		
	Fragment Thresh	CTL	[256 to 2346 / 2346 / 1]
042	Adjusts the fragment threshold for the IEEE802.11 card. This SP is displayed only when the IEEE802.11 card is installed.		
	11g CTS to Self	CTL	[0 to 1 / 1 / 1] 0: Off, 1: On
043	Determines whether the CTS self function is turned on or off. This SP is displayed only when the IEEE802.11 card is installed.		
044	11g Slot Time	CTL	[0 to 1 / 1 / 1] 0: 20µm, 1: 9µm
011	Selects the slot time for IEEE802.11.		
045	WPA Debug Lyl	CTL	[0 to 3 / 3 / 1] 1: Info, 2: Warning, 3: Error
040	Selects the debug log for WPA authentication application. This SP is displayed only when the IEEE802.11 card is installed.		

5842	GWWS Analysis DFU		
	Setting 1	CTL	
		Bit	Groups
		0	System & other groups (LSB)
		1	Capture related
001	This is a debugging tool. It sets	2	Certification related
001	the debugging output mode of each Net File process. Default: Bit SW 1000 0000	3	Address book related
		4	Machine management related
		5	Output related (printing, delivery)
		6	Repository related
		7	Debug log output
	Setting 2	CTL	
	Default: Bit SW 0000 0000	Bit	Groups
002		0-6	Not used
		7	Log time stamp setting 0: Date/Hour/Minute/Second 1: Minute/Second/Msecond

5844	USB		
	Transfer Rate	CTL	
001	Sets the speed for USB data [Full Speed] [Auto Change]	transmiss	sion.

	Vendor ID	CTL	
002	Sets the vendor ID: Initial Setting: 0x05A Ricoh C [0x0000 to 0xFFFF/1] DFU	ompany	
	Product ID	CTL	
003	Sets the product ID. [0x0000 to 0xFFFF/1] DFU		
	Device Release No.	CTL	
004	[0000 to 9999/1] DFU		BCD (binary coded decimal) display. erts the number to hexadecimal number

5845	Delivery Server Setting	CTL	-	
00.10	Provides items for delivery server settings.			
001	FTP Port Num	[0 to 65535 / 3670 / 1 /step]		
	Sets the FTP port number u	sed whe	en image files to the Scan Router Server.	
	Srv IP (Primary)	Range:	000.000.000.000 to 255.255.255.255	
002	Use this SP to set the Scan Router Server address. The IP address under the transfer tab can be referenced by the initial system setting.			
	Retry Interval	[60 to 9	999 / 300 / 1 second /step]	
003	Specifies the interval time for server or SMTP/FTP/NCP/S		ng the scanned image data to the deliver ver after sending error.	
	No. of Retries	[0 to 99	0 / 3 / 1 time/step]	
004	Specifies the retry times for sending the scanned image data to the deliver server or SMTP/FTP/NCP/SMB server after sending error.			

	DeliErr DispTime	[0 to 999 / 300 / 1 s	econd /step]
006	Use this setting to determine the length of time the prompt message is displayed when a test error occurs during document transfer with the NetFile application and an external device.		
	Svr IP (Secondary)	Range: 000.000.00	0.000 to 255.255.255.255
008	·	er of Scan Router. T	ter designated to function as his SP allows only the setting setting.
	Deli Svr Model	[0 to 4 / 0 / 1 /step]	
009	Allows changing the model of the delivery server registered by the I/O device 0: Unknown, 1: SG1 Provided, 2: SG1 Package, 3: SG2 Provided, 4: SG2 Package		
	Deli Svr Capabty	[0 to 255 / 0 / 1 /ste	p]
	Bit7 = 1 Comment information exits		Changes the capability of the server that is registered as an I/O device.
	Bit6 = 1 Direct specification of mail address possible		
	Bit5 = 1 Mail RX confirmation setting possible		
010	Bit4 = 1 Address book automatic update function exists		
	Bit3 = 1 Fax RX delivery function exists		
	Bit2 = 1 Sender password function exists		
	Bit1 = 1 Function to link MK exists	-1 user and Sender	
	Bit0 = 1 Sender specificatio 1, Bit6 is set to "0")	n required (if set to	

SM Appendix 5-73 D067/D068/D069/D072

	Delivery Svr Cap (Ext)	[0 to 255 / 0 / 1 /step]	
	Changes the capability of the server that is registered as an I/O device.		
011	Bit7 = 1 Address book usage limitation (Limitation for each authorized user) Bit6 = 1 RDH authorization link Bit5 to 0: Not used		
013	Svr Schm (Primary)	-	
0.10	Specifies the scheme of the	e primary delivery server.	
014	Svr Port Num (Pri)	-	
	Specifies the port number of the primary delivery server.		
015	Srv URL Path (Pri)	-	
	Specifies the URL path of the primary delivery server.		
016	Svr Schm (Sec)	-	
	Specifies the scheme of the secondary delivery server.		
017	Svr Port Num (Sec)	-	
	Specifies the port number of the secondary delivery server.		
018	Srv URL Path (Sec)	-	
	Specifies the URL path of the secondary delivery server.		
022	Instant Trans Off	[0 or 1 / 1 / -] 0: Disable, 1: Enable	
	Enables or disables the prevention function for the continuous data sending.		

5846	UCS Settings	CTL		
3040	Provides items for delivery server settings.			
	Machine ID (DelSvy)	Displays ID		
001	Displays the unique device ID in use by the delivery server directory. The value is only displayed and cannot be changed. This ID is created from the NIC MAC or IEEE 1394 EUI. The ID is displayed as either 6-byle or 8-byte binary.			
	MC ID Clr (DelSvy)	Clears ID		
002	Clears the unique ID of the device used as the name in the file transfer directory. Execute this SP if the connection of the device to the delivery server is unstable. After clearing the ID, the ID will be established again automatically by cycling the machine off and on.			
	Maximum Entries	[150 to 999 / 150 / 1 /step]		
003	If a value smaller than the p	the maximum number of entries that UCS can handle. smaller than the present value is set, the UCS managed data is nd the data (excluding user code information) is displayed.		
	Delsvr Rtry Tmer	[0 to 255 / 0 / 1 /step]		
006	Sets the interval for retry atte	empts when the delivery server fails to acquire the k.		
	Delsvr Rtry Tmes	[0 to 255 / 0 / 1 /step]		
007	Sets the number of retry attempts when the delivery server fails to acqui delivery server address book.			
	Delsvr Maxentri	[200 to 999 / 200 / 1/step]		
Sets the maximum number account entries information managed by UCS.		·		

SM Appendix 5-75 D067/D068/D069/D072

010	LDAP Search Tout	[1 to 255 / 60 / 1 /step]	
	Sets the length of the timeout for the search of the LDAP server.		
020	WSD Max Entries	[5 to 255 / 250 / 1 /step]	
020	Sets the maximum entries for	or the address book of the WSD (SD-scanner)	
021	Folder Auth chg	[0 or 1 / 0 / -] 0: Login user name 1: address book	
	[AddrB Acl Info] Address Bo	ok Access Control List Information	
041	This SP must be executed immediately after installation of an HDD unit in a basic machine that previously had no HDD. The first time the machine is powered on with the new HDD installed, the system automatically takes the address book from the NVRAM and writes it onto the new HDD. However, the new address book on the HDD can be accessed only by the system administrator at this stage. Executing this SP by the service technician immediately after power on grants full address book access to all users.		
043	Addr B Media		
	Displays the slot number wh	nere an address book data is in.	
047	Ini Local Addr B	Clears the local address book information, including the user code.	
048	Ini Deli Addr B	Clears the distribution address book information, except the user code.	
049	Ini LDAP Addr B	Clears the LDAP address book information, except the user code.	
050	Ini All Addr B	Clears all directory information managed by UCS, including all user codes. Turn the main power switch off and on after executing this SP.	

051	Bkup All Addr B	Uploads all directory information to the SD card.
052	Restr All Addr B	Downloads all directory information from the SD card.
053	Clear Backup Info	Deletes the address book data from the SD card in the service slot. Deletes only the files that were uploaded from this machine. This feature does not work if the card is write-protected. Note: After you do this SP, go out of the SP mode, and then turn the power off. Do not remove the SD card until the Power LED stops flashing.
060	Search Option	This SP uses bit switches to set up the fuzzy search options for the UCS local address book. Bit0: Checks both upper/lower case characters Bit1: Japan only Bit2 to 7: Not used
062	Compl Opt1 ⁽¹⁾	Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to upper case and sets the length of the password. [0 to 32 / 0 / 1 /step]
063	Compl Opt2 ⁽¹⁾	Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to lower case and defines the length of the password. [0 to 32 / 0 / 1 /step]

064	Compl Opt3 ⁽¹⁾	Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to numbers and defines the length of the password. [0 to 32 / 0 / 1 /step]
065	Compl Opt4 ⁽¹⁾	Use this SP to set the conditions for password entry to access the local address book. Specifically, this SP limits the password entry to symbols and defines the length of the password. [0 to 32 / 0 / 1 /step]
091	FTP Auth Port Setting	Specifies the FTP port for getting a distribution server address book that is used in the identification mode. [0 to 65535 / 3671 / 1 /step]
094	Encryption Stat	Shows the status of the encryption function for the address book data.

Note (1):

SP5846-062 to SP5846-065 do not normally require adjustment.

These SP modes are enabled only after the system administrator has set up a group password policy to control access to the address book.

SM Appendix

	Web Service	CTL	-	
5848		ch assignment for the access control setting. on access and delivery from Scan Router.		
002	Ac: Repo (only Lower 4 Bits)			
004	ac: UD (only Lower 4 bits)			
005	ac: For Cherry (only Lower 4 bits)		nes access control on and off.	
007	ac: Log Fax (Lower 4 bits)		No access control Denies access to DeskTop Binder.	
009	ac: Job Ctrl (Lower 4 bits)			
011	ac: Dev Mng (Lower 4 bits)			
022	ac: Uadmin (Lower 4bits)			
099	DL Image Setting	DFU		
100	Max. Size: DL Image	[1 to 1	024/1 K]	
210	Log Type: Job1			
211	Log Type: Job2			
212	Log Type: Access	-	ys the log server settings. can be adjusted with the Web Image	
213	Primary Srv	Monitor.		
214	Secondary Srv			
215	Start Time			

SM Appendix 5-79 D067/D068/D069/D072

216	Interval Time	Specifies the transmit interval. [1 to 1000 / 1 / 1 hour/step] This SP is activated only when SP5848-217 is set to "2 (Transmit periodically)".
217	Timing	Selects the transmit timing. [0 to 2 / 0 / 1/step] 0: No Transmit, 1: Transmit one by one 2: Transmit periodically

5849	Installation Date		CTL	
0043	Displays or prints the installation date of the machine.			
001	Display	The "Counter Clear Day" has been changed to "Installation Date" or "Inst. Date".		
002	Print	Determines whether the installation date is printed on the printout for the total counter. [0 or 1/ 1 / 1/step] 0: Off (No Print), 1: On (Print)		
003	Total Counter	Displays the total counter when the installation date is registered to the machine.		

5851	Bluetooth		
001	Mode	CTL	Sets the operation mode for the Bluetooth Unit. Press either key. 0 :Public, 1: Private

	Remote ROM Update			
5856	Allows the technician to upgrade the firmware using a parallel cable when updating the remote ROM.			
002	Local Port	[0 or 1 / 0 / 1/step] CTL 0 : Disallow 1: Allow		
5857	Debug Log Save	CTL	-	
	ON/OFF	0: OFF, 1: ON		
001	Switches the debug log feature on and off. The debug log cannot be captured until this feature is switched on.			
	Target (2: HDD 3: SD)			
	Selects the destination where the debugging information generated by the			

002 event selected by SP5858 will be stored if an error is generated

Specifies the debug log number for saving to an SD card.

Specifies the decimal key number of the log to be written to the hard disk.

[2 to 3 /1] 2: HDD

3: SD Card

Save to HDD

Save to SD Card

005

006

	HDD to SD Card Latest
009	Takes the most recent 4 MB of the log written to the hard disk and copies them to the SD Card. A unique file name is generated to avoid overwriting existing file names on the SD Card. Up to 4MB can be copied to an SD Card. 4 MB segments can be copied one by one to each SD Card.
	HDD to SD Any
010	Takes the log of the specified key from the log on the hard disk and copies it to the SD Card. A unique file name is generated to avoid overwriting existing file names on the SD Card. Up to 4 MB can be copied to an SD Card. 4 MB segments can be copied one by one to each SD Card. This SP does not execute if there is no log on the HDD with no key specified.
011	Erase HDD Debug Data
	Erases all debug logs on the HDD
	Erase SD Debug
012	Erases SD debug logs in the SD card. Turn off and on after executing this SP.
013	Dsply-SD Space
0.10	Displays the remaining space in the SD card.
	SD to SD Latest (Latest 4 MB)
014	Saves the debug log (latest 4 MB) in memory to the SD card. A unique file name is generated to avoid overwriting existing file names on the SD card. Up to 4MB can be copied to the SD card. 4 MB segments can be copied one by one to the SD card.

	SD to SD Any (Latest 4 MB Any Key)				
015	Saves the specified debug log (with SP5-857-006) in memory to the SD card. A unique file name is generated to avoid overwriting existing file names on the SD card. Up to 4MB can be copied to the SD card. 4 MB segments can be copied one by one to the SD card.				
016	Make HDD Debug				
	This SP creates a 32 MB file to store a log on the HDD.				
017	Make SD Debug				
	Executes the making of a file (4MB) for saving debug logs.				

	Debug Log Save: SC	CTL	-	
5858	These SPs select the content of the debugging information to be saved to the destination selected by SP5857-2. SP5858-3 stores one SC specified by number. Refer to the chapter "Trouble Shooting" for a list of SC error codes.			
001	Engine SC	Turns the save function on/off for SC codes generated by copier engine errors. [0 or 1 / 0 / 1/ step] 0: OFF, 1: ON		
002	Controller SC	Turns the save function on/off for SC codes generated by GW controller errors. [0 or 1 / 0 / 1/ step] 0: OFF, 1: ON		
003	Any SC	[0 to 65535 / 0 / 1 /step]		

		Turns the save function on/off for jam errors.
004	Jam	[0 or 1 / 0 / 1/ step]
		0: OFF, 1: ON

5859	Debug Log Save Key	CTL	-
001	Key 1		
002	Key 2		
003	Key 3		
004	Key 4	These	SPs allow you to set up to 10 keys for log
005	Key 5	These SPs allow you to set up to 10 keys for log files for functions that use common memory on the controller board. [-9999999 to 9999999 / 0 / -]	
006	Key 6		
007	Key 7		1
008	Key 8		
009	Key 9		
010	Key 10		

5860	SMTP/POP3/IMAP4	CTL	-	
	Par Mail Rec Tout [1 to 168 / 72 / 1 hour/step]			
020		e to wait before saving mail that breaks up during d mail is discarded if the remaining portion of the new prescribed time.		
	MDN Res RFC2298	[0 to 1	/1/-]	
Determines whether RFC2298 compliance is switched on for l 0: No, 1: Yes		ompliance is switched on for MDN reply mail.		

	SMTP Aut Field Rep [0 to 1 / 0 / –]				
022	Determines whether the FROM item of the mail header is switched to the validated account after the SMTP server is validated. 0: No. "From" item not switched. 1: Yes. "From" item switched.				
	SMTP Aut. Direct Set [0 or 1 / 0 / –]				
025	Selects the authentication method for SMPT. Bit switch: Bit 0: LOGIN Bit 1: PLAIN Bit 2: CRAM MD5 Bit 3: DIGEST MD5 Bit 4 to 7: Not used Note This SP is activated only when SMTP authorization is enabled by UP mode.				
026	S/MINE Header				

5866	E-mail Report		
001	Report Validity	-	[0 or 1 / 0 / –] 0: Enabled, 1: Disabled
	Enables or disables the E-mail alert function.		
005	Add Date Field	CTL	[0 or 1 / 0 / –] 0: Not add, 1: Add
000	Adds or does not add the date field to the header of the alert mail.		

5869	RAM Disk Setting			
001	Mail Function	GWINIT	[0 or 1 / 0 / -] 0: ON, 1: OFF	
	Turns on or off the e-mail	I function.		

5870	Common Key Info Writing		
001	Writing	CTL	Writes to flash ROM the common proof for validating the device for @Remote specifications.
003	Initialize	CTL	Formats the common proof area of the flash ROM. FA

\Rightarrow	5873	SD Card Appli Move	
	001	Move Exec	This SP copies the application programs from the original SD card in SD card slot 2 to an SD card in SD card slot 1.
	002	Undo Exec	This SP copies back the application programs from an SD card in the SD Card Slot 2 to the original SD card in the SD card slot 1. Use this menu when you have mistakenly copied some programs by using "Move Exec" (SP5873-1).

5875	SC Auto Reboot		
001	Reboot Mode	CTL	Enables or disables the automatic reboot function when an SC error occurs. [0 or 1 / 0 / -] 0: The machine reboots automatically when the machine issues an SC error and logs the SC error code. If the same SC occurs again, the machine does not reboot. 1: The machine does not reboot when an SC error occurs. The reboot is not executed for Type A, B or C SC codes.
002	Reboot Method	CTL	Selects the reboot method for SC. [0 or 1 / 0 / -] 0: Manual reboot, 1: Automatic reboot

5878	Option Setup		
001	Data Overwrite Security	-	Enables the Data Overwrite Security unit.
002	Encryption Option	-	Press "EXECUTE" on the operation panel. Then turn the machine off and on.

5881	Delete Fixed Sent		
001	Delete Fixed Sent	1	Deletes the fixed form sentence.

5885	Set WIM Function
200	Detect Mem Leak
201	DocSvr Timeout

5887	SD GetCounter SSP	
001	This SP saves the counter list of the machine to an SD card in the slot 3. The folder of "SD_COUNTER" must be made in an SD card for this SP.	

	Person Info Prot
5888*	Selects the protection level for logs. [0 to 1 / 0 / 1} 0: No authentication, No protection for logs 1: No authentication, Protected logs (an administrator can see the logs)

5893	[SDK Apli Cnt Name]	*CTL	-	
	Displays the counter name of each SDK application.			
001	SDK-1	SDK-1		
002	SDK-2			
003	SDK-3			
004	SDK-4			
005	SDK-5			
006	SDK-6			

5902	Test Pattern Print	
5902 1	Test Pattern Print" in this section.	

5907*	Plug & Play	
5907 1	Selects the brand name and production name for the Plug and Play function. These names are stored in the NVRAM. When the NVRAM data is corrupted, select these names once again. Use the right-arrow or left-arrow key to scroll through the list of brand names. To select a brand name, press the OK key. An asterisk (*) indicates which manufacture is currently selected.	

5912*	PCU Alarm Counter	[0 to 255 / 45 / 1/step]	
	Printout		
5912 1	Specifies the PCU alarm level. The PCU alarm is issued when the following condition is met: PAc x 1000 >= PCUc where PAc is the value specified in this SP and PCUc is the PCU counter. When you specify 0 (zero), the PCU alarm is deactivated.		

5913	Switch Permission	
	Print Application	
002	Sets the length of time to elapse before allowing another application to take control of the display when the application currently controlling the display is not operating because a key has not been pressed. [3 to 30 / 3 / 1 second/step]	

5974	Cherry Server
001	Selects which version of the Scan Router application program, "Light" or "Full (Professional)", is installed. [0 to 1 / 0 / 1 /step] 0: Light version (supplied with this machine) 1: Full version (optional)

	Device Setting		
5985	The NIC and USB support features are built into the GW controller. Use this SP to enable and disable these features. In order to use the NIC and USB functions built into the controller board, these SP codes must be set to "1".		
001	On Board NIC	[0 to 2 / 0 / 1 /step] 0: OFF, 1: ON, 2: ON: Limited When the "Function limitation" is set, "On board NIC" is limited only for the @Remote or LDAP/NT authentication. Other network applications than @Remote or LDAP/NT authentication are not available when this SP is set to "2". Even if you can change the initial settings of those network applications, settings may not actually work.	
002	On Board USB	[0 or 1 / 0 / 1/step] 0: OFF, 1: ON	

	SP Print Mode	SMC Print
In the SP mode, press Copy Window to move to the copy screen, so paper size, then press Start. Select A4/LT (Sideways) or larger to enthat all the information prints. Press SP Window to return to the SP select the desired print, and press "EXECUTE".		s Start. Select A4/LT (Sideways) or larger to ensure n prints. Press SP Window to return to the SP mode,
001	All (Data List)	
002	SP (Mode Data List)	
003	User Program	
004	Logging Data	
005	Diagnostic Report	
006	Non-Default (Prints only SPs set to values other than defaults.)	
007	NIB Summary	
021	Copier UP	
022	Scanner SP	
023	Scanner UP	

5998 Engine Memory Clear		Engine Memory Clear
001 See the section "Memory Clear" in this chapter.		

SP6-XXX (Peripherals)

6006*	ADF Adjustment ("DF Image Adjustment" in the "Adjusting Copy Image Area") NOTE: Available menus depend on the machine model and its configuration.		
001	StoS/Front Regist	[-5.0 to +5.0 / 0.0 / 0.1 mm/step]	
		stration for the front side of the original, for ARDF ect "+" or "–" before entering the value	
	Leading Regist	[-5.0 to +5.0 / 0.0 / 0.1 mm/step]	
002	Adjusts the leading edge registration for ARDF mode. Use the leading edge registration for ARDF mode. Use the leading select "+" or "-" before entering the value.		
	Trailing Erase	[-3.0 to +3.0 / -1.5 / 0.1 mm/step]	
003	Adjusts the trailing edge erase margin for ARDF mode. Use the key to select "+" or "-" before entering the value.		
	S to S/ Rear Regist	[-5.0 to +5.0 / 0.0 / 0.1 mm/step]	
004	Adjusts the side-to-side registration for the 2nd side of the original, for ARDF mode. Use the key to select "+" or "–" before entering the value		
005	Sub-scan Magnif	[-0.9 to +0.9 / 0.0 / 0.1 %/step]	
000	Adjusts the sub-scan magnification for the ARDF.		
	Origin Curl Adj	[0 = No / 1 = Yes]	
006	Turns on or off the skew correction at 2nd side scanning. This SP is activated only when the duplex mode is selected.		
007	Skew Correction	[-20 to +20 / 0.0 / 1 mm/step]	
	Adjusts the original buckle for the skew correction at 2ns side scanning. This SP is activated only when SP6-006-006 is set to "1 (Yes)".		

¥	(I)	
	ŏ	Ø,
ב	9	2
9	2	Ġ
d	뜻	ì
⋖	0,	

6009	ADF Free Run	
001	Duplex Mode	
	Performs an ARDF free run in duplex scanning mode. Press "ON" to start; press "OFF" to stop.	
	Simplex Mode	
003	Performs an ARDF free run at simplex scanning mode. Press "ON" to start; press "OFF" to stop.	

6910*	ADF Shading Time	[0 to 60 / 30 / 1 s/step]
001	and heat in the room may a	the shading processing in the ARDF mode. Light ffect the scanner response. Reduce this setting if ne white level is drifting during ARDF copy jobs.

6930*	ADF Hole Setting	[0 or 1 / 0 / -] 0 : No, 1: Yes
001	Enables or disables the ADI When "1: Yes" is selected, to originals in the ARDF.	hole setting. he machine prevents feed jams of the punched

SP7-XXX (Data Log)

7001*	Total Operation	
00	1 Displays the total operation time (total drum rotation time).	

7401*	Total SC Counter	[0 to 9999 / 0 / 1/step]
001	Displays how many times \$	SC codes are generated.

7403*	SC History	
001	Latest	
002	Latest 1	
003	Latest 2	
004	Latest 3	
005	Latest 4	Displays the most recent 10 service calls.
006	Latest 5	Displaye the most recent to convice dance.
007	Latest 6	
008	Latest 7	
009	Latest 8	
010	Latest 9	

7502*	Counter–Paper Jam	[0 to 9999 / 0 / 1/step]
001	Displays the total number of	of copy paper jams.

7503*	Counter-Orgn Jam	[0 to 9999 / 0 / 1/step]
001	Displays the total number of	of original jams,

	Paper Jam/Loc	[0 to 9999 / 0 / 1/step]
7504*	Displays the total number of	of the paper jams classified by timing and location.
001	At power on	
001	Paper jam occurs at power on.	
010	Regist NoFeed: OFF	
010	Paper does not reach the r	egistration sensor (from a paper tray).
011	1 Vertical SN: OFF	
011	Paper does not reach the relay sensor.	
012	1 Vertical SN: ON	
012	Paper is caught at the rela	y sensor.
021	Vertical SN: OFF	
021	Paper does not reach the v	vertical transport sensor.
022	Vertical SN: ON	
022	Paper is caught at the vertical transport sensor.	
050	Regist Bypass: OFF	
	Paper does not reach the r	egistration sensor (from the by-pass tray).

	Regist Duplex: OFF
060	Paper does not reach the registration sensor during reverse-side printing (for duplex printing).
070	Regist SN: ON
	Paper is caught at the registration sensor.
120	1 Exit SN: ON
.20	Paper is caught at the exit sensor (previous page).
121	Exit SN: OFF
121	Paper does not reach the exit sensor.
122	2 Exit SN: ON
	Paper is caught at the exit sensor.
123	Dup Inverter: OFF
120	Paper does not reach the duplex inverter sensor (from the registration roller).
125	Dup Inverter: ON
	Paper is caught at the duplex inverter sensor.

	Original Jam Location
7505	Displays the total number of original jams by location. These jams occur when the original does not activate the sensors. Note Lag. Jam occurs when the paper remains at the sensor for longer than the prescribed time. Late: Jam occurs because paper fails to arrive at the prescribed time.
210	Regist SN: OFF
211	Regist SN: ON
212	Paper Exit SN: OFF
213	Paper Exit SN: ON
214	Inverter: OFF
215	Inverter: ON

7506	[Paper Jam/ Size] Jam Counter: Paper Size			
006	A5 LEF			
044	HLT LEF			
133	A4 SEF	CTL		
134	A5 SEF		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Displays the number of jams according to the
142	B5 SEF			
164	LG SEF			[0 to 9999 / 0 / 1 sneet/step]
166	LT SEF			
172	HLT SEF			
255	Others			

7507*	Dsply-P Jam Hist				
001	Lastest				
002	Latest 1	Displays the copy jam history (the most recent 10 jams)			
003	Latest 2	Sample Display: CODE:007			
004	Latest 3	SIZE:05h			
005	Latest 4	TOTAL:0000334 DATE: Mon Mar 15 11:44:50 2000 where: CODE is the SP7504-*** number (see above. SIZE is the ASAP paper size code in hex. TOTAL is the total jam error count (SP7502)			
006	Latest 5				
007	Latest 6				
008	Latest 7				
009	Latest 8	DATE is the date the jams occurred.			
010	Latest 9				
Size	Code	Size	Code	Size	Code
A4 (S)	05	A3 (L)	84	DLT (L)	A0
A5 (S)	06	A4 (L)	85	LG (L)	A4
B5 (S)	0E	A5 (L)	86	LT (L)	A6
LT (S)	26	B4 (L)	8D	HLT (L)	AC
HLT (S)	2C	B5 (L)	8E	Others	FF

7508*	Dsply-O Jam Hist	ory
001	Lastest	
002	Last 1	Displays the original jam history (the most recent 10 jams).
003	Last 2	Sample Display: CODE:007
004	Last 3	SIZE:05h
005	Last 4	TOTAL:0000334 DATE: Mon Mar 15 11:44:50 2000
006	Last 5	where:
007	Last 6	CODE is the SP7505*** number (see above. SIZE is the ASAP paper size code in hex.
008	Last 7	TOTAL is the total error count (SP7503)
009	Last 8	DATE is the date the jams occurred.
010	Last 9	

7624	Part Replacement	
001	PCU	
	Selects the PM maintenance for PCU.	

7801	Memory/Version/PN
255	-
200	Displays the he part number and version of all ROMs in the machine

7803*	PM Counter	
001	Paper	Displays the PM counter.

7804	PM Count Reset	
	Paper	
001	Resets the PM counter (SP7-803-001). When the program ends normally, the message "Completed" is displayed.	

7807	Reset-SC/Jam
001	Resets the SC, paper, original, and total jam counters. When the program ends normally, the message "Completed" is displayed. SP7-807-1 does not reset the following logs: SP7-507 (Display-Paper Jam History) and SP7-508 (Display-Original Jam History).

7826	MF Error Counter Japan Only	
	Displays the number of counts requested of the card/key counter.	
001	Error Total	A request for the count total failed at power on. This error will occur if the device is installed but disconnected.
002	Error Staple	The request for a staple count failed at power on. This error will occur if the device is installed but disconnected.

7827	MF Error Counter Clear
7027	Press Execute to reset to 0 the values of SP7826. Japan Only

7832*	Display-Self-Diag
001	Displays the SC codes and the number of their occurrences. Each number is in the range of 0 to 9999.

7836	[Resident Memory]
7555	Displays the contents of the memory on the controller board.

	Assert Info					
7901	Records the location where a problem is detected in the program. The data stored in this SP is used for problem analysis. DFU					
001	File Name	-	-			
002	Number of Lines	-	-			
003	Location	-	-			

	Dsply-Info Count				
7991*	Displays the total operating time or the total number of operations. The time is displayed in the following format: day: hour: minute: second.				
003	Dsply-ID S Work				
	The total of the time when the ID sensor is working.				
004	Dsply-Dev Counter				
001	The total number of paper outputs.				
005	Dsply-ID Er Count				
	The total number of ID-sensor errors.				

SM Appendix 5-101 D067/D068/D069/D072

7992*	Reset-Info Count	
Reset-Dev Count		
	Clears the development counter (SP7-991-004).	
005	Reset-ID Er Count	
	Clears the ID sensor error counter (SP7-991-005).	

SP8-XXX (History)

Most of the SPs in this group are prefixed with a letter that indicates the mode of operation (the mode of operation is referred to as an "application"). Before reading the Group 8 Service Table, make sure that you understand what these prefixes mean.

Prefixes	What it means		
T:	Total: (Grand Total).	Grand total of the items counted for all applications (C, F, P, etc.)	
C:	Copy application.		
F:	Fax application.	Totals (pages, jobs, etc.) executed for each application when the job was not stored on the	
P:	Print application.	document server.	
S:	Scan application.		
O:	Other applications (external network applications, for example)	Refers to network applications such as Web Image Monitor. Utilities developed with the SDK (Software Development Kit) will also be counted with this group in the future.	

The Group 8 SP codes are limited to 17 characters, forced by the necessity of displaying them on the small LCDs of printers and faxes that also use these SPs. Read over the list of abbreviations below and refer to it again if you see the name of an SP that you do not understand.

Key for Abbreviations

Abbreviation What it means		
/	"By", e.g. "T:Jobs/Apl" = Total Jobs "by" Application	
>	More (2> "2 or more", 4> "4 or more"	
AddBook	Address Book	
Apl	Application	
B/W	Black & White	
Bk	Black	
С	Cyan	
ColCr	Color Create	
ColMode	Color Mode	
Comb	Combine	
Comp	Compression	
Deliv	Delivery	
DesApl	Designated Application. The application (Copy, Fax, Scan, Print) used to store the job on the document server, for example.	
Dev Counter	Development Count, no. of pages developed.	
Dup, Duplex	Duplex, printing on both sides	
Emul	Emulation	
FC	Full Color	
FIN	Post-print processing, i.e. finishing (punching, stapling, etc.)	
Full Bleed	No Margins	
GenCopy	Generation Copy Mode	

Abbreviation	What it means		
GPC	Get Print Counter. For jobs 10 pages or less, this counter does not count up. For jobs larger than 10 pages, this counter counts up by the number that is in excess of 10 (e.g., for an 11-page job, the counter counts up 11-10 =1)		
IFax	Internet Fax		
ImgEdt	Image Edit performed on the original with the copier GUI, e.g. border removal, adding stamps, page numbers, etc.		
К	Black (YMCK)		
LS	Local Storage. Refers to the document server.		
LSize	Large (paper) Size		
Mag	Magnification		
МС	One color (monochrome)		
NRS	NRS (@Remote), which allows a service center to monitor machines remotely. "@Remote" is used overseas; "CSS" is used in Japan.		
Org	Original for scanning		
OrgJam	Original Jam		
Palm 2	Print Job Manager/Desk Top Editor: A pair of utilities that allows print jobs to be distributed evenly among the printers on the network, and allows files to moved around, combined, and converted to different formats.		
PC	Personal Computer		

Abbreviation	What it means
PGS	Pages. A page is the total scanned surface of the original. Duplex pages count as two pages, and A3 simplex count as two pages if the A3/DLT counter SP is switched ON.
PJob	Print Jobs
Ppr	Paper
PrtJam	Printer (plotter) Jam
PrtPGS	Print Pages
R	Red (Toner Remaining). Applies to the wide format model A2 only. This machine is under development and currently not available.
RCG	Remote Communication Gate
Rez	Resolution
sc	Service Code (Error SC code displayed)
Scn	Scan
Sim, Simplex	Simplex, printing on 1 side.
S-to-Email	Scan-to-E-mail
SMC report printed with SP5990. All of the Group 8 corecorded in the SMC report.	
Svr	Server
TonEnd Toner End	
TonSave	Toner Save

Abbreviation	What it means
TXJob	Send, Transmission
YMC	Yellow, Magenta, Cyan
YMCK	Yellow, Magenta, Cyan, Black



All of the Group 8 SPs are reset with SP5 801 1 Memory All Clear.

8 191	T:Total Scan PGS	CTL	These SPs count the pages scanned by
8 192	C:Total Scan PGS	CTL	each application that uses the scanner
8 193	F:Total Scan PGS	CTL	to scan images. [0 to 99999999 / 0 / 1]
8 195	S:Total Scan PGS	CTL	[6 to 0000000 / 0 / 1]

- SP 8 191 to 8 196 count the number of scanned sides of pages, not the number of physical pages.
- These counters do not count reading user stamp data, or reading color charts to adjust color.
- Previews done with a scanner driver are not counted.
- A count is done only after all images of a job have been scanned.
- Scans made in SP mode are not counted.

Examples

- If 3 B5 pages and 1 A3 page are scanned with the scanner application but not stored, the S: count is 4.
- If both sides of 3 A4 sheets are copied and stored to the document server using the Store File button in the Copy mode window, the C: count is 6 and the L: count is 6.
- If both sides of 3 A4 sheets are copied but not stored, the C: count is 6.
- If you enter document server mode then scan 6 pages, the L: count is 6.

	T:LSize Scan PGS	CTL	[0 to 99999999 / 0 / 1]		
8 201	These SPs count the total number of large pages input with the scanner for scan and copy jobs. Large size paper (A3/DLT) scanned for fax transmission is not counted. • Note • These counters are displayed in the SMC Report, and in the User Tools display.				
	F:LSize Scan PGS	CTL	[0 to 99999999 / 0 / 1]		
8 203	These SPs count the number of large pages scanned by original type for Fax jobs.				
	S:LSize Scan PGS	CTL	[0 to 99999999 / 0 / 1]		
8 205	These SPs count the total number of large pages input with the scanner for scan jobs only. Large size paper (A3/DLT) scanned for fax transmission are not counted. Note These counters are displayed in the SMC Report, and in the User Tools display.				

	ADF Org Feed	ds	CTL	[0 to 99999999 / 0 / 1]	
8 221	These SPs count the number of pages fed through the ADF for front and back side scanning.				
001	Front	Number of front sides fed for scanning: With an ADF/ARDF that can scan both sides simultaneously, the Front side count is the same as the number of pages fed for either simplex or duplex scanning. With an ADF/ARDF that cannot scan both sides simultaneously, the Front side count is the same as the number of pages fed for duplex front side scanning. (The front side is determined by which side the user loads face up.)			
002	Back	Number of rear sides fed for scanning: With an ADF/ARDF that can scan both sides simultaneously, the Back count is the same as the number of pages fed for duplex scanning. With an ADF/ARDF that cannot scan both sides simultaneously, the Back count is the same as the number of pages fed for duplex rear-side scanning.			

- When 1 sheet is fed for duplex scanning the Front count is 1 and the Back count is 1.
- If a jam occurs during the job, recovery processing is not counted to avoid double counting. Also, the pages are not counted if the jam occurs before the first sheet is output.

8 281	T:Scan PGS/TWAIN	CTL	These SPs count the number of
8 285	S:Scan PGS/TWAIN	CTL	pages scanned using a TWAIN driver. These counters reveal how the TWAIN driver is used for delivery functions. [0 to 99999999 / 0 / 1] Note At the present time, these counters perform identical counts.
		I	1
8 291	T:Scan PGS/Stamp	CTL	These SPs count the number of
8 293	F:Scan PGS/Stamp	CTL	pages stamped with the stamp in the ADF unit.
8 295	S:Scan PGS/Stamp	CTL	[0 to 99999999 / 0 / 1]
	T:Scan PGS/Size	CTL	[0 to 99999999 / 0 / 1]
8 301	These SPs count by size the total number of pages scanned by all applications. Use these totals to compare original page size (scanning) and output (printing) page size [SP 8-441].		
	C:Scan PGS/Size	CTL	[0 to 99999999 / 0 / 1]
8 302	These SPs count by size the total number of pages scanned by the Copy application. Use these totals to compare original page size (scanning) and output (printing) page size [SP 8-442].		
	F:Scan PGS/Size	CTL	[0 to 99999999 / 0 / 1]
8 303	These SPs count by size the total number of pages scanned by the		

output page size [SP 8-443].

application. Use these totals to compare original page size (scanning) and

	S:Scan PGS/Size	CTL	[0 to 99999999 / 0 / 1]
8 305		tals to co	number of pages scanned by the Scan mpare original page size (scanning) and
001	A3		
002	A4		
003	A5		
004	B4		
005	B5		
006	DLT	_	
007	LG		
008	LT		
009	HLT		
010	Full Bleed		
254	Other (Standard)		
255	Other (Custom)		

8 381	T:Total PrtPGS	CTL	
8 382	C:Total PrtPGS	CTL	These SPs count the number of pages printed by the customer. The counter
8 383	F:Total PrtPGS	CTL	for the application used for storing the
8 384	P:Total PrtPGS	CTL	pages increments. [0 to 99999999 / 0 / 1]
8 385	S:Total PrtPGS	CTL	
8 387	O:Total PrtPGS	CTL	

SM Appendix 5-111 D067/D068/D069/D072

- When the A3/DLT double count function is switched on with SP5104, 1 A3/DLT page is counted as 2.
- When several documents are merged for a print job, the number of pages stored is counted for the application that stored them.
- These counters are used primarily to calculate charges on use of the machine, so the following pages are not counted as printed pages:

Blank pages in a duplex printing job.

Blank pages inserted as document covers, chapter title sheets, and slip sheets.

Reports printed to confirm counts.

All reports done in the service mode (service summaries, engine maintenance reports, etc.)

Test prints for machine image adjustment.

Error notification reports.

Partially printed pages as the result of a copier jam.

	LSize PrtPGS	CTL	[0 to 99999999 / 0 / 1]
8 391	Note In addition to bei	ng disp	on paper sizes A3/DLT and larger. Played in the SMC Report, these counters Be User Tools display on the copy machine.

8 411	Prints/Duplex	CTL	This SP counts the amount of paper (front/back counted as 1 page) used for duplex printing. Last pages printed only on one side are not counted. [0 to 99999999 / 0 / 1]
-------	---------------	-----	--

	T:PrtPGS/Dup Com	ıb	CTL	[0 to 99999999 / 0 / 1]	
8 421	These SPs count by	These SPs count by binding and combine, and n-Up settings the number			
	of pages processed	for p	rinting.	This is the total for all applications.	
	C:PrtPGS/Dup Con	nb	CTL	[0 to 99999999 / 0 / 1]	
8 422	These SPs count by	y bind	ing and	combining, and n-Up settings the number	
	of pages processed	for p	rinting b	by the copier application.	
	F:PrtPGS/Dup Com	nb	CTL	[0 to 99999999 / 0 / 1]	
8 423	These SPs count by	y bind	ing and	combining, and n-Up settings the number	
	of pages processed	for p	rinting b	by the fax application.	
	P:PrtPGS/Dup Con	nb	CTL	[0 to 99999999 / 0 / 1]	
8 424	These SPs count by	y bind	ing and	combining, and n-Up settings the number	
	of pages processed	for p	rinting b	by the printer application.	
	S:PrtPGS/Dup Con	GS/Dup Comb C		[0 to 99999999 / 0 / 1]	
8 425	These SPs count by binding and combining, and n-Up settings the number				
	of pages processed	I for printing by the scanner application.			
	O:PrtPGS/Dup Con	nb	CTL	[0 to 99999999 / 0 / 1]	
8 427	These SPs count by	y bind	ing and	combining, and n-Up settings the number	
	of pages processed	for p	rinting b	by Other applications	
001	Simplex> Duplex	-			
002	Duplex> Duplex	-			
003	Book> Duplex	-			
004	Simplex Combine	-			
005	Duplex Combine	-			
006	2>	2 pages on 1 side (2-Up)			
007	4>	4 pa	ges on	1 side (4-Up)	

SM Appendix 5-113 D067/D068/D069/D072

System Service Mode (F/SPF: D068/D069)

008	6>	6 pages on 1 side (6-Up)	
009	8>	8 pages on 1 side (8-Up)	
010	9>	9 pages on 1 side (9-Up)	
011	16>	16 pages on 1 side (16-Up)	
012	Booklet	-	
013	Magazine	-	

- These counts (SP8-421 to SP8-427) are especially useful for customers who need to improve their compliance with ISO standards for the reduction of paper consumption.
- Pages that are only partially printed with the n-Up functions are counted as 1 page.
- Here is a summary of how the counters work for Booklet and Magazine modes:

Вос	klet	Magazine		
Original Pages	Count	Original Pages	Count	
1	1	1	1	
2	2	2	2	
3	2	3	2	
4	2	4	2	
5	3	5	4	
6	4	6	4	
7	4	7	4	
8	4	8	4	

	T:PrtPGS/Ppr Size	CTL	[0 to 99999999 / 0 / 1]			
8 441	These SPs count by print paper size the number of pages printed by all applications.					
	C:PrtPGS/Ppr Size	CTL	[0 to 99999999 / 0 / 1]			
8 442	These SPs count by prince copy application.	nt paper	size the number of pages printed by the			
	F:PrtPGS/Ppr Size	CTL	[0 to 99999999 / 0 / 1]			
8 443	These SPs count by print paper size the number of pages printed by the fax application.					
	P:PrtPGS/Ppr Size	CTL	[0 to 99999999 / 0 / 1]			
8 444	These SPs count by print paper size the number of pages printed by the printer application.					
	S:PrtPGS/Ppr Size	CTL	[0 to 99999999 / 0 / 1]			
8 445	These SPs count by print paper size the number of pages printed by the scanner application.					

	O:PrtPGS/Ppr Size	CTL	[0 to 99999999 / 0 / 1]
8 447	These SPs count by pr applications.	int paper	size the number of pages printed by Other
001	A3		
002	A4		
003	A5		
004	B4		
005	B5		
006	DLT		
007	LG		
008	LT		
009	HLT		
010	Full Bleed		
254	Other (Standard)		
255	Other (Custom)		

These counters do not distinguish between LEF and SEF.

8 451	PrtPGS/Ppr Tray	CTL	[0 to 99999999 / 0 / 1]	
0 401	These SPs count the	number of sheets fed from each paper feed station.		
001	Bypass	Bypass Tra	ay	
002	Tray 1	Copier		
003	Tray 2	Copier		
004	Tray 3	Copier		
005	Tray 4	Currently i	not used.	
006	Tray 5	Currently not used.		
007	Tray 6	Currently not used.		
008	Tray 7	Currently not used.		
009	Tray 8	Currently I	not used.	
010	Tray 9	Currently i	not used.	
011	Tray 10	Currently I	not used.	
012	Tray 11	Currently I	not used.	
013	Tray 12	Currently not used.		
014	Tray 13	Currently not used.		
015	Tray 14	Currently not used.		
016	Tray 15	Currently i	not used.	

		T:PrtPGS/Ppr Type	CTL	[0 to 99999999 / 0 / 1]		
8 461		 These SPs count by paper type the number pages printed by all applications. These counters are not the same as the PM counter. The PM counter is based on feed timing to accurately measure the service life of the feed rollers. However, these counts are based on output timing. Blank sheets (covers, chapter covers, slip sheets) are also counted. During duplex printing, pages printed on both sides count as 1, and a page printed on one side counts as 1. 				
		C:PrtPGS/Ppr Type	CTL	[0 to 99999999 / 0 / 1]		
8 462		These SPs count by paper application.	type the	number pages printed by the copy		
		F:PrtPGS/Ppr Type	CTL	[0 to 99999999 / 0 / 1]		
8 463		These SPs count by paper application.	type the	number pages printed by the fax		
		P:PrtPGS/Ppr Type	CTL	[0 to 99999999 / 0 / 1]		
8 464		These SPs count by paper type the number pages printed by the printer application.				
	001	Normal				
	002	Recycled				
	003	Special				
	004	Thick				
	005	Normal (Back)				
	006	Thick (Back)				
	007	OHP				
	800	Other				

		I				
	T:PrtPGS/FIN	CTL	[0 to 99999999 / 0 / 1]			
8 521	These SPs count by finishing mode the total number of pages printed by all applications.					
	C:PrtPGS/FIN	CTL	[0 to 99999999 / 0 / 1]			
8 522	These SPs count by finis the Copy application.	hing mod	le the total number of pages printed by			
	F:PrtPGS/FIN	CTL	[0 to 99999999 / 0 / 1]			
8 523	These SPs count by finishing mode the total number of pages printed by the Fax application. Note Print finishing options for received faxes are currently not available.					
	P:PrtPGS/FIN	CTL	[0 to 99999999 / 0 / 1]			
8 524	These SPs count by finis the Print application.	These SPs count by finishing mode the total number of pages printed by the Print application.				
	S:PrtPGS/FIN	CTL	[0 to 99999999 / 0 / 1]			
8 525	These SPs count by finis the Scanner application.	hing mod	de the total number of pages printed by			
001	Sort					
002	Stack	Stack				
003	Staple	Staple				
004	Booklet					
005	Z-Fold	Z-Fold				
006	Punch					
007	Other					

SM Appendix 5-119 D067/D068/D069/D072



- If stapling is selected for finishing and the stack is too large for stapling, the unstapled pages are still counted.
- The counts for staple finishing are based on output to the staple tray, so jam recoveries are counted.

	T:Counter	CTL	[0 to 99999999 / 0 / 1]		
8 581	This SP counts the total output broken down by color output, regardless of the application used. In addition to being displayed in the SMC Report, these counters are also displayed in the User Tools display on the copy machine.				
001	Total				

8 591	O:Counter	CTL	[0 to 99999999 / 0 / 1]	
8 591 1	A3/DLT	These SPs count the totals for A3/DLT paper		
8 591 2	Duplex		ber of duplex pages printed, and the of staples used. These totals are for	
0 001 2	Бирісх	Other (O:) applications only.		

8 601	Cvg Counter	CTL	[0 to 99999999 / 0 / 1]
8 601 1	Cvg: BW %	Displays the total coverage of each mode.	
8 601 11	Cvg: BW Pages	Displays to	he number of the printouts in each

		T:FAX TX PGS	CTL	[0 to 99999999 / 0 / 1]		
8 631		This SP counts by color mode the number of pages sent by fax to a telephone number.				
		F:FAX TX PGS	CTL	[0 to 99999999 / 0 / 1]		
8 633		This SP counts by color mode the number of pages sent by fax to a telephone number.				
001 B/W						

- If a document has color and black-and-white pages mixed, the pages are counted separately as B/W or Color.
- At the present time, this feature is provided for the Fax application only so SP8631 and SP8633 are the same.
- The counts include error pages.
- If a document is sent to more than one destination with a Group transmission, the count is done for each destination.
- Polling transmissions are counted but polling RX are not.
- Relay, memory, and confidential mailbox transmissions and are counted for each destination.

		T:IFAX TX PGS	CTL	[0 to 99999999 / 0 / 1]		
8 641		This SP counts by color mode the number of pages sent by fax to as fax images using I-Fax.				
		F:IFAX TX PGS	CTL	[0 to 99999999 / 0 / 1]		
8 643		This SP counts by color mode the number of pages sent by Fax as fax images using I-Fax.				
001 B/W						

- If a document has color and black-and-white pages mixed, the pages are counted separately as B/W or Color.
- At the present time, this feature is provided for the Fax application only so SP8641 and SP8643 are the same.
- The counts include error pages.
- If a document is sent to more than one destination with a Group transmission, the count is done for each destination.
- Polling transmissions are counted but polling RX are not.
- Relay, memory, and confidential mailbox transmissions and are counted for each destination.

	T:S-to-Email PGS	CTL	[0 to 99999999 / 0 / 1]			
8 651	This SP counts by color mode the total number of pages attached to an e-mail for both the Scan and document server applications.					
	S:S-to-Email PGS	CTL	[0 to 99999999 / 0 / 1]			
8 655	This SP counts by color mode the total number of pages attached to an e-mail for the Scan application only.					
001	B/W					
002	Color					



- The count for B/W and Color pages is done after the document is stored on the HDD. If the job is cancelled before it is stored, the pages are not counted.
- If Scan-to-Email is used to send a 10-page document to 5 addresses, the count is 10 (the pages are sent to the same SMTP server together).
- If Scan-to-PC is used to send a 10-page document to 5 folders, the count is 50 (the document is sent to each destination of the SMB/FTP server).
- Due to restrictions on some devices, if Scan-to-Email is used to send a 10-page document to a large number of destinations, the count may be divided and counted separately. For example, if a 10-page document is sent to 200 addresses, the count is 10 for the first 100 destinations and the count is also 10 for the second 100 destinations, for a total of 20.).

	T:Deliv PGS/Svr	CTL	[0 to 99999999 / 0 / 1]		
8 661	These SPs count by color mode the total number of pages sent to a Scan Router server by both Scan and LS applications.				
	S:Deliv PGS/Svr	CTL	[0 to 99999999 / 0 / 1]		
8 665	These SPs count by color mode the total number of pages sent to a Scan Router server by the Scan application.				
001	B/W				
002	Color				

↓ Note

- The B/W and Color counts are done after the document is stored on the HDD of the Scan Router server.
- If the job is canceled before storage on the Scan Router server finishes, the count is not done.
- The count is executed even if there is confirmation of the arrival at the Scan Router server.

		T:Deliv PGS/PC	CTL	[0 to 99999999/ 0 / 1]		
8 671		These SPs count by color mode the total number of pages sent to a folder on a PC (Scan-to-PC) with the Scan and LS applications.				
		S:Deliv PGS/PC	CTL	[0 to 99999999 / 0 / 1]		
8 675		These SPs count by color mode the total number of pages sent with Scan-to-PC with the Scan application.				
	001	B/W				
002 Color						



- Print jobs done with Web Image Monitor and Desk Top Binder are added to the count.
- If several documents are merged for sending, the number of pages stored are counted for the application that stored them.
- When several documents are sent by a Fax broadcast, the F: count is done for the number of pages sent to each destination.

8 681	T:PCFAX TXPGS	CTL	These SPs count the number of pages sent	
8 683	F:PCFAX TXPGS	CTL	by PC Fax. These SPs are provided for the Fax application only, so the counts for SP8-681 and SP8-683 are the same. [0 to 99999999 / 0 / 1]	

- This counts pages sent from a PC using a PC fax application, from the PC through the copier to the destination.
- When sending the same message to more than one place using broadcasting, the pages are only counted once. (For example, a 10-page fax is sent to location A and location B. The counter goes up by 10, not 20.)

	TX PGS/Port	CTL	[0 to 99999999 / 0 / 1]	
8 701	These SPs count the number of pages sent by the physical port used to send them. For example, if a 3-page original is sent to 4 destinations via ISDN G4, the count for ISDN (G3, G4) is 12.			
001	PSTN-1	-		
002	PSTN-2	-		
003	PSTN-3	-		
004	ISDN (G3,G4)	-		
005	Network	-		

8 711	T:Scan PGS/Comp	CTL [0 to 99999999 / 0 / 1]		
8 715	S:Scan PGS/Comp		[0 to 99999999 / 0 / 1]	
	These SPs count the number of pages sent by each compression mode.			
-001	JPEG/JPEG2000	-		
-002	TIFF M/S (Multi/Single)	-		
-003	PDF	-		
-004	Other	-		

	RX PGS/Port		[0 to 9999999/ 0 / 1]	
8741	These SPs count the number of pages received by the physical port used to receive them.			
001	PSTN-1			
002	PSTN-2			
003	PSTN-3			
004	ISDN (G3,G4)			
005	Network			

8 771	Dev Counter	CTL	[0 to 99999999/ 0 / 1]
0771	This SP counts the total number of developed images.		
001	Total		

SM Appendix 5-125 D067/D068/D069/D072

8 861

001 Bk

8 781		Toner Botol Info.	*BICU	[0 to 99999999/ 0 / 1]	
		This SP counts the total number of developed images.			
	001	Total			
		Toner Remain	CTL	[0 to 100 / 0 / 1]	
8 801		This SP displays the percent of toner remaining for each color. This SP allows the user to check the toner supply at any time. Note This precise method of measuring remaining toner supply (1% steps) is better than other machines on the market that can only measure in increments of 10 (10% steps).			
	001	κ			
				T	
		Cvr Cnt:0-10%	*BICU	[0 to 99999999/ 0 / 1]	
8 851		These SPs display the number of scanned sheets on which the coverage of each color is from 0% to 10%.			
	011	0-2%:Bk			
	021	3-4%: Bk			
	031	5-7%: Bk			
	041	8-10%: Bk			
		Cvr Cnt: 11-20%	*BICU	[0 to 99999999/ 0 / 1]	

of each color is from 11% to 20%.

These SPs display the number of scanned sheets on which the coverage

		Cvr Cnt: 21-30%	*BICU	[0 to 99999999/ 0 / 1]	
These SPs display the number of scanned sheets on which the coof each color is from 21% to 30%.			-	е	
	001	Bk			
		Cvr Cnt: 31%-	*BICU	[0 to 99999999/ 0 / 1]	
8 881		These SPs display of each color is 31%		er of scanned sheets on which the coverager.	е
	001	Bk			
8 891		Page/Toner Bottle	*BICU	[0 to 99999999/ 0 / 1]	
		This SP displays the number of sheets output by the scan application.			
	001	Bk			
		Page/Toner k Prev1	*BI0	CU [0 to 99999999/ 0 / 1]	
8 901		This SP displays the the previously repla		of sheets output by the scan application wi	th
	001	Bk			
		Page/Toner k Prev2	2 *BIG	[0 to 99999999/ 0 / 1]	
8 911				of sheets output by the scan application with oreviously replaced unit (two steps back from	
	001	Bk			

8 921	Cvr Cnt/Total	*BICU	
001	Coverage(%): BK	[0 to 2147483647 / 0 / 1] These SPs display the total coverage percentage of sheets output by the machine.	
011	Covwerage/P: Bk	[0 to 99999999 / 0 / 1] These SPs display the total coverage pages output b the machine.	

		Machine Status	CTL	[0 to 99999999 / 0 / 1]
8 941		mode. These SPs are	e amount of time the machine spends in each operation re useful for customers who need to investigate or improvement of their compliance with ISO Standards.	
0	001	Operation Time	Engine operation time. Does not include time while controller is saving data to HDD (while engine is not operating).	
0	002	Standby Time	Engine not operating. Includes time while controller saves data to HDD. Does not include time spent in Energy Save, Low Power, or Off modes.	
0	003	Energy Save Time	Includes time while the machine is performing background printing.	
0	004	Low Power Time	Includes time in Energy Save mode with Engine on. Includes time while machine is performing background printing.	
0	005	Off Mode Time	backgrou	time while machine is performing und printing. Does not include time machine powered off with the power switches.

×	Ø	
寰	ŏ	S
Ľ	9	ළ
þ	_	ak
þ	S	
Q.		

006	SC	Total down time due to SC errors.
007	PrtJam	Total down time due to paper jams during printing.
008	OrgJam	Total down time due to original jams during scanning.
009	Supply PM Unit End	Total down time due to toner end.

8 999	AdominCounter	CTL	[0 to 9999999 / 0 / 1]	
0 333	Displays the user setting counter for administrator.			
001	Total	-		
003	Copy: BW	-		
007	Printer: BW	-		
010	FaxP: BW	-		
013	Duplex	-		
015	Cvr: BW %	-		
017	Cvr: BW Pages	-		
101	SedTtl: FC			
102	SendTtl: BW	-		
103	FaxSend	-		
104	FaxSend: BW			
105	FaxSend: BW	-		

5.1.2 INPUT CHECK (SP5-803)

Conducting Input Check

- 1. Select SP5-803.
- 2. Select the number (see the table below) corresponding to the component.
- 3. Select "Execute." The copy mode is activated.
- 4. The sign "01H" or "00H" is displayed (see the table below).

Input Check Table

Num.	Sensor/Switch	1h	0h
001	Safety SW	Open	Closed
003	Right Cover SW	Open	Closed
006	Upper Relay S	Paper detected	Not detected
007	Lower Relay S	Paper detected	Not detected
009	Regist Sensor	Paper detected	Not detected
010	Exit Sensor	Paper detected	Not detected
011	Duplex Inverter S	Paper detected	Not detected
014	By-pass PE S	Paper detected	Not detected
016	Upper PE S	Paper detected	Not detected
017	BK-Upper PE S	Paper detected	Not detected
020	BK-Lower PE S	Paper detected	Not detected
027	PCU Set Signal	Installed	Not installed
028	BK type	*	*
030	Duplex Installed	Installed	Not installed

Num.	Sensor/Switch	1h	0h
032	Main M Lock	Locked	Not locked
033	Polygon M Lock	Locked	Not locked
035	Total CO Install	Installed	Not installed
036	Key CO Install	Installed	Not installed
037	L-Synchronization	Detected	Not detected
039	DF-Cover Open S	Open	Closed
040	DF-Original Set S	Paper detected	Not detected
041	DF-Registration S	Paper detected	Not detected
042	DF-Exit S	Paper detected	Not detected
044	DF-Reverse S	Paper detected	Not detected
045	Platen Cover S	Open	Closed
050	Fan Motor Lock (High speed)	High speed	Low speed or stop
052	Front Cover SW	Open	Closed
053	HP Sensor	Detected	Not detected
055	BK-UpperCover SW	Open	Closed
056	BK-LowerCover SW	Open	Closed

* Available Paper Feed Unit

00	None
30	1-tray paper feed unit

5.1.3 OUTPUT CHECK (SP5-804)

Conducting Output Check

▲CAUTION

- To prevent mechanical or electrical damage, do not keep an electrical component on for a long time.
- 1. Select SP5-804.
- 2. Select the number (see the table below) corresponding to the component.
- 3. Select "ON."
- 4. To stop the operation, select "OFF."

Output Check Table

Num.	Component
001	Main M- Fwd
002	Main M- Rev
003	Quenching Lamp
004	Toner Sup CL
005	Fan M- High
006	Fan M- Low
007	Registration CL
800	By-pass Feed CL
009	Upper Feed CL
010	BK-Upper Feed CL
015	BK-Lower Feed CL
020	Duplex Inv M- Rev

Num.	Component	
021	Duplex Inv M- Fwd	
024	Duplex Inv M- Hold	
026	Polygon M	
027	Polygon M/LD	
028	LD	
029	DF-Feed M	
030	DF-Transport M	
031	DF-Feed CL	
034	DF-Gate SOL (Junction Gate Solenoid)	
038	Fusing SOL	

When checking Fan Motor High (005) or Fan Motor Low (006) note the following:

- These motors may not respond when the fusing temperature is high.
- Selecting "ON" checks that one of these motors normally operates. Selecting "OFF" turns off the motor that you have started by selecting "ON." However, this does not guarantee that the motor normally stops during normal operation.

5.1.4 PRINTER SERVICE MODE

Service Mode Table

1001	Bit Sv	Bit Switch					
001	Bit Sw	ritch 1	0	1			
	bit 0	DFU	-	-			
	bit 1	DFU	-	-			
	bit 2	DFU	-	-			
	bit 3	No I/O Timeout	0: Disable	1: Enable			
		Enables/Disables MFP I/O Timeouts. Enabled: The MFP I/O Timeout setting will have no affect. I/O Timeouts will never occur.					
	bit 4	SD Card Save Mode	0: Disable	1: Enable			
		Enabled: Print jobs will be saved to an SD Card in the GW SD slot (Card Save Function" in the service tables of Field Service Manual).					
	bit 5	DFU	-	-			
	bit 6	DFU	-	-			
	bit 7 [RPCS,PCL]: Printable area frame border		0: Disable	1: Enable			
	Enable: The machine prints all RPCS and PCL jobs with a border edges of the printable area.			border on the			

1001	Bit Sv	Bit Switch					
002	Bit Sw	vitch 2	0	1			
	bit 0	DFU	-	-			
	bit 1	DFU	-	1			
	bit 2			Normal Collate			
		A collation type (shift or normal) will be applied to all jobs that do not already have a 'Collate Type' configured. • Note • If #5-0 is enabled, this Bit Switch has no effect.					
	bit 3	[PCL5e/c,PS]: PDL Auto Switching	0: Enable	1: Disable			
	Disabled: The MFPs ability to change the PDL processor mid-job. Some host systems submit jobs that contain both PS and PCL5e/o PDL switching is disabled, these jobs will not be printed properly.			PCL5e/c. If Auto			
	bit 4 DFU -		-				
bit 5 DF		DFU	-	-			
	bit 6	DFU	-	-			
	bit 7	DFU	-	-			

1001	Bit Switch					
003	Bit Sw	itch 3	0	1		
	bit 0	DFU	-	-		
	bit 1	DFU	-	-		
	bit 2	[PCL5e/c]: Legacy HP compatibility	0: Disable	1: Enable		
		Enabled: Uses the same left margin as older HP models such as HP4000/HP8000. In other words, the left margin defined in the job (usually " <esc>*r0A") will be changed to "<esc>*r1A"</esc></esc>				
	bit 3	DFU	-	-		
	bit 4	DFU	-	-		
	bit 5	DFU				
	bit 6	DFU				
	bit 7	DFU	-	-		

1001	Bit Switch		
00	Bit Switch 4 DFU	-	-

1001	Bit Switch					
005	Bit Sw	ritch 5	0	1		
	bit 0	DFU	-	-		
	bit 1 Multiple copies if a paper size or type mismatch occurs		Disabled (single copy)	Enabled (multiple)		
		If a paper size or type mismatch occurs during copies, only a single copy is output by default can be configured to print all copies even if a	. Using this B	itSw, the device		
	bit 2	DFU	-	-		
	bit 3 [PS] PS Criteria		Pattern3	Pattern1		
	Change the number of PS criterion used by the PS interpreter to determine whether a job is PS data or not. Pattern3: includes most PS commands. Pattern1: A small number of PS tags and headers			eter to		
	bit 4 Increase max number of the stored jobs to 1000 jobs.		Disable (100)	Enable (1000)		
	Enabled: Changes the maximum number of jobs that can be sto HDD via Job Type settings to 1000. The default is 100.			pe stored on the		
	bit 5	DFU	-	1		
	bit 6	Method for determining the image rotation for the edge to bring on	Disable	Enable		
Enabled: The image rotation will be performed as they we specifications of older models for the binding of pages of r jobs. The old models are below: -PCL-: Pre-04A models						

SM Appendix 5-137 D067/D068/D069/D072

	bit 7	Letterhead mode printing	Disable	Enable (Duplex)
		Routes all pages through the duplex unit. If the or the last page of an odd-paged duplex job, a duplex unit. This could result in problems with pages.	are not routed	d through the

\Rightarrow	1001	Bit Switch						
	006	Bit Switch	Bit Switch 6 0 1					
			Make By-Pass printer priority tray		Enable			
	bit 0	hit O	If enabled, the Bypass tray will be included in	(Default)				
			auto tray selection and be the printer priority					
			tray					
		bit 1~7	DFU	-	-			

1001	Bit Switch		
007	Bit Switch 7 DFU	-	-

1001	Bit Swite	Bit Switch				
008	Bit Switc	Bit Switch 8		1		
	bit 0~7	DFU	-	-		

1003	Clear Setting	Not used
1004	Print Summary	Prints the service summary sheet (An error log is printed in addition to the configuration page).
1005	Display Version	Displays the version of the controller firmware.
1006	Sample/Locked print	0: Link with Doc., 1: On Enables and disables the document server. When you select "0" the document server is enabled or disables in accordance with copy service mode SP5-967. When you select "1" the document server is enabled regardless of service mode SP5-967.

SP Modes Related to Printer Controller

The following SP modes are located in the copier SP mode. Refer to section 5.1 of the main unit service manual.

SP No.	Description	Function and Setting
5801	Memory All Clear	Resets data for process control and all software counters, and returns all modes and adjustments to their defaults values. Section "Memory Clear" in this chapter for details.
5907	Plug & Play	Selects the brand name and the production name for Windows Plug & Play. This information is stored in NVRAM.
7832	Detailed Display of Self-Diagnostics	Displays the controller self-diagnostic result.

5.1.5 SCANNER PROGRAM MODE TABLE

Service Table Key

Notation	What it means	
[range / default / step] Example: [-9 to +9 / +3.0 / 0.1 mm step]. The setting can be add in the range ±9, value reset to +3.0 after an NVRAM reset, and value can be changed in 0.1 mm steps with each key press.		
italics	Comments added for your reference.	
*	This value is stored in NVRAM. After a RAM reset, the default value (factory setting) is restored.	
DFU	Denotes "Design or Factory Use". Do not change this value.	

SP1	Mode Number		Function and [Setting]
1001* 5 Scan NV Version		Scan NV Version	Displays the scanner NV version. This shows as following: Function name _ Model name _ Version
1004*	1	Compression Type	Selects the compression type for binary picture processing. [1: MH, 2: MR, 3: MMR]
1005*	1	Erase Margin	Creates an erase margin for all edges of the scanned image. If the machine has scanned the edge of the original, create a margin. [0 to 5 / 0mm / 1mm step]
1009*	1	Remote Scan disable	Enables or disables the network TWAIN scanner function. 0: enable, 1: disable

1012	1	User Info Release	Clears or does not clear a user information after a job. [0 or 1 / 1 / -] 0: Not clear, 1: Clear
1013	1	Multi Media Func	Display or not display a "Scan To Multi Media" function. [0 or 1 / 1 / -] 0: OFF, 1: ON

SP	Number/Name	Function and [Setting]	
	Compression level (grayscale or full color)		
2021	These SP codes set the compression ratio for the grayscale or full color processing mode that can be selected with the notch settings on the operation panel. Range: 5 (lowest ratio) \longleftrightarrow 95 (highest ratio)		
1	Comp1: 5-95 (Middle I-Qual)	[5 to 95 / 20 /1/step]	
2	Comp2: 5-95 (High I-Qual)	[5 to 95 / 40 /1/step]	
3	Comp3: 5-95 (Low I-Qual)	[5 to 95 / 65 /1/step]	
4	Comp4: 5-95 (Highest I-Qual)	[5 to 95 / 80 /1/step]	
5	Comp5: 5-95 (Lowest I-Qual)	[5 to 95 / 95 /1/step]	

For the settings of the image quality, see the copier SP-mode table.

5.2 SYSTEM SERVICE MODE (BASIC: D067/D072)

5.2.1 SERVICE MODE TABLES

SP1-XXX (Feed)

1001*	LE Registration	[-9.0 to 9.0 / 0.0 / 0.1 mm/step]
1001 1	All Trays	Adjusts the leading-edge registration
1001 2	By-pass	("Adjusting Copy Image Area" in the section
1001 3	Duplex	"Replacement and Adjustment").

1002*	S-to-S Regist	[-9.0 to 9.0 / 0.0 / 0.1 mm/step]
1002 1	1st Tray	Adjusts the side-to-side registration (
1002 2	2nd Tray	"Adjusting Copy Image Area" in the section "Replacement and Adjustment"). SP1-002-001
1002 3	3rd Tray	is applied to all trays. SP1-002-002, 003 and
1002 5	By-pass	005 adjusts the difference from SP1-002-001.
1002 6 Duplex	Adjusts the side-to-side registration of the 2nd side in duplex copying. The 1st side is adjusted by SP1-002-001 through 005.	

1003*	Paper Feed Timing	Adjusts the amount of paper buckle on the registration roller.
1003 1	1st tray	[0 to 10 / 5 / 1 mm/step]
1003 3	Bank Trays	[0 to 10 / 5 / 1 mm/step]
1003 4	By-pass	[0 to 10 / 5 / 1 mm/step]
1003 5	Duplex	[0 to 20 / 5 / 1 mm/step]

1103*	Fusing Idling		[0 = No / 1 = Yes]	
	Enables or disables the contact-release control. The following table lists the results.			e following table lists the
	Setting		0 = No	1 = Yes
1103 1	C-R control		Works	Does not work
	Idling time		Shorter	Longer
	Fusing quality		Lower	Higher

1105*	Fusing Temp Adj		
	Adjusts the target fusing temperature. Note that the thermistor is at the center of the hot roller.		
1105 1	Warm Up-Center	[140 to 180 / 160 / 1°C/step]	
1105 3	Standby-Center	[140 to 160 / 150 / 1°C/step]	
1105 5	Copying-Center	[140 to 180 / 160 / 1°C/step]	
1105 7	Low Level 2-Center	[0 to 80 / 60 / 1°C/step]	
1105 9	Thick-Center	[140 to 185 / 165 / 1°C/step]	

1106 Display Fusing		Display Fusing
1106 1 (Center and Leading edge) Displays the fusing		(Center and Leading edge) Displays the fusing temperature.

	Fusing Soft Start DFU		
1107*	Adjusts the number of zero-cross cycles of the fusing lamp AC supply needed to bring the fusing lamp power to 100% while bringing the lamp up to the standby temperature or while copying. Increase this value if the machine is experiencing sudden power dropouts.		
1107 1	Warm Up Soft Start	[0 = 10 times / 1 = 20 times / 2 = 50 times]	
1107 2	Other Soft Start	[0 = 10 times / 1 = 20 times / 2 = 50 times / 3 = 1 time]	
1107 3	Soft Stop Setting	[0: No / 1: Yes]	

1108*	Set	-Fusing Start	[0 = 1s / 1 = 1.5s / 2 = 2s]
1108	1 Spe	Specifies the interval for fusing-temperature control.	

	1109	Nip Band Check	
Conducts the nip band check ("Adjusting Nip Band "Replacement and Adjustment").		Conducts the nip band check ("Adjusting Nip Band" in the section "Replacement and Adjustment").	

1110*	Fan Control Timer	[30 to 60 / 30 / 1 s/step]
1110 1	specified time before changi	e. The fan motor keeps its operating speed for the ng the speed or stopping. The fan control timer m suddenly stopping. This function protects the

SM Appendix

1159*	Fusing Jam SC	[0 = No / 1 = Yes]
1159 1	set to "1" (default: 0), consec	utive jam detection at the fusing unit. If this SP is cutive fusing jam alarm occurs (SC559) when the ecutive paper jams at the fusing unit.

1902	Display-AC Freq.	
1902 1	Displays the fusing lamp power control frequency (as detected by the zero cross signal generator). The displayed value is 1/5 the actual frequency: 10 and lower = 50 Hz, 11 and higher = 60 Hz.	

1911*	By-pass Envelope	[0 = No / 1= Yes]
1911 1	program (SP1-911-001) and	nvelope printing runs when you enable this you select "Thick Paper" as the paper type of the Settings > Tray Paper Settings > Paper Type:

System Service Mode (Basic: D067/D072)

SP2-XXX (Drum)

2001*	CR Bias Adj	
	Printing	[-2100 to -1500 / -1650 / 1 V/step]
2001 1	Adjusts the voltage applied to the charge roller for printing. The voltage changes automatically as charge-roller voltage control works. The value here is the base value for the charge-roller voltage control.	
	ID sensor pattern	[0 to 400 / 300 / 1 V/step]
2001 2	Adjusts the voltage applied to the charge roller for the ID sensor pattern (as part of charge-roller voltage correction). The charge-roller voltage is obtained by adding SP2-001-002 to the value of SP2-001-001.	

2101*	Erase Margin Adj	Adjusts the width of the erased area ("Adjusting Copy Image Area" in the section "Replacement and Adjustment").
2101 1	Leading Edge	[0.0 to 9.0 / 3.0 / 0.1 mm/step] Specification: 2 ± 1.5 mm
2101 2	Trailing Edge	[0.0 to 9.0 / 4.0 / 0.1 mm/step] Specification: 2 +2.5/–1.5 mm
	The rear trailing edge is this value plus 1.2 mm.	
2101 3	Left side	[0.0 to 9.0 / 2.0 / 0.1 mm/step] Specification: 2 ± 1.5 mm
	The rear left edge is this value plus 0.3 mm.	
2101 4	Right side	[0.0 to 9.0 / 2.0 / 0.1 mm/step] Specification: 2 +2.5/–1.5 mm
	The rear right edge is this value plus 0.3 mm.	

2201*	Dv Bias Adj	
	Printing	[-1500 to -200 / -650 / 1 V/step]
2201 1	Adjusts the voltage applied to the development roller for printing. Image density becomes higher when you specify a smaller value (a greater absolute value). Image density becomes lower when you specify a greater value (a smaller absolute value).	
	ID sensor pattern	[-2 = LL (220 V) / -1 = L (260 V) / 0 = N (300 V) / 1 = H (340 V) / 2 = HH (380 V)]
2201 2	Adjusts the voltage applied to the development roller for the ID sensor pattern. The voltage applied is obtained by adding SP2-201-002 to SP2-201-1. The setting affects ID sensor pattern density, which in turn affects the toner supply.	

2213*	Outputs After NE
2213 1	[0 = 50 pages / 1 = 20 sheets] Sets the number of copy/print/fax pages that can be made after toner near-end has been detected. Reduce the number of pages if the user normally makes copies with a high image ratio.

2214	Develpr Initialize
2214 1	Initializes the TD sensor toner supply target voltage and the TD sensor gain value. Execute this SP replacing the developer or the TD sensor.

System Service Mode (Basic: D067/D072)

2221	ID Error Analysis ("ID Sensor Error Analysis (SP2-221)")	
2221 1	Vsg	Displays the Vsg value.
2221 2	Vsp	Displays the Vsp value.
2221 3	PWM	Displays the PWM value.
2221 4	Vsdp	Displays the Vsdp value.
2221 5	Vt	Displays the Vt value.
2221 6	Vts	Displays the Vts value.

2301*	Tr Current Adj (🖝 "Image Transfer Current").	
	Normal paper	[$-2 = -4 \mu A / -1 = -2 \mu A / 0 = 0 \mu A / 1 = 2 \mu A / 2$ = $+4 \mu A$]
2301 1	Adjusts the current applied to the transfer roller when feeding from a paper tray. Use a high setting if the user normally feeds relatively thick paper (within spec) from a paper tray	
	Thick/Special	[$-2 = -4 \mu A / -1 = -2 \mu A / 0 = 0 \mu A / 1 = 2 \mu A / 2$ = $+4 \mu A$]
2301 2	Adjusts the current applied to the transfer roller when feeding from the by-pass tray. Use a high setting (a) if the user normally feeds relatively thick paper from the by-pass tray, or (b) if waste toner is re-attracted from the drum (which can occur when using transparencies).	

	Duplex	[$-2 = -4 \mu A / -1 = -2 \mu / 0 = 0 \mu A / 1 = 2 \mu A / 2 = +4 \mu A$]
2301 3	Adjusts the current applied to the transfer roller when carrying out a duplex job. Use this SP if there is poor image transfer on the rear side of duplex copies.	
	Cleaning	[–10 to 1 / –1 / 1 μA/step]
2301 4	Adjusts the current applied to the transfer roller for roller cleaning. Increase the current if toner remains on the roller after cleaning. (Remaining toner may cause dirty background on the rear side.)	

2802	Forced Develpr Churn	
2802 1	Initializes the developer and checks the TD sensor output (Vt). The machine mixes the developer for 2 minutes while reading and displaying the Vt value. The machine does not initialize the TD sensor output. If the machine has not been used for a long period, prints may have a dirty background. In a case like this, use this SP to mix the developer. The message "Completed" is displayed when the program ends normally.	

2906*	Tailing Crctn	
	Shift value	[0.0 to 1.0 / 0.0 / 0.1 mm/step]
2906 1	Shifts the image position at the intervals specified by SP2-906-002. When copier is continuously printing vertical lines (such as in tables), the paper not separate correctly. This SP can prevent this.	
2906 2	Interval	[1 to 10 / 1 / 1 page/step]
2000 2	Changes the interval of the image position shift specified by SP2-906-001.	

2908	Forced Toner Supp	
2908 1	Supplies the toner to the development unit. The processing stops under either of the following conditions: The toner density in the development unit reaches the standard level. The processing has continued for two 2 minutes.	

2915*	Polygon Idling	[0 = None / 1 = 15 s / 2 = 25 s]
2915 1	starts its operation when an cover or DF is opened. The	motor idling time. The polygon mirror motor original is set, a key is pressed, or the platen motor stops if no manual operation is performed you set "0", the motor does not stop while the us.

2921*	* Toner Supply Mode	
2921 1	[0 = Sensor 1 / 1 = Sensor 2 (DFU)] Selects the toner supply mode. Keep the default setting as long as the TD sensor is working.	

2922*	Toner Supply Time	[0.1 to 5.0 / 0.6 / 0.1 s/step]
2922 1	specified time. To validate th	e. The toner supply motor remains on for the his setting, select "0" in SP2-921-001. Specify a ds to make many copies having high proportions

2926*	Standard Vt	[0.00 to 5.00 / 2.50 / 0.01 V/step] DFU
2926 1	,	new developer). The TD sensor output is the TD sensor initial setting process. This SP is 1001 is "0", "1", or "2".

2927*	ID Sensor Control	[0 = No / 1 = Yes]
2927 1	Determines whether the ID sensor signal is referenced or not for the toner density control. Keep the default value in usual operations.	

2928	Toner End Clear	
2928 1	Clears the following messages and counters without supplying the toner: Toner near end message Toner end message Toner near end counter Toner end counter on not use this SP in usual operations. When the toner in the development unit is abnormally insufficient, the drum may attract the toner carrier to its surface. The toner carrier damages the drum surface	

2929*	Vref Limits	Adjust the upper or lower Vref limit.
2929 1	Upper	[0.50 to 3.50 / 3.20 / 0.01V/step] DFU
2929 2	Lower	[0.50 to 3.50 / 0.70 / 0.01V/step] DFU

2994*	ID Detect Temp	[30 to 90 / 30 / 1 °C/step]
2994 1		eshold. The ID sensor signal is not referenced e is at the specified level or higher while the ng up.

System Service Mode (Basic: D067/D072)

2996*	T Roller Cleaning	[0 = No / 1 = Yes]
2996 1	backside of the paper becor	e transfer roller before each job. Select "1" if the mes unclean when output. Note that the copier t the first copy when you select "1". If you select er cleaned.

2998*	Main Mag- print	[-0.5 to +0.5 / 0.0 / 0.1%/step]
2998 1	Adjusts the magnification ("Adjusting Copy Image Area" in the section "Replacement and Adjustment"). The specification is 100 ± 1.0%.	

SP4-XXX (Scanner)

4008*	Sub-Scan Magnification (Scanner) [-0.9 to +0.9 / 0.0 / 0.1%/s	
4008 1	Adjusts the sub-scan magnification (section "Replacement and Adjustment").	

4009*	Main Scan Magnification (Scanner) [-0.9 to +0.9 / 0.0 / 0.1%/ste	
4009 1	Adjusts the main-scan magnification (section "Replacement and Adjustment").	

4010*	Leading Edge Scan Registration	[-5.0 to +5.0 / 0.0 / 0.1 mm/step]
4010 1	Adjusts the leading edge registration (section "Replacement and Adjustment"	"Adjusting Copy Image Area" in the").

4011*	Side-to-side Scan Regist	[-2.0 to +2.0 / 0.0 / 0.1 mm/step]
4011 1	Adjusts the side-to-side registration for "Adjusting Copy Image Area" in the sec	scanning in platen mode (ction "Replacement and Adjustment").

4012*	Scan Erase Margin	[0 to 9.0 / 1.0 / 0.1 mm/step]
4012 1	Leading edge	
4012 2	Trailing edge	Adjusts the scanning margin. Generally, the scanning margin should be as little as possible
4012 3	Left Side	To adjust the image area, use SP2-101.
4012 4	Right Side	

4	1013	Scanner Free Run
	4013 1	Conducts the scanner free run with the exposure lamp on.

4015*	White Plate Scan	
	Start position	[-3.0 to +6.0 / 0.0 / 0.1 mm/step]
Adjusts the scanning start position on the white plate. The base v mm from the scanner home position. This SP specifies the offset base value.		•
	Scanning Length	[-3.0 to +6.0 / 0.0 / 0.1 mm/step]
4015 2 position (SP4-015-001) and ends at the		white plate scan. The scan begins from the start ends at the specified distance. The base value is e offset from this base value. Specify 0 (zero) or a

4428	Scan Auto Adjustment	
4428 1	Conducts the automatic scanner adjustment. Use this SP after replacing the white plate ("Scanning" in the section "Replacement and Adjustment").	

4450	Image Path	
001	BK Offset Enable	[0 or 1 / 1 / -] 0: OFF, 1: ON
001	Uses or does not use the black reduction image path.	
002	SH Path Enable	[0 or 1 / 0 / 1 /step] 0: No, 1: Yes
002	Uses or does not use the shading image path.	

4606	SBU Offset-Target	
4607 1	EVEN	
4607 2	ODD	[0 to 63 / 10 / 1 /step]
4607 3	RED	Adjusts the target black level for each signal.
4607 4	GREEN	These are used for offset adjustment in the SBU.
4607 5	BLUE	

4607	SBU Gain-Target	
4607 1	EVEN	
4607 2	ODD	[0 to 255 / 180 / 1 /step] Adjusts the target white level for each signal. These are used for gain adjustment in the SBU.
4607 3	RED	
4607 4	GREEN	
4607 5	BLUE	

4623	SBU Offset-Result	
4623 1	EVEN	
4623 2	ODD	[0 to 255 / 0 / 1 /step] Displays the result value of the offset adjustment in the SBU.
4623 3	RED	
4623 4	GREEN	
4623 5	BLUE	

4628	SBU Gain-Result	
4628 1	EVEN	
4628 2	ODD	[0 to 255 / 0 / 1 /step]
4628 3	RED	Displays the result value of the gain adjustment
4628 4	GREEN	in the SBU.
4628 5	BLUE	

4640	SBU Offset-Loop	
4640 1	EVEN	
4640 2	ODD	[0 to 10 / 0 / 1 /step]
4640 3	RED	Displays the number of the offset adjustment in
4640 4	GREEN	the SBU.
4640 5	BLUE	

4641	SBU Gain-Loop	
4641 1	EVEN	
4641 2	ODD	[0 to 10 / 0 / 1 /step]
4641 3	RED	Displays the number of the gain adjustment in
4641 4	GREEN	the SBU.
4641 5	BLUE	

4642	SBU Offsetpre-Loop	
4642 1	EVEN	
4642 2	ODD	[0 to 3 / 0 / 1 /step]
4642 3	RED	Displays the number of the pre-offset adjustment
4642 4	GREEN	in the SBU.
4642 5	BLUE	

4646	SBU Adj Error	
4646 1	Offsetpre-Mono	
4646 2	Offsetpre-Color	
4646 3	Offset-Mono	[0 = Success / 1 = Failure]
4646 4	Offset-Color	Displays the result of SBU adjustment.
4646 5	Gain-Mono	
4646 6	Gain-Color	

4654*	SBU Offset-Adjust	
4654 1	EVEN	
4654 2	ODD	[0 to 255 / - / 1 /step]
4654 3	RED	Displays the offset value of the offset adjustme
4654 4	GREEN	in the SBU.
4654 5	BLUE	

4658*	SBU Gain-Adjust	
4658 1	EVEN	
4658 2	ODD	[0 to 511 / - / 1 /step]
4658 3	RED	Displays the gain value of the gain adjustment in
4658 4	GREEN	the SBU.
4658 5	BLUE	

4685*	Gray Balance-Book	
4685 1	RED	[128 to 383 / 256 / 1 /step]
4685 2	GREEN	Adjusts the coefficient of the gray balance
4685 3	BLUE	adjustment for the book scanning.

4686*	Gray Balance-DF	
4686 1	RED	[128 to 383 / 256 / 1 /step]
4686 2	GREEN	Adjusts the coefficient of the gray balance
4686 3	BLUE	adjustment for the DF scanning.

4687*	White Balance	
4687 1	Adjust	[222 to 281 / 256 / 1 /step] Adjust the correction value for the white plate adjustment.
4687 2	Result	Displays the current value of the white plate adjustment. If SP4-428 has not been done, this value is "0".

4690	White Peek Init	
4658 1	EVEN	
4658 2	ODD	[0 to 255 / - / 1 /step]
4658 3	RED	Displays the white offset value of the pre-offset
4658 4	GREEN	adjustment in the SBU.
4658 5	BLUE	

4693	Black Peek Init	
4658 1	EVEN	
4658 2	ODD	[0 to 255 / - / 1 /step]
4658 3	RED	Displays the black offset value of the pre-offset
4658 4	GREEN	adjustment in the SBU.
4658 5	BLUE	

4902*	Exposure Lamp ON	[0 : OFF / 1: ON]
4902 1	Turns the exposure lamp or to turn it off specify "0".	or off. To turn on the exposure lamp, specify "1";

4903*	ADS Level	[0 to 255 / 252 / 1/step]
4903 1	Adjusts the ADS level.	

4904*	ADS Lower Limit	[0 to 255 / 80 / 1/step]
4904 1	Adjusts the ADS lower limit.	

4905*	ADS Area Select	[0 = All / 1 = One]
4905 1	Checks the whole area (0 = ADS level. The specific area ARDF: ±37.5 mm from Platen Cover: 15 to 90	the center

4921* Image Adj Selection		
Copy [0 to 10 / 0 / 1/step]		[0 to 10 / 0 / 1/step]
4921 1	0 = None, 1 = Text 1, 2 =Te	tings from SP4-922 to SP4-932 are used for. xt 2, 3= Photo 1, 4 = Photo 2, 5 = Photo 3, , 8 = Special 3, 9 = Special 4, 10 = Special 5

4922*	Scanner Gamma	[0=System default/1=Text/2=Photo]
4922 1	Сору	Selects "text" or "photo" as the priority output mode. This setting is applied to all image processing modes of SP4-921.

	Notch Selection	
4923*	Selects the value of the center ID adjustment notch for the ID adjustment LEDs. Normally the center notch is 3 (range 1-5). If -1 is selected, each notch shifts down (becomes lighter). If +1 is selected, each notch shifts up (becomes darker). This setting is applied to all image processing modes of SP4-921.	
4923 1	Copy [-1 = Light / 0 = Normal / +1 = Dark]	

	Texture Removal	
4926*	default value for each modhave a default of 3 and Ph 1: No removal applied. 2 – 6: Removal applied at	al level that is used with error diffusion. 0: The de is used. Text 1, Photo 2, Special 2, and Special 5 noto 1, 3 have a default of 6. the level specified here. The higher the setting mage will become (more texture removal). This he originals in SP4-921.
4926 1	Сору	[0 to 6 / 0 / 1/step]

	Line Width Correction	
Adjusts the line width correction algorithm. Positive settings prod lines; negative settings produce thinner lines. This setting is only the originals in SP4-921.		
4927 1	Сору	[-2 to 2 / 0 / 1/step]

	Independent Dot Erase	
4928*	Selects the dot erase level. Higher settings provide greater erasure. This setting is only applied to the originals in SP4-921.	
4928 1	Copy [-2 to 2 / 0 / 1/step]	

4929*	Positive/Negative	[0 = No, 1 = Yes]
4929 1	Сору	Inverts white and black. This setting is only applied to the originals in SP4-921.

4930*	Sharpness-Edge	[-2 to 2 / 0 / 1/step]
4930 1	Сору	Adjust the clarity. This setting is only applied to the originals in SP4-921.

4931*	Sharpness-Solid	[-2 to 2 / 0 / 1/step]
4931 1	Сору	Adjust the clarity. This setting is only applied to the originals in SP4-921.

4932*	Sharpness-Low ID	[-2 to 2 / 0 / 1/step]
4932 1	Сору	Adjust the clarity. This setting is only applied to the originals in SP4-921.

4941*	White Line Erase	[0 to 2 / 1 / 1/step]
4941 1		ng

4942*	Black Line Erase	[0 to 3 / 2 / 1/step]
4942 1	are scanned by the DF. [0 = No / 1 = Very weak / 2	e level. This setting is effective only when originals = Weak / 3 = Strong] rdless of what mode has been selected in

SP5-XXX (Mode)

5001	All Indicators On	
5001 1	Turns on all LEDs. The LCD turns on or off every 3 seconds. Press the reset key to end this program.	

5045*	Display-Counter	[0 or 1 / 0 / -] 0: 1 counter, 1: 2 couters
5045 1	Displays the number of the installed couter.	

5113*	Optional Counter Type	0: None 1: Key Card20+ 2: Key Card20– 11: Key Card4+ 12: Key Card4–
5113 1	Selects the corresponding key for installed devices such as coin lock.	

5120*
5120 1

5121*	Count Up Timing	[0 = Feed In / 1 = Exit]
5121 1	Selects the count-up timing 0 = Feed: At each paper 1 = Exit: At each paper	er feed

5501*	PM Alarm Interval	[0 to 9999 / 0 / 1K copies/step]
5501 1	Printout	Specifies when the PM alarm occurs.

\Rightarrow	5801	Memory Clear (basic model only) (Refer to IMPORTANT NOTE in Sect 6.3	
	5801 2	Engine ("Memory Clear" in this section)	

5802	Machine Free Run
5802 1	Conducts machine free run (including the scanner unit). Press "ON" to start; press "OFF" to stop.

5803	Input Check
	■ "Input Check" in this section.

5804	Output Check
	"Output Check" in this section.

5807*	Area Selection	
5807 1	Selects the display language. 2 North America, 3 Europe, 5 Asia, 6 China SP5-807-001 is not cleared by SP5-801-002. NOTE: SC982 is displayed if you specify a language that is inconsistent with your local model.	

5811*	Serial Num Input
5811 1	Serial Number Input" in this section.

5812*	Service TEL	
	Telephone	
5812 1	Specifies the telephone number of the service representative. (The number is displayed when a service call condition occurs.) To input a dash, press ③. To delete the current telephone number, press ⑤.	
	Facsimile	
5812 2	Specifies the fax number printed on user counter reports. To input a dash, press ③. To delete the current fax number, press ⑤.	

5824 NVRAM Upload		NVRAM Upload
	5824 1	"NVRAM Upload/Download" in this section.

5825 NVRAM Download		
5825 1	■ "NVRAM Upload/Download" in this section.	

5827	Program Download ("Firmware Update Procedure" in this section)	
5827 1	Copy the software program from the IC card to the flash ROM. To execute this SP, (1) turn off the main power switch, (2) insert the IC card, (3) press the power key and hold it down, and (4) turn on the main power switch (while you keep holding the power key). The copier reads the software program from the IC card if you turn on the copier like this. The SP mode is automatically activated.	

5901 Printer Free Run	
5901 1 Executes the free run. Press "ON" to start; press "OFF" to stop.	

5902	Test Pattern Print
5902 1	Test Pattern Print" in this section.

5907*	Plug & Play Setting	
5907 1	Selects the brand name and production name for the Plug and Play function. These names are stored in the NVRAM. When the NVRAM data is corrupted, select these names once again. Use the right-arrow or left-arrow key to scroll through the list of brand names. To select a brand name, press the OK key. An asterisk (*) indicates which manufacture is currently selected.	

5912*	PCU Alarm Counter (Printout)	[0 to 255 / 45 / 1/step]
5912 1	condition is met: PAc x 1000 >= PCUc	PCU alarm is issued when the following this SP and PCUc is the PCU counter. J alarm is deactivated.

×	Ф	
	ਰ	S
Ĭ	9	픚
a	_	퓽
d١	Ŗ	
Q		

5990 1	All	
5990 2	SP	
5990 3	User Program	SMC Print" in this section.
5990 4	Logging Data	
5990 5	Big font	

5990

SMC Print

SP6-XXX (Peripherals)

6006*	ADF Adjustment ("DF Image Adjustment" in the "Adjusting Copy Image Area") NOTE: Available menus depend on the machine model and its configuration.		
	StoS/Front Regist	[-5.0 to +5.0 / 0.0 / 0.1 mm/step]	
6006 1	Adjusts the side-to-side registration mode. Use the \$\partial \text{key to select "+"}	for the front side of the original, for ARDF or "-" before entering the value	
	Leading Regist	[-5.0 to +5.0 / 0.0 / 0.1 mm/step]	
6006 2	Adjusts the leading edge registration for ARDF mode. Use the key to select "+" or "-" before entering the value.		
	Trailing Erase	[-3.0 to +3.0 / -1.5 / 0.1 mm/step]	
6006 3	Adjusts the trailing edge erase margin for ARDF mode. Use the select "+" or "-" before entering the value.		
	S to S/ Rear Regist	[-5.0 to +5.0 / 0.0 / 0.1 mm/step]	
6006 4	Adjusts the side-to-side registration for the 2nd side of the original, for ARDF mode. Use the \$\infty\$ key to select "+" or "-" before entering the value		
6006 5	Sub-scan Magnif	[-0.9 to +0.9 / 0.0 / 0.1 %/step]	
00000	Adjusts the sub-scan magnification for the ARDF.		
	Origin Curl Adj	[0 = No / 1 = Yes]	
6006 6	Turns on or off the skew correction at 2nd side scanning. This SP is activated only when the duplex mode is selected.		
	Skew Correction	[-20 to +20 / 0.0 / 1 mm/step]	
6006 7	Adjusts the original buckle for the skew correction at 2ns side scanning. This SP is activated only when SP6-006-006 is set to "1 (Yes)".		

	Ψ.	10
o	\simeq	g
U	2	~
0	М	9
d	0	$\boldsymbol{\sigma}$
d		
1	Ų	

6009	ADF Free Run	
	Duplex Mode	
6009 1	Performs an ARDF free run in duplex scanning mode. Press "ON" to start; press "OFF" to stop.	
	Simplex Mode	
6009 3	Performs an ARDF free run at simplex scanning mode. Press "ON" to start; press "OFF" to stop.	

69	10*	ADF Shading Time	[0 to 60 / 30 / 1 s/step]
	6910 1	and heat in the room may a	or the shading processing in the ARDF mode. Light affect the scanner response. Reduce this setting if the white level is drifting during ARDF copy jobs.

SP7-XXX (Data Log)

7001*	Total Operation		
7001 1	Displays the total operation	n time (total drum rotation time).	
7401*	Counter–SC Total	[0 to 9999 / 0 / 1/step]	
7401 1	Displays how many times S	SC codes are generated.	
7403*	SC History		
7403 1	Displays the histories of the	e latest 10 SC codes.	
7502*	Counter-Paper Jam [0 to 9999 / 0 / 1/step]		
7502 1	Displays the total number of copy paper jams.		
7503*	Counter–Orgn Jam	[0 to 9999 / 0 / 1/step]	
7503 1	Displays the total number of original jams,		
7504*	Counter-Each P Jam	[0 to 9999 / 0 / 1/step]	
	Displays the total number of the paper jams classified by timing and location.		
7504 1	At power on		
75041	Paper jam occurs at power on.		
7504 10	Off-Regist NoFeed		
7504 10	Paper does not reach the registration sensor (from a paper tray).		

7504 11	Off-1 Vertical SN
	Paper does not reach the relay sensor.
7504 12	On-1 Vertical SN
7.001.12	Paper is caught at the relay sensor.
7504 21	Vertical SN: OFF
7.001.21	Paper does not reach the vertical transport sensor.
7504 22	Vertical SN: ON
700122	Paper is caught at the vertical transport sensor.
7504 50	Off-Regist Bypass
700100	Paper does not reach the registration sensor (from the by-pass tray).
	Off-Regist Duplex
7504 60	Paper does not reach the registration sensor during reverse-side printing (for duplex printing).
7504 70	On-Regist SN
750470	Paper is caught at the registration sensor.
7504 120	On-Exit SN
7004 120	Paper is caught at the exit sensor (previous page).
7504 121	Off-Exit SN
7004 121	Paper does not reach the exit sensor.
7504 122	On-Exit SN
1001122	Paper is caught at the exit sensor.

7504 123	Off-Dup Inverter	
1		Paper does not reach the duplex inverter sensor (from the registration roller).
	7504 125	On-Dup Inverter
	7007 120	Paper is caught at the duplex inverter sensor.

	Counter-Each O Jam	[0 to 9999 / 0 / 1/step]	
7505*	Displays the total number of original jams by location. These jams occur when the original does not activate the sensors. Note Lag. Jam occurs when the paper remains at the sensor for longer than the prescribed time. Late: Jam occurs because paper fails to arrive at the prescribed time.		
210	Regist SN: OFF	·	
211	Regist SN: ON		
212	Paper Exit SN: OFF		
213	Paper Exit SN: ON		
214	Inverter: OFF		
215	Inverter: ON		

7507*	Dsply-P Jam Hist				
001	Lastest				
002	Latest 1	Displays the co	py jam his	tory (the most recent	10 jams)
003	Latest 2	Sample Display	:		
004	Latest 3	SIZE:05h			
005	Latest 4	TOTAL:000033		50 2000	
006	Latest 5	where:	DATE: Mon Mar 15 11:44:50 2000 where:		
007	Latest 6	CODE is the SP7504-*** number (see above. SIZE is the ASAP paper size code in hex. TOTAL is the total jam error count (SP7502)			
008	Latest 7				
009	Latest 8	DATE is the date the jams occurred.			
010	Latest 9				
Size	Code	Size	Code	Size	Code
A4 (S)	05	A3 (L)	84	DLT (L)	A0
A5 (S)	06	A4 (L)	85	LG (L)	A4
B5 (S)	0E	A5 (L)	86	LT (L)	A6
LT (S)	26	B4 (L)	8D	HLT (L)	AC
HLT (S)	2C	B5 (L)	8E	Others	FF

7508*	Dsply-O Jam History		
001	Last		
002	Last 1	Displays the original jam history (the most recent 10 jams).	
003	Last 2	Sample Display: CODE:007	
004	Last 3	SIZE:05h	
005	Last 4	TOTAL:0000334 DATE: Mon Mar 15 11:44:50 2000	
006	Last 5	where:	
007	Last 6	CODE is the SP7505*** number (see above. SIZE is the ASAP paper size code in hex.	
008	Last 7	TOTAL is the total error count (SP7503)	
009	Last 8	DATE is the date the jams occurred.	
010	Last 9		

7801	Memory/Version/PN	
7801 2	Memory/Version (BICU)	
70012	Displays the version of the BICU board	
7801 15	Printer/Scanner	
	Displays the version of the controller board.	

7803*	Display-PM Count
7803 1	Displays the PM counter.

7804	Reset–PM Counter	
7804 1	Resets the PM counter (SP7-803-001). When the program ends normally, the message "Completed" is displayed.	

7807	Reset–SC/Jam Counters	
7807 1	Resets the SC, paper, original, and total jam counters. When the program ends normally, the message "Completed" is displayed. SP7-807-1 does not reset the following logs: SP7-507 (Display-Paper Jam History) and SP7-508 (Display-Original Jam History).	

7808	Reset-Counters	
7808 1	Resets all counters except for the management counters. The management counters are the counters that are not changed by NVRAM Download (SP5-825-001; "NVRAM Data Upload/Download"). When the program ends normally, the message "Completed" is displayed.	

7810	Reset–Key Op Code		
7810 1	Resets the key operator code. Use SP7-810-1 when the customer has forgotten the key-operator code. If the customer has forgotten the key operator code, a new one can be specified by using: User Tools: System Settings \rightarrow Key Operator Tools \rightarrow Key Operator Code \rightarrow On \rightarrow Enter Key Operator Code. When the program ends normally, the message "Completed" is displayed, if the program ends abnormally, an error message is displayed.		

7832*	Display-Self-Diag	
7832 1	Displays the SC codes and the number of their occurrences. Each number is in the range of 0 to 9999.	

7991*	Dsply-Info Count
	Displays the total operating time or the total number of operations. The time is displayed in the following format: day: hour: minute: second.
	Dsply-Timer Count
7991 1	The total of the time when the main switch is kept on (excluding the time when the safety switch is off).
7991 3	Dsply-ID S Work
	The total of the time when the ID sensor is working.
7991 4	Dsply-Dev Counter
	The total number of paper outputs.
7991 5	Dsply-ID Er Count
	The total number of ID-sensor errors.

7992*	Reset-Info Count	
7992 1	Reset-Timer Count	
	Clears the timer counter (SP7-991-001).	
7992 4	Reset-Dev Count	
	Clears the development counter (SP7-991-004).	
7992 5	Reset-ID Er Count	
. 302 0	Clears the ID sensor error counter (SP7-991-005).	

SP8-XXX (History)

8191*	T: Total Scan PGS	[0 to 9999999 / 0 / 1 sheet/step]
001	Displays the total number of scanned originals. Both sides are counted when the front and reverse sides of an original (fed from the DF) are scanned.	

8192*	C: Total Scan PGS	[0 to 9999999 / 0 / 1 sheet/step]
001		of scanned originals in copy mode. Both sides are dreverse sides of an original (fed from the DF) are

8195*	S: Total Scan PGS	[0 to 9999999 / 0 / 1 sheet/step]
001	' '	of scanned originals in scanner mode. Both sides and reverse sides of an original (fed from the DF)

8221*	ADF Org Feed [0 to 9999999 / 0 / 1 sheet/step]		
001	Front		
001	Displays the total number of scanned front sides of originals fed from the DF.		
002	Back		
002	Displays the total number of scanned 2nd sides of originals fed from the DF.		

8381*	T: Total Prt PGS	[0 to 9999999 / 0 / 1 sheet/step]
001	Displays the print count of all application programs.	

8382*	C: Total Prt PGS	[0 to 9999999 / 0 / 1 sheet/step]
001	Displays the print count of the copier application program.	

SM Appendix 5-177 D067/D068/D069/D072

8384*	P: Total Prt PGS	[0 to 9999999 / 0 / 1 sheet/step]
001	Displays the print count of the printer application program.	

8411*	Prints/Duplex	[0 to 9999999 / 0 / 1 sheet/step]
001	Displays the total count of the duplex printing.	

8422*	C: PrtPGS/Dup Comb	[0 to 9999999 / 0 / 1 sheet/step]	
001	Simplex > Duplex		
002	Duplex> Duplex		
004	Simplex Combine	Displays the total print count of copier application	
005	Duplex Combine	classified by combination/duple type.	
006	2> (2 in 1)		
007	4> (4 in 1)		

8441*	T: PrtPGS/Ppr Size		
8442*	C: PrtPGS/Ppr Size	[0 to 9999999 / 0 / 1 sheet/step]	
8444*	S: PrtPGS/Ppr Size		
-002	A4		
-003	A5		
-005	B5		
-007	LG	Displays the number of pages printed by each	
-008	LT	copier application program.	
-009	HLT		
-254	Other (Standard)		
-255	Other (Custom)		

8451*	C: PrtPGS/Ppr Tray	[0 to 9999999 / 0 / 1 sheet/step]	
001	Bypass Tray		
002	Tray 1	Displays the total print count classified by paper	
003	Tray 2	source.	
004	Tray 3		

8461*	T: PrtPGS/Ppr Type	
8462* C: PrtPGS/Ppr Type		[0 to 9999999 / 0 / 1 sheet/step]
8464*	S: PrtPGS/Ppr Type	
-001	Normal	
-004	Thick	Displays the total number of pages printed by
-007	ОНР	each copier application program.
-008	Other	

8522*	C:PrtPGS/FIN	[0 to 9999999/ 0 / 1/step]	
001	Sort	The SP counts by finishing mode the total number of pages printed by the Copy application.	

Appendix: SP Mode Tables

5.2.2 INPUT CHECK (SP5-803)

Conducting Input Check

- 1. Select SP5-803.
- 2. Select the number (see the table below) corresponding to the component.
- 3. Select "Execute." The copy mode is activated.
- 4. The sign "01H" or "00H" is displayed (see the table below).

Input Check Table

Num.	Sensor/Switch	1h	0h
001	Safety SW	Open	Closed
003	Right Cover SW	Open	Closed
006	Upper Relay S	Paper detected	Not detected
007	Lower Relay S	Paper detected	Not detected
009	Regist Sensor	Paper detected	Not detected
010	Exit Sensor	Paper detected	Not detected
011	Duplex Inverter S	Paper detected	Not detected
014	By-pass PE S	Paper detected	Not detected
016	Upper PE S	Paper detected	Not detected
017	BK-Upper PE S	Paper detected	Not detected
020	BK-Lower PE S	Paper detected	Not detected
027	PCU Set Signal	Installed	Not installed
028	BK type	*	*
030	Duplex Installed	Installed	Not installed
032	Main M Lock	Locked	Not locked

Num.	Sensor/Switch	1h	0h
033	Polygon M Lock	Locked	Not locked
035	Total CO Install	Installed	Not installed
036	Key CO Install	Installed	Not installed
037	L-Synchronization	Detected	Not detected
039	DF-Cover Open S	Open	Closed
040	DF-Original Set S	Paper detected	Not detected
041	DF-Registration S	Paper detected	Not detected
042	DF-Exit S	Paper detected	Not detected
044	DF-Reverse S	Paper detected	Not detected
045	Platen Cover S	Open	Closed
050	Fan Motor Lock (High speed)	High speed	Low speed or stop
052	Front Cover SW	Open	Closed
053	HP Sensor	Detected	Not detected
055	BK-UpperCover SW	Open	Closed
056	BK-LowerCover SW	Open	Closed

^{*} Available Paper Feed Unit

00	None
30	1-tray paper feed unit

5.2.3 OUTPUT CHECK (SP5-804)

Conducting Output Check

ACAUTION

- To prevent mechanical or electrical damage, do not keep an electrical component on for a long time.
- 1. Select SP5-804.
- 2. Select the number (see the table below) corresponding to the component.
- 3. Select "ON."
- 4. To stop the operation, select "OFF."

Output Check Table

Num.	Component	
001	Main M- Fwd	
002	Main M- Rev	
003	Quenching Lamp	
004	Toner Sup CL	
005	Fan M- High	
006	Fan M- Low	
007	Registration CL	
008	By-pass Feed CL	
009	Upper Feed CL	
010	BK-Upper Feed CL	
015	BK-Lower Feed CL	
020	Duplex Inv M- Rev	
021	Duplex Inv M- Fwd	

Appendix: SP Mode Tables

Num.	Component	
024	Duplex Inv M- Hold	
026	Polygon M	
027	Polygon M/LD	
028	LD	
029	DF-Feed M	
030	DF-Transport M	
031	DF-Feed CL	
034	DF-Gate SOL (Junction Gate Solenoid)	
038	Fusing SOL	

When checking Fan Motor High (005) or Fan Motor Low (006) note the following:

- These motors may not respond when the fusing temperature is high.
- Selecting "ON" checks that one of these motors normally operates. Selecting "OFF" turns off the motor that you have started by selecting "ON." However, this does not guarantee that the motor normally stops during normal operation.

Appendix: SP Mode Tables

5.2.4 PRINTER SERVICE PROGRAM MODE TABLE

SP No.	Description	Function and Setting
1003	Clear Setting	Not used
1005	Display Version	Displays the version of the controller firmware.
1006	Sample/Locked print	0: Link with Doc., 1: On Enables and disables the document server. When you select "0" the document server is enabled or disables in accordance with copy service mode SP5-967. When you select "1" the document server is enabled regardless of service mode SP5-967.

5.2.5 SCANNER PROGRAM MODE TABLE

Service Table Key

Notation	What it means		
[range / default / step]	Example: [-9 to +9 / \pm 3.0 / 0.1 mm step]. The setting can be adjusted in the range \pm 9, value reset to \pm 3.0 after an NVRAM reset, and the value can be changed in 0.1 mm steps with each key press.		
italics	Comments added for your reference.		
*	This value is stored in NVRAM. After a RAM reset, the default value (factory setting) is restored.		
DFU	Denotes "Design or Factory Use". Do not change this value.		

SP1	Mode Number		Function and [Setting]
1001*	5	Scan NV Version	Displays the scanner NV version. This shows as following: Function name _ Model name _ Version
1004*	1	Compression Type	Selects the compression type for binary picture processing. [1: MH, 2: MR, 3: MMR]
1005*	1	Erase Margin	Creates an erase margin for all edges of the scanned image. If the machine has scanned the edge of the original, create a margin. [0 to 5 / 0mm / 1mm step]

1009*	1	Remote Scan disable	Enables or disables the network TWAIN scanner function. 0 : enable, 1: disable
1012	1	User Info Release	Clears or does not clear a user information after a job. [0 or 1 / 1 / -] 0: Not clear, 1: Clear
1013	1	Multi Media Func	Display or not display a "Scan To Multi Media" function. [0 or 1 / 1 / -] 0: OFF, 1: ON

SP	Number/Name	Function and [Setting]		
	Compression level (grayscale or full color)			
2021	These SP codes set the compression ratio for the grayscale or full color processing mode that can be selected with the notch settings on the operation panel. Range: 5 (lowest ratio) \leftrightarrow 95 (highest ratio)			
001	Comp1: 5-95 (Middle I-Qual)	[5 to 95 / 20 /1/step]		
002	Comp2: 5-95 (High I-Qual)	[5 to 95 / 40 /1/step]		
003	Comp3: 5-95 (Low I-Qual)	[5 to 95 / 65 /1/step]		
004	Comp4: 5-95 (Highest I-Qual)	[5 to 95 / 80 /1/step]		
005	Comp5: 5-95 (Lowest I-Qual)	[5 to 95 / 95 /1/step]		

For the settings of the image quality, see the copier SP-mode table.

APPENDIX: FAX TROUBLESHOOTING GUIDE (ONLY FOR D068/D069)

REVISION HISTORY					
Page	Page Date Added/Updated/New				
		None			

Appendix: Fax Troubleshooting Guide

6. APPENDIX: FAX TROUBLESHOOTING GUIDE (ONLY FOR D068/D069)

6.1 FAX ERROR CODES

- This section is used only for F/SPF models (D068/D069).
- If an error code occurs, retry the communication. If the same problem occurs, try to fix the problem as suggested below. Note that some error codes appear only in the error code display and on the service report.

Code	Meaning	Suggested Cause/Action
0-00	DIS/NSF not detected within 40 s of Start being pressed	 Check the line connection. The machine at the other end may be incompatible. Replace the NCU or FCU. Check for DIS/NSF with an oscilloscope. If the rx signal is weak, there may be a bad line.
0-01	DCN received unexpectedly	 The other party is out of paper or has a jammed printer. The other party pressed Stop during communication.
0-03	Incompatible modem at the other end	The other terminal is incompatible.

Code	Meaning	Suggested Cause/Action
0-04	CFR or FTT not received after modem training	 Check the line connection. Try changing the tx level and/or cable equalizer settings. Replace the FCU. The other terminal may be faulty; try sending to another machine. If the rx signal is weak or defective, there may be a bad line. Cross reference Tx level - NCU Parameter 01 (PSTN) Cable equalizer - G3 Switch 07 (PSTN) Dedicated Tx parameters in Service Program Mode
0-05	Modem training fails even G3 shifts down to 2400 bps.	 Check the line connection. Try adjusting the tx level and/or cable equalizer. Replace the FCU. Check for line problems. Cross reference See error code 0-04.
0-06	The other terminal did not reply to DCS	 Check the line connection. Try adjusting the tx level and/or cable equalizer settings. Replace the NCU or FCU. The other end may be defective or incompatible; try sending to another machine. Check for line problems. Cross reference See error code 0-04.

Code	Meaning	Suggested Cause/Action
0-07	No post-message response from the other end after a page was sent	 Check the line connection. Replace the NCU or FCU. The other end may have jammed or run out of paper. The other end user may have disconnected the call. Check for a bad line. The other end may be defective; try sending to another machine.
0-08	The other end sent RTN or PIN after receiving a page, because there were too many errors	 Check the line connection. Replace the NCU or FCU. The other end may have jammed, or run out of paper or memory space. Try adjusting the tx level and/or cable equalizer settings. The other end may have a defective modem/NCU/FCU; try sending to another machine. Check for line problems and noise. Cross reference Tx level - NCU Parameter 01 (PSTN) Cable equalizer - G3 Switch 07 (PSTN) Dedicated Tx parameters in Service Program Mode
0-14	Non-standard post message response code received	 Incompatible or defective remote terminal; try sending to another machine. Noisy line: resend. Try adjusting the tx level and/or cable equalizer settings. Replace the NCU or FCU. Cross reference See error code 0-08.

SM Appendix 6-3 D067/D068/D069/D072

Fax Error Codes

Code	Meaning	Suggested Cause/Action
0-15	The other terminal is not capable of specific functions.	The other terminal is not capable of accepting the following functions, or the other terminal's memory is full. Confidential rx Transfer function SEP/SUB/PWD/SID
0-16	CFR or FTT not detected after modem training in confidential or transfer mode	 Check the line connection. Replace the NCU or FCU. Try adjusting the tx level and/or cable equalizer settings. The other end may have disconnected, or it may be defective; try calling another machine. If the rx signal level is too low, there may be a line problem. Cross reference See error code 0-08.
0-20	Facsimile data not received within 6 s of retraining	 Check the line connection. Replace the NCU or FCU. Check for line problems. Try calling another fax machine. Try adjusting the reconstruction time for the first line and/or rx cable equalizer setting. Cross reference Reconstruction time - G3 Switch 0A, bit 6 Rx cable equalizer - G3 Switch 07 (PSTN)

Code	Meaning	Suggested Cause/Action
0-21	EOL signal (end-of-line) from the other end not received within 5 s of the previous EOL signal	 Check the connections between the FCU, NCU, & line. Check for line noise or other line problems. Replace the NCU or FCU. The remote machine may be defective or may have disconnected. Cross reference Maximum interval between EOLs and between ECM frames - G3 Bit Switch 0A, bit 4
0-22	The signal from the other end was interrupted for more than the acceptable modem carrier drop time (default: 200 ms)	 Check the line connection. Replace the NCU or FCU. Defective remote terminal. Check for line noise or other line problems. Try adjusting the acceptable modem carrier drop time. Cross reference Acceptable modem carrier drop time - G3 Switch 0A, bits 0 and 1
0-23	Too many errors during reception	 Check the line connection. Replace the NCU or FCU. Defective remote terminal. Check for line noise or other line problems. Try asking the other end to adjust their tx level. Try adjusting the rx cable equalizer setting and/or rx error criteria. Cross reference Rx cable equalizer - G3 Switch 07 (PSTN) Rx error criteria - Communication Switch 02, bits 0 and 1

Code	Meaning	Suggested Cause/Action
0-30	The other terminal did not reply to NSS(A) in Al short protocol mode	 Check the line connection. Try adjusting the tx level and/or cable equalizer settings. The other terminal may not be compatible. Cross reference Dedicated tx parameters - Section 4
0-32	The other terminal sent a DCS, which contained functions that the receiving machine cannot handle.	 Check the protocol dump list. Ask the other party to contact the manufacturer.
0-33	The data reception (not ECM) is not completed within 10 minutes.	 Check the line connection. The other terminal may have a defective modem/NCU/FCU.
0-52	Polarity changed during communication	Check the line connection. Retry communication.
0-55	FCU does not detect the SG3.	FCU firmware or board defective.SG3 firmware or board defective.
0-56	The stored message data exceeds the capacity of the mailbox in the SG3.	SG3 firmware or board defective.
0-70	The communication mode specified in CM/JM was not available (V.8 calling and called terminal)	 The other terminal did not have a compatible communication mode (e.g., the other terminal was a V.34 data modem and not a fax modem.) A polling tx file was not ready at the other terminal when polling rx was initiated from the calling terminal.

Code	Meaning	Suggested Cause/Action
0-74	The calling terminal fell back to T.30 mode, because it could not detect ANSam after sending CI.	 The calling terminal could not detect ANSam due to noise, etc. ANSam was too short to detect. Check the line connection and condition. Try making a call to another V.8/V.34 fax.
0-75	The called terminal fell back to T.30 mode, because it could not detect a CM in response to ANSam (ANSam timeout).	 The terminal could not detect ANSam. Check the line connection and condition. Try receiving a call from another V.8/V.34 fax.
0-76	The calling terminal fell back to T.30 mode, because it could not detect a JM in response to CM (CM timeout).	 The called terminal could not detect a CM due to noise, etc. Check the line connection and condition. Try making a call to another V.8/V.34 fax.
0-77	The called terminal fell back to T.30 mode, because it could not detect a CJ in response to JM (JM timeout).	 The calling terminal could not detect a JM due to noise, etc. A network that has narrow bandwidth cannot pass JM to the other end. Check the line connection and condition. Try receiving a call from another V.8/V.34 fax.
0-79	The called terminal detected CI while waiting for a V.21 signal.	 Check for line noise or other line problems. If this error occurs, the called terminal falls back to T.30 mode.

Code	Meaning	Suggested Cause/Action
0-80	The line was disconnected due to a timeout in V.34 phase 2 – line probing.	 The guard timer expired while starting these phases. Serious noise, narrow bandwidth, or low signal level can cause these errors. If these errors happen at the transmitting terminal: Try making a call at a later time. Try using V.17 or a slower modem using dedicated tx parameters. Try increasing the tx level. Try adjusting the tx cable equalizer setting. If these errors happen at the receiving terminal: Try adjusting the rx cable equalizer setting. Try increasing the tx level. Try using V.17 or a slower modem if the same error is frequent when receiving from multiple senders.

Code	Meaning	Suggested Cause/Action
0-81	The line was disconnected due to a timeout in V.34 phase 3 – equalizer training.	
0-82	The line was disconnected due to a timeout in the V.34 phase 4 – control channel start-up.	
0-83	The line was disconnected due to a timeout in the V.34 control channel restart sequence.	
0-84	The line was disconnected due to abnormal signaling in V.34 phase 4 – control channel start-up.	 The signal did not stop within 10 s. Turn off the machine, then turn it back on. If the same error is frequent, replace the FCU.
0-85	The line was disconnected due to abnormal signaling in V.34 control channel restart.	 The signal did not stop within 10 s. Turn off the machine, then turn it back on. If the same error is frequent, replace the FCU.
0-86	The line was disconnected because the other terminal requested a data rate using MPh that was not available in the currently selected symbol rate.	 The other terminal was incompatible. Ask the other party to contact the manufacturer.

Code	Meaning	Suggested Cause/Action
0-87	The control channel started after an unsuccessful primary channel.	 The receiving terminal restarted the control channel because data reception in the primary channel was not successful. This does not result in an error communication.
0-88	The line was disconnected because PPR was transmitted/received 9 (default) times within the same ECM frame.	 Try using a lower data rate at the start. Try adjusting the cable equalizer setting.
2-11	Only one V.21 connection flag was received	 Replace the FCU.
2-12	Modem clock irregularity	Replace the FCU.
2-13	Modem initialization error	 Turn off the machine, then turn it back on. Update the modem ROM. Replace the FCU.
2-23	JBIG compression or reconstruction error	Turn off the machine, then turn it back on.
2-24	JBIG ASIC error	Turn off the machine, then turn it back on.

Code	Meaning	Suggested Cause/Action
2-25	JBIG data reconstruction error (BIH error)	
2-26	JBIG data reconstruction error (Float marker error)	JBIG data errorCheck the sender's JBIG function.
2-27	JBIG data reconstruction error (End marker error)	Update the MBU ROM.
2-28	JBIG data reconstruction error (Timeout)	
2-29	JBIG trailing edge maker error	FCU defectiveCheck the destination device.
2-50	The machine resets itself for a fatal FCU system error	If this is frequent, update the ROM, or replace the FCU.
2-51	The machine resets itself because of a fatal communication error	If this is frequent, update the ROM, or replace the FCU.
2-53	Snd msg() in the manual task is an error because the mailbox for the operation task is full.	The user did the same operation many times, and this gave too much load to the machine.
4-01	Line current was cut	 Check the line connector. Check for line problems. Replace the FCU or the NCU.

Code	Meaning	Suggested Cause/Action
4-10	Communication failed because of an ID Code mismatch (Closed Network) or Tel. No./CSI mismatch (Protection against Wrong Connections)	 Get the ID Codes the same and/or the CSIs programmed correctly, then resend. The machine at the other end may be defective.
5-10	DCR timer expired	Replace the FCU.
5-20	Storage impossible because of a lack of memory	Temporary memory shortage.Test the SAF memory.
5-21	Memory overflow	
5-23	Print data error when printing a substitute rx or confidential rx message	Test the SAF memory.Ask the other end to resend the message.
5-25	SAF file access error	Replace an SD card or HDD.Replace the FCU.
6-00	G3 ECM - T1 time out during reception of facsimile data	
6-01	G3 ECM - no V.21 signal was received	Try adjusting the rx cable equalizer.Replace the FCU.
6-02	G3 ECM - EOR was received	

Code	Meaning	Suggested Cause/Action
6-04	G3 ECM - RTC not detected	 Check the line connection. Check for a bad line or defective remote terminal. Replace the FCU.
6-05	G3 ECM - facsimile data frame not received within 18 s of CFR, but there was no line fail	 Check the line connection. Check for a bad line or defective remote terminal. Replace the FCU. Try adjusting the rx cable equalizer Cross reference Rx cable equalizer - G3 Switch 07 (PSTN)
6-06	G3 ECM - coding/decoding error	Defective FCU.The other terminal may be defective.
6-08	G3 ECM - PIP/PIN received in reply to PPS.NULL	 The other end pressed Stop during communication. The other terminal may be defective.
6-09	G3 ECM - ERR received	 Check for a noisy line. Adjust the tx levels of the communicating machines. See code 6-05.
6-10	G3 ECM - error frames still received at the other end after all communication attempts at 2400 bps	 Check for line noise. Adjust the tx level (use NCU parameter 01 or the dedicated tx parameter for that address). Check the line connection. Defective remote terminal.

Code	Meaning	Suggested Cause/Action
6-21	V.21 flag detected during high speed modem communication	The other terminal may be defective or incompatible.
6-22	The machine resets the sequence because of an abnormal handshake in the V.34 control channel	 Check for line noise. If the same error occurs frequently, replace the FCU. Defective remote terminal.
6-99	V.21 signal not stopped within 6 s	Replace the FCU.
13-17	SIP user name registration error	 Double registration of the SIP user name. Capacity for user-name registration in the SIP server is not sufficient.
13-18	SIP server access error	Incorrect initial setting for the SIP server.Defective SIP server.
13-24	SIP authentication password error	The input password for the authentication does not match the password registered in the SIP server.
14-00	SMTP Send Error	 Error occurred during sending to the SMTP server. Occurs for any error other than 14-01 to 16. For example, the mail address of the system administrator is not registered.

Code	Meaning	Suggested Cause/Action
14-01	SMTP Connection Failed	 Failed to connect to the SMTP server (timeout) because the server could not be found. The PC is not ready to transfer files. SMTP server not functioning correctly. The DNS IP address is not registered. Network not operating correctly. Destination folder selection not correct.
14-02	No Service by SMTP Service (421)	 SMTP server operating incorrectly, or the destination for direct SMTP sending is not correct. Contact the system administrator and check that the SMTP server has the correct settings and operates correctly. Contact the system administrator for direct SMTP sending and check the sending destination.

Appendix: Fax Troubleshooting Guide

Code	Meaning	Suggested Cause/Action
14-03	Access to SMTP Server Denied (450)	 Failed to access the SMTP server because the access is denied. SMTP server operating incorrectly. Contact the system administrator to determine if there is a problem with the SMTP server and to check that the SMTP server settings are correct. Folder send destination is incorrect. Contact the system administrator to determine that the SMTP server settings and path to the server are correct. Device settings incorrect. Confirm that the user name and password settings are correct. Direct SMTP destination incorrect. Contact the system administrator to determine if there is a problem at the destination at that the settings at the destination are correct.
14-04	Access to SMTP Server Denied (550)	SMTP server operating incorrectlyDirect SMTP sending not operating correctly

Code	Meaning	Suggested Cause/Action
14-05	SMTP Server HDD Full (452)	 Failed to access the SMTP server because the HDD on the server is full. Insufficient free space on the HDD of the SMTP server. Contact the system administrator and check the amount of space remaining on the SMTP server HDD. Insufficient free space on the HDD where the destination folder is located. Contact the system administrator and check the amount of space remaining on the HDD where the target folder is located. Insufficient free space on the HDD at the target destination for SMTP direct sending. Contact the system administrator and check the amount of space remaining on the target HDD.
14-06	User Not Found on SMTP Server (551)	 The designated user does not exist. The designated user does not exist on the SMTP server. The designated address is not for use with direct SMTP sending.
14-07	Data Send to SMTP Server Failed (4XX)	 Failed to access the SMTP server because the transmission failed. PC not operating correctly. SMTP server operating incorrectly Network not operating correctly. Destination folder setting incorrect. Direct SMTP sending not operating correctly.

Code	Meaning	Suggested Cause/Action
14-08	Data Send to SMTP Server Failed (5XX)	 Failed to access the SMTP server because the transmission failed. SMTP server operating incorrectly Destination folder setting incorrect. Direct SMTP sending not operating correctly. Software application error.
14-09	Authorization Failed for Sending to SMTP Server	 POP-Before-SMTP or SMTP authorization failed. Incorrect setting for file transfer
14-10	Addresses Exceeded	 Number of broadcast addresses exceeded the limit for the SMTP server.
14-11	Buffer Full	■ The send buffer is full so the transmission could not be completed. Buffer is full due to using Scan-to-Email while the buffer is being used send mail at the same time.
14-12	Data Size Too Large	 Transmission was cancelled because the detected size of the file was too large.
14-13	Send Cancelled	 Processing is interrupted because the user pressed Stop.
14-14	Security Locked File Error	Update the software because of the defective software.
14-15	Mail Data Error	 The transmitting a mail is interrupted via DCS due to the incorrect data. Update the software because of the defective software.

Code	Meaning	Suggested Cause/Action
14-16	Maximum Division Number Error	 When a mail is divided for the mail transmission and the division number of a mail are more than the specified number, the mail transmission is interrupted. Update the software because of the defective software.
14-17	Incorrect Ticket	Update the software because of the defective software.
14-18	Access to MCS File Error	 The access to MCS file is denied due to the no permission of access. Update the software because of the defective software.
14-30	MCS File Creation Failed	 Failed to create the MCS file because: The number of files created with other applications on the Document Server has exceeded the limit. HDD is full or not operating correctly. Software error.
14-31	UFS File Creation Failed	 UFS file could not be created: Not enough space in UFS area to handle both Scan-to-Email and IFAX transmission. HDD full or not operating correctly. Software error.
14-32	Cancelled the Mail Due to Error Detected by NFAX	 Error detected with NFAX and send was cancelled due to a software error.

Code	Meaning	Suggested Cause/Action
14-33	No Mail Address For the Machine	 Neither the mail address of the machine nor the mail address of the network administrator is registered.
14-34	Address designated in the domain for SMTP sending does not exist	 Operational error in normal mail sending or direct SMTP sending. Check the address selected in the address book for SMTP sending. Check the domain selection.
14-50	Mail Job Task Error	Due to an FCU mail job task error, the send was cancelled: Address book was being edited during creation of the notification mail. Software error.
14-51	UCS Destination Download Error	Not even one return notification can be downloaded: The address book was being edited. The number for the specified destination does not exist (it was deleted or edited after the job was created).
14-60	Send Cancel Failed	The cancel operation by the user failed to cancel the send operation.
14-61	Notification Mail Send Failed for All Destinations	All addresses for return notification mail failed.
14-62	Transmission Error due to the existence of zero line page	 When the 0 line page exists in received pages with G3 communication, the transmission is interrupted.

Code	Meaning	Suggested Cause/Action
15-01	POP3/IMAP4 Server Not Registered	 At startup, the system detected that the IP address of the POP3/IMAP4 server has not been registered in the machine.
15-02	POP3/IMAP4 Mail Account Information Not Registered	 The POP3/IMAP4 mail account has not been registered.
15-03	Mail Address Not Registered	The mail address has not been registered.
15-10	DCS Mail Receive Error	Error other than 15-11 to 15-18.
15-11	Connection Error	The DNS or POP3/IMAP4 server could not be found: The IP address for DNS or POP3/IMAP4 server is not stored in the machine. The DNS IP address is not registered. Network not operating correctly.
15-12	Authorization Error	POP3/IMAP4 send authorization failed: Incorrect IFAX user name or password. Access was attempted by another device, such as the PC. POP3/IMAP4 settings incorrect.
15-13	Receive Buffer Full	Occurs only during manual reception. Transmission cannot be received due to insufficient buffer space. The buffer is being used for mail send or Scan-to-Email.
15-14	Mail Header Format Error	The mail header is not standard format. For example, the Date line description is incorrect.

Code	Meaning	Suggested Cause/Action
15-15	Mail Divide Error	The e-mail is not in standard format. There is no boundary between parts of the e-mail, including the header.
15-16	Mail Size Receive Error	The mail cannot be received because it is too large.
15-17	Receive Timeout	May occur during manual receiving only because the network is not operating correctly.
15-18	Incomplete Mail Received	Only one portion of the mail was received.
15-31	Final Destination for Transfer Request Reception Format Error	The format of the final destination for the transfer request was incorrect.
15-39	Send/Delivery Destination Error	The transmission cannot be delivered to the final destination: Destination file format is incorrect. Could not create the destination for the file transmission.
15-41	SMTP Receive Error	 Reception rejected because the transaction exceeded the limit for the "Auth. E-mail RX" setting.
15-42	Off Ramp Gateway Error	The delivery destination address was specified with Off Ramp Gateway OFF.
15-43	Address Format Error	 Format error in the address of the Off Ramp Gateway.
15-44	Addresses Over	The number of addresses for the Off Ramp Gateway exceeded the limit of 30.

Code	Meaning	Suggested Cause/Action
15-61	Attachment File Format Error	The attached file is not TIFF format.
15-62	TIFF File Compatibility Error	 Could not receive transmission due to: Resolution error Image of resolution greater than 200 dpi without extended memory. Resolution is not supported. Page size error The page size was larger than A3. Compression error File was compressed with other than MH, MR, or MMR.
15-63	TIFF Parameter Error	The TIFF file sent as the attachment could not be received because the TIFF header is incorrect: The TIFF file attachment is a type not supported. The TIFF file attachment is corrupted. Software error.
15-64	TIFF Decompression Error	The file received as an attachment caused the TIFF decompression error: The TIFF format of the attachment is corrupted. Software error.
15-71	Not Binary Image Data	The file could not be received because the attachment was not binary image data.
15-73	MDN Status Error	 Could not find the Disposition line in the header of the Return Receipt, or there is a problem with the firmware.

Code	Meaning	Suggested Cause/Action
15-74	MDN Message ID Error	 Could not find the Original Message ID line in the header of the Return Receipt, or there is a problem with the firmware.
15-80	Mail Job Task Read Error	Could not receive the transmission because the destination buffer is full and the destination could not be created (this error may occur when receiving a transfer request or a request for notification of reception).
15-81	Repeated Destination Registration Error	Could not repeat receive the transmission because the destination buffer is full and the destination could not be created (this error may occur when receiving a transfer request or a request for notification of reception).
15-91	Send Registration Error	Could not receive the file for transfer to the final destination: The format of the final destination or the transfer destination is incorrect. Destinations are full so the final and transfer destinations could not be created.
15-92	Memory Overflow	Transmission could not be received because memory overflowed during the transaction.
15-93	Memory Access Error	 Transaction could not complete due to a malfunction of SAF memory.
15-94	Incorrect ID Code	The machine rejected an incoming e-mail for transfer request, because the ID code in the incoming e-mail did not match the ID code registered in the machine.

Code	Meaning	Suggested Cause/Action
15-95	Transfer Station Function	 The machine rejected an incoming e-mail for transfer because the transfer function was unavailable.
22-00	Original length exceeded the maximum scan length	 Divide the original into more than one page. Check the resolution used for scanning. Lower the scan resolution if possible. Add optional page memory.
22-01	Memory overflow while receiving	 Wait for the files in the queue to be sent. Delete unnecessary files from memory. Transfer the substitute reception files to an another fax machine, if the machine's printer is busy or out of order. Add an optional SAF memory card or hard disk.
22-02	Tx or rx job stalled due to line disconnection at the other end	 The job started normally but did not finish normally; data may or may not have been received fully. Restart the machine.
22-04	The machine cannot store received data in the SAF	Update the ROMReplace the FCU.
22-05	No G3 parameter confirmation answer	Defective FCU board or firmware.
23-00	Data read timeout during construction	Restart the machine.Replace the FCU.

Fax Error Codes

Code	Meaning	Suggested Cause/Action
25-00	The machine software resets itself after a fatal transmission error occurred	Update the ROMReplace the FCU.
F0-xx	V.34 modem error	Replace the FCU.
F6-xx	SG3 modem error	 Update the SG3 modem ROM. Replace the SG3 board. Check for line noise or other line problems. Try communicating another V.8/V.34 fax.

6.2 IFAX TROUBLESHOOTING

- This section is used only for F/SPF models (D068/D069).
- Use the following procedures to determine whether the machine or another part of the network is causing the problem.

Communication Route	Item	Action [Remarks]
General LAN	1. Connection with the LAN	 Check that the LAN cable is connected to the machine. Check that the LEDs on the hub are lit.
Contract Ly liv	2. LAN activity	 Check that other devices connected to the LAN can communicate through the LAN.
	Network settings on the PC	 Check the network settings on the PC. [Is the IP address registered in the TCP/IP properties in the network setup correct? Check the IP address with the administrator of the network.]
Between IFAX and PC	2. Check that PC can connect with the machine	 Use the "ping" command on the PC to contact the machine. [At the MS-DOS prompt, type ping then the IP address of the machine, then press Enter.]
	3. LAN settings in the machine	 Check the LAN parameters Check if there is an IP address conflict with other PCs. [Use the "Network" function in the User Tools. If there is an IP address conflict, inform the administrator.]

Communication Route	ltem	Action [Remarks]
Between machine and e-mail server	LAN settings in the machine	 Check the LAN parameters Check if there is an IP address conflict with other PCs. [Use the "Network" function in the User Tools. If there is an IP address conflict, inform the administrator.]
	E-mail account on the server	 Make sure that the machine can log into the e-mail server. Check that the account and password stored in the server are the same as in the machine. [Ask the administrator to check.]
Between machine and e-mail server	2. E-mail server	Make sure that the client devices which have an account in the server can send/receive e-mail. [Ask the administrator to check. Send a test e-mail with the machine's own number as the destination. The machine receives the returned e-mail if the communication is performed successfully.]

Communication Route	ltem	Action [Remarks]
	E-mail account on the Server	 Make sure that the PC can log into the e-mail server. Check that the account and password stored in the server are the same as in the machine. [Ask the administrator to check.]
Between e-mail server and internet	2. E-mail server	 Make sure that the client devices which have an account in the server can send/receive e-mail. [Ask the administrator to check. Send a test e-mail with the machine's own number as the destination. The machine receives the returned e-mail if the communication is performed successfully.]
	3. Destination e-mail address	 Make sure that the e-mail address is actually used. Check that the e-mail address contains no incorrect characters such as spaces.
Between e-mail server and internet	Router settings	 Use the "ping" command to contact the router. Check that other devices connected to the router can sent data over the router. [Ask the administrator of the server to check.]
Between e-mail server and internet	Error message by e-mail from the network of the destination.	 Check whether e-mail can be sent to another address on the same network, using the application e-mail software. Check the error e-mail message. [Inform the administrator of the LAN.]

6.3 IP-FAX TROUBLESHOOTING

This section is used only for F/SPF models (D068/D069).

6.3.1 IP-FAX TRANSMISSION

Cannot send by IP Address/Host Name

Check Point		Action
1	LAN cable connected?	Check the LAN cable connection.
2	Specified IP address/host name correct?	Check the IP address/host name.
3	Firewall/NAT is installed?	Cannot breach the firewall. Send by using another method (Fax, Internet Fax)
4	Transmission sent manually?	Manual sending not supported.
5	IP address of local machine registered?	Register the IP address.
6	Remote terminal port number setting other than 1720?	Send by specifying the port number.
7	Specified port number correct?	Confirm the port number of the remote fax.
8	DNS server registered when host name specified?	Contact the network administrator.
9	Remote fax a T.38 terminal?	Check whether the remote fax is a T38 terminal.

Check Point		Action
10	Remote fax switched off or busy?	Check that the remote fax is switched on.
	Network bandwidth too narrow?	Request the network administrator to increase the bandwidth.
11		Raise the delay level. IPFAX SW 01 Bit 0 to 3
		IP-Fax bandwidth is the same as the DCS speed. Set IP-Fax SW00 Bit 6 to 1.
12	Remote fax cancelled transmission?	Check whether the remote fax cancelled the transmission.

Appendix: Fax Troubleshooting Guide

Cannot send via VoIP Gateway

Check Point		Action
1	LAN cable connected?	Check the LAN cable connection.
2	VoIP Gateway T.38 standard?	Contact the network administrator.
3	VoIP Gateway installed correctly?	Contact the network administrator.
4	VoIP Gateway power switched on?	Contact the network administrator.
5	Is the IP address/host name of the specified Gateway correct?	Check the IP address/host name.
6	Number of the specified fax correct?	Check the remote fax number.
7	Firewall/NAT is installed?	Cannot breach the firewall. Send by using another method (Fax, Internet Fax)
8	Transmission sent manually?	Manual sending not supported.
9	IP address of local fax registered?	Register the IP address.
10	DNS registered when host name specified?	Contact the network administrator.
11	Remote fax a G3 fax?	Check that the remote fax is a G3 fax.
12	G3 fax is connected to VoIP gateway?	Check that G3 fax is connected.
13	Remote G3 fax turned on?	Check that G3 fax is switched on.
		Request the network administrator to increase the bandwidth.
14	Network bandwidth too narrow?	Raise the network delay level. IPFAX SW 01 Bit 0 to 3
		IP-Fax bandwidth is the same as the DCS speed. Set IP-Fax SW00 Bit 6 to 1.

Appendix: Fax Troubleshooting Guide

Cannot send by Alias Fax number.

Check Point		Action
1	LAN cable connected?	Check the LAN cable connection.
2	Number of specified Alias fax correct?	Confirm the Alias of the remote fax. Error Code: 13-14
3	Firewall/NAT installed?	Cannot breach the firewall. Send by using another method (Fax, Internet Fax)
4	Transmission sent manually?	Manual sending not supported.
5	Gatekeeper installed correctly?	Contact the network administrator.
6	Gatekeeper power switched on?	Contact the network administrator.
7	IP address/host name of Gatekeeper correct?	Check the IP address/host name.
8	DNS server registered when Gatekeeper host name specified?	Contact the network administrator.
9	Enable H.323 SW is set to on?	Check the settings. See User Parameter SW 34 Bit 0
10	IP address of local fax registered?	Register the IP address of the local fax.
11	Alias number of local fax registered?	Register the Alias number of the local fax.

IP-Fax Troubleshooting

Check Point		Action
12	Remote fax registered in Gatekeeper?	Contact the network administrator.
13	Remote fax a T.38 terminal?	Check whether the remote fax is a T38 terminal.
14	Remote fax switched off or busy?	Contact the network administrator.
	Network bandwidth too narrow?	Request the system administrator to increase the bandwidth.
15		Raise the delay level. IPFAX SW 01 Bit 0 to 3
		Lower the modem transmission baud rate. IPFAX SW 05
16	Remote fax cancelled transmission?	Check whether the remote fax cancelled the transmission.

SM Appendix

6.3.2 IP-FAX RECEPTION

Cannot receive by IP Address/Host name.

Check Point		Action
1	LAN cable connected?	Check the LAN cable connection.
2	Firewall/NAT is installed?	Cannot breach the firewall. Send by using another method (Fax, Internet Fax)
3	IP address of local fax registered?	Register the IP address.
4	Port number specified at remote sender fax (if required)?	Request the sender to specify the port number.
5	Specified port number correct (if required)?	Request the sender to check the port number.
6	DNS server registered when host name specified on sender side?	Contact the network administrator. Note The sender machine displays this error code if the sender fax is a Ricoh model.
		Request the system administrator to increase the bandwidth.
7	Network bandwidth too narrow?	Lower the start modem reception baud rate on the receiving side. IPFAX SW06
8	Remote fax cancelled transmission?	Check whether the remote fax cancelled the transmission.

Cannot receive by VoIP Gateway.

Check Point		Action
1	LAN cable connected?	Check the LAN cable connection.
2	Firewall/NAT is installed?	Cannot breach the firewall. Request the remote fax to send by using another method (Fax, Internet Fax)
3	VoIP Gateway installed correctly?	Contact the network administrator.
4	VoIP Gateway power switched on?	Contact the network administrator.
5	IP address/host name of specified VoIP Gateway correct on sender's side?	Request the remote fax to check the IP address/host name.
6	DNS server registered when host name specified on sender side?	Contact the network administrator.
7	Network bandwidth too narrow?	Request the network administrator to increase the bandwidth.
8	G3 fax connected?	Check that G3 fax is connected.
9	G3 fax power switched on?	Check that G3 fax is switched on.

Cannot receive by Alias Fax number.

Check Point		Action
1	LAN cable connected?	Check the LAN cable connection.
2	Firewall/NAT is installed?	Cannot the breach firewall. Request the remote fax to send by using another method (Fax, Internet Fax)
3	Gatekeeper installed correctly?	Contact the network administrator. Note The sender machine displays this error code when the sender fax is a Ricoh model.
4	Power to Gatekeeper switched on?	Contact the network administrator. Note The sender machine displays this error code when the sender fax is a Ricoh model.
5	IP address/host name of Gatekeeper correct on the sender's side?	Request the sender to check the IP address/host name. Note The sender machine displays this error code when the sender fax is a Ricoh model.
6	DNS server registered when Gatekeeper host name specified on sender's side?	Contact the network administrator. Note The sender machine displays this error code when the sender fax is a Ricoh model.

Che	ck Point	Action
7	Enable H.323 SW is set to on?	Request the sender to check the settings. User Parameter SW 34 Bit 0 Note Only if the remote sender fax is a Ricoh fax.
8	Local fax IP address registered?	Register the IP address.
9	Local fax Alias number registered?	Register the Alias number.
		Request the system administrator to increase the bandwidth.
10	Network bandwidth too narrow?	Lower the start modem reception baud rate on the receiving side. IPFAX SW06
11	Remote fax cancelled transmission?	Check whether the remote fax cancelled the transmission.
12	Local fax registered in Gatekeeper?	Contact the network administrator. Note The sender machine displays this error code when the sender fax is a Ricoh model.

APPENDIX: FAX SERVICE PROGRAM (ONLY FOR D068/D069)

REVISION HISTORY				
Page Date Added/Updated/New				
100	100 05/14/2009 Updated Information – Service RAM Addresses			
102 05/14/2009 Updated Information – Service RAM Addresses				

Appendix: Fax Service Program

7. APPENDIX: FAX SERVICE PROGRAM (ONLY FOR D068/D069)

7.1 SYSTEM SERVICE MODE

Only for F/SPF models: D068/D069

7.1.1 SP1-XXX (BIT SWITCHES)

"Bit Switches"

1	Mode No.		Function	
	System Switch	า		
101	001 – 032	00 – 1F	Change the bit switches for system settings for the fax option (** "Bit Switches")	
	Ifax Switch			
102	001 – 016	00 – 0F	Change the bit switches for internet fax settings for the fax option (** "Bit Switches")	
	Printer Switch			
103	001 – 016	00 – 0F	Change the bit switches for printer settings for the fax option (Bit Switches")	
	Communication	on Switch		
104	001 – 032	00 – 1F	Change the bit switches for communication settings for the fax option (** "Bit Switches")	

	G3-1 Switch		
105	001 – 016	00 – 0F	Change the bit switches for the protocol settings of the standard G3 board (** "Bit Switches")
	IP fax Switch		
111	001 – 016	00 – 0F	Change the bit switches for optional IP fax parameters (** "Bit Switches")

7.1.2 SP2-XXX (RAM DATA)

2	Mode No.		Function
	RAM Read/\	Vrite	
101	001		Change RAM data for the fax board directly. (** "Service RAM Addresses")
	Memory Dump		
102	001	G3-1 Memory Dump	Print out RAM data for the fax board. (** "Service RAM Addresses")
	G3-1 NCU P	arameters	
103	001 – 023	CC, 01 – 22	NCU parameter settings for the standard G3 board. ("NCU Parameters")

7.1.3 SP3-XXX (TEL LINE SETTINGS)

3	Mode No.		Function
404	Service Stati	on	
101	001	Fax Number	Enter the fax number of the service station.
102	Serial Numb	er	,
102	000		Enter the fax unit's serial number.
	PSTN-1 Port	Settings	
	001	Select Line	Select the line type setting for the G3-1 line. If the machine is installed on a PABX line, select "PABX", "PABX(GND)" or "PABX(FLASH)".
103	002	PSTN Access Number	Enter the PSTN access number for the G3-1 line.
	003	Memory Lock Disabled	If the customer does not want to receive transmissions using Memory Lock on this line, turn this SP on.
	IPFAX Port Settings		
	001	H323 Port	-
	002	SIP Port	-
	003	RAS Port	-
107	004	Gatekeeper port	-
	005	T.38 Port	-
	006	SIP Server Port	-
	007	IPFAX Protocol Priority	Select "H323" or "SIP".

201	FAX SW		
	001 – 032	00 – 1F	-

7.1.4 SP4-XXX (ROM VERSIONS)

4	Mode No.		Function
101	002 – 007	FCU ROM Version	Displays the FCU ROM version.
102	002 – 065	Error Codes	Displays the latest 64 fax error codes.
103	002 – 004	G3-1 ROM Version	Displays the G3-1 modem version.

Appendix: Fax Service Program

7.1.5 SP5-XXX (INITIALIZING)

5	Mode No.	Function		
	Initialize SRAM			
101	001	Initializes the bit switches and user parameters, user data in the SRAM, files in the SAF memory, and clock.		
102	Erase All Files			
102	001	Erases all files stored in the SAF memory.		
103	Reset Bit Switches			
100	001	Resets the bit switches and user parameters.		
	Factory setting			
104	001	Resets the bit switches and user parameters, user data in the SRAM and files in the SAF memory.		
105	Reset All Bit Switches			
100	001	Initializes all the current bit switch settings.		
	Reset Security Bit Switches			
106	001	Initializes only the security bit switches. If you select automatic output/display for the user parameter switches, the security settings are initialized.		

7.1.6 SP6-XXX (REPORTS)

6	Mode No.		Function	
	System P	System Parameter List		
101	001	-	Touch the "ON" button to print the system parameter list.	
	Service M	1onitor		
102	001	-	Touch the "ON" button to print the service monitor report.	
	G3 Proto	col Dump List		
103	001	G3-1 (All Communications)	Prints the protocol dump list of all communications for the G3-1 line.	
	002	G3-1 (1 Communication)	Prints the protocol dump list of the last communication for the G3-1 line.	
	All Files print out			
105	001	-	Prints out all the user files in the SAF memory, including confidential messages. • Do not use this function, unless the customer is having trouble printing confidential messages or recovering files stored using the memory lock feature.	
	Journal P	rint out		
106	001	All Journals	The machine prints all the communication records on the report.	
	002	Specified Date	The machine prints all communication records after the specified date.	

	Log List F	Print out	
	001	All log files	
	002	Printer	
	003	SC/TRAP Stored	
	004	Decompression	
	005	Scanner	
107	006	JOB/SAF	These log print out functions are for designer
	007	Reconstruction	use only.
	800	JBIG	
	009	G3CCU	
	010	Fax Job	
	011	CCU	
	012	Scanner Condition	
	IP Protoc	ol Dump List	
108	001	All Communications	Prints the protocol dump list of all communications for the IP fax line.
	002	1 Communication	Prints the protocol dump list of the last communication for the IP fax line.

7.1.7 SP7-XXX (TEST MODES)

These are the test modes for PTT approval.

7	Function
101	G3-1 Modem Tests
102	G3-1 DTMF Tests
103	Ringer Test
104	G3-1 V34 (S2400baud)
105	G3-1 V34 (S2800baud)
106	G3-1 V34 (S3000baud)
107	G3-1 V34 (S3200baud)
108	G3-1 V34 (S3429baud)
109	Message Test

7.2 BIT SWITCHES

This section is used only for F/SPF models (D068/D069).

MWARNING

Do not adjust a bit switch or use a setting that is described as "Not used", as this may cause the machine to malfunction or to operate in a manner that is not accepted by local regulations. Such bits are for use only in other areas, such as Japan.



Default settings for bit switches are not listed in this manual. Refer to the System
 Parameter List printed by the machine.

7.2.1 SYSTEM SWITCHES

Syst	System Switch 00 [SP No. 1-101-001]		
No	FUNCTION	COMMENTS	
0	Dedicated transmission parameter programming 0: Disabled, 1: Enabled	Set this bit to 1 before changing any dedicated transmission parameters. Reset this bit to 0 after programming dedicated transmission parameters.	
1	Not used	Do not change	
2	Technical data printout on the Journal 0: Disabled 1: Enabled	1: Instead of the personal name, the following data are listed on the Journal for each G3 communication.	

e.g. 0000 (1) // 32 (2) V34 (3) // 288 (4) // 264 (5) // L0100 (6) 03 (7) 04 (8)

(1): EQM value (Line quality data). A larger number means more errors.

(2): Symbol rate (V.34 only)

(3): Final modem type used

(4): Starting data rate (for example, 288 means 28.8 kbps)

(5): Final data rate

(6): Rx revel (refer to the note after this table for how to read the rx level)

(7): Total number of error lines that occurred during non-ECM reception.

(8): Total number of burst error lines that occurred during non-ECM reception.

2 Note

EQM and rx level are fixed at "FFFF" in tx mode.

The seventh and eighth numbers are fixed at "00" for transmission records and ECM reception records.

Rx level calculation

Example: 0000 // 32 V34 // 288/264 // L 01 00 03 04

The four-digit hexadecimal value (N) after "L" indicates the rx level.

The high byte is given first, followed by the low byte. Divide the decimal value of N by -16 to get the rx level.

In the above example, the decimal value of N (= 0100 [H]) is 256.

So, the actual rx level is 256/-16 = -16 dB

3	Not used	Do not change this setting.
4	Line error mark print 0: OFF, 1: ON (print)	When "1" is selected, a line error mark is printed on the printout if a line error occurs during reception.
5	G3/G4 communication parameter display 0: Disabled 1: Enabled	This is a fault-finding aid. The LCD shows the key parameters (see below). This is normally disabled because it cancels the CSI display for the user. Be sure to reset this bit to 0 after testing.

6	Protocol dump list output after each communication 0: Off 1: On	This is only used for communication troubleshooting. It shows the content of the transmitted facsimile protocol signals. Always reset this bit to 0 after finishing testing. If system switch 09 bit 6 is at "1", the list is only printed if there was an error during the communication.
7	Not used	Do not change the setting.

System Switch 01 - Not used (Do not change the factory settings.)

System Switch 02 [SP No. 1-101-003]

No	FUNCTION	COMMENTS
0-1	Not used	Do not change these settings.
2	Force after transmission stall 0: Off 1: On	With this setting on, the machine resets itself automatically if a transmission stalls and fails to complete the job.
3-5	Not used	Do not change these settings.
6-7	Memory read/write by RDS Bit 7: 0, Bit 6: 0 Always disabled Bit 7: 0, Bit 6: 1 User selectable Bit 7: 1, Bit 6: 0 User selectable Bit 7: 1, Bit 6: 1 Always enabled	(0,0): All RDS systems are always locked out. (0,1), (1,0): Normally, RDS systems are locked out, but the user can temporarily switch RDS on to allow RDS operations to take place. RDS will automatically be locked out again after a certain time, which is stored in System Switch 03. Note that if an RDS operation takes place, RDS will not switch off until this time limit has expired. (1,1): At any time, an RDS system can access the machine.

Syst	System Switch 03 [SP No. 1-101-004]		
No	FUNCTION	COMMENTS	
0-7	Length of time that RDS is temporarily switched on when bits 6 and 7 of System Switch 02 are set to "User selectable"	00 - 99 hours (BCD). This setting is only valid if bits 6 and 7 of System Switch 02 are set to "User selectable". The default setting is 24 hours.	

System Switch 04 [SP No. 1-101-005]		
No	FUNCTION	COMMENTS
0-2	Not used	Do not change these settings.
3	Printing dedicated tx parameters on Quick/Speed Dial Lists 0: Disabled 1: Enabled	1: Each Quick/Speed dial number on the list is printed with the dedicated tx parameters (10 bytes each). The first 10 bytes of data are the programmed dedicated tx parameters; 34 bytes of data are printed (the other 24 bytes have no use for service technicians).
4-7	Not used	Do not change these settings.

System Switch 05 - Not used (Do not change the factory settings.)		
System Switch 06 - Not used (Do not change the factory settings.)		
System Switch 07 - Not used (Do not change the factory settings.)		
System Switch 08 - Not used (Do not change the factory settings.)		

Syst	System Switch 09 [SP No. 1-101-010]		
No	FUNCTION	COMMENTS	
0	Not used	Do not change these settings.	
1	Inclusion of communications on the Journal when no image data was exchanged. 0: Disabled 1: Enabled	O: Communications that reached phase C (message tx/rx) of the T.30 protocol are listed on the Journal. 1: Communications that reached phase A (call setup) of T.30 protocol are listed on the Journal. This will include telephone calls.	
2	Automatic error report printout 0: Disabled 1: Enabled	O: Error reports will not be printed. 1: Error reports will be printed automatically after failed communications.	
3	Printing of the error code on the error report 0: No 1: Yes	1: Error codes are printed on the error reports.	
4	Not used	Do not change this setting.	
5	Power failure report 0: Disabled 1: Enabled	1: A power failure report will be automatically printed after the power is switched on if a fax message disappeared from the memory when the power was turned off last.	
6	Conditions for printing the protocol dump list 0: Print for all communications 1: Print only when there is a communication error	This switch becomes effective only when system switch 00 bit 6 is set to 1. 1: Set this bit to 1 when you wish to print a protocol dump list only for communications with errors.	

	Priority given to various types	
	of remote terminal ID when	This bit determines which set of priorities the
	printing reports	machine uses when listing remote terminal names
7	0: RTI > CSI > Dial label > Tel.	on reports.
	Number	Dial Label: The name stored, by the user, for the
	1: Dial label > Tel. number >	Quick/Speed Dial number.
	RTI > CSI	

System	System Switch 0A [SP No. 1-101-011]		
No	FUNCTION	COMMENTS	
0-3	Not used	Do not change these settings.	
4	Dialing on the ten-key pad when the external telephone is off-hook 0: Disabled 1: Enabled	 0: Prevents dialing from the ten-key pad while the external telephone is off-hook. Use this setting when the external telephone is not by the machine, or if a wireless telephone is connected as an external telephone. 1: The user can dial on the machine's ten-key pad when the handset is off-hook. 	
5	On hook dial 0: Disabled 1: Enabled	0: On hook dial is disabled.	
6-7	Not used	Do not change the factory settings.	

System Switch 0B - Not used (Do not change the factory settings.)

System Switch 0C - Not used (Do not change the factory settings.)

System Switch 0D - Not used (Do not change the factory settings.)

Syst	System Switch 0E [SP No. 1-101-015]		
No	FUNCTION	COMMENTS	
0-1	Not used	Do not change the settings.	
2	Not used	This machine does not have the capture function.	
3	Action when the external handset goes off-hook 0: Manual tx and rx operation 1: Memory tx and rx operation (the display remains the same)	0: Manual tx and rx are possible while the external handset is off-hook. However, memory tx is not possible.1: The display stays in standby mode even when the external handset is used, so that other people can use the machine for memory tx operation.Note that manual tx and rx are not possible with this setting.	
4-7	Not used	Do not change these settings.	

Syste	em Switch 0F [S	P No. 1-101-016]	
No	FU	INCTION	COMMENTS
	Country/area co	ode for functional	
	00: France	11: USA	
	01: Germany	12: Asia	
	02: UK	13: Japan	
	03: Italy	14: Hong Kong	
	04: Austria	15: South Africa	This country/area code determines the
	05: Belgium	16: Australia	This country/area code determines the factory settings of bit switches and RAM
	06: Denmark	17: New Zealand	addresses. However, it has no effect on
0-7	07: Finland	18: Singapore	the NCU parameter settings and communication parameter RAM
	08: Ireland	19: Malaysia	addresses. Cross reference
	09: Norway	1A: China	NCU country code:
	0A: Sweden	1B: Taiwan	SP No. 2-103-001 for G3-1
	0B: Switz.	1C: Korea	
	0C: Portugal	20: Turkey	
	0D: Holland	21: Greece	
	0E: Spain	22: Hungary	- -
	0F: Israel	23: Czech	
	10:	24: Poland	

Syst	System Switch 10 [SP No. 1-101-017]			
No	FUNCTION	COMMENTS		
0-7	Threshold memory level for parallel memory transmission	Threshold = N x 128 KB + 256 KB N can be between 00 - FF(H) Default setting: 02(H) = 512 KB		

Syst	System Switch 11 [SP No. 1-101-018]				
No	FUNCTION	COMMENTS			
0	TTI printing position 0: Superimposed on the page data 1: Printed before the data leading edge	Change this bit to 1 if the TTI overprints information that the customer considers to be important (G3 transmissions).			
1	Not used	Japan Only			
2-7	Not used	Do not change the factory settings.			

Syst	System Switch 12 [SP No. 1-101-019]				
No	FUNCTION	COMMENTS			
0-7	TTI printing position in the main scan direction	TTI: 08 to 92 (BCD) mm Input even numbers only. This setting determines the print start position for the TTI from the left edge of the paper. If the TTI is moved too far to the right, it may overwrite the file number which is on the top right of the page. On an A4 page, if the TTI is moved over by more than 50 mm, it may overwrite the page number.			

System Switch 13 - Not used (do not change these settings)

System Switch 14 - Not used (do not change these settings)

Syst	System Switch 15 [SP No. 1-101-022]				
No	FUNCTION	COMMENTS			
0	Not used	Do not change the settings.			
1	Going into the Energy Saver mode automatically 0: Enabled 1: Disabled	1: The machine will restart from the Energy Saver mode quickly, because the +5V power supply is active even in the Energy Saver mode.			
2-3	Not used	Do not change these settings.			
4-5	Interval for preventing the machine from entering Energy Saver mode if there is a pending transmission file. Bit 5: 0, Bit 4: 0 1 min Bit 5: 0, Bit 4: 1 30 min1 Bit 5: 1, Bit 4: 0 1 hour Bit 5: 1, Bit 4: 1 24 hours	If there is a file waiting for transmission, the machine does not go to Energy Saver mode during the selected period. After transmitting the file, if there is no file waiting for transmission, the machine goes to the Energy Saver mode.			
6-7	Not used	Do not change			

System Switch 16 [SP No. 1-101-023]				
No	FUNCTION	COMMENTS		
0	Parallel Broadcasting 0: Disabled 1: Enabled	The machine sends messages simultaneously using all available ports during broadcasting.		
1-7	Not used	Do not change these settings.		

System Switch 17 - Not used (do not change these settings)

System Switch 18 - Not used (do not change these settings)

System Switch 19 [SP No. 1-101-026]				
No	FUNCTION	COMMENTS		
0-6	Not used	Do not change the settings.		
7	Special Original mode 0: Disabled 1: Enabled	1: If the customer frequently wishes to transmit a form or letterhead which has a colored or printed background, change this bit to "1". "Original 1" and "Original 2" can be selected in addition to the "Text", "Text/Photo" and "Photo" modes.		

System Switch 1A - Not used (do not change these settings)

System Switch 1B [SP No. 1-101-028]

In this switch setting, there is a limitation. Do not select the same image quality in two modes.

e.g) these setting combination is not allowed:

[Bit1: 0, Bit 0: 1 = **Text**] [Bit3: 0, Bit 2:0 = Photo/ Diffusion]

[Bit 6: 0, Bit 5: 0, Bit 4: 0 = **Text**]

No.	FUNCTION						COMMENTS
0-1	Image Quality in Text mode Bit 1: 0, Bit 0: 0 = Text/ Sharp Bit 1: 0, Bit 0: 1 = Text			-p	image	etting determines the desirable scanning quality when the text mode is selected to operation panel.	
2-3	Image Quality in Photo mode Bit 3: 0, Bit 2: 0 = Photo/ Diffusion Bit 3: 0, Bit 2: 1 = Photo/ Dithering			е	image	etting determines the desirable scanning quality when the photo mode is selected to operation panel.	
	Image Quality in Special Original mode					image	etting determines the desirable scanning quality when the special original mode is ed with the operation panel.
	Bit 6	Bit 5	Bit 4	Mode		;	
	0	0	0	Text			
4-6	0	0	1	Text/ Sha		arp	
	0	1	0	Photo/ Diffe		usion	
	0	1	1	Photo/ Dith		nering	
	1	0	0	Dropout c		color	
	1	0	1	-			
7	Not used Do			Do r	not char	nge these settings.	

System Switch 1C - Not used (do not change these settings)

Syste	System Switch 1D [SP No. 1-101-030]				
No	FUNCTION	COMMENTS			
0	RTI/CSI/CPS code display 0: Enable 1: Disable	0: RTI, CSI, CPS codes are displayed on the top line of the LCD panel during communication. 1: Codes are switched off (no display)			
1	Not used	Do not change this setting.			
2	Destination telephone number display limitation 0: OFF, 1: ON	When "1" is selected, the destination telephone number display is limited and redial is disabled.			
3	Operation selection without PIN code registered 0: Transmission interrupted 1: No interrupted transmission	0: When "0" is selected without PIN code registration, transmission is interrupted and an alert message shows on the LCD.			
4-7	Not used	Do not change these settings.			

Syst	System Switch 1E [SP No. 1-101-031]				
No	FUNCTION	COMMENTS			
0	Communication after the Journal data storage area has become full 0: Impossible 1: Possible	 0: When this switch is on and the journal history becomes full, the next report prints. If the journal history is not deleted, the next transmission cannot be received. This prevents overwriting communication records before the machine can print them. 1: If the buffer memory of the communication records for the Journal is full, fax communications are still possible. But the machine will overwrite the oldest communication records. Note: This setting is effective only when Automatic Journal printout is enabled but the machine cannot print the report (e.g., no paper). 			
1	Action when the SAF memory has become full during scanning 0: The current page is erased. 1: The entire file is erased.	O: If the SAF memory becomes full during scanning, the successfully scanned pages are transmitted. 1: If the SAF memory becomes full during scanning, the file is erased and no pages are transmitted. This bit switch is ignored for parallel memory transmission.			
2	RTI/CSI display priority 0: RTI 1: CSI	This bit determines which identifier, RTI or CSI, is displayed on the LCD while the machine is communicating in G3 non-standard mode.			
3	File No. printing 0: Enabled 1: Disabled	1: File numbers are not printed on any reports.			

4	Action when authorized reception is enabled but authorized RTIs/CSIs are not yet programmed 0: All fax reception is disabled 1: Faxes can be received if the sender has an RTI or CSI	If authorized reception is enabled but the user has stored no acceptable sender RTIs or CSIs, the machine will not be able to receive any fax messages. If the customer wishes to receive messages from any sender that includes an RTI or CSI, and to block messages from senders that do not include an RTI or CSI, change this bit to "1", then enable Authorized Reception. Otherwise, keep this bit at "0 (default setting)".
5-7	Not used	Do not change the settings

Syst	System Switch 1F [SP No. 1-101-032]				
No	FUNCTION	COMMENTS			
0	Not used	Do not change the settings.			
1	Report printout after an original jam during SAF storage or if the SAF memory fills up 0: Enabled 1: Disabled	0: When an original jams, or the SAF memory overflows during scanning, a report will be printed. Change this bit to "1" if the customer does not want to have a report in these cases. Memory tx – Memory storage report Parallel memory tx – Transmission result report			
2	Not used	Do not change the settings.			
3	Received fax print start timing (G3 reception) 0: After receiving each page 1: After receiving all pages	0: The machine prints each page immediately after the machine receives it.1: The machine prints the complete message after the machine receives all the pages in the memory.			

Bit Switches

4-6	Not used	Do not change the factory settings.
7	Action when a fax SC has occurred 0: Automatic reset 1: Fax unit stops	O: When the fax unit detects a fax SC code other than SC1201 and SC1207, the fax unit automatically resets itself. 1: When the fax unit detects any fax SC code, the fax unit stops. Cross Reference Fax SC codes - See "Troubleshooting"

Appendix: Fax Service Program

7.2.2 I-FAX SWITCHES

I-fax Switch 00 - Not used (do not change the settings) [SP No. 1-102-001]

I-fax	I-fax Switch 01 [SP No. 1-102-002]		
No	FUNCTION	COMMENTS	
	Original Line Resolution of TX Attachment File	These settings set the maximum resolution of the original that the destination can receive.	
0	200x100 Standard		
1	200x200 Detail	0: Not selected	
2	200x400 Fine	1: Selected	
3	300 x 300 Reserve	If more than one of these three bits is set to "1", the higher resolution has priority. For example, if	
4	400 x 400 Super Fine	both Bit 0 and Bit 2 are set to "1" then the	
5	600 x 600 Reserve	resolution is set for "Bit 2 200 x 400.	
6	Reserve		

mm/inch

This setting selects mm/inch conversion for mail transmission.

0: Off (No conversion), 1: On (Conversion)

When on (set to "1"), the machine converts millimeters to inches for sending mail.

There is no switch for converting inches to millimeters.

Unlike G3 fax transmissions which can negotiate between sender and receiver to determine the setting, mail cannot negotiate between terminals; the mm/inch selection is determined by the sender fax.

7 When this switch is Off (0):

Images scanned in inches are sent in inches.

Images scanned in mm are sent in mm.

Images received in inches are transmitted in inches.

Images received in mm are transmitted in mm.

When this switch is On (1):

Images scanned in inches are sent in inches.

Images scanned in mm are converted to inches.

Images received in inches are transmitted in inches.

Images received in mm are converted to inches.

I-fax Switch 02 [SP No. 1-102-003]		
No	FUNCTION	COMMENTS
	RX Text Mail Header Processing	
0	This setting determines whether the header information is printed with text e-mails when they are received. 0: Prints only text mail. 1: Prints mail header information attached to text mail. When a text mail is received with this switch On (1), the "From" address and "Subject" address are printed as header information. When a mail with only binary data is received (a TIFF-F file, for example), this setting is ignored and no header is printed.	
	Output from Attached Document at E-mail TX Error	
This setting determines whether only the first page or all parattachment are printed at the sending station when a transit This allows the customer to see which documents have not destinations if sent to the wrong e-mail addresses, for example 1: Prints 1st page only. 1: Prints all pages.		ending station when a transmission error occurs. which documents have not reached their intended

Text String for Return Receipt

This setting determines the text string output for the Return Receipt that confirms the transmission was received normally at the destination.

00: "Dispatched"

Sends from PC mail a request for a Return Receipt. Receives the Return Receipt with "dispatched" in the 2nd part:

Disposition: Automatic-action/MDN-send automatically; dispatched

The "dispatched" string is included in the Subject string.

2-3 01: "Displayed"

Sends from PC mail a request for a Return Receipt. Receives the Return Receipt with "displayed" in the 2nd part:

Disposition: Automatic-action/MDN-send automatically; displayed

The "displayed" string is included in the Subject string.

10: Reserved

11: Reserved

A mail requesting a Return Receipt sent from an IFAX with this switch set to "00" (for "dispatched") received by Microsoft Outlook 2000 may cause an error. If any setting other than "displayed" (01) causes a problem, change the setting to "01" to enable normal sending of the Return Receipt.

Media accept feature

This setting adds or does not add the media accept feature to the answer mail to confirm a reception.

0: Does not add the media accept feature to the answer mail

1: Adds the media accept feature to the answer mail.

Use this bit switch if a problem occurs when the machine receives an answer mail, which contains the media accept feature field.

SM Appendix

5-6 Not Used

4

Image Resolution of RX Text Mail

This setting determines the image resolution of the received mail.

0: 200 x 200

1: 400 x 400

7

The "1" setting requires installation of the Function Upgrade Card in order to have enough SAF (Store and Forward) memory to receive images at 400 x 400 resolution.

I-fax Switch 03 - Not used (do not change the settings) [SP No. 1-102-004]

I-fax Switch 04 [SP No. 1-102-005]			
No	FUNCTION	COMMENTS	
	Subject for Delivery TX/Memory Transfer		
0	Subject for Delivery TX/Memory Transfer This setting determines whether the RTI/CSI registered on this machine or the RTI/CSI of the originator is used in the subject lines of transferred documents. 0: Puts the RTI/CSI of the originator in the Subject line. If this is used, either the RTI or CSI is used. Only one of these can be received for use in the subject line. 1: Puts the RTI/CSI registered on this machine in the Subject line. When this switch is used to transfer and deliver mail to a PC, the information in the Subject line that indicates where the transmission originated can be used to determine automatically the destination folder for each e-mail.		

Subject corresponding to mail post database

- 0: Standard subject
- 1: Mail post database subject

The standard subject is replaced by the mail post database subject in the following three cases:

- 1) When the service technician sets the service (software) switch.
- 1 2) When memory sending, delivery specified by F code or SMTP reception is done.
 - 3) With relay broadcasting (1st stage without the Schmidt 4 function).

↓ Note

This switch does not apply for condition 3) when the RX system is set up for memory sending, delivery by F-code, sending with SMTP RX and when operators are using FOL (to prevent problems when receiving transmissions).

2-7 Not Used

I-fax	I-fax Switch 05 [SP No. 1-102-006]		
No	FUNCTION	COMMENTS	
0	Mail Addresses of SMTP Broadcast Recipients		
	transmissions broadcasted using For example:	addresses of the destinations that receive g SMTP protocol are recorded in the Journal. of destinations: 9" in the Journal indicates a	
1	I-Fax Automatic Re-dial Setting 0: OFF 1: ON	Determines whether the I-fax automatically redials when an error occurs.	
2-7	Not used	•	

I-fax Switch 06 - Not used (do not change the settings) [SP No. 1-102-007]

I-fax Switch 07 - Not used (do not change the settings) [SP No. 1-102-008]

I-fax Switch 08 [SP No. 1-102-009]		
FUNCTION	COMMENTS	
Memory Threshold for POP Mail Reception		
This setting determines the amount of SAF (Store and Forward) memory. (SAF stores fax messages to send later for transmission to more than one location, also holds incoming messages if they cannot be printed.) When the amount of		
memory available falls below th mail is then stored on the mail s	y available falls below this setting, mail can no longer be received; received then stored on the mail server.	
00-FF (0 to 1024 KB: HEX)		
Note		
■ The hexadecimal number you enter is multiplied by 4 KB to determine the		
	FUNCTION Memory Threshold for POP Main This setting determines the amount stores fax messages to send lateral also holds incoming messages memory available falls below the mail is then stored on the mail is 00-FF (0 to 1024 KB: HEX)	

I-fax	I-fax Switch 09 [SP No. 1-102-010]		
No	FUNCTION	COMMENTS	
0-3	Not used	Do not change the settings	
4-7	Restrict TX Retries	This setting determines the number of retries when connection and transmission fails due to errors. 01-F (1-15 Hex)	

I-fax Switch 0A - Not used (do not change the settings) [SP No. 1-102-011]
I-fax Switch 0B - Not used (do not change the settings) [SP No. 1-102-012]
I-fax Switch 0C - Not used (do not change the settings) [SP No. 1-102-013]
I-fax Switch 0D - Not used (do not change the settings) [SP No. 1-102-014]
I-fax Switch 0E - Not used (do not change the settings) [SP No. 1-102-015]

I-fax	I-fax Switch 0F [SP No. 1-102-016]		
No	FUNCTION	COMMENTS	
	Delivery Method for SMTP RX Files		
0	This setting determines whether files received with SMTP protocol are delive output immediately. O: Off. Files received via SMTP are output immediately without delivery. 1: On. Files received via SMTP are delivered immediately to their destination.		
1-7	Not used		

7.2.3 PRINTER SWITCHES

Print	Printer Switch 00 [SP No. 1-103-001]		
No	FUNCTION	COMMENTS	
0	Select page separation marks 0: Off 1: On	 0: If a 2 page RX transmission is split, [*] is printed in the bottom right corner of the 1st page and only a [2] is printed in the upper right corner of the 2nd page. 1: If a 2 page RX transmission is split into two pages, for example, [*] [2] is printed in the bottom right corner of the 1st page and only a [2] is printed in the upper right corner of the 2nd page. Note This helps the user to identify pages that have been split because the size of the paper is smaller than the size of the document received. (When A5 is used to print an A4 size document, for example.) 	
1	Repetition of data when the received page is longer than the printer paper 0: Off 1: On	1: Default. 10 mm of the trailing edge of the previous page are repeated at the top of the next page. 0: The next page continues from where the previous page stopped without any repeated text.	
2	Prints the date and time on received fax messages 0: Disabled 1: Enabled	This switch is only effective when user parameter 02 - bit 2 (printing the received date and time on received fax messages) is enabled. 1: The machine prints the received and printed date and time at the bottom of each received page.	
3-7	Not used	Do not change the settings.	

Printer Switch 01 - Not used (do not change the settings) [SP No. 1-103-002]

Print	Printer Switch 02 [SP No. 1-103-003]			
No	FUNCTION	COMMENTS		
0	1st paper feed station usage for fax printing 0: Enabled 1: Disabled	0: The paper feed station can be used to print fax messages and reports.1: The specified paper feed station will not be used for printing fax messages and reports.		
1	2nd paper feed station usage for fax printing 0: Enabled 1: Disabled	■ Do not disable usage for a paper feed station which has been specified by User Parameter Switch 0F (15), or which is used for the Specified Cassette Selection feature.		
2-7	Not used	Do not change the settings.		

Print	Printer Switch 03 [SP No. 1-103-004]			
No	FUNCTION	COMMENTS		
0	Length reduction of received data 0: Disabled 1: Enabled	0: Incoming pages are printed without length reduction. (Page separation threshold: Printer Switch 03, bits 4 to 7) 1: Incoming page length is reduced when printing. (Maximum reducible length: Printer Switches 04, bits 0 to 4)		
1-3	Not used	Do not change the settings		

4-7	Page separation setting when sub scan compression is forbidden 00-0F (0-15 mm: Hex) Default: 6 mm	Page separation threshold (with reduction disabled with switch 03-0 above). For example, if this setting is set to "10", and A4 is the selected paper size: If the received document is 10 mm or less longer than A4, then the 10 mm are cut and only 1 page prints. If the received document is 10 mm longer than A4, then the document is onlit into 2 pages.
		then the document is split into 2 pages.

Print	Printer Switch 04 SP No. 1-103-005						
No	FUNCTION				CON	MENTS	
	Maximum reducible length when length reduction is enabled with switch 03-0 above. <maximum length="" reducible=""> = <paper length=""> + (N x 5mm) "N" is the decimal value of the binary setting of bits 0 to 4.</paper></maximum>						
	Bit 4	Bit 3	Bit 2	2	Bit 1	Bit 0	Setting
0-4	0	0	0		0	0	0 mm
	0	0	0		0	1	5 mm
	0	0	1		0	0	20 mm
	1	1	1		1	1	155 mm
		ays and B5 sideducible length			ngth> + 0.75 >	(N x 5mm)	

5-6	place. Bit 6: 0, Bit 5: 0 = 4 mm Bit 6: 1, Bit 5: 0 = 10 mm	on the next page, when page separation has taken
	Bit 6: 0, Bit 5: 1 = 15 mm Bit 6: 1, Bit 5: 1 = Not used	
7	Not used.	Do not change the setting.

Printer Switch 05 - Not used (do not change the settings)

Print	Printer Switch 06 [SP No. 1-103-007]		
No	FUNCTION	COMMENTS	
0	Printing while a paper cassette is pulled out, when the Just Size Printing feature is enabled. 0: Printing will not start 1: Printing will start if another cassette has a suitable size of paper, based on the paper size selection priority tables.	Cross reference Just size printing on/off – User switch 05, bit 5	
1-7	Not used.	Do not change the settings.	

Print	Printer Switch 07 [SP No. 1-103-008]			
No	FUNCTION	COMMENTS		
0-3	Not used.	Do not change the settings.		
4	List of destinations in the Communication Failure Report for broadcasting 0: All destinations 1: Only destinations where communication failure occurred	1: Only destinations where communication failure occurred are printed on the Communication Failure Report.		
5-7	Not used.	Do not change the settings.		

Printer Switch 08 - Not used (do not change the settings) [SP No. 1-103-009]
Printer Switch 09 - Not used (do not change the settings) [SP No. 1-103-010]
Printer Switch 0A - Not used (do not change the settings) [SP No. 1-103-011]
Printer Switch 0B - Not used (do not change the settings) [SP No. 1-103-012]
Printer Switch 0C - Not used (do not change the settings) [SP No. 1-103-013]
Printer Switch 0D - Not used (do not change the settings) [SP No. 1-103-014]

Printe	Printer Switch 0E [SP No. 1-103-015]			
No	FUNCTION	COMMENTS		
0	Paper size selection priority 0: Width 1: Length	O: A paper size that has the same width as the received data is selected first. 1: A paper size which has enough length to print all the received lines without reduction is selected first.		
1	Paper size selected for printing A4 width fax data 0: 8.5" x 11" size 1: A4 size	This switch determines which paper size is selected for printing A4 width fax data, when the machine has both A4 and 8.5" x 11" size paper.		
2	Page separation 0: Enabled 1: Disabled	1: If all paper sizes in the machine require page separation to print a received fax message, the machine does not print the message (Substitute Reception is used). After a larger size of paper is set in a cassette, the machine automatically prints the fax message.		
3-4	Printing the sample image on reports Bit 4: 0, Bit 3: 0 = The upper half only Bit 4: 0, Bit 3: 1 = 50% reduction in sub-scan only Bit 4: 1, Bit 3: 0 = Same size Bit 4: 1, Bit 3: 1 = Not used	"Same size" means the sample image is printed at 100%, even if page separation occurs. User Parameter Switch 19 (13H) bit 4 must be set to "0" to enable this switch. Refer to Detailed Section Descriptions for more on this feature.		
5-6	Not used	Do not change the settings.		

		0: When page separation has taken place,
	Equalizing the reduction ratio	all the pages are reduced with the same
	among separated pages	reduction ratio.
7	(Page Separation)	1: Only the last page is reduced to fit the
	0: Enabled	selected paper size when page separation
	1: Disabled	has taken place. Other pages are printed
		without reduction.

Print	Printer Switch 0F [SP No. 1-103-016]		
No	FUNCTION	COMMENTS	
0-1	Smoothing feature Bit 1: 0 Bit 0: 0 = Disabled Bit 1: 0 Bit 0: 1 = Disabled Bit 1: 1 Bit 0: 0 = Enabled Bit 1: 1 Bit 0: 1 = Not used	(0, 0) (0, 1): Disable smoothing if the machine receives halftone images from other manufacturers fax machines frequently.	
2-7	Not used	Do not change the settings.	

7.2.4 COMMUNICATION SWITCHES

Com	Communication Switch 00 [SP No. 1-104-001]			
No	FUNCTION	COMMENTS		
0-1	Compression modes available in receive mode Bit 1: 0 Bit 0: 0 = MH only Bit 1: 0 Bit 0: 1 = MH/MR Bit 1: 1 Bit 0: 0 = MH/MR/MMR Bit 1: 1 Bit 0: 1 = MH/MR/MMR/JBIG	These bits determine the compression capabilities to be declared in phase B (handshaking) of the T.30 protocol.		
2-3	Compression modes available in transmit mode Bit 3: 0 Bit 2: 0 = MH only Bit 3: 0 Bit 2: 1 = MH/MR Bit 3: 1 Bit 2: 0 = MH/MR/MMR Bit 3: 1 Bit 2: 1 = MH/MR/MMR/JBIG	These bits determine the compression capabilities to be used in the transmission and to be declared in phase B (handshaking) of the T.30 protocol.		
4	Not used	Do not change the settings.		
5	JBIG compression method: Reception 0: Only basic supported 1: Basic and optional both supported	Change the setting when communication problems occur using JBIG compression.		
6	JBIG compression method: Transmission 0: Basic mode priority 1: Optional mode priority	Change the setting when communication problems occur using JBIG compression.		
7	Not used	Do not change the settings.		

Com	Communication Switch 01 [SP No. 1-104-002]		
No	FUNCTION	COMMENTS	
0	ECM 0: Off 1: On	If this bit is set to 0, ECM is switched off for all communications. In addition, V.8 protocol and JBIG compression are switched off automatically.	
1-5	Not used	Do not change the setting.	
6-7	Maximum printable page length available Bit 7: 0 Bit 6: 0 = No limit Bit 7: 0 Bit 6: 1 = B4 (364 mm) Bit 7: 1 Bit 6: 0 = A4 (297 mm) Bit 7: 1 Bit 6: 1 = Not used	The setting determined by these bits is informed to the transmitting terminal in the pre-message protocol exchange (in the DIS/NSF frames).	

Communication Switch 02 [SP No. 1-104-003]			
No	FUNCTION		COMMENTS
0	G3 Burst error threshold 0: Low 1: High	received pa send a neg threshold va	more consecutive error lines in the age than the threshold, the machine will ative response. The Low and High alues depend on the sub-scan and are as follows. $6(L) \rightarrow 12(H)$ $12(L) \rightarrow 24(H)$ $18(L) \rightarrow 36(H)$ $24(L) \rightarrow 48(H)$
1	Acceptable total error line ratio 0: 5% 1: 10%		line ratio for a page exceeds the ratio, RTN will be sent to the other end.

2	Treatment of pages received with errors during G3 reception 0: Deleted from memory without printing 1: Printed	0: Pages received with errors are not printed.
3	Hang-up decision when a negative code (RTN or PIN) is received during G3 immediate transmission 0: No hang-up, 1: Hang-up	O: The next page will be sent even if RTN or PIN is received. 1: The machine will send DCN and hang up if it receives RTN or PIN. This bit is ignored for memory transmissions or if ECM is being used.
4-7	Not used	Do not change the settings.

Com	Communication Switch 03 [SP No. 1-104-004]		
No	FUNCTION	COMMENTS	
0-7	Maximum number of page retransmissions in a G3 memory transmission	00 - FF (Hex) times. This setting is not used if ECM is switched on. Default setting - 03(H)	

Communication Switch 04 - Not used (do not change the settings)
Communication Switch 05 - Not used (do not change the settings)
Communication Switch 06 - Not used (do not change the settings)
Communication Switch 07 - Not used (do not change the settings)
Communication Switch 08 - Not used (do not change the settings)

Communication Switch 09 [SP No. 1-104-010]		
No	FUNCTION	COMMENTS
0-7	I-Fax dial interval setting	Adjusts the interval of the I-fax dialing. The interval of I-fax dialing is calculated by following formula. [Interval time = specified value with this switch x 2 sec]

Communication Switch 0A [SP No. 1-104-011]		
No	FUNCTION	COMMENTS
0	Point of resumption of memory transmission upon redialing 0: From the error page 1: From page 1	O: The transmission begins from the page where transmission failed the previous time. 1: Transmission begins from the first page, using normal memory transmission.
1-7	Not used	Do not change the settings.

Communication Switch 0B – Not used (do not change the settings)

Communication Switch 0C – Not used (do not change the settings)

Com	Communication Switch 0D [SP No. 1-104-014]		
No	FUNCTION	COMMENTS	
0-7	The available memory threshold, below which ringing detection (and therefore reception into memory) is disabled	00 to FF (Hex), unit = 4 kbytes (e.g., 06(H) = 24 kbytes) One page is about 24 kbytes. The machine refers to this setting before each fax reception. If the amount of remaining memory is below this threshold, the machine cannot receive any fax messages. If this setting is kept at 0, the machine will detect ringing signals and go into receive mode even if there is no memory available. This will result in communication failure.	

Com	Communication Switch 0E [SP No. 1-104-015]		
No	FUNCTION	COMMENTS	
0-7	Minimum interval between automatic dialing attempts	06 to FF (Hex), unit = 2 s (e.g., 06(H) = 12 s) This value is the minimum time that the machine waits before it dials the next destination.	

Communication Switch 0F - Not used (do not change the settings.)

Communication Switch 10 [SP No. 1-104-017]		
No	FUNCTION	COMMENTS
0-7	Memory transmission: Maximum number of dialing attempts to the same destination	01 – FE (Hex) times

D067/D068/D069/D072

Communication Switch 11 – Not used (do not change the settings.)

Com	Communication Switch 12 [SP No. 1-104-019]		
No	FUNCTION	COMMENTS	
0-7	Memory transmission: Interval between dialing attempts to the same destination	01 – FF (Hex) minutes	

Communication Switch 13 – Not used (do not change the settings.)

Com	Communication Switch 14 [SP No. 1-104-021]		
No	FUNCTION	COMMENTS	
0	Inch-to-mm conversion during transmission 0: Disabled 1: Enabled	O: In immediate transmission, data scanned in inch format are transmitted without conversion. In memory transmission, data stored in the SAF memory in mm format are transmitted without conversion. Note: When storing the scanned data into SAF memory, the fax unit always converts the data into mm format. 1: The machine converts the scanned data or stored data in the SAF memory to the format which was specified in the set-up protocol (DIS/NSF) before transmission.	
1-5	Not used	Do not change the factory settings.	

6-7	Available unit of resolution in which fax messages are received Bit 7: 0, Bit 6: 0 = mm Bit 7: 0, Bit 6: 1 = inch Bit 7: 1, Bit 6: 0 = mm and inch (default)	For the best performance, do not change the factory settings. The setting determined by these bits is informed to the transmitting terminal in the pre-message protocol exchange (in the DIS/NSF frames).
	Bit 7: 1, Bit 6: 1 = Not used	

Communication Switch 15 – Not used (do not change the settings)
Communication Switch 16 – Not used (do not change the settings)
Communication Switch 17 – Not used (do not change the settings)
Communication Switch 18 - Not used (do not change the settings)
Communication Switch 19 - Not used (do not change the settings)
Communication Switch 1A - Not used (do not change the settings)

Com	Communication Switch 1B [SP No. 1-104-028]			
No	FUNCTION	COMMENTS		
0-7	Extension access code (0 to 7) to turn V.8 protocol On/Off 0: On 1: Off	If the PABX does not support V.8/V.34 protocol procedure, set this bit to "1" to disable V.8. Example: If "0" is the PSTN access code, set bit 0 to 1. When the machine detects "0" as the first dialed number, it automatically disables V.8 protocol. (Alternatively, if "3" is the PSTN access code, set bit 3 to 1.)		

Com	Communication Switch 1C [SP No. 1-104-029]				
No	FUNCTION	COMMENTS			
0-1	Extension access code (8 and 9) to turn V.8 protocol On/Off 0: On 1: Off	Refer to communication switch 1B. Example: If "8" is the PSTN access code, set bit 0 to 1. When the machine detects "8" as the first dialed number, it automatically disables V.8 protocol. (If "9" is the PSTN access code, use bit 1.)			
2-7	Not used	Do not change the settings.			

Communication Switch 1D - Not used (do not change the settings)

Communication Switch 1E - Not used (do not change the settings)

Communication Switch 1F - Not used (do not change the settings)

7.2.5 G3-1 SWITCHES

G3 S	G3 Switch 00 [SP No. 1-105-001]				
No	FUNCTION	COMMENTS			
0-1	Monitor speaker during communication (tx and rx) Bit 1: 0, Bit 0: 0 = Disabled Bit 1: 0, Bit 0: 1 = Up to Phase B Bit 1: 1, Bit 0: 0 = All the time Bit 1: 1, Bit 0: 1 = Reserved	 (0, 0): The monitor speaker is disabled all through the communication. (0, 1): The monitor speaker is on up to phase B in the T.30 protocol. (1, 0): Used for testing. The monitor speaker is on all through the communication. Make sure that you reset these bits after testing. 			
2	Monitor speaker during memory transmission 0: Disabled 1: Enabled	1: The monitor speaker is enabled during memory transmission.			
3-7	Not used	Do not change the settings.			

G3 S	G3 Switch 01 [SP No. 1-105-002]				
No	FUNCTION	COMMENTS			
0-3	Not used	Do not change the settings.			
4	DIS frame length 0: 10 bytes 1: 4 bytes	1: The bytes in the DIS frame after the 4th byte will not be transmitted (set to 1 if there are communication problems with PC-based faxes which cannot receive the extended DIS frames).			
5	Not used	Do not change the setting.			
6	Forbid CED/AMsam output 0: Off 1: On (Forbid output)	Do not change this setting (Default: 0: Off), unless communication problem is caused by a CED or ANSam transmission.			
7	Not used	Do not change the setting.			

G3 S	G3 Switch 02 [SP No. 1-105-003]				
No	FUNCTION	COMMENTS			
0	G3 protocol mode used 0: Standard and non-standard 1: Standard only	Change this bit to 1 only when the other end can only communicate with machines that send T.30-standard frames only. 1: Disables NSF/NSS signals (these are used in non-standard mode communication)			
1-6	Not used	Do not change the settings.			
7	Short preamble 0: Disabled 1: Enabled	Refer to Appendix B in the Group 3 Facsimile Manual for details about Short Preamble.			

G3 S	G3 Switch 03 [SP No. 1-105-004]				
No	FUNCTION	COMMENTS			
0	DIS detection number (Echo countermeasure) 0: 1 1: 2	O: The machine will hang up if it receives the same DIS frame twice. 1: Before sending DCS, the machine will wait for the second DIS which is caused by echo on the line.			
1	Not Used	Do not change the settings.			
2	V.8 protocol 0: Disabled 1: Enabled	0: V.8/V.34 communications will not be possible. Note: Do not set to 0 unless the line condition is always bad enough to slow down the data rate to 14.4 kbps or lower.			
3	ECM frame size 0: 256 bytes 1: 64 bytes	Keep this bit at "0" in most cases.			

4	CTC transmission conditions 0: After one PPR signal received 1: After four PPR signals received (ITU-T standard)	0: When using ECM in non-standard (NSF/NSS) mode, the machine sends a CTC to drop back the modem rate after receiving a PPR, if the following condition is met in communications at 14.4, 12.0, 9.6, and 7.2 kbps. ✓ NTransmit ≤ NResend NTransmit- Number of transmitted frames NResend- Number of frames to be retransmitted 1: When using ECM, the machine sends a CTC to drop back the modem rate after receiving four PPRs. PPR, CTC: These are ECM protocol signals. This bit is not effective in V.34 communications.
5	Modem rate used for the next page after receiving a negative code (RTN or PIN) 0: No change 1: Fallback	1: The machine's tx modem rate will fall back before sending the next page if a negative code is received. This bit is ignored if ECM is being used.
6	Not Used	Do not change the settings
7	Select detection of reverse polarity in ringing 0: Off 1: On	This switch is used to prevent reverse polarity in ringing on the phone line (applied to PSTN-G3 ringing). Do not change this setting 0: No detection ⇒ Outside Japan 1: Detection ⇒ Inside Japan only

G3 Switch 04 [SP No. 1-105-005]				
No	FUNCTION	COMMENTS		
0-3	Training error detection threshold	0 - F (Hex); 0 - 15 bits If the number of error bits in the received TCF is below this threshold, the machine informs the sender that training has succeeded.		
4-7	Not used	Do not change the settings.		

G3 S	G3 Switch 05 [SP No. 1-105-006]					
No	FUNCTION					COMMENTS
	Initial Tx modem rate					
	Bit 3	Bit 2	Bit 1	Bit 0	bps	
	0	0	0	1	2.4k	
	0	0	1	0	4.8k	
	0	0	1	1	7.2k	
	0	1	0	0	9.6k	
	0	1	0	1	12.0k	These bits set the initial starting modem rate for transmission.
	0	1	1	0	14.4k	Use the dedicated transmission parameters if
0-3	0	1	1	1	16.8k	you need to change this for specific receivers. If a modem rate 14.4 kbps or slower is selected V.8 protocol should be disabled manually. Cross reference V.8 protocol on/off - G3 switch 03, bit2
	1	0	0	0	19.2k	
	1	0	0	1	21.6k	
	1	0	1	0	24.0k	
	1	0	1	1	26.4k	
	1	1	0	0	28.8k	
	1	1	0	1	31.2k	
	1	1	1	0	33.6k	
	Other settings - Not used				d l	

4-5	Initial modem type for 9.6 k or 7.2 kbps. Bit 5: 0, Bit 4: 0 = V.29 Bit 5: 0, Bit 4: 1 = V.17 Bit 5: 1, Bit 4: 0 = V.34 Bit 5: 1, Bit 4: 1 = Reserved	These bits set the initial modem type for 9.6 and 7.2 kbps, if the initial modem rate is set at these speeds.
6-7	Not used	Do not change the settings.

G3 S	G3 Switch 06 [SP No. 1-105-007]					
No			FUN	CTION	N	COMMENTS
	Initial	Rx m	odem	rate		
	Bit 3	Bit 2	Bit 1	Bit 0	bps	
	0	0	0	1	2.4k	
	0	0	1	0	4.8k	
	0	0	1	1	7.2k	
0 1 0 0 9.6k • Thes	Those site cot the initial starting					
	0	1	0	1	12.0k	modem rate for reception. Use a lower setting if high speeds
	0	1	1	0	14.4k	pose problems during reception.
0-3	0	1	1	1	16.8k	 If a modem rate 14.4 kbps or slower is selected, V.8 protocol should be
	1	0	0	0	19.2k	disabled manually.
	1	0	0	1	21.6k	Cross reference: V.8 protocol on/off - G3 switch 03, bit2
	1	0	1	0	24.0k	
	1	0	1	1	26.4k	
	1 1 0 0 28.8k					
	1	1	0	1	31.2k	
	1	1	1	0	33.6k	
	Other	settin	gs - N	ot use	ed	

	Mode	m type	es ava	ilable f	or reception	
	Bit 7	Bit 6	Bit 5	Bit 4	Setting	
	0	0	0	1	V.27ter	
	0	0	1	0	V.27ter,V.29	The setting of these bits is used to
	0	0	1	1	V.27ter, V.29, V.33	inform the transmitting terminal of the available modem type for the machine in receive mode.
4-7						
	0	1	0	1	V.27ter, V.29, V.17/V33, V.34	V.8 protocol on/off - G3 switch 03, bit2
	Other settings - Not used		d			

G3 S	G3 Switch 07 [SP No. 1-105-008]				
No	FUNCTION	COMMENTS			
0-1	PSTN cable equalizer (tx mode: Internal) Bit 1: 0, Bit 0: 0 = None Bit 1: 0, Bit 0: 1 = Low Bit 1: 1, Bit 0: 0 = Medium Bit 1: 1, Bit 0: 1 = High	Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone exchange. Use the dedicated transmission parameters for specific receivers. Also, try using the cable equalizer if one or more of the following symptoms occurs. Communication error Modem rate fallback occurs frequently. Note This setting is not effective in V.34 communications.			

2-3	PSTN cable equalizer (rx mode: Internal) Bit 3: 0, Bit 2: 0 = None Bit 3: 0, Bit 2: 1 = Low Bit 3: 1, Bit 2: 0 = Medium Bit 3: 1, Bit 2: 1 = High	Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone exchange. Also, try using the cable equalizer if one or more of the following symptoms occurs. Communication error with error codes such as 0-20, 0-23, etc. Modem rate fallback occurs frequently. Note This setting is not effective in V.34 communicatio
4	PSTN cable equalizer (V.8/V.17 rx mode: External) 0: Disabled 1: Enabled	Keep this bit at "1".
5	Not used	Do not change the settings.
6	Parameter selection for dial tone detection 0: Normal parameter 1: Specific parameter	0: This uses the fixed table in the ROM for dial tone detection. 1: This uses the specific parameter adjusted with SRAM (69ECBEH - 69ECDEH). Select this if the dial tone cannot be detected when the "Normal parameter: 0" is selected.
7	Not used	Do not change the settings.

G3 Switch 08 - Not used (do not change the settings)

G3 Switch 09 - Not used (do not change the settings)

G3 Sv	G3 Switch 0A [SP No. 1-105-011]					
No	FUNCTION	COMMENTS				
0-1	Maximum allowable carrier drop during image data reception Bit 1: 0, Bit 0: 0 = 200 Bit 1: 0, Bit 0: 1 = 400 Bit 1: 1, Bit 0: 0 = 800 Bit 1: 1, Bit 0: 1 = Reserved	These bits set the acceptable modem carrier drop time. Try using a longer setting if error code 0-22 is frequent.				
2	Select cancellation of high-speed RX if carrier signal lost while receiving 0: Off 1: On	This switch setting determines if high-speed receiving ends if the carrier signal is lost when receiving during non-ECM mode				
3	Not used	Do not change the settings				
4	Maximum allowable frame interval during image data reception. 0: 5 s 1: 13 s	This bit set the maximum interval between EOL (end-of-line) signals and the maximum interval between ECM frames from the other end. Try using a longer setting if error code 0-21 is frequent.				
5	Not used	Do not change the settings.				
6	Reconstruction time for the first line in receive mode 0: 6 s 1: 12 s	When the sending terminal is controlled by a computer, there may be a delay in receiving page data after the local machine accepts set-up data and sends CFR. This is outside the T.30 recommendation. But, if this delay occurs, set this bit to 1 to give the sending machine more time to send data. Refer to error code 0-20. ITU-T T.30 recommendation: The first line should come within 5 s of CFR.				

7	Not used	Do not change the settings.
---	----------	-----------------------------

G3 Switch 0B Not used (do not change the settings).

G3 Switch 0C Not used (do not change the settings).

G3 Switch 0D Not used (do not change the settings).

G3 S	G3 Switch 0E [SP No 1-105-015]				
	Set CNG send time interval Some machines on the receiving side may not be able to automatically switch the 3-second CNG interval.				
0-7	High order bit	3000-2250ms: 3000-50xNms 3000 – 50 x Nms 0F (3000 ms) ≤ N ≤ FF (2250 ms)			
	Low order bit	00-0E(3000-3700ms: 3000+50xNms 3000 − 50 x Nms 0F (3000 ms) ≤ N ≤ 0F (3700 ms)			

G3 S	Switch 0F [SP No. 1-105-016]	
No	FUNCTION	COMMENTS
0	Alarm when an error occurred in Phase C or later 0: Disabled 1: Enabled	If the customer wants to hear an alarm after each error communication, change this bit to "1".
1	Alarm when the handset is off-hook at the end of communication 0: Disabled 1: Enabled	If the customer wants to hear an alarm if the handset is off-hook at the end of fax communication, change this bit to "1".

2-3	Not used	Do not change the settings.
4	Sidaa manual calibration setting 0: Off 1: On	manually calibrates for communication with a line, whose current change occurs such as an optical fiber line.
5-6	Not used	Do not change the settings.

7.2.6 IP FAX SWITCHES

IP Fax	IP Fax Switch 00 [SP No. 1-111-001]				
No.	FUNCTION	COMMENTS			
0	Not used	Do not change this setting.			
1	IP Fax Transport 0: TCP, 1: UDP	Selects TCP or UDP protocol for IP-Fax			
2	IP Fax single port selection 0: OFF, 1: ON (enable)	Selects single data port.			
3	IP Fax double ports (single data port) selection 0: OFF, 1: ON (enable)	Selects whether IP-Fax uses a double port.			
4	IP Fax Gatekeeper 0: OFF, 1: ON (enable)	Enables/disables the communication via the gatekeeper for IP-Fax.			
5	IP Fax T30 bit signal reverse 0: LSB first, 1: MSB first	Reverses the T30 bit signal.			
6	IP Fax max bit rate setting 0: Not affected, 1: Affected	When "0" is selected, the max bit rate does not affect the value of the DIS/DCS. When "1" is selected, the max bit rate affects the value of the DIS/DCS.			
7	IP Fax received telephone number confirmation 0: No confirmation, 1: Confirmation	When "0" is selected, fax data is received without checking the telephone number. When "1" is selected, fax data is received only when confirming that the telephone number from the sender matches the registered telephone number in this machine. If this confirmation fails, the line is disconnected.			

IP-Fa	x Swite	ch 01				
No.		FUNCTION				COMMENTS
	Select IP FAX Delay Level					Raise the level by selecting a higher setting
	Bit3	Bit2	Bit1	Bit0	Setting	if too many transmission errors are occurring on the network.
	0	0	0	0	Level 0	If TCP/UDP is enabled on the network, raise
0-3	0	0	0	1	Level 1	this setting on the T.30 machine. Increasing the delay time allows the recovery of more
	0	0	1	0	Level 2	lost packets.
	0	0	1	1	Level 3	If only UDP is enabled, increase the number of redundant packets.
						Level 1 to 2: 3 Redundant packets Level 3: 4 Redundant packets
4-7	IP Fa	IP Fax preamble wait time setting			e setting	Selects the preamble wait time. [00 to 0f] There are 16 values in this 4-bit binary switch combination. Waiting time: set value level x 100 ms Max: 0f (1500 ms) Min: 00 (No wait time) The default is "0000" (00H).

IP Fax	IP Fax Switch 02 [SP No. 1-111-003]					
No.	FUNCTION	COMMENTS				
0	IP Fax bit signal reverse setting 0: Maker code setting 1: Internal bit switch setting	When "0" is selected, the bit signal reverse method is decided by the maker code. When "1" is selected, the bit signal reverse method is decided by the internal bit switch. (When communicating between IP Fax devices, LSB first is selected.)				

1	IP Fax transmission speed setting 0: Modem speed 1: No limitation	Selects the transmit speed for IP Fax communication.
2	SIP transport setting 0: TCP 1: UDP	This bit switch sets the transport that has priority for receiving IP Fax data. This function is activated only when the sender has both TCP and UDP.
3	CCM connection 0: No CCM connection 1: CCM connection	When "1" is selected, only the connection call message with H.323 or no tunneled H.245 is transmitted via CCM.
4	Message reception selection from non-registered SIP server 0: Answer 1: Not answer	O: This answers the INVITE message from the SIP server not registered for the machine. 1: This does not receive the INVITE message from the SIP server not registered for the machine and send a refusal message.
5	ECM communication setting 0: No limit for image compression 1: Limit for image compression	O: This does not limit the type of the image compression with ECM communication. 1: When the other end machine is Ciscco, this permits the image compression other than JBIG or MMR with ECM communication.
6-7	Not used	Do not change these settings.

IP Fax	IP Fax Switch 03 [SP No. 1-111-004]				
No.	FUNCTION	COMMENTS			
0	Effective field limitation for G3 standard function information 0: OFF, 1: 4byte (DIS)	Limits the effective field for standard G3 function information.			
1	Switching between G3 standard and G3 non standard 0: Enable switching 1: G3 standard only	Enables/disables switching between G3 standard and G3 non-standard.			
2	Not used.	Do not change this setting.			
3	ECM frame size selection at transmitting 0: 256byte, 1: 64byte	Selects the ECM frame size for sending.			
4	DIS detection times for echo prevention 0: 1 time, 1: 2 times	Sets the number of times for DIS to detect echoes.			
5	CTC transmission selection 0: PPRx1 1: PPRx4	When "0" is selected, the transmission condition is decided by error frame numbers. When "1" is selected, the transmission condition is based on the ITU-T method.			
6	Shift down setting at receiving negative code 0: OFF, 1: ON	Selects whether to shift down when negative codes are received.			
7	Not used	Do not change this setting.			

IP Fax	IP Fax Switch 04 [SP No. 1-111-005]					
No.	FUNCTION	COMMENTS				
0						
1	TCF error threshold	Sets the TCF error threshold level. [00 to 0f]				
2	Tor chor uncondu	The default is "1111" (0fH).				
3						
4-7	Not used	Do not change these settings.				

IP Fax	P Fax Switch 05 [SP No. 1-111-006]					
No.	FUNCTION				СОММ	ENTS
0-3	Modem bit rate setting for transmission Sets the modem bit rate for transmission. The default is "0110" (14.4K bps).				10" (14.4K bps).	
	Bit 4	Bit 3		Bit 2	Bit 1	
	0	0		0	1	2400 bps
	0	0		1	1	4800 bps
	0	0		1	1	7200 bps
	0	1		0	0	9600 bps
	0	1		0	1	12.0 Kbps
	0	1		1	0	14.4 Kbps
	0	1		1	1	16.8 Kbps
	1	0		0	0	19.2 Kbps
	1	0		0	1	21.6 Kbps
	1	0		1	0	24.0 Kbps

	ė	
×	<u> 2</u>	Ξ
•	>	6
Ξ	7	7
Ð	Š	9
9	м	5
9	æ	屲
4	ш	

	1	0	1	1	26.4 Kbps
	1	1	0	0	28.8 Kbps
	1	1	0	1	31.2 Kbps
	1	1	1	0	33.6 Kbps
4-5	Modem setting for transmission Sets the modem for transmission. The default is "00" (V29). Bit 5: 0, Bit 4: 0 = V29 Bit 5: 0, Bit 4: 1 = V17 Bit 5: 1, Bit 4: 0 = V34* Bit 5: 1, Bit 4: 1 = Not used *V34 is not supported for IP-Fax communication.				
6-7	Not used		Do not o	change these se	ettings.

IP Fax	IP Fax Switch 06 [SP No. 1-111-007]						
No.	FUNCTION			COMM	IENTS		
	Modem bit rate setting for reception Sets the modem bit rate for reception. The default is "0110" (14.4K bps).						
	Bit 3	Bit 2	Bit 1 Bit				
	0	0		0	1	2400 bps	
	0	0		1	0	4800 bps	
	0	0		1	1	7200 bps	
	0	1		0	0	9600 bps	
	0	1		0	1	12.0 Kbps	
	0	1	1		0	14.4 Kbps	
0-3	0	1		1	1	16.8 Kbps	
	1	0	0		0	19.2 Kbps	
	1	0	0		1	21.6 Kbps	
	1	0	1		0	24.0 Kbps	
	1	0		1	1	26.4 Kbps	
	1	1	0		0	28.8 Kbps	
	1	1	0		1	31.2 Kbps	
	1	1		1	0	33.6 Kbps	

	Modem setting for reception Sets the modem type for reception. The default is "0100" (V27ter, V29, V17).							
	Bit 7	Bit 6						
	0	0	0	1	V27ter			
	0	0	1	0	V27ter, V29			
4-7	0	0	1	1	V27ter, V29, V33 (invalid)			
	0	1	0	0	V27ter, V29, V17			
	0	1	0	1	V27ter, V29, V17, V34*			
	*V34 is not supported for IP-Fax communication.							

IP Fax	IP Fax Switch 07 [SP No. 1-111-008]				
No.	FUNCTION	COMMENTS			
0	TSI information 0: Not added, 1: Added	Adds or does not add TSI information to NSS(S).			
1	DCN transmission setting at T1 timeout 0: Not transmitted, 1: Transmitted	Transmits or does not transmit DCN at T1 timeout.			
2	Not used	Do not change this setting.			
3	Hang up setting at DIS reception disabled 0: No hang up 1: Hang up after transmitting DCN	Sets whether the machine disconnects after DIS reception.			
4	Number of times for training 0: 1 time, 1: 2 times	Selects the number of times training is done at the same bit rate.			
5	Space CSI transmission setting at no CSI registration 0: Not transmitted, 1: Transmitted	When "0" is selected, frame data is enabled. When "1" is selected, the transmitted data is all spaces.			
6-7	Not used	Do not change these settings.			

IP Fax	IP Fax Switch 08 [SP No. 1-111-009]			
No.	FUNCTION	COMMENTS		
0-1	T1 timer adjustment Adjusts the T1 timer. The default is "00" (35 seconds). Bit 1: 0, Bit 0: 0 = 35 sec Bit 1: 0, Bit 0: 1 = 40 sec Bit 1: 1, Bit 0: 0 = 50 sec Bit 1: 1, Bit 0: 1 = 60 sec	-		
2-3	T4 timer adjustment Adjust the T4 timer. The default is "00" (3 seconds). Bit 3: 0, Bit 2: 0 = 3 sec Bit 3: 0, Bit 2: 1 = 3.5 sec Bit 3: 1, Bit 2: 0 = 4 sec Bit 3: 1, Bit 2: 1 = 5 sec	-		
4-5	T0 timer adjustment Bit 5: 0, Bit 4: 0 = 75 sec Bit 5: 0, Bit 4: 1 = 120 sec Bit 5: 1, Bit 4: 0 = 180 sec Bit 5: 1, Bit 4: 1 = 240 sec	Adjusts the fail safe timer. This timer sets the interval between "setup" data transmission and T.38 phase decision. If your destination return is late on the network or G3 fax return is late, adjust the longer interval timer. The default is "00" (75 seconds).		
6-7	Not used	Do not change these settings.		

7.3 NCU PARAMETERS

- This section is used only for F/SPF models (D068/D069).
- The following tables give the RAM addresses and the parameter calculation units that the machine uses for ringing signal detection and automatic dialing. The factory settings for each country are also given. Most of these must be changed by RAM read/write (SP2-102), but some can be changed using NCU Parameter programming (SP2-103); if SP2-103 can be used, this will be indicated in the Remarks column. The RAM is programmed in hex code unless (BCD) is included in the Unit column.

Address	Function							
680500	Country/Area co	Country/Area code for NCU parameters						
	Use the Hex value to program the country/area code directly into this address, or use the decimal value to program it using SP2-103-001					is		
	Country /Area	Decimal	Hex	Country /Area	Decimal	Hex		
	France	00	00	USA	17	11		
	Germany	01	01	Asia	18	12		
	UK	02	02	Hong Kong	20	14		
	Italy	03	03	South Africa	21	15		
	Austria	04	04	Australia	22	16		
	Belgium	05	05	New Zealand	26	17		
	Denmark	06	06	Singapore	24	18		
	Finland	07	07	Malaysia	25	19		
	Ireland	08	08	China	26	1A		
	Norway	09	09	Taiwan	27	1B		

Address	Function					
	Sweden	10	0A	Korea	28	1C
	Switzerland	11	0B	Turkey	32	20
	Portugal	12	0C	Greece	33	21
	Holland	13	0D	Hungary	34	22
	Spain	14	0E	Czech	35	23
	Israel	15	0F	Poland	36	24

Address	Function	Unit	Remarks
680501	Line current detection time		Line current detection is
680502	Line current wait time	20 ms	disabled. Line current is not
680503	Line current drop detect time		detected if 680501 contains FF.
680504	PSTN dial tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone
680505	PSTN dial tone frequency upper limit (low byte)		detection is disabled.
680506	PSTN dial tone frequency lower limit (high byte)	. Hz (BCD)	If both addresses contain FF(H), tone
680507	PSTN dial tone frequency lower limit (low byte)	HZ (BCD)	detection is disabled.
680508	PSTN dial tone detection time		If 680508 contains
680509	PSTN dial tone reset time (LOW)	20 ms	FF(H), the machine pauses for the pause
68050A	PSTN dial tone reset time (HIGH)		time (address 68050D / 68050E). Italy: See Note 2.

Address	Function		
68050B	PSTN dial tone continuous tone time		
68050C	PSTN dial tone permissible drop time		
68050D	PSTN wait interval (LOW)		_
68050E	PSTN wait interval (HIGH)		
68050F	PSTN ring-back tone detection time	20 ms	Detection is disabled if this contains FF.
680510	PSTN ring-back tone off detection time	20 ms	-
680511	PSTN detection time for silent period after ring-back tone detected (LOW)	20 ms	-
680512	PSTN detection time for silent period after ring-back tone detected (HIGH)	20 ms	-
680513	PSTN busy tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.
680514	PSTN busy tone frequency upper limit (low byte)	TIZ (BCD)	
680515	PSTN busy tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone
680516	PSTN busy tone frequency lower limit (low byte)	(505)	detection is disabled.

Address	Function			
680517	PABX dial tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone	
680518	PABX dial tone frequency upper limit (low byte)	(= == /	detection is disabled.	
680519	PABX dial tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone	
68051A	PABX dial tone frequency lower limit (low byte)		detection is disabled.	
68051B	PABX dial tone detection time		If 68051B contains FF, the machine pauses for the pause time (680520 / 680521).	
68051C	PABX dial tone reset time (LOW)	20 ms		
68051D	PABX dial tone reset time (HIGH)			
68051E	PABX dial tone continuous tone time			
68051F	PABX dial tone permissible drop time			
680520	PABX wait interval (LOW)		_	
680521	PABX wait interval (HIGH)			
680522	PABX ringback tone detection time	20 ms	If both addresses	
680523	PABX ringback tone off detection time	20 ms	contain FF(H), tone detection is disabled.	
680524	PABX detection time for silent period after ringback tone detected (LOW)	20 ms	If both addresses contain FF(H), tone detection is disabled.	

Address	Function		
680525	PABX detection time for silent period after ringback tone detected (HIGH)	20 ms	
680526	PABX busy tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone
680527	PABX busy tone frequency upper limit (low byte)	(= 0 =)	detection is disabled.
680528	PABX busy tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone
680529	PABX busy tone frequency lower limit (low byte)		detection is disabled.
68052A	Busy tone ON time: range 1		
68052B	Busy tone OFF time: range 1		
68052C	Busy tone ON time: range 2	20 ms	
68052D	Busy tone OFF time: range 2		
68052E	Busy tone ON time: range 3		-
68052F	Busy tone OFF time: range 3		
680530	Busy tone ON time: range 4	20 ms	
680531	Busy tone OFF time: range 4		
680532	Busy tone continuous tone detection time		

Address	Function			
680533	Busy tone signal state time tolerance for all ranges, and number of cycles required for detection (a setting of 4 cycles means that ON-OFF-ON or OFF-ON-OFF must be detected twice). Tolerance (±) Bit 1: 0, Bit 0: 0 = 75% Bits 2 and 3 must always be kept at 0. Bit 1: 0, Bit 0: 0 = 50% Bits 2 and 3 must always be kept at 0. Bit 1: 0, Bit 0: 0 = 25% Bit 1: 0, Bit 0: 0 = 12.5% Bits 7, 6, 5, 4 - number of cycles required for cadence detection			
680534	International dial tone frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone detection is disabled.	
680535	International dial tone frequency upper limit (low byte)	(202)		
680536	International dial tone frequency lower limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone	
680537	International dial tone frequency lower limit (low byte)		detection is disabled.	
680538	International dial tone detection time			
680539	International dial tone reset time (LOW)		If 680538 contains FF,	
68053A	International dial tone reset time (HIGH)	20 ms	the machine pauses for the pause time (68053D / 68053E).	
68053B	International dial tone continuous tone time		Belgium: See Note 2.	
68053C	International dial tone permissible drop time			

Address	Function		
68053D	International dial wait interval (LOW)		_
68053E	International dial wait interval (HIGH)		
68053F	Country dial tone upper frequency limit (HIGH)		If both addresses contain FF(H), tone
680540	Country dial tone upper frequency limit (LOW)	Hz (BCD)	detection is disabled.
680541	Country dial tone lower frequency limit (HIGH)	TIZ (BCB)	If both addresses contain FF(H), tone
680542	Country dial tone lower frequency limit (LOW)		detection is disabled.
680543	Country dial tone detection time		
680544	Country dial tone reset time (LOW)	20 ms	If 680543 contains FF, the machine pauses for the pause time (680548 /
680545	Country dial tone reset time (HIGH)		680549).
680546	Country dial tone continuous tone time	-	-
680547	Country dial tone permissible drop time		
680548	Country dial wait interval (LOW)	20 ms	-
680549	Country dial wait interval (HIGH)		

Address	Fu	ınction	
68054A	Time between opening or closing the DO relay and opening the OHDI relay	1 ms	See Notes 3, 6 and 8. SP2-103-012 (parameter 11).
68054B	Break time for pulse dialing	1 ms	See Note 3. SP2-103-013 (parameter 12).
68054C	Make time for pulse dialing	1 ms	See Note 3. SP2-103-014 (parameter 13).
68054D	Time between final OHDI relay closure and DO relay opening or closing	1 ms	See Notes 3, 6 and 8. SP2-103-015 (parameter 14). This parameter is only valid in Europe.
68054E	Minimum pause between dialed digits (pulse dial mode)	. 20 ms	See Note 3 and 8. SP2-103-016 (parameter 15).
68054F	Time waited when a pause is entered at the operation panel	20 1113	SP2-103-017 (parameter 16). See Note 3.
680550	DTMF tone on time	.1 ms	SP2-103-018 (parameter 17).
680551	DTMF tone off time	1 1115	SP2-103-019 (parameter 18).
680552	Tone attenuation level of DTMF signals while dialing	-N x 0.5 -3.5 dBm	SP2-103-020 (parameter 19). See Note 5.

Address	Function			
680553	Tone attenuation value difference between high frequency tone and low frequency tone in DTMF signals	-dBm x 0.5	SP2-103-021 (parameter 20). The setting must be less than –5dBm, and should not exceed the setting at 680552h above. See Note 5.	
680554	PSTN: DTMF tone attenuation level after dialling	-N x 0.5 -3.5 dBm	SP2-103-022 (parameter 21). See Note 5.	
680555	ISDN: DTMF tone attenuation level after dialling	-dBm x 0.5	See Note 5	
680556	Not used	-	Do not change the settings.	
680557	Time between 68054Dh (NCU parameter 14) and 68054Eh (NCU parameter 15)	1 ms	This parameter takes effect when the country code is set to France.	
680558	Not used	-	Do not change the setting.	
680559	Grounding time (ground start mode)	20 ms	The Gs relay is closed for this interval.	
68055A	Break time (flash start mode)	1 ms	The OHDI relay is open for this interval.	
68055B	International dial access code (High)	BCD	For a code of 100: 68055B - F1	
68055C	International dial access code (Low)		68055C - 00	

Address	Fu	ınction	
68055D	PSTN access pause time	20 ms	This time is waited for each pause input after the PSTN access code. If this address contains FF[H], the pause time stored in address 68054F is used. Do not set a number more than 7 in the UK.
68055E	Progress tone detection level, and cadence detection enable flags	Bit 7: 0, Bit 6: 0, Bit 5: 0 = -25.0 dBm Bit 7: 0, Bit 6: 0, Bit 5: 1 = -35.0 dBm Bit 7: 0, Bit 6: 1, Bit 5: 0 = -30.0 dBm Bit 7: 1, Bit 6: 0, Bit 5: 0 = -40.0 dBm Bit 7: 1, Bit 6: 1, Bit 5: 0 = -49.0 dBm Bits 2, 0 - See Note 2.	
68055F To 680564	Not used	-	Do not change the settings.
680565	Long distance call prefix (HIGH)	BCD	For a code of 0:
680566	Long distance call prefix (LOW)	BCD	680565 – FF 680566 - FF
680567 to 680571	Not used	-	Do not change the settings.
680572	Acceptable ringing signal frequency: range 1, upper limit	1000/ N (Hz).	SP2-103-003 (parameter 02).
680573	Acceptable ringing signal frequency: range 1, lower limit		SP2-103-004 (parameter 03).

Address	Function			
680574	Acceptable ringing signal frequency: range 2, upper limit		SP2-103-005 (parameter 04).	
680575	Acceptable ringing signal frequency: range 2, lower limit		SP2-103-006 (parameter 05).	
680576	Number of rings until a call is detected	1	SP2-103-007 (parameter 06). The setting must not be zero.	
680577	Minimum required length of the first ring	20 ms	See Note 4. SP2-103-008 (parameter 07).	
680578	Minimum required length of the second and subsequent rings	20 ms	SP2-103-009 (parameter 08).	
680579	Ringing signal detection reset time (LOW)	. 20 ms	SP2-103-010 (parameter 09).	
68057A	Ringing signal detection reset time (HIGH)	20 1110	SP2-103-011 (parameter 10).	
68057B to 680580	Not used	-	Do not change the settings.	
680581	Interval between dialing the last digit and switching the Oh relay over to the external telephone when dialing from the operation panel in handset mode.	20 ms	Factory setting: 500 ms	

Address	Function						
680582	Bits 0 and 1 - Handset off-hook det Bit 1:0, Bit 0: 0 = 200 ms Bit 1:0, Bit 0: 1 = 800 ms Other Not used Bits 2 and 3 - Handset on-hook det Bit 3: 0, Bit 2: 0 = 200 ms Bit 3: 0, Bit 2: 1 = 800 ms Other Not used Bits 4 to 7 - Not used	-					
680583 To 6805A0	Not used	-	Do not change the settings.				
6805A1	Acceptable CED detection frequency upper limit (high byte)	BCD (Hz)	If both addresses contain FF(H), tone				
6805A2	Acceptable CED detection frequency upper limit (low byte)	303 (. 12)	detection is disabled.				
6805A3	Acceptable CED detection frequency lower limit (high byte)	BCD (Hz)	If both addresses contain FF(H), tone				
6805A4	Acceptable CED detection frequency lower limit (low byte)	305 (1.12)	detection is disabled.				
6805A5	CED detection time 20 ms ± 20 ms		Factory setting: 200 ms				
6805A6	Acceptable CNG detection frequency upper limit (high byte)	BCD (Hz)	If both addresses				
6805A7	Acceptable CNG detection frequency upper limit (low byte)	1000 (112)	contain FF(H), tone detection is disabled.				

Address	Fu	unction		
6805A8	Acceptable CNG detection frequency lower limit (high byte)	BCD (Hz)	If both addresses contain FF(H), tone	
6805A9	Acceptable CNG detection frequency lower limit (low byte)		detection is disabled.	
6805AA	Not used	-	Do not change the setting.	
6805AB	CNG on time	20 ms	Factory setting: 500 ms	
6805AC	CNG off time	20 ms	Factory setting: 3000 ms	
6805AD	Number of CNG cycles required for detection	-	The data is coded in the same way as address 680533.	
6805AE	Not used	-	Do not change the settings.	
6805AF	Acceptable AI short protocol tone (800Hz) detection frequency upper limit (high byte)	Hz (BCD)	If both addresses contain FF(H), tone	
6805B0	Acceptable AI short protocol tone (800Hz) detection frequency upper limit (low byte)	(202)	detection is disabled.	
6805B1	Acceptable AI short protocol tone (800Hz) detection frequency lower limit (high byte)	Hz(BCD)	If both addresses contain FF(H), tone	
6805B2	Acceptable AI short protocol tone (800Hz) detection frequency lower limit (low byte)		detection is disabled.	

Address	Function					
6805B3	Detection time for 800 Hz Al short protocol tone	20 ms	Factory setting: 360 ms			
6805B4	PSTN: Tx level from the modem	-N – 3 dBm	SP2-103-002 (parameter 01).			
6805B5	PSTN: 1100 Hz tone transmission level	- N 6805B4 - See Note 7.	0.5N 6805B5 -3.5 (dB)			
6805B6	PSTN: 2100 Hz tone transmission level	- N6805B4 - 0 See Note 7.	0.5N 6805B6 –3 (dB)			
6805B7	PABX: Tx level from the modem	- dBm				
6805B8	PABX: 1100 Hz tone transmission level	- N 6805B7 - 0.5N 6805B8 (dB)				
6805B9	PABX: 2100 Hz tone transmission level	- N 6805B7 - 0.5N 6805B9 (dB)				
6805BD	Modem turn-on level (incoming signal detection level)	-37-0.5N (dBm)				
6805BE to 6805C6	Not used	-	Do not change the settings.			
6805C7	Bits 0 to 3 – Not used Bit 4 = V.34 protocol dump 0: Simple, 1: Detailed (default) Bits 5 to 7 – Not used.					
6805C8 to 6805D9	Not used	-	Do not change the settings.			
6805DA	T.30 T1 timer	1 s				

Address	Function							
6805E0 bit	Maximum wait time for message	or post		0: 12 s 1: 30 s	1: Maximum wait time for post message (EOP/EOM/MPS) can be changed to 30 s. Change this bit to "1" if communication errors occur frequently during V.17 reception.			
	Bit 2 sets the level of the call signal, Bit 3 3 sets the call signal impedance	Bit 2	0	RT=0 (Low)				
		2.7.2	1	RT=1 (High)				
6805E4			0	RZ=0 (High)	-			
		Bit 3	1	RZ=1 (Composite)				
	Bit 0 sets the ring	Bit 0	0	Auto				
	detection method, Bit 1 sets the ring	Dit 0	1	Fixed	If any setting is changed,			
6805E5	detection method	Bit 1	0	Use RDTP	select a setting that is higher than the default			
	when fixed.	5.,	1	Use RDTN	setting.			
	Bits 2 to 7: Not used							

NOTES

- 1. If a setting is not required, store FF in the address.
- 2. Italy and Belgium only

RAM address 68055E: the lower four bits have the following meaning.

Bit 2 - 1: International dial tone cadence detection enabled (Belgium)

Bit 1 - Not used

Bit 0 - 1: PSTN dial tone cadence detection enabled (Italy)

If bit 0 or bit 2 is set to 1, the functions of the following RAM addresses are changed. 680508 (if bit 0 = 1) or 680538 (if bit 2 = 1): tolerance for on or off state duration (%), and number of cycles required for detection, coded as in address 680533.

```
68050B (if bit 0 = 1) or 68053B (if bit 2 = 1): on time, hex code (unit = 20 ms) 68050C (if bit 0 = 1) or 68053C (if bit 2 = 1): off time, hex code (unit = 20 ms)
```

- 3. Pulse dial parameters (addresses 68054A to 68054F) are the values for 10 pps. If 20 pps is used, the machine automatically compensates.
- 4. The first ring may not be detected until 1 to 2.5 wavelengths after the time specified by this parameter.
- The calculated level must be between 0 and 10.

The attenuation levels calculated from RAM data are:

High frequency tone:

- $-0.5 \times N_{680552}/_{680554}-3.5 \text{ dBm}$
- - 0.5 x N₆₈₀₅₅₅ dBm

Low frequency tone:

- $-0.5 \times (N_{680552}/_{680554} + N_{680553}) -3.5 \text{ dBm}$
- $-0.5 \text{ x } (N_{680555} + N_{680553}) \text{ dBm}$



- N₆₈₀₅₅₂, for example, means the value stored in address 680552(H)
- 6. 68054A: Europe Between Ds opening and Di opening, France Between Ds closing and Di opening
 - 68054D: Europe Between Ds closing and Di closing, France Between Ds opening and Di closing
- 7. Tone signals which frequency is lower than 1500Hz (e.g., 800Hz tone for Al short protocol) refer to the setting at 6805B5h. Tones which frequency is higher than 1500Hz refer to the setting at 6805B6h.
- 8. 68054A, 68054D, 68054E: The actual inter-digit pause (pulse dial mode) is the sum of the period specified by the RAM addresses 68054A, 68054D, and 68054E.

7.4 DEDICATED TRANSMISSION PARAMETERS

This section is used only for F/SPF models (D068/D069).

There are two sets of transmission parameters: Fax and E-mail

Each Quick Dial Key and Speed Dial Code has eight bytes of programmable parameters allocated to it. If transmissions to a particular machine often experience problems, store that terminal's fax number as a Quick Dial or Speed Dial, and adjust the parameters allocated to that number.

The programming procedure will be explained first. Then, the eight bytes will be described.

7.4.1 PROGRAMMING PROCEDURE

- 1. Set the bit 0 of System Bit Switch 00 to 1.
- Enter Address Book Management mode ([User Tools]> System Settings> Administrator Tools > Address Book Management).
- 3. Select the address book that you want to program.
- 4. Press the "Dest." Key to enter the fax and e-mail parameter settings.
- 5. For the fax parameter, select "Fax Settings", for the E-mail parameter, select "E-mail Settings".
- 6. Press the "OK" key, and then press "Start" key. Make sure that the LED of the Start button lights green.
- 7. The settings for the switch 00 are now displayed. Press the bit number that you wish to change.
- 8. To scroll through the parameter switches, either:
- 9. Select the next switch: press "Next" or Select the previous switch: "Prev." until the correct switch is displayed. Then go back to step 6.
- 10. After the setting is changed, press "OK" key.
- 11. After finishing, reset bit 0 of System Bit Switch 00 to 0.

7.4.2 PARAMETERS

Fax Parameters

The initial settings of the following fax parameters are all FF(H) - all the parameters are disabled.

Switch 00

FUNCTION AND COMMENTS

ITU-T T1 time (for PSTN G3 mode)

If the connection time to a particular terminal is longer than the NCU parameter setting, adjust this byte. The T1 time is the value stored in this byte (in hex code), multiplied by 1 second.

Range:

0 to 120 s (00h to 78h)

FFh - The local NCU parameter factory setting is used.

Do not program a value between 79h and FEh.

Appendix: Fax Service Program

Switc	h 01						
No			FU	JNCTI	ON	COMMENTS	
	Tx le	vel .					
	Bit4	Bit3	Bit2	Bit1	Bit0		If communication with a particular
	0	0	0	0	0	0	remote terminal often contains
	0	0	0	0	1	-1	errors, the signal level may be inappropriate. Adjust the Tx level
0-4	0	0	0	1	0	-2	for communications with that terminal until the results are better
0-4	0	0	0	1	1	-3	If the setting is "Disabled", the NCU
	0	0	1	0	0	-4	parameter 01 setting is used.
	4	4	4	+	4	4	Do not use settings other
	0	1	1	1	1	– 15	than listed on the left.
	1	1	1	1	1	Disabled	

SM Appendix

D067/D068/D069/D072

Use a higher setting if there is signal loss at higher frequencies because of the length of wire between the modem and the telephone exchange when calling the number stored in this Quick/Speed Dial. Cable equalizer Also, try using the cable equalizer if Bit 7: 0, Bit 6: 0, Bit 5: 0 = None one or more of the following Bit 7: 0, Bit 6: 0, Bit 5: 1 = Low 5-7 symptoms occurs. Bit 7: 0, Bit 6: 1, Bit 5: 0 = Medium Communication error with error Bit 7: 0, Bit 6: 1, Bit 5: 1 = High codes such as 0-20, 0-23, etc. Bit 7: 1, Bit 6: 1, Bit 5: 1 = Disabled Modem rate fallback occurs frequently. ↓ Note Do not use settings other than listed on the left. If the setting is "Disabled", the bit switch setting is used.

Swit	Switch 02						
No			FUN	CTION		COMMENTS	
	Initial Tx modem rate						
	Bit3	Bit2	Bit1	Bit0	bps		
	0	0	0	0	Not used		
	0	0	0	1	2400		
	0	0	1	0	4800		
	0	0	1	1	7200		
	0	1	0	0	9600	If training with a particular remote terminal always takes too long, the initial modem	
	0	1	0	1	12000	rate may be too high. Reduce the initial Tx	
	0	1	1	0	14400	modem rate using these bits. For the settings 14.4 or kbps slower,	
0-3	0	1	1	1	16800	Switch 04 bit 4 must be changed to 0.	
	1	0	0	0	19200	■ Do not use settings other than	
	1	0	0	1	21600	listed on the left. If the setting is	
	1	0	1	0	24000	"Disabled", the bit switch setting is used.	
	1	0	1	1	26400		
	1	1	0	0	28800		
	1	1	0	1	31200		
	1	1	1	0	33600		
	1	1	1	1	Disabled		
	Other	settin	gs: No	t used			

4-7	Not used	Do not change the settings.
-----	----------	-----------------------------

Swite	Switch 03				
No	FUNCTION	COMMENTS			
0-1	Inch-mm conversion before tx Bit 1: 0, Bit 0: 0 = Inch-mm conversion available Bit 1: 0, Bit 0: 1 = Inch only Bit 1: 1, Bit 0: 0 = Not used Bit 1: 1, Bit 0: 1 = Disabled	The machine uses inch-based resolutions for scanning. If "inch only" is selected, the printed copy may be slightly distorted at the other end if that machine uses mm-based resolutions. If the setting is "Disabled", the bit switch setting is used.			
2-3	DIS/NSF detection method Bit 3: 0, Bit 2: 0 = First DIS or NSF Bit 3: 0, Bit 2: 1 = Second DIS or NSF Bit 3: 1, Bit 2: 0 = Not used Bit 3: 1, Bit 2: 1 = Disabled	(0, 1): Use this setting if echoes on the line are interfering with the set-up protocol at the start of transmission. The machine will then wait for the second DIS or NSF before sending DCS or NSS. If the setting is "Disabled", the bit switch setting is used.			
4	V.8 protocol 0: Off 1: Disabled	If transmissions to a specific destination always end at a lower modem rate (14,400 bps or lower), disable V.8 protocol so as not to use V.34 protocol. 0: V.34 communication will not be possible. If the setting is "Disabled", the bit switch setting is used.			
5	Compression modes available in transmit mode 0: MH only 1: Disabled	This bit determines the capabilities that are informed to the other terminal during transmission. If the setting is "Disabled", the bit switch setting is used.			

wanted when sending to a particular terminal, use ECM during transmission the (0, 0) setting.

Bit 7: 0, Bit 6: 0 = Off

Bit 7: 0, Bit 6: 1 = On

6-7

Bit 7: 1, Bit 6: 0 = Not used

Bit 7: 1, Bit 6: 1 = Disabled



 V.8/V.34 protocol and JBIG compression are automatically disabled if ECM is disabled.

For example, if ECM is switched on but is not

If the setting is "Disabled", the bit switch setting is used.

Switch 04 - Not used (do not change the settings)

Switch 05 - Not used (do not change the settings)

Switch 06 - Not used (do not change the settings)

Switch 07 - Not used (do not change the settings)

Switch 08 - Not used (do not change the settings)

Switch 09 - Not used (do not change the settings)

E-mail Parameters

The initial settings of the following e-mail parameters are all "0" (all parameters disabled).

Switch	Switch 00				
No	FUNCTION	COMMENTS			
0	MH Compression mode for e-mail attachments 0: Off 1: On	Switches MH compression on and off for files attached to e-mails for sending.			
1	MR Compression mode for e-mail attachments 0: Off 1: On	Switches MR compression on and off for files attached to e-mails for sending.			
2	MMR Compression mode for e-mail attachments 0: Off 1: On	Switches MMR compression on and off for files attached to e-mails for sending.			
3-6	Not used	Do not change these settings.			
7	Designates the bits to reference for compression method of e-mail attachments 0: Registered (Bit 0 to 6) 1: No registration.	The "0" selection (default) references the settings for Bits 00, 01, 02 above. The "1" selection ignores the selections of Bits 00, 01, 02.			

Switch	Switch 01					
No	FUNCTION	COMMENTS				
0	Original width of e-mail attachment: A4 0: Off 1: On	Sets the original width of the e-mail attachment as A4.				
1	Original width of e-mail attachment: B4 0: Off 1: On	Sets the original width of the e-mail attachment as B4.				
2	Original width of e-mail attachment: A3 0: Off 1: On	Sets the original width of the e-mail attachment as A3.				
3-6	Not used	Do not change these settings.				
7	Designates the bits to reference for original size of e-mail attachments 0 : Registered (Bit 0 to 6) 1: No registration.	The "0" selection (default) references the settings for Bits 00, 01, 02 above. The "1" selection ignores the selections of Bits 00, 01, 02.				

Switch	Switch 02					
No	FUNCTION	COMMENTS				
0	Line resolution of e-mail attachment: 200 x 100 0: Off 1: On	Sets the line resolution of the e-mail attachment as 200 x100.				
1	Line resolution of e-mail attachment: 200 x 200 0: Off 1: On	Sets the line resolution of the e-mail attachment as 200 x 200.				
2	Line resolution of e-mail attachment: 200 x 400 0: Off 1: On	Sets the line resolution of the e-mail attachment as 200 x 400.				
3	Not used	Do not change these settings.				
4	Line resolution of e-mail attachment: 400 x 400 0: Off 1: On	Sets the line resolution of the e-mail attachment as 400 x 400.				
5-6	Not used	Do not change these settings.				
7	Designates the bits to reference for original size of e-mail attachments 0 : Registered (Bit 0 to 6) 1: No registration.	The "0" selection (default) references the settings for Bits 00, 01, 02, 04 above. The "1" selection ignores the selections of Bits 00, 01, 02, 04.				

Switch 03 - Not used (do not change the settings)

Switch	Switch 04					
No	FUNCTION	COMMENTS				
0	Full mode address selection 0: Full mode address 1: No full mode (simple mode)	If the other ends have the addresses, which have the full mode function flag ("0"), this machine determines them as full mode standard machines. This machine attaches the "demand of reception confirmation" to a message when transmitting. This machine updates the reception capability to the address book when receiving.				
1-7	Not used	Do not change these settings.				

Switch 05						
No	FUNCTION	COMMENTS				
0	Directr transmission selection to SMTP server 0: ON 1: OFF	Allows or does not allow the direct transmission to SMTP server.				
1-7	Not used	Do not change these settings.				

Switch 06 - Not used (do not change the settings)

Switch 07 - Not used (do not change the settings)

Switch 08 - Not used (do not change the settings)

Switch 09 - Not used (do not change the settings)

7.5 SERVICE RAM ADDRESSES

This section is used only for F/SPF models (D068/D069).

∴CAUTION

Do not change the settings which are marked as "Not used" or "Read only."

680000(H) - Machine code

680001 to 680004(H) - ROM version (Read only)

680001(H) - Revision number (BCD)

680002(H) - Year (BCD)

680003(H) - Month (BCD)

680004(H) - Day (BCD)

680005(H) - Machine code 2 (check ram2)

680006 to 680015(H) - Machine's serial number (16 digits - ASCII)

680016(H) - Language code

Bit0: Japanese, Bit1: English (UK), Bit2: English (USA), Bit3: French,

Bit4: German, Bit5: Spanish, Bit6: Italian, Bit7: Dutch, Bit8: Swedish,

Bit9: Norwegian, Bit10: Danish, Bit11: Finnish, Bit12: Czech,

Bit13: Hungarian, Bit14: Polish, Bit15: Portuguese, Bit16: Russian,

Bit17: Traditional Chinese, Bit18: Simplified Chinese, Bit19: Hangul

680018(H) - Total program checksum (low)

680019(H) - Total program checksum (high)

680020 to 68003F(H) - System bit switches

680050 to 68005F(H) - Printer bit switches

680060 to 68007F(H) - Communication bit switches

680080 to 68008F(H) - G3 bit switches

680090 to 68009F(H) - G3-2 bit switches: Not used

6800A0 to 6800AF(H) - G3-3 bit switches: Not used

6800D0(H) - User parameter switch 00 (SWUER 00): Not used

6800D1(H) - User parameter switch 01 (SWUSR_01): Not used

6800D2(H) - User parameter switch 02 (SWUSR 02)

Bit 0: Forwarding mark printing on forwarded messages

0: OFF, 1: ON (Print)

Bit 1: Center mark printing on received copies

(This switch is not printed on the user parameter list.)

0: OFF, 1: ON (Print)

Bit 2: Reception time printing

(This switch is not printed on the user parameter list.)

0: OFF, 1: ON (Print)

Bit 3: TSI print on received messages 0: OFF, 1: ON (Print)

Bit 4: Checkered mark printing

(This switch is not printed on the user parameter list.)

0: OFF, 1: ON (Print)

Bit 5: Not used

Bit 6: Not used

Bit 7: Not used

6800D3(H) - User parameter switch 03 (SWUSR_03: Automatic report printout)

Bit 0: Transmission result report (memory transmissions) 0: Off, 1: On

Bit 1: Not used

Bit 2: Memory storage report 0: Off, 1: On

Bit 3: Polling reserve report (polling reception) 0: Off, 1: On

Bit 4: Polling result report (polling reception) 0: Off, 1: On

Bit 5: Transmission result report (immediate transmissions) 0: Off, 1: On

Bit 6: Not used

Bit 7: Journal 0: Off, 1: On

6800D4(H) - User parameter switch 04 (SWUSR_04: Automatic report printout)

Bit 0: Not used

Bit 1: Automatic communication failure report and transfer result report output 0: Off, 1: On

Bits 2 to 3: Not used

Bit 4: Indicates the parties 0: Not indicated, 1: Indicated

Bit 5: Include sender's name on reports 0: Off, 1: On

Bit 6: Not used

Bit 7: Inclusion of a sample image on reports 0: Off, 1: On

6800D5(H) - User parameter switch 05 (SWUSR_05)

Bit 0: Substitute reception when the base copier is in an SC condition

0: Enabled, 1: Disabled

Bits 1 and 2: Condition for substitute rx when the machine cannot print messages (Paper end, toner end, jam, and during night mode)

Bit 2: 0, Bit 1: 0 = The machine receives all the fax messages.

Bit 2: 0, Bit 1: 1 = The machine receives the fax messages with RTI or CSI.

Bit 2: 1, Bit 1: 0 = The machine receives the fax messages with the same ID code.

Appendix: Fax Service Program

Bit 2: 1, Bit 1: 1 = The machine does not receive anything.

Bits 3 and 4: Not used

Bit 5: Just size printing 0: Off, 1: On

Bit 6: Not used

Bit 7: Add paper display when a cassette is empty 0: Off, 1: On

6800D6(H) - User parameter switch 06 (SWUSR 06): Not used

6800D7(H) - User parameter switch 07 (SWUSR_07)

Bits 0 and 1: Not used

Bit 2: Parallel memory transmission 0: Off, 1: On

Bits 3 to 7: Not used

6800D8(H) - User parameter switch 08 (SWUSR_08)

Bits 0 and 1: Not used.

Bit 2: Authorized reception

0: Only faxes from senders whose RTIs/CSIs are specified for this feature are accepted.

1: Only faxes from senders whose RTIs/CSIs are not specified for this feature are accepted.

Bits 3 to 7: Not used.

6800D9(H) - User parameter switch 09 (SWUSR_09): Not used

6800DA(H) - User parameter switch 10 (SWUSR_0A)

Bits 0 to 2: Not used

Bit 3: Page reduction 0: Off, 1: On

Bits 4 and 5: Not used

Bit 6: Use both e-mail notification and printed reports to confirm the transmission results 0:

Off, 1: On

Bit 7: Not used

6800DB(H) - User parameter switch 11 (SWUSR_0B)

Bits 0 and 1: Not used

Bit 2: White original detection 0: Off, 1: On (alarm and alert message on the LCD)

Bits 3 and 4: Not used

Bit 6: Printout of messages received while acting as a forwarding station 0: Off, 1: On

Bit 7: Not used

6800DC(H) - User parameter switch 12 (SWUSR 0C): Not used

6800DD(H) - User parameter switch 13 (SWUSR_0D): Not used

6800DE(H) - User parameter switch 14 (SWUSR 0E)

Bit 0: Message printout while the machine is in Night Printing mode 0: On, 1: Off

Service RAM Addresses Rev. 05/14/2009

Bit 1: Maximum document length detection 0: Double letter, 1: Longer than double-letter

(well log) - up to 1,200 mm

Bit 2: Not used

Bit 3: Fax mode settings, such as resolution, before a mode key

(Copy/Fax/Printer/Scanner) is pressed 0: Not cleared, 1: Cleared

Bits 4 to 7: Not used

6800DF(H) - User parameter switch 15 (SWUSR_0F)

(This switch is not printed on the user parameter list.)

Bits 0, 1 and 2: Cassette for fax printout

Bit 2: 0, Bit 1: 0, Bit 0: 1 = 1st paper feed station

Bit 2: 0, Bit 1: 1, Bit 0: 0 = 2nd paper feed station

Bit 2: 0, Bit 1: 1, Bit 0: 1 = 3rd paper feed station

Bit 2: 1, Bit 1: 0, Bit 0: 0 = 4th paper feed station

Bit 2: 1, Bit 1: 0, Bit 0: 1 = LCT

Other settings Not used

Bits 3 and 4: Not used

Bit 5: Using the cassette specified by bits 0, 1 and 2 above only 0: On, 1: Off

Bits 6 and 7: Not used

6800E0(H) - User parameter switch 16 (SWUSR_10)

(This switch is not printed on the user parameter list.)

Bits 0 and 1: Not used

Bit 2: Paper size selection priority for an A4 size fax message when A4/LT size paper is not

available. 0: A3 has priority, 1: B4 has priority

Bits 3 to 7: Not used

6800E1(H) - User parameter switch 17 (SWUSR_11)

Bit 0: Not used

Bit 1: Disable Broadcasting: To avoid accidentally specifying multiple destinations, users can disable broadcasting. They cannot specify group destinations if they disable broadcasting. They can specify only one address at a time.

1: On, 0: Off

Bit 2: Inclusion of the "Add" button when a sequence of Quick/Speed dials is selected for broadcasting 0:Not needed, 1: Needed

Bits 3, 5 and 6: Not used

Bit 4: Display Destination Prior to transmission: To prevent documents being sent to the wrong destination, users can configure the machine to display the destination again after it has been entered and before the file is sent. 1: On, 0: Off

Bit 7: Press "Start" key without an original when using the on hook dial or external phone, 0: displays "Cannot detect original size". 1: Receives fax messages.

6800E2(H) - User parameter switch 18 (SWUSR 12)

Bit 0: TTI date 0: Off, 1: On

Appendix: Fax Service Program

Bit 1: TTI sender 0: Off, 1: On
Bit 2: TTI file number 0: Off, 1: On
Bit 3: TTI page number 0: Off, 1: On

Bits 4 to 7: Not used

6800E3(H) - User parameter switch 19 (SWUSR_13)

Bit 0: Not used

Bit 1: Journal format

0: The Journal is separated into transmissions and receptions

1: The Journal is separated into G3-1, G3-2, and G3-3 communications

Bit 2: Not used

Bit 3: 90° image rotation during B5 portrait Tx (This switch is not printed on the user parameter list.) 0: Off, 1: On

Bit 4: Reduction of sample images on reports to 50% in the main scan and sub-scan directions. (This switch is not printed on the user parameter list.) 0: Technician adjustment (printer switch 0E bits 3 and 4), 1: 50% reduction

Bit 5: Use of A5 size paper for reports (This switch is not printed on the user parameter list.)
0: Off, 1: On

Bits 6 and 7: Not used

6800E4(H) - User parameter switch 20 (SWUSR_14)

Bit 0: Automatic printing of the LAN fax result report 0: Off, 1: On

Bit 1: Not used.

Bits 2 to 5: Store documents in memory which could not be printed from PC fax (LAN fax) driver

Bit 5	Bit 4	Bit 3	Bit 2	Setting
0	0	0	0	0 min.
0	0	0	1	1 min.
4	→	→	→	→
1	1	1	0	14 min.
1	1	1	1	15 min.

Service RAM Addresses Rev. 05/14/2009

Bits 6 and 7: Not used.

6800E5(H) - User parameter switch 21 (SWUSR_15)

Bit 0: Print results of sending reception notice request message 0: Disabled (print only

when error occurs), 1: Enabled

Bit 1: Respond to e-mail reception acknowledgment request 0: Disabled, 1: Enabled

Bit 2: Not used

Bit 3: File format for forwarded folders 0: TIFF, 1:PDF

Bit 4: Transmit Journal by E-mail 0: Disabled, 1: Enabled

Bit 5: Not used

Bit 6: Network error display 0: Displayed, 1: Not displayed

Bit 7: Transmit error mail notification 0: Enabled, 1: Disabled

6800E6(H) - User parameter switch 22 (SWUSR_16)

(This switch is not printed on the user parameter list.)

Bit 0: Dial tone detection (PSTN 1) 0: Disabled, 1: Enabled

Bits 1 to 3: Not used

Reentered Count						
7	6	5	4	Count		
0	0	0	0	0		
0	0	0	1	1		
0	0	1	0	2		
				÷		
1	1	1	1	15		

Bits 4 to 7: Re-enter Fax number to confirm destination (0 -15) (Default: 0000) (See **Reentered Count** chart) Enter the fax number again to confirm the destination is correct. Tx is disabled if the confirmation fax number does not match the first fax number. This function prevents faxes from being sent to the incorrect destination.

6800E7(H) - User parameter switch 23 (SWUSR 17): Not used

6800E8(H) - User parameter switch 24 (SWUSR_18): Not used

6800E9(H) - User parameter switch 25 (SWUSR 19)

Bits 0 to 3: Not used

Bit 4: RDS operation 0: Not acceptable, 1: Acceptable for the limit specified by system switch 03



 This bit is only effective when RDS operation can be selected by the user (see system switch 02).

Bits 5 to 7: Not used

6800EA(H) and 6800EB(H) - User parameter switches 26 and 27 (SWUSR 1A and 1B):

Not used

6800EC(H) - User parameter switch 28 (SWUSR 1C)

- Ringing times setting in the TEL line priority mode: 00 to 99 (BCD)

6800ED(H) - User parameter switch 29 (SWUSR 1D): Not used

6800EE(H) and 6800EF(H) - User parameter switches 30 and 31 (SWUSR_1E and 1F):

Not used

6800F0(H) - User parameter switch 32 (SWUSR_20)

```
Bit 0: Quotation priority for a destination when there is no destination of the specified type
```

- 0: Paper output priority = Priority order: 1. IP-fax destination, 2. Fax Number, 3. E-mail address, 4. Folder
- 1: Electric putout order = Priority order: 1. E-mail address, 2. Folder, 3. IP-fax destination, 4. Fax number

Bits 1 to 7: Not used

6800F1(H) - User parameter switch 33 (SWUSR_21): Not used

6800F2(H) - User parameter switch 34 (SWUSR_22)

Bit 0: Gatekeeper server used with IP-Fax 0: Disabled, 1: Enabled

Bit 1: SIP server used with IP-Fax 0: Disabled, 1: Enabled

Bits 2 to 7: Not used

680100 to 68010F(H) - G4 Parameter Switches - Not used

680110 to 68012F(H) - G4 Internal Switches - Not used

680130 to 68016F(H) - Service Switches (SCU) - Not used

680170 to 68017F(H) - IFAX Switches

680180 to 68018F(H) - IP-FAX Switches

680190 to 6801AF(H) - Service station's fax number (SP3-101)

6801B0 to 6801B9(H) - Own fax PABX extension number

6801BA to 6801C3(H) - Own fax number (PSTN) - Not used

6801C4 to 6801D7(H) - Own fax number (ISDN G4) - Not used

6801D8 to 6801E3(H) - The first subscriber number (ISDN G3) - Not used

6801E4 to 6801EF(H) - The second subscriber number (ISDN G3) - Not used

6801F0 to 6801FB(H) - The first subscriber number (ISDN G4) - Not used

6801FC to 680207(H) - The second subscriber number (ISDN G4) - Not used

680208 to 68021B(H) - PSTN-1 RTI (Max. 20 characters - ASCII) - See the following note.

68021C to 68022F(H) - PSTN-2 RTI (Max. 20 characters - ASCII) - Not used

680230 to 680246(H) - PSTN-3 RTI (Max. 20 characters - ASCII) - Not used

680247 to 680286(H) - TTI 1 (Max. 64 characters - ASCII) - See the following note.

680287 to 6802C6(H) - TTI 2 (Max. 64 characters - ASCII) - Not used

6802C7 to 680306(H) - TTI 3 (Max. 64 characters - ASCII) - Not used

680307 to 68031A(H) - PSTN-1 CSI (Max. 20 characters - ASCII)

68031B to 68032E(H) - PSTN-2 CSI (Max.20 characters - ASCII) - Not used

68032F to 680342(H) - PSTN-3 CSI (Max.20 characters - ASCII) - Not used

680343(H) - Number of PSTN-1 CSI characters (Hex)

680344(H) - Number of PSTN-2 CSI characters (Hex) - Not used

680345(H) Number of PSTN-3 CSI characters (Hex) - Not used

↓ Note

• If the number of characters is less than the maximum (20 for RTI, 64 for TTI), add a stop code (00[H]) after the last character.

680370(H) ID for transmission and reception (Read only – Do not change the settings)

680374 to 680375(H) - Envelopment ID for the envelopment reception (BCD)

680380 to 680387(H) - Last power off time (Read only)

680380(H) - 01(H) - 24-hour clock, 00(H) - 12-hour clock (AM), 02(H) - 12-hour clock (PM)

680381(H) - Year (BCD)

680382(H) - Month (BCD)

680383(H) - Day (BCD)

680384(H) - Hour

680385(H) - Minute

680386(H) - Second

680387(H) - 00: Monday, 01: Tuesday, 02: Wednesday, ///, 06: Sunday

680394(H) - Optional equipment — Not used

680395(H) - Optional equipment (Read only – Do not change the settings)

Bits 0 to 3: Not used

Bit 4: G3-2 0: Not installed, 1: Installed

Bit 5: G3-3 0: Not installed, 1: Installed

Bit 6 and 7: Not used

680401 to 68040D - Not used

680410(H) - G3-1 Modem ROM version (Read only)

680412(H) - G3-2 Modem ROM version - Not used

680414(H) - G3-3 Modem ROM version - Not used

680420(H) - Number of multiple sets print (Read only)

680476(H) - Time for economy transmission - Not used

68048C(H) - Dial in (BCD)

680492(H) - Transmission monitor volume 00 - 07(H)

680493(H) - Reception monitor volume 00 - 07(H)

680494(H) - On-hook monitor volume 00 - 07(H)

680495(H) - Dialing monitor volume 00 - 07(H)

680496(H) - Buzzer volume 00 - 07(H)

680497(H) - Beeper volume 00 - 07(H)

6804A8(H) - Machine code (Check ram 4)

```
6804D2(H) - Serial number (Max. 8 characters ASCII)
```

685E6C to 685E6F(H) - Transmission counter (HEX)

685E70 to 685E73(H) - Reception counter (HEX)

685EDC to 685EDF(H) - E-mail transmission counter (HEX)

685EE0 to 685EE3(H) - E-mail reception counter (HEX)

688E8E to 68918D(H) - SIP server address (Read only)

688E8E(H) - Proxy server - Main (Max. 128 characters - ASCII)

688F0E(H) - Proxy server - Sub (Max. 128 characters - ASCII)

688F8E(H) - Redirect server - Main (Max. 128 characters - ASCII)

68900E(H) - Redirect server - Sub (Max. 128 characters - ASCII)

68908E(H) - Registrar server - Main (Max. 128 characters - ASCII)

68910E(H) - Registrar server - Sub (Max. 128 characters - ASCII)

68918E(H) - Gatekeeper server address - Main (Max. 128 characters - ASCII)

68920E(H) - Gatekeeper server address - Sub (Max. 128 characters - ASCII)

68928E(H) - Arias Number (Max. 128 characters - ASCII)

68930E(H) - SIP user name (Max. 128 characters - ASCII)

68938E(H) - SIP authentication password (Max. 128 characters - ASCII)

68938E(H) - SIP digest authentication password (Max. 128 characters - ASCII)

68940E(H) - Gateway address information (Max. 7100 characters - ASCII)

68AFCA(H) - Stand-by port number for H.232 connection

68AFCCH) - Stand-by port number for SIP connection

68AFCE(H) - RAS port number

68AFD0(H) - Gatekeeper port number

68AFD2(H) - Port number of data waiting for T.38

68AFD4(H) - Port number of SIP server

68AFD6(H) - Priority for SIP and H.323 0: H.323, 1: SIP

68AFD7(H) - SIP function 0: Disabled, 1: Enabled

68AFD8(H) - H.323 function 0: Disabled, 1: Enabled

68AFD9(H) - SIP digest authentication function 0: Disabled, 1: Enabled

68AFDA(H) - IP-Fax backup data 00 - 600 (H)

69ECBE(H) - 69ECDE(H) - Dial tone detection parameter (Max. 11 x 3 lines)

This initializes following order. [0x04, 0x40, 0x03, 0x60, 0x64, 0xf4, 0x01,0x64, 0x04, 0xc8, 0x00]

PAPER TRAY UNIT B421

	REVISION HISTORY			
Page	Page Date Added/Updated/New			
		None		


B421TABLE OF CONTENTS

1	OVERALL MACHINE INFORMATION	1
-	1.1 MECHANICAL COMPONENT LAYOUT	
	1.2 ELECTRICAL COMPONENT LAYOUT	
	1.3 DRIVE LAYOUT	
	1.4 OVERALL ELECTRICAL CIRCUIT	2
	1.5 DETAILED DESCRIPTIONS	
	1.5.1 PAPER FEED AND SEPARATION	
	1.6 PAPER LIFT MECHANISM	
	1.7 PAPER END DETECTION	
	1.8 SIDE AND END FENCES	5
2	REPLACEMENT AND ADJUSTMENT	6
2	REPLACEMENT AND ADJUSTMENT2.1 FEED ROLLER AND FRICTION PAD	
2		6
2	2.1 FEED ROLLER AND FRICTION PAD	6
2	2.1 FEED ROLLER AND FRICTION PAD2.2 REMOVING THE PAPER TRAY UNIT FROM THE COPIER	6
2	2.1 FEED ROLLER AND FRICTION PAD	6 6 6
2	2.1 FEED ROLLER AND FRICTION PAD 2.2 REMOVING THE PAPER TRAY UNIT FROM THE COPIER If Optional Tray Heater Is Not Installed If Optional Tray Heater Is Installed 2.3 SENSORS 2.4 DRIVE SECTION.	6 6 6 7
2	2.1 FEED ROLLER AND FRICTION PAD 2.2 REMOVING THE PAPER TRAY UNIT FROM THE COPIER	6 6 6 7
2	2.1 FEED ROLLER AND FRICTION PAD 2.2 REMOVING THE PAPER TRAY UNIT FROM THE COPIER	66 66 7 8
2	2.1 FEED ROLLER AND FRICTION PAD 2.2 REMOVING THE PAPER TRAY UNIT FROM THE COPIER	66 66 77 88 88

aper Tray Unit B421

1. OVERALL MACHINE INFORMATION


1.1 MECHANICAL COMPONENT LAYOUT



- 1. Feed Roller
- 2. Friction Pad

- 3. Bottom Plate
- 4. Optional Tray Heater


1.2 ELECTRICAL COMPONENT LAYOUT



- 1. Tray Main Board
- 2. Paper Feed Motor
- 3. Paper Feed Clutch

- 4. Door Switch
- 5. Paper Feed Sensor
- 6. Paper End Sensor


1.3 DRIVE LAYOUT



- 1. Paper Feed Motor
- 2. Paper Feed Clutch

- 3. Feed Roller
- 4. Friction Pad


1.4 OVERALL ELECTRICAL CIRCUIT



aper Tray Unit B421

1.5 DETAILED DESCRIPTIONS

1.5.1 PAPER FEED AND SEPARATION




The paper tray holds 500 sheets. A friction-pad feed system is used.

[A]: Paper feed roller

[B]: Friction pad

1.6 PAPER LIFT MECHANISM




With tray partially or fully out of unit: Pushing down bottom plate [A] engages latch [B], locking the plate down. Latch [B] is held in place by spring [C].

When user pushes tray in: Runner [D] on frame pushes in rounded slider [E], retracting the latch. Springs [F] push the plate up. The latch remains retracted while the drawer is in the unit, so that the plate cannot be locked down.

SM 3 B421


1.7 PAPER END DETECTION



- [A]: Paper End Feeler
- [B]: Paper End Sensor
- [C]: Cutout in Paper Tray
- If paper is present: feeler [A] pushed up, deactivating sensor [B].
- If no paper is present: feeler [A] drops into cutout [C], activating sensor [B].
- The feeler is rounded so that it lifts out of the way when the tray is inserted or pulled out.

aper Tray Unit B421

1.8 SIDE AND END FENCES



[A]: Side Fence [B]: End Fence

• Side Fence: Set width to A4, 81/4", or 81/2".

• End fence: Set from 11" to 13", with standard settings at 11", A4, and 13". To

feed 14" paper, the end fence can be removed and placed in

internal compartment.


• Both fences can be secured with screws at standard positions.

SM 5 B421

2. REPLACEMENT AND ADJUSTMENT

2.1 FEED ROLLER AND FRICTION PAD

- 1. Take the tray out of the paper tray unit.
- 2. Clip ring [A]
- 3. Shaft assembly [B]
- 4. Feed roller [C] (Ѿ x 1)
- 5. Friction pad [D]



2.2 REMOVING THE PAPER TRAY UNIT FROM THE COPIER

If Optional Tray Heater Is Not Installed


1. Lift the copier off of the paper tray unit.

If Optional Tray Heater Is Installed

- 1. Refer to Section 1.4.2 of the B044/B045/B046 Service Manual, and carry out the following steps of that procedure in this order:
 - Step 2 (remove both paper trays)
 - Step 7 (remove copy tray)
 - Step 8 (remove rear cover)
 - Step 9 (remove FCU cover plate)
- 2. Refer to Section 1.4.2 of the B044/B045/B046 Service Manual, and do the following:
 - Unscrew the ground line.
 - Unclamp the heater harness clamps.
 - Disconnect the heater harness from the relay harness.
 - Unwrap and remove the core.
- 3. Pull the relay harness down and out through the hole in the PSU bracket, and then pull it all the way in through the hole at the rear of the (main) paper tray unit.
- 4. Remove the 3 screws fastening the paper tray unit to the copier (**►** 1.4.2 of the B044/B045/B046 Service Manual, Step 6).
- 5. Lift the copier off the paper tray unit.
 - To reinstall, refer to the procedure in Section 1.4.2 of the B044/B045/B046 Service Manual. Carry out most of that procedure, starting from Step 5 and omitting unnecessary steps.

2.3 SENSORS

- 1. Remove the copier from the paper tray unit (2.2).
- 2. Open the PTU's right door [A].
- [B]: Paper end sensor ($\square \times 1$)
- [C]: Paper feed sensor (1 feeler [D], 🖆 × 1)




2.4 DRIVE SECTION

2.4.1 DRIVE BLOCK

1. Remove copier from paper tray unit (**►** 2.2).


2. Open the paper tray unit's right door [A].

3. Drive block [B] ($\mathscr{F} \times 4$)



2.4.2 PAPER FEED MOTOR

- 1. Drive block (2.4.1)
- 2. Paper feed motor [A] (\square × 1)




aper Tray Unit B421

2.4.3 PAPER FEED CLUTCH


- 1. Drive block (2.4.1)
- 2. Detach the clutch cover [A] $(\langle \overline{\rangle} \rangle \times 1, \ \hat{\beta} \times 2)$.
- 3. Paper feed clutch [B] (≅ × 1)

 Detach the connector from the board side, not the clutch side.



2.4.4 TRAY MAIN BOARD (2.4.1)

Tray main board [A]
 (ℰ×2, all connectors)



ARDF DF1000 B872

REVISION HISTORY			
Page	Page Date Added/Updated/New		
		None	

ARDF DF1000 B872

TABLE OF CONTENTS

•	. REPLACEMENT AND ADJUSTMENT	I
	1.1 COVER	1
	1.1.1 REAR COVER	1
	1.2 DOCUMENT FEED COMPONENTS	2
	1.2.1 ORIGINAL FEED UNIT	2
	1.2.2 SEPARATION ROLLER	2
	1.3 ELECTRICAL COMPONENTS	3
	1.3.1 DF DRIVE BOARD	3
	1.3.2 ORIGINAL SET AND INVERTER SENSOR	3
	1.3.3 REGISTRATION AND EXIT SENSOR	4
	Registration Sensor Reflector	5
	1.4 ORIGINAL FEED DRIVE	6
	1.4.1 DF FEED MOTOR	6
	1.4.2 DF TRANSPORT MOTOR	6
	1.4.3 DF FEED CLUTCH	7
2		ρ
2	. DETAILED DESCRIPTIONS	
2.	DETAILED DESCRIPTIONS	8
2.	2.1.1 MECHANICAL COMPONENT LAYOUT	8 8
2	DETAILED DESCRIPTIONS 2.1 COMPONENT LAYOUT 2.1.1 MECHANICAL COMPONENT LAYOUT 2.1.2 ELECTRICAL COMPONENT LAYOUT	8 8 9
2.	2.1.1 MECHANICAL COMPONENT LAYOUT	8 8 9
2.	2.1 COMPONENT LAYOUT	8 9 9 11
2.	2.1 COMPONENT LAYOUT	8 9 9 . 11
2.	2.1 COMPONENT LAYOUT	8 9 9 . 11 . 12
2.	2.1 COMPONENT LAYOUT	8 9 9 . 11 . 12 . 12
2.	2.1 COMPONENT LAYOUT 2.1.1 MECHANICAL COMPONENT LAYOUT 2.1.2 ELECTRICAL COMPONENT LAYOUT Electrical Component Descriptions 2.1.3 DRIVE LAYOUT 2.2 BASIC OPERATION 2.2.1 PICK-UP AND SEPARATION 2.2.2 CLUTCH OPERATION	8 9 9 . 11 . 12 . 12
2.	2.1 COMPONENT LAYOUT	8 9 9 . 11 . 12 . 12
2	DETAILED DESCRIPTIONS 2.1 COMPONENT LAYOUT 2.1.1 MECHANICAL COMPONENT LAYOUT 2.1.2 ELECTRICAL COMPONENT LAYOUT Electrical Component Descriptions 2.1.3 DRIVE LAYOUT 2.2 BASIC OPERATION 2.2.1 PICK-UP AND SEPARATION 2.2.2 CLUTCH OPERATION 2.2.3 ORIGINAL TRANSPORT AND EXIT Single-Sided Originals	8 9 9 . 11 . 12 . 12 . 12

i

Read This First

Safety and Symbols

Replacement Procedure Safety

ACAUTION

 Turn off the main power switch and unplug the machine before beginning any of the replacement procedures in this manual.

Symbols Used in this Manual

This manual uses the following symbols.

: See or Refer to

Screws
 S

: Connector

☼: Clip ring


C: E-ring

Clamp


1. REPLACEMENT AND ADJUSTMENT

1.1 COVER

1.1.1 REAR COVER



- 1. Open the ARDF [A].
- 2. Release the three hooks




- 3. Open the left cover [B].
- 4. Open the original tray [C].
- 5. Rear cover [D] (x 1, hook x 4)

1.2 DOCUMENT FEED COMPONENTS

1.2.1 ORIGINAL FEED UNIT


1. Open the left cover.



2. Original feed unit [A] ((() x 1)

1.2.2 SEPARATION ROLLER

- 1. Open the left cover.
- 2. Original feed unit ("Original Feed Unit")




- 3. Separation roller cover [A] (hook x 2)
- 4. Separation roller stopper [B] (hook)
- 5. Separation roller [C]

1.3 ELECTRICAL COMPONENTS

1.3.1 DF DRIVE BOARD


1. Rear cover (see "Rear Cover")



2. DF drive board [A] (x 2, y x 4, ground cable x 1)

1.3.2 ORIGINAL SET AND INVERTER SENSOR


- 1. Open the left cover.
- 2. Original feed unit (see the "Original Feed Unit")
- 3. DF feed clutch (see the "DF Feed Clutch")




- 4. Original feed-in guide plate [A] (x 2).
- 5. Original set sensor [B] (≅ x 1, hook)
- 6. Inverter sensor [C] (🗐 x 1, hook)

1.3.3 REGISTRATION AND EXIT SENSOR

- 1. Open the left cover.
- 2. Original feed unit (see the "Original Feed Unit")
- 3. DF feed clutch (see the "DF Feed Clutch")
- 4. Original feed-in guide plate (see the "Original Set and Inverter Sensor")
- 5. DF feed motor (see the "DF Feed Motor")
- 6. DF transport motor (see the "DF Transport Motor")



- 7. Transport roller [A] (\mathbb{C} x 2, gear x 2, bushing x 2)
- 8. Separation roller unit [B] (\mathbb{C} x 2, gear x 1, bushing x 2)
- 9. Inverter upper guide plate [C] (x 4, □ x 3, x 4)




- 10. Inverter lower guide plate [D] (hook x 2)
- 11. Registration sensor [E] (☐ x 1, hook)

12. Exit sensor [F] (町 x 1, hook)

Registration Sensor Reflector






b262r508

Clean the registration sensor reflector [A] as necessary.

1.4 ORIGINAL FEED DRIVE

1.4.1 DF FEED MOTOR


1. Rear cover (see "Rear Cover")



- 2. Inner cover [A] (\$\beta\$ x 1)
- 3. DF feed motor with bracket [B] (x 2, x 4, x 3, timing belt)
- 4. DF feed motor [C] (x 2)


1.4.2 DF TRANSPORT MOTOR

- 1. Rear cover (see "Rear Cover")
- 2. DF feed motor (see "DF Feed Motor")



- 3. DF transport motor with bracket [A] (x 2, spring x 1, timing belt)
- 4. DF transport motor [B] (x 2)

1.4.3 DF FEED CLUTCH




- 1. Open the left cover.
- 2. Front cover [A] (F x 1)
- 3. Bracket [B] (x 1, 1)
- 4. DF feed clutch [C] (町 x 1)

2. DETAILED DESCRIPTIONS

2.1 COMPONENT LAYOUT


2.1.1 MECHANICAL COMPONENT LAYOUT



- 1. Separation Roller
- 2. Paper Feed Roller
- 3. Pick-up Roller
- 4. Original Set Sensor
- 5. Inverter Roller
- 6. Junction Gate

- 7. Exit Roller
- 8. Exit Sensor
- 9. Registration Sensor
- 10. Registration Roller
- 11. Inverter Sensor
- 12. Transport Roller

2.1.2 ELECTRICAL COMPONENT LAYOUT



- 1. DF Feed Clutch
- 2. Registration Sensor
- 3. Exit Sensor
- 4. Left Cover Sensor
- 5. DF Transport Motor
- 6. DF Feed Motor
- 7. Inverter Sensor
- 8. DF Drive Board
- 9. Junction Gate Solenoid
- 10. Original Set Sensor


Electrical Component Descriptions

Symbol	Name	Function	Index No.	
Motors				
- DF Feed		Drives the feed, separation, pick-up rollers, transport roller and inverter roller.	6	
-	DF Transport	Drives the registration and exit rollers	5	
Sensors				
-	Registration	Detects the original exposure timing, and checks for original misfeeds.	2	
-	Exit	Detects the leading edge of the original to turn on the junction gate solenoid and DF feed	3	

Component Layout

	, 		
		clutch in single-sided mode. Detects the trailing edge of the original to turn off the transport and feed motor and junction gate solenoid in single-sided mode. Detects the trailing edge of the original to turn on the DF feed clutch. In single-sided mode, used to detect original misfeeds.	
-	Left Cover	Detects whether the feed-in cover is opened or not.	4
-	Original Set	Detects if an original is on the original tray.	10
-	Inverter	Detects the leading edge of the original to turn off the DF feed motor and checks for original misfeeds.	7
Solenoic	ls		
-	Junction Gate	Opens and closes the junction gate.	9
Magnetio	Clutches		
-	DF Feed	Drives the feed and pick-up rollers.	1
PCBs			
-	Main	Interfaces the sensor signals with the copier, and transfers the magnetic clutch, solenoid and motor drive signals from the copier.	8

2.1.3 DRIVE LAYOUT



- 1. DF Feed Motor
- 2. Feed Roller
- 3. Pick-up Roller
- 4. Inverter Roller
- 5. DF Feed Clutch
- 6. Separation Roller
- 7. Transport Roller
- 8. DF Transport Motor
- 9. Exit Roller
- 10. Registration Roller
- DF Feed Motor: Drives the feed, separation, pick-up, and transport and inverter rollers.
- DF Transport Motor: Drives the registration and exit rollers.

2.2 BASIC OPERATION

2.2.1 PICK-UP AND SEPARATION

The ARDF uses an FRR (feed & reverse roller) system.

Setting paper moves the feeler, causing the original set sensor to inform the CPU that the ARDF is ready to feed.


Press $\textcircled{\circ}$ \rightarrow short time lag \rightarrow DF feed clutch engages \rightarrow DF motor starts. The motor drives the DF pickup roller, DF feed roller, DF separation roller, and transport roller. The pickup roller drives the top sheet(s) between the feed and separation roller, where the top sheet is separated and fed to the transport rollers.

2.2.2 CLUTCH OPERATION

The DF feed clutch is provided to stop feeding when the original is fed to the inverter tray in double-sided mode. If the DF feed clutch does not stop the pick-up, feed and separation rollers in double-sided mode, the next original is fed while the first original is at the inverter tray and an original jam occurs.

2.2.3 ORIGINAL TRANSPORT AND EXIT


Single-Sided Originals



The feed motor feeds the separated original to the registration roller [A]. A short time after an original reaches the registration sensor [B], the DF feed motor stops briefly, the scanner moves to DF scan position, and the white peak is read. The DF feed motor and DF transport motor then start and the sheet is scanned.

After scanning, the original is fed out by the exit roller [C].

Double-Sided Originals




After an original has been fed to the registration sensor [B] by the transport roller, the DF feed motor stops briefly. After the scanner has moved to DF scan position, and the white peak has been read, the front side of the original is then scanned.

When the exit sensor [C] detects the leading edge of the original, the junction gate solenoid is activated and the junction gate [E] opens. The original is then transported towards the inverter table.

Soon after the trailing edge of the original passes the exit sensor, the junction gate solenoid switches off and the junction gate [E] is closed. When the original has been fed onto the inverter table, the feed and transport motors stop. After that, the feed motor rotates in reverse and the original is fed to the exit roller [D] by the inverter roller [F]. At this time, the feed motor stops briefly to adjust the original skew.

After adjusting the original skew, the original is fed again by the exit roller [D] and registration roller [B] to the scanning area (where the reverse side will be scanned).

Basic Operation



The original is then sent to the inverter table again to be turned over. This is done so that the duplex copies will be properly stacked front side down in the exit tray [G] in the correct order.

Original Set Sensor

During one-to-one copying, copy paper is fed to the registration roller in advance (while the original is still being scanned), to increase the copy speed. The original set sensor monitors the stack of originals in the original tray, and detects when the trailing edge of the last page has been fed in. The main CPU then stops the copier from feeding an unwanted extra sheet of copy paper.